

Parametric Technology Corporation

**Pro/ENGINEER® Wildfire® 5.0
J-Link User's Guide**

July 2010

Copyright © 2010 Parametric Technology Corporation and/or Its Subsidiary Companies. All Rights Reserved.

User and training guides and related documentation from Parametric Technology Corporation and its subsidiary companies (collectively "PTC") are subject to the copyright laws of the United States and other countries and are provided under a license agreement that restricts copying, disclosure, and use of such documentation. PTC hereby grants to the licensed software user the right to make copies in printed form of this documentation if provided on software media, but only for internal/personal use and in accordance with the license agreement under which the applicable software is licensed. Any copy made shall include the PTC copyright notice and any other proprietary notice provided by PTC. Training materials may not be copied without the express written consent of PTC. This documentation may not be disclosed, transferred, modified, or reduced to any form, including electronic media, or transmitted or made publicly available by any means without the prior written consent of PTC and no authorization is granted to make copies for such purposes.

Information described herein is furnished for general information only, is subject to change without notice, and should not be construed as a warranty or commitment by PTC. PTC assumes no responsibility or liability for any errors or inaccuracies that may appear in this document.

The software described in this document is provided under written license agreement, contains valuable trade secrets and proprietary information, and is protected by the copyright laws of the United States and other countries. It may not be copied or distributed in any form or medium, disclosed to third parties, or used in any manner not provided for in the software licenses agreement except with written prior approval from PTC.

UNAUTHORIZED USE OF SOFTWARE OR ITS DOCUMENTATION CAN RESULT IN CIVIL DAMAGES AND CRIMINAL PROSECUTION. PTC regards software piracy as the crime it is, and we view offenders accordingly. We do not tolerate the piracy of PTC software products, and we pursue (both civilly and criminally) those who do so using all legal means available, including public and private surveillance resources. As part of these efforts, PTC uses data monitoring and scouring technologies to obtain and transmit data on users of illegal copies of our software. This data collection is not performed on users of legally licensed software from PTC and its authorized distributors. If you are using an illegal copy of our software and do not consent to the collection and transmission of such data (including to the United States), cease using the illegal version, and contact PTC to obtain a legally licensed copy.

Important Copyright, Trademark, Patent, Licensing, and Data Collection Information:

- For Windchill products, select About Windchill at the bottom of the product page.
- For CADD5, click the "i" button on the main menu.
- For InterComm products, on the Help main page, click the link for **Copyright**.
- For other products, click **Help > About** on the main menu of the product.
- For products with an Application button, click the button and then navigate to the product information.

UNITED STATES GOVERNMENT RESTRICTED RIGHTS LEGEND

This document and the software described herein are Commercial Computer Documentation and Software, pursuant to FAR 12.212(a)-(b) (OCT'95) or DFARS 227.7202-1(a) and 227.7202-3(a) (JUN'95), and are provided to the US Government under a limited commercial license only. For procurements predating the above clauses, use, duplication, or disclosure by the Government is subject to the restrictions set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software Clause at DFARS 252.227-7013 (OCT'88) or Commercial Computer Software-Restricted Rights at FAR 52.227-19(c)(1)-(2) (JUN'87), as applicable. 04012010

Parametric Technology Corporation, 140 Kendrick Street, Needham, MA 02494 USA

Contents

About This Guide	i
Purpose	ii
Audience	ii
Contents	ii
Prerequisites	iv
Documentation	iv
Conventions	iv
Software Product Concerns and Documentation Comments	v
Chapter 1: Setting Up J-Link	1-1
Setting Up Your Machine	1-2
Setting Up a Synchronous J-Link Program	1-2
Standalone Applications	1-2
Registering a J-Link Application	1-4
Setting Up a Model Program	1-5
Start and Stop Methods	1-7
Chapter 2: Java Programming Considerations	2-1
Use of the JDK in J-Link Applications	2-2
Java Overview	2-3
Java Keywords	2-4
Java Data Types	2-6
Event Handling	2-6
Comments	2-7
Chapter 3: Overview of J-Link	3-1
Class Types	3-2
Pro/ENGINEER-Related Interfaces	3-2

Compact Data Classes.....	3-4
Unions	3-5
Sequences	3-6
Arrays	3-7
Enumeration Classes	3-9
Action Listeners.....	3-10
Utilities.....	3-12
Creating Applications.....	3-14
Importing Packages.....	3-14
Exception Handling	3-15
Chapter 4: J-Link Programming Considerations	4-1
J-Link Thread Restrictions	4-2
Optional Arguments to J-Link Methods.....	4-2
Optional Returns for J-Link Methods.....	4-3
Parent-Child Relationships Between J-Link Objects	4-3
Run-Time Type Identification in J-Link	4-4
Chapter 5: The J-Link Online Browser	5-1
Online Documentation — J-Link APIWizard	5-2
Installing the APIWizard	5-2
Starting the APIWizard	5-2
Web Browser Environments.....	5-3
Loading the Swing Class Library.....	5-3
Automatic Index Tree Updating.....	5-6
APIWizard Interface	5-6
Chapter 6: Session Objects	6-1
Overview of Session Objects.....	6-2
Getting the Session Object	6-2
Getting Session Information	6-2
Directories.....	6-5
File Handling	6-5
Configuration Options.....	6-6
Macros.....	6-7
Colors and Line Styles	6-8
Accessing the Pro/ENGINEER Interface	6-8
The Text Message File.....	6-8
Writing a Message Using a Message Pop-up Dialog Box.....	6-10
Accessing the Message Window.....	6-11
Message Classification.....	6-12
Displaying Feature Parameters.....	6-14

File Dialogs	6-15
Customizing the Pro/ENGINEER Navigation Area	6-19
Chapter 7: Selection	7-1
Interactive Selection	7-2
Accessing Selection Data	7-4
Controlling Selection Display	7-5
Programmatic Selection	7-6
Selection Buffer	7-7
Introduction to Selection Buffers	7-7
Reading the Contents of the Selection Buffer	7-8
Removing the Items of the Selection Buffer	7-9
Adding Items to the Selection Buffer	7-9
Chapter 8: Menus, Commands, and Pop-up Menus	8-1
Introduction	8-2
Menu Bar Definitions	8-2
Creating New Menus and Buttons	8-2
Finding Pro/ENGINEER commands	8-6
Access Listeners for Commands	8-6
Bracket Listeners for Commands	8-8
Designating Commands	8-12
Command Icons	8-12
Designating the Command	8-13
Placing the Toolbar Button	8-14
Pop-up Menus	8-15
Adding a Pop-up Menu to the Graphics Window	8-15
Using the Trail File to Determine Existing Pop-up Menu Names	8-16
Listening for Pop-up Menu Initialization	8-16
Accessing the Pop-up Menus	8-17
Adding Content to the Pop-up Menu	8-17
Chapter 9: Models	9-1
Overview of Model Objects	9-2
Getting a Model Object	9-2
Model Descriptors	9-3
Retrieving Models	9-4
Model Information	9-6
Model Operations	9-9
Running ModelCHECK	9-11
Custom Checks	9-12

Chapter 10: Drawings	10-1
Overview of Drawings in J-Link	10-2
Creating Drawings from Templates	10-2
Drawing Creation Errors	10-3
Obtaining Drawing Models	10-6
Drawing Information	10-6
Drawing Operations	10-7
Drawing Sheets	10-10
Drawing Sheet Information	10-10
Drawing Sheet Operations	10-11
Drawing Views	10-15
Creating Drawing Views	10-15
Obtaining Drawing Views	10-20
Drawing View Information	10-21
Drawing Views Operations	10-26
Drawing Dimensions	10-26
Obtaining Drawing Dimensions	10-27
Creating Drawing Dimensions	10-27
Drawing Dimensions Information	10-31
Drawing Dimensions Operations	10-33
Drawing Tables	10-38
Creating Drawing Cells	10-38
Selecting Drawing Tables and Cells	10-39
Creating Drawing Tables	10-39
Retrieving Drawing Tables	10-40
Drawing Tables Information	10-41
Drawing Tables Operations	10-42
Drawing Table Segments	10-48
Repeat Regions	10-49
Detail Items	10-50
Listing Detail Items	10-50
Creating a Detail Item	10-51
Detail Entities	10-52
Instructions	10-52
Detail Entities Information	10-56
Detail Entities Operations	10-56
OLE Objects	10-57
Detail Notes	10-57
Instructions	10-58
Detail Notes Information	10-62

Details Notes Operations.....	10-64
Detail Groups	10-64
Instructions	10-64
Detail Groups Information.....	10-65
Detail Groups Operations	10-66
Detail Symbols	10-68
Detail Symbol Definitions.....	10-68
Detail Symbol Instances	10-76
Detail Symbol Groups.....	10-86
Detail Attachments	10-89
Free Attachment	10-90
Parametric Attachment	10-90
Offset Attachment.....	10-91
Unsupported Attachment.....	10-92
Chapter 11: Solid	11-1
Getting a Solid Object	11-2
Solid Information	11-2
Solid Operations.....	11-3
Solid Units	11-5
Types of Unit Systems.....	11-6
Accessing Individual Units	11-7
Modifying Individual Units	11-9
Creating a New Unit	11-9
Accessing Systems of Units	11-10
Modifying Systems of Units	11-10
Creating a New System of Units.....	11-11
Conversion to a New Unit System	11-11
Mass Properties	11-12
Annotations	11-14
Cross Sections	11-15
Materials.....	11-15
Accessing Material Types.....	11-17
Accessing Material Properties	11-18
Accessing User-defined Material Properties	11-21
Chapter 12: Windows and Views	12-1
Windows.....	12-2
Getting a Window Object.....	12-2
Window Operations	12-3
Embedded Browser.....	12-4

Views	12-4
Getting a View Object.....	12-5
View Operations	12-5
Coordinate Systems and Transformations	12-6
Coordinate Systems	12-6
Transformations	12-8
Chapter 13: ModelItem	13-1
Solid Geometry Traversal	13-2
Getting ModelItem Objects	13-2
ModelItem Information	13-3
Layer Objects.....	13-4
Getting Layer Objects.....	13-4
Layer Operations.....	13-4
Chapter 14: Features	14-1
Access to Features	14-2
Feature Information	14-3
Feature Operations.....	14-4
Feature Groups and Patterns	14-6
Changes To Feature Groups.....	14-7
User Defined Features.....	14-8
Read Access to Groups and User Defined Features	14-9
Creating Features from UDFs.....	14-9
Creating UDFs.....	14-10
Creating Interactively Defined UDFs	14-11
Creating a Custom UDF	14-11
Chapter 15: Datum Features	15-1
Datum Plane Features.....	15-2
Datum Axis Features	15-6
General Datum Point Features	15-7
Datum Coordinate System Features	15-9
Chapter 16: Geometry Evaluation	16-1
Geometry Traversal	16-2
Geometry Terms	16-2
Traversing the Geometry of a Solid Block.....	16-3
Curves and Edges	16-3
The t Parameter	16-3
Curve and Edge Types.....	16-4
Evaluation of Curves and Edges	16-5
Solid Edge Geometry	16-6

Curve Descriptors	16-6
Contours.....	16-7
Surfaces	16-8
UV Parameterization	16-8
Surface Types	16-9
Surface Information	16-10
Evaluation of Surfaces.....	16-10
Surface Descriptors	16-12
Axes, Coordinate Systems, and Points.....	16-12
Evaluation of ModelItems	16-12
Interference	16-13
Analyzing Interference Information	16-14
Analyzing Interference Volume.....	16-15
Chapter 17: Dimensions and Parameters	17-1
Overview	17-2
The ParamValue Object.....	17-2
Accessing a ParamValue Object.....	17-2
Accessing the ParamValue Value	17-3
Parameter Objects	17-3
Creating and Accessing Parameters	17-4
Parameter Selection Options.....	17-5
Parameter Information.....	17-7
Parameter Restrictions	17-9
Dimension Objects	17-13
Getting Dimensions	17-13
Dimension Information.....	17-13
Dimension Tolerances.....	17-14
Chapter 18: Relations	18-1
Accessing Relations.....	18-2
Adding a Customized Function to the Relations Dialog Box in Pro/ENGINEER... ..	18-4
Relation Function Options	18-5
Relation Function Listeners	18-6
Chapter 19: Assemblies and Components	19-1
Structure of Assemblies and Assembly Objects	19-2
Assembly Components.....	19-4
Regenerating an Assembly Component.....	19-8
Creating a Component Path	19-8
Component Path Information.....	19-8
Assembling Components	19-9

Constraint Attributes.....	19-11
Assembling a Component Parametrically	19-11
Redefining and Rerouting Assembly Components	19-14
Exploded Assemblies	19-20
Skeleton Models	19-21
Chapter 20: Family Tables	20-1
Working with Family Tables.....	20-2
Accessing Instances.....	20-2
Accessing Columns.....	20-3
Accessing Cell Information.....	20-4
Creating Family Table Instances	20-5
Creating Family Table Columns	20-5
Chapter 21: Action Listeners	21-1
J-Link Action Listeners.....	21-2
Creating an ActionListener Implementation.....	21-2
Action Sources.....	21-3
Types of Action Listeners	21-4
Session Level Action Listeners	21-4
UI Command Action Listeners.....	21-5
Model Level Action listeners.....	21-5
Solid Level Action Listeners	21-8
Feature Level Action Listeners.....	21-10
Cancelling an ActionListener Operation	21-11
Chapter 22: Interface	22-1
Exporting Files and 2D Models.....	22-2
Export Instructions.....	22-3
Exporting Drawing Sheets.....	22-5
Exporting to PDF and U3D	22-6
Exporting 3D Geometry	22-13
Export Instructions.....	22-14
Export Utilities	22-17
Shrinkwrap Export	22-18
Setting Shrinkwrap Options.....	22-19
Surface Subset Options	22-21
Faceted Solid Options	22-22
Merged Solid Options.....	22-24
VRML Representation	22-25
Importing Files	22-26
Import Instructions.....	22-26

Importing 2D Models	22-28
Importing 3D Geometry.....	22-29
Plotting Files.....	22-32
Printing Files	22-33
Printer Options.....	22-34
Placement Options	22-37
Model Options	22-39
Plotter Configuration File (PCF) Options	22-40
Solid Operations.....	22-41
Window Operations.....	22-43
Chapter 23: Simplified Representations	23-1
Overview	23-2
Retrieving Simplified Representations	23-3
Creating and Deleting Simplified Representations.....	23-4
Extracting Information About Simplified Representations	23-5
Modifying Simplified Representations	23-8
Adding Items to and Deleting Items from a Simplified Representation	23-8
Simplified Representation Utilities.....	23-9
Chapter 24: Asynchronous Mode	24-1
Overview	24-2
Setting up an Asynchronous J-Link Application	24-2
Simple Asynchronous Mode	24-4
Starting and Stopping Pro/ENGINEER	24-4
Connecting to a Pro/ENGINEER Process.....	24-7
Connecting Via Connection ID	24-8
Status of a Pro/ENGINEER Process	24-9
Getting the Session Object.....	24-9
Full Asynchronous Mode.....	24-9
Troubleshooting Asynchronous J-Link.....	24-14
Chapter 25: Task Based Application Libraries	25-1
Managing Application Arguments	25-2
Modifying Arguments.....	25-3
Launching a Pro/Toolkit DLL.....	25-4
Creating J-Link Task Libraries	25-6
Launching Tasks from J-Link Task Libraries.....	25-7
Chapter 26: Graphics	26-1
Overview	26-2
Getting Mouse Input.....	26-2
Drawing a Mouse Box	26-3

Displaying Graphics	26-3
Controlling Graphics Display	26-4
Displaying Text in the Graphics Window	26-7
Controlling Text Fonts	26-8
Display Lists and Graphics	26-8
Chapter 27: External Data	27-1
External Data	27-2
Introduction to External Data	27-2
Compatibility with Pro/TOOLKIT	27-3
Accessing External Data	27-3
Storing External Data	27-4
Initializing Data Objects	27-4
Retrieving External Data	27-5
Exceptions	27-9
Chapter 28: Windchill Connectivity APIs	28-1
Introduction	28-2
Non-Interactive Mode Operations	28-2
Accessing a Windchill Server from a Pro/ENGINEER Session	28-2
Accessing Information Before Registering a Server	28-3
Registering and Activating a Server	28-4
Accessing Information From a Registered Server	28-5
Information on Servers in Session	28-6
Accessing Workspaces	28-6
Creating and Modifying the Workspace	28-7
Workflow to Register a Server	28-8
Aliased URL	28-9
Server Operations	28-10
Save	28-11
Upload	28-12
CheckIn	28-13
Retrieval	28-15
Checkout and Download	28-15
Undo Checkout	28-18
Import and Export	28-18
File Copy	28-21
Server Object Status	28-22
Object Lock Status	28-22
Delete Objects	28-24
Conflicts During Server Operations	28-24
Utility APIs	28-37

Sample Batch Workflow	28-38
Appendix A: Summary of Technical Changes	A-1
Critical Technical Changes	A-2
pfcDetail.DetailSymbolInstItem.GetInstructions	A-2
Printing Instructions	A-2
No-Resolve Mode	A-3
New Methods	A-3
2D Export.....	A-3
3D Export.....	A-4
Datum Features	A-4
Drawing Sheets	A-7
Export to PDF	A-8
Family Tables	A-8
Models	A-8
Printing Files	A-9
User Interface	A-11
Utility	A-12
Pro/ENGINEER Window	A-12
Superseded Methods	A-13
Miscellaneous Technical Changes.....	A-13
3D Import Formats.....	A-13
Datum Features Properties	A-14
Export Formats	A-15
New Types for pfcSession.BaseSession.ListFiles.....	A-16
Obsolete Data Exchange Formats	A-17
Appendix B: Sample Applications	B-1
Installing J-Link	B-2
Sample Applications.....	B-2
InstallTest	B-2
InstallTest	B-4
jlinkexamples	B-6
jlinksyncexamples.....	B-6
Parameter Editor	B-6
Round Checker Utility	B-8
Save Check Utility	B-9
Appendix C: Java Options and Debugging	C-1
Supported Java Virtual Machine Versions	C-2
Overriding the Java command used by Synchronous J-Link	C-2
Debugging a Synchronous Mode Application	C-3

CLASSPATH Variables	C-3
Synchronous Mode	C-3
JAVA Options for Asynchronous Mode	C-4
Appendix D: Digital Rights Management	D-1
Introduction	D-2
Implications of DRM on J-Link	D-2
Exception Types.....	D-2
Copy Permission to Interactively Open Models.....	D-5
Additional DRM Implications	D-6
Appendix E: Geometry Traversal	E-1
Example 1	E-2
Example 2	E-2
Example 3.....	E-3
Example 4.....	E-4
Example 5.....	E-5
Appendix F: Geometry Representations	F-1
Surface Parameterization	F-2
Plane	F-3
Cylinder	F-3
Cone.....	F-4
Torus	F-5
General Surface of Revolution	F-6
Ruled Surface.....	F-6
Tabulated Cylinder	F-7
Coons Patch.....	F-8
Fillet Surface	F-8
Spline Surface	F-9
NURBS Surface	F-10
Cylindrical Spline Surface	F-11
Edge and Curve Parameterization.....	F-13
Line.....	F-13
Arc.....	F-14
Spline	F-14
NURBS.....	F-15
Appendix G: J-Link Classes	G-1
List of J-Link Classes.....	G-2

About This Guide



This section contains information about the contents and conventions of this user guide.

Topic	Page
Purpose	ii
Audience	ii
Contents	ii
Prerequisites	iv
Documentation	iv
Software Product Concerns and Documentation Comments	v

Purpose

This manual describes how to use J-Link, a Java language toolkit for Pro/ENGINEER. J-Link makes possible the development of Java programs that access the internal components of a Pro/ENGINEER session, to customize Pro/ENGINEER models.

Audience

This manual is intended for experienced Pro/ENGINEER users who are already familiar with Java or another object-oriented language.

Contents

This manual contains the following chapters and appendixes:

Chapter 1, Setting Up J-Link—Describes how to set up your environment so you can run J-Link.

Chapter 2, Java Programming Considerations—An overview of the Java programming language.

Chapter 3, Overview of J-Link—Describes the fundamentals of Pro/J.Link.

Chapter 4, J-Link Programming Considerations—Tips and considerations for use when developing applications for J-Link

Chapter 5, The J-Link Online Browser—Describes how to use the online browser provided with J-Link

Chapter 6, Session Objects—Describes how to program on the session level using J-Link.

Chapter 7, Selection—Describes using Interactive Selection in J-Link.

Chapter 8, Menus, Commands, and Pop-up Menus—Describes how to create and modify menus, commands, and pop-up menus in the Pro/ENGINEER user interface using J-Link.

Chapter 9, Models—Describes how to program on the model level using J-Link.

Chapter 10, Drawings—Describes how to program drawing functions using J-Link.

Chapter 11, Solid—Describes how to program with solids using J-Link.

Chapter 12, Windows and Views—Describes how to access Pro/ENGINEER windows and saved views using J-Link.

Chapter 13, ModelItem—Describes the J-Link methods that enable you to access and manipulate ModelItems.

Chapter 14, Features—Describes how to program on the feature level using J-Link.

Chapter 15, Datum Features—Describes methods for reading the properties of Datum features.

Chapter 16, Geometry Evaluation—Describes geometry representation, and how to evaluate geometry using J-Link.

Chapter 17, Dimensions and Parameters—Describes the J-Link methods and classes that affect dimensions and parameters.

Chapter 18, Relations—Describes how to access relations on all models and model items in Pro/ENGINEER using J-Link.

Chapter 19, Assemblies and Components—Describes the J-Link methods that access the Pro/ENGINEER assembly.

Chapter 20, Family Tables—Describes how to use J-Link classes and methods to access and manipulate family table information.

Chapter 21, Action Listeners—Describes the J-Link methods that enable you to use action listeners.

Chapter 22, Interface—Describes various ways of importing and exporting files.

Chapter 23, Simplified Representations—Allows you to use a simple reproduction of a complicated subassembly to reduce regeneration time.

Chapter 24, Asynchronous Mode—A multi-process mode where J-Link and Pro/ENGINEER can perform concurrent operations.

Chapter 25, Task Based Application Libraries—Describes how applications created using the different Pro/ENGINEER API products are interoperable.

Chapter 26, Graphics—Covers J-Link Graphics including displaying lists, displaying text and using the mouse.

Chapter 27, External Data—Describes how to use external data in J-Link.

Chapter 28, Windchill Connectivity APIs—Describes the J-Link APIs that support Windchill servers and server operations in a connected Pro/ENGINEER session.

Appendix A, Summary of Technical Changes—Contains a list of new and enhanced capabilities for J-Link under Pro/ENGINEER Wildfire 5.0.

Appendix B, Sample Applications—Lists the sample applications provided with J-Link.

Appendix C, Java Options and Debugging—Describes how to control the procedure used by Pro/ENGINEER to invoke J-Link applications.

Appendix D, Digital Rights Management—Describes implications of DRM on J-Link applications.

Appendix E, Geometry Traversal—Illustrates the relationships between faces, contours, and edges.

Appendix F, Geometry Representations—Describes the geometry representations of the data used by J-Link.

Appendix G, J-Link Classes—Lists and briefly describes the classes that make up the J-Link interface.

Prerequisites

This manual assumes you have the following knowledge:

- Pro/ENGINEER
- The syntax and language structure of Java.

Documentation

The documentation for J-Link includes the following:

- *J-Link User's Guide*.
- An online browser that describes the syntax of the J-Link methods and provides a link to the online version of this manual. The online version of the documentation is updated more frequently than the printed version. If there are any discrepancies, the online version is the correct one.

Conventions

The following table lists conventions and terms used throughout this book.

Convention	Description
#	The pound sign (#) is the convention used for a UNIX prompt.
UPPERCASE	Pro/ENGINEER-type menu name (for example, PART).
Boldface	Windows-type menu name or menu or dialog box option (for example, View), or utility. Boldface font is also used for keywords, J-Link methods, names of dialog box buttons, and Pro/ENGINEER commands.
Monospace (Courier)	Code samples appear in courier font like this. Java aspects (methods, classes, data types, object names, and so on) also appear in Courier font.
<i>Emphasis</i>	Important information appears <i>in italics like this</i> . Italic font is also used for file names and uniform resource locators (URLs).
Mode	An environment in Pro/ENGINEER in which you can perform a group of closely related functions (Drawing, for example).
Model	An assembly, part, drawing, format, layout, case study, sketch, and so on.
Solid	A part or an assembly.

Notes:

- Important information that should not be overlooked appears in notes like this.
- All references to mouse clicks assume the use of a right-handed mouse.

Software Product Concerns and Documentation Comments

For resources and services to help you with PTC software products, see the *PTC Customer Service Guide*. It includes instructions for using the World Wide Web or fax transmissions for customer support.

In regard to documentation, PTC welcomes your suggestions and comments. You can send feedback in the following ways:

- Send comments electronically to *doc-webhelp@ptc.com*.
- Fill out and mail the PTC Documentation Survey in the customer service guide.

1

Setting Up J-Link

This chapter describes how to set up your environment so you can run J-Link.

Topic	Page
Setting Up Your Machine	1 - 2
Setting Up a Synchronous J-Link Program	1 - 3

Setting Up Your Machine

See Java Options and Debugging for more information about supported Java Virtual Machines and how to setup Pro/ENGINEER.

Setting Up a Synchronous J-Link Program

A synchronous J-Link application is started and managed by Pro/ENGINEER. Control belongs to either Pro/ENGINEER or the application, but not both at the same time.

An asynchronous application is started independent of Pro/ENGINEER with the option to start or connect to Pro/ENGINEER processes. Refer to chapter "Asynchronous Mode" for details on setting up an asynchronous application.

You can run synchronous J-Link programs as standalone applications or model-specific programs. Most of the required settings for these two programs are independent of the programs themselves. This enables you to convert an application program to a model program, or vice versa.

Standalone Applications

You can start the J-Link application independently at any time, regardless of which models are in session. A registry file contains key information regarding the execution of the program.

Using application programs you can make additions to the Pro/ENGINEER user interface, gather or change data associated with the models in session, or add session-level `ActionListener` routines. See the chapter Action Listeners for more information on `ActionListeners`.

Registry File

A registry file contains Pro/ENGINEER-specific information about the standalone application you want to load.

The registry file called *proth.dat* is a simple text file, where each line consists of one predefined keyword followed by a value. The standard form of the *proth.dat* file is as follows:

```
name          java_demo
startup       java
java_app_class MyJavaApp
```

```

java_app_start    start
java_app_stop     stop
allow_stop        true
delay_start       true
text_dir          <path to text directory used by
                  message and menu related commands>
end

```

The fields of the registry file are as follows:

- *name*—Assigns a unique name to this J-Link application. The name identifies the application when there is more than one in the *protk.dat* file. The maximum size of the name is 31 characters for the name, plus the end-of-string character.
- *startup*—Specifies the method to be used by Pro/ENGINEER to communicate with the application. For J-Link applications, set *startup* to “java.”
- *java_app_class*—Specifies the fully qualified package and name of a Java class. This class contains the J-Link application’s start and stop methods (described below).
- *java_app_classpath*—An optional field to specify the full path to the J-Link application classes and archives (including the J-Link archive *pfc.jar*). Refer to the section “CLASSPATH Variables” section for more information on the other available mechanisms to set the CLASSPATH. This field has a character limit of 2047 wide characters (*wchar_t*).
- *java_app_start*—Specifies the start method of your program. See the section Start and Stop Methods on page 1 - 7 for more information.
- *java_app_stop*—Specifies the stop method of your program. See the section Start and Stop Methods on page 1 - 7 for more information.
- *allow_stop*—Stops the application during the session if it is set to true. If this field is missing or set to false, you cannot stop the application, regardless of how it was started.
- *delay_start*—Enables you to choose when to start the J-Link application if it is set to true. Pro/ENGINEER does not start the J-Link application during startup. If this field is missing or is set to false, the J-Link application starts automatically.

- *text_dir*—Specifies the location of the text directory that contains the language-specific directories. The language-specific directories contain the message files, menu files, resource files and UI bitmaps in the language supported by the J-Link application. The files must be located under a directory called "text" or "text/<language>", if localized messages are used in the application. This field has a character limit of 2047 wide characters (wchar_t).
- *end*—Indicates the end of the description of the J-Link application. You can define multiple J-Link applications in the registry files. All these applications are started by Pro/ENGINEER.

Registering a J-Link Application

Registering a J-Link application means providing information about the files that form the J-Link application to Pro/ENGINEER. To do this, create a small text file, called the J-Link “registry file,” that Pro/ENGINEER will find and read.

Pro/ENGINEER searches for the registry file in the following order:

1. A file called *protk.dat* or *prodev.dat* in the current directory
2. A file named in a “PROTKDAT”, “PRODEV DAT”, or “TOOLKIT_REGISTRY_FILE” statement in the Pro/ENGINEER configuration file
3. A file called *protk.dat* or *prodev.dat* in the directory <Pro/ENGINEER>/<MACHINE>/text/<LANGUAGE>
4. A file called *protk.dat* or *prodev.dat* in the directory <Pro/ENGINEER>/text

In the last two options, the variables are as follows:

- <Pro/ENGINEER>—The Pro/ENGINEER loadpoint (*not* the J-Link loadpoint)
- <MACHINE>—The machine-specific subdirectory such as i486_nt
- <LANGUAGE>—The language of Pro/ENGINEER with which the J-Link application is used such as “usascii” (English), “german”, or “japanese”

If more than one registry file having the same filename exists in this search path, J-Link stops searching after finding the first instance of the file and starts all the J-Link applications specified in it. If more than one registry file having different filenames exists in this search path, Pro/ENGINEER stops searching after finding one instance of each of them and starts all the J-Link applications specified in them.

Option 1 is used normally during development, because the J-Link application is seen only if you start Pro/ENGINEER from the specific directory that contains *protk.dat*. or *protk.dev*.

Option 2 or 4 is recommended when making an end-user installation, because it makes sure that the registry file is found irrespective of the directory used to start Pro/ENGINEER.

Option 3 enables you to have a different registry file for each platform, and for each Pro/ENGINEER language. This is more commonly used for J-Link applications that have a platform dependent setup.

Starting and Stopping a Standalone Application

If the *delay_start* field in the registry file is set to false, the J-Link application starts automatically when you start Pro/ENGINEER. Otherwise start the program by following these steps:

1. From the Pro/ENGINEER toolbar, select **Utilities > Auxiliary Applications**.
2. Choose the name of the application.
3. Click **Start**.
 - **Start** - activates start method
 - **Stop** - activates stop method

If the *allow_stop* field in the registry file is set to true, you can click **Stop** in the Auxiliary Applications dialog box to stop the application. Click **Start** to restart it. If the *allow_stop* field is set to false, the program runs until the Pro/ENGINEER session ends.

Setting Up a Model Program

A model program is a J-Link program specific to a particular solid model, that is part or assembly. Pro/ENGINEER activates the start method for a program when it loads the part into memory and activates the stop method when it erases the part from memory.

Using model programs you can add programming logic to the interaction with a solid model. You can create a dialog box to drive the regeneration of a part or create model-specific utilities to generate reports or engineering information from a model. As Java programs are platform independent, the same model program runs on any UNIX or Windows installation of Pro/ENGINEER.

To setup a model program you need to:

- Associate and run a J-Link application with a model
- Create a JAR file for Model-Program Dependency

Associating and Running a J-Link Application with a Model

1. Load the solid model that you want to associate and run with the J-Link application.
2. From the PART or ASSEMBLY menu, select **Tools > Program > J-Link**.
3. If the application is stored in a Java archive (JAR) file, click **Add File** in the Model Programs dialog box and add the JAR file to the list of Java archive files. If the application is stored in a .class file proceed to the next step.
4. Click **Add** and enter the following information in the Java Application Properties dialog box:
 - **Application Name**—A unique name for this J-Link application. The maximum size of the name is 31 characters for the name, plus the end-of-string character.
 - **Class Name**—The Java class that contains the start and stop methods for the J-Link application. This class must reside in a JAR file you have added to the list or in a directory that is part of your CLASSPATH.
 - **Start Method Name**—The method in the **Class Name** class that will be called whenever the model is loaded into a session.
 - **Stop Method Name**—The method in the **Class Name** class that will be called whenever the model is erased.

The J-Link application immediately attempts to run. If it cannot start successfully an exception condition is listed in the Status column of the Model Programs dialog box.

JAR File Needed for Model-Program Dependency

Although individual class files are associated with a model, there is no dependency between the model and the program. Therefore, Pro/INTRALINK and Windchill are not able to recognize the relationship between the class files and the model. To create a dependency, include all the class files and the source code in a Java archive file (jar file). JAR files are created through the command `jar`, which is a part of the standard Java Development Kit (JDK) package.

To create a JAR file use a command similar to the following command string:

```
jar cvf0 myjar.jar *.java *.class
```

Note: You must use the command-line switch 0 (zero) because JAVA cannot read classes from compressed JAR files.

You can add JAR files to, or remove them from, a model by using the buttons on the left side of the model program interface. All the JAR files for the model program must be placed in the Pro/ENGINEER search path.

Note: When naming a J-Link model program JAR file, you must use lower case.

Start and Stop Methods

All synchronous J-Link programs must have a static start and stop method regardless of whether they will run standalone or as model programs. You can give these methods any name you want because you identify them in the registry file or in the model program setup. Pro/ENGINEER automatically calls these methods upon starting or stopping a program. All methods that you want to call in a particular program must be called in the start and stop methods, or you must use the start method to register listeners to react to events in the Pro/ENGINEER interface.

For example:

```
public static void startMyProgram() {
    runMyUtilities();
    configureMyModels();
    addMyUI();
}

public static void stop() {
    cleanupModels();
    outputToPrinterFiles();
}
```

```
}
```

J-Link start and stop methods must be public, static, return void and take no arguments. You can configure applications based on the Pro/ENGINEER version and build or custom command line arguments using methods described in the Session chapter.

2

Java Programming Considerations

This chapter contains a brief overview of the Java programming language. None of the information provided in this chapter is specific to J-Link.

Topic	Page
Use of the JDK in J-Link Applications	2 - 2
Java Overview	2 - 3
Java Keywords	2 - 4
Java Data Types	2 - 4
Event Handling	2 - 6
Comments	2 - 7

Use of the JDK in J-Link Applications

Sun Microsystems provides a large number of objects and methods with the Java Development Kit (JDK). These objects and methods include the following:

- Utilities and methods for a large volume of common programming tasks—Java has APIs for manipulating data, creating vectors (expandable arrays), responding to events, creating queues, and creating hash tables.
- Methods for file manipulation—The `java.io` API contains objects that enable you to read and write data to and from files.
- Creation of Web-enabled applets—The `java.applet` API enables quick creation of a Java applet for use in an HTML page.
- Access to user interface components—The `java.awt` and “Swing” APIs allow creation of simple and complex user interfaces.
- Java Database Connectivity (JDBC)—JDBC provides interaction with database objects

For information on specific classes and methods in the Java API's, visit the Sun Web site at the following URL:

<http://java.sun.com/reference/docs>

Examples in this guide usually do not use classes from the Java API beyond the ones found in the package `java.lang`. Most of the other packages can be used to improve a J-Link program, but they are not absolutely necessary to create the program.

Java Overview

Java is an object-oriented programming language that offers portability across multiple platforms.

Note: The *Java Overview* presented here describes technical information known to be true for Java version 1.1.5. Later Java versions may render some of this information incorrect or obsolete.

Java offers the following benefits:

- **Inheritance**—One of the fundamental concepts of an object-oriented language is *inheritance*. A subclass inherits variables and methods not only from the class above it but also from all of its ancestors. Consider the following code:

```
class A {
    public A() {
        // Constructor of class A
    }
}

class B extends A {
    public B() {
        //A is a superclass of B, B is a subclass of A.
    }
}
```

Java does not support multiple inheritance. But *implementation* of an interface is a way around this restriction. For example:

```
interface A {
    public void doNothing();
    // Only the declaration of a method
}

// Constructor of B
class B implements A {
    // Implementation of this method
    public void doNothing() {
    }
}
```

- **Polymorphism**—You can substitute a derived class whenever its base class is required.

- **Method overriding and overloading**—You can redefine a superclass method with an exact signature and return type. In addition, you can define methods or constructors with different signatures.
- **Platform-independent interpreter**—Java is architecture-neutral. When you compile a Java program, the compiler translates your program into platform-independent instructions called Java bytecodes. You then use an interpreter to parse each Java bytecode and run it on the computer. Your Java program is compiled only once, but is interpreted each time you run it.

Java bytecodes are like machine code instructions for the Java Virtual Machine (JVM).

- **High performance**—Java is a high-performance language that is dynamic—you can load Java classes into a running Java interpreter.
- **No pointers**—Java does not allow you to use pointers to directly reference memory locations. However, all object references are, in effect, pointers, because they refer to a location in memory that contains an object. Therefore, setting one object equal to another does not create a new version of the object. For example:

```
String mystring = yourstring;
```

In this example, a new `String` object is not created.

- **Garbage collection**—Java does not require you to free memory after you are finished with it. The garbage collection routines within the JVM recognize data that is no longer used and automatically free the memory.
- **No preprocessors**—Java does not include a command preprocessor like C or C++. Therefore, you cannot declare global constants as you do in C. Instead, you can declare a field within an object to be static and final, which effectively declares that field to be constant.

Java Keywords

This section describes the Java keywords most commonly used when using J-Link.

The following keywords specify the accessibility to data:

- **public**—Accessible from the class, subclass, package, and world.
- **private**—Accessible only from the class.
- **protected**—Accessible from the class, subclass, and package.
- **package**—Accessible from the class and package. This is the default access.

The following keywords describe variables or methods:

- **static**—The method or variable is not attached to a particular object, but to an entire class.

The advantage of a static method is that you do not need to define an instance of the class in order to use the method.

- **final**—Specifies that the class, method, or field will not be modified by another object.

A static final declaration identifies a constant.

- **new**—Creates instances of various classes. The following statement shows an example of instantiation:

```
String mystring = new String ("This is my string.");
```

Except for single objects, you cannot use the **new** keyword to initialize J-Link objects. You can use **new** to construct objects that do not explicitly belong to J-Link (that is, Java API objects).

- **instanceof**—The Java **instanceof** operator is a way to determine whether a particular object can be correctly cast to a specified class. The instanceof operator produces a Boolean value that identifies whether the object is a member of that class. The typical use is as follows:

```
if (<objectname> instanceof <classname>)
```

In J-Link this operator should be used to distinguish between various levels of inheritance.

Java Data Types

Java allows primitive types to be wrapped inside of classes. These wrappers are used to provide an object definition for every type of data within Java. In J-Link, certain methods take a wrapped object argument instead of a primitive type. You can convert one to the other by creating a new instance, as in the following example:

```
boolean yes_or_no = true;
Boolean yes_or_no_object = new Boolean (yes_or_no);
Integer seven = new Integer (7);
```

The following table lists the type wrappers provided by Java.

Data Type	Java Wrapper Class
int	Integer
float	Float
double	Double
char	Character
byte	Byte
boolean	Boolean
—	String

Note: Java represents character strings only as objects, not as arrays of characters. There is no corresponding primitive string type.

The following keywords specify the implementation types:

native—A method implemented in another language (usually C or C++) that can be called from Java

abstract—A method or class that has no implementation

Event Handling

Java implements listeners and adapters to notify you of certain events. There are three kinds of listeners:

- *ActionListener*—Waits for a specified action, such as clicking on a button in a dialog box

- *ItemListener*—Waits for a specified item, such as a checked check box
- *FocusListener*—Waits for a specified keyboard or mouse focus event on a component

Java exceptions enable you to test for and handle certain events. To create event handling, use the following keywords:

- **try**—Execute a control block using predeclared exception handlers.
- **catch**—Specify the exceptions to “catch” in a **try** block.
- **finally**—Specify a control block to be applied after a **try** block, regardless of whether an exception is handled by a **catch** clause within the **try** block.
- **throw**—Immediately send control to a handler for that specific exception.

Comments

Java provides three different types of comment characters: C++-style, C-style, and javadoc-style.

As in the C++ language, two double slashes (`//`) are used to specify a one-line comment. For example:

```
.  
. .  
. .  
// This method retrieves the value of the dimension.  
. .  
. .  
. .
```

Java also supports C-style comment characters (`/* */`). All the text within these characters is considered a comment. For example:

```
.  
. .  
. .  
{  
/* Open the file input.txt with read-only  
   access. */  
  
   inStream = new RandomAccessFile ("input.txt", "r");  
. .  
. .  
. .
```

Java also supports documentation comments for javadoc, a tool that automatically creates Web pages from your code. See the URL <http://java.sun.com/products/jdk/javadoc/index.html> for more information on javadoc.

Documentation comments are delimited by the characters “/**” and “*/”. For example:

```
/** The following code example shows how to create a
 * random-access file. The program reads a line from
 * one file (input.txt) and writes it to another file
 * (output.txt).
 */
.
.
.
```

3

Overview of J-Link

This chapter provides an overview of J-Link.

Topic	Page
Class Types	3 - 2
Creating Applications	3 - 14

Class Types

J-Link is made up of a number classes in many packages. The following are the eight main classes.

- `Pro/ENGINEER-Related Interfaces`—Contain unique methods and attributes that are directly related to the functions in `Pro/ENGINEER`.
- `Compact Data Classes`—Classes containing data needed as arguments to some J-Link methods. See the section, `Compact Data Classes`, for additional information.
- `Union Classes`—A class with a potential for multiple types of values. See the section `Union Classes` for additional information.
- `Sequence Classes`—Expandable arrays of objects or primitive data types. See the section `Sequences` for more information.
- `Array Classes`—Arrays that are limited to a certain size. See the section `Arrays` for more information.
- `Enumeration Classes`—Defines enumerated types. See the section `Enumeration Classes` for more information.
- `ActionListener Classes`—Enables you to specify programs that will run only if certain events in `Pro/ENGINEER` take place. See the `Action Listeners` section for more information.
- `Utility Classes`—Contains static methods used to initialize certain J-Link objects. See the `Utilities` section for more information.

Each class shares specific rules regarding initialization, attributes, methods, inheritance, or exceptions. The following seven sections describe these classes in detail.

Pro/ENGINEER-Related Interfaces

The `Pro/ENGINEER`-related interfaces contain methods that directly manipulate objects in `Pro/ENGINEER`. Examples of these objects include models, features, and parameters.

Initialization

You cannot construct one of these objects using the Java keyword **new**. Some objects that represent `Pro/ENGINEER` objects cannot be created directly but are returned by a **Get** or **Create** method.

For example, **pfcSession.Session.GetCurrentModel** returns a Model object set to the current model and **pfcModelItem.ParameterOwner.CreateParam** returns a newly created Parameter object for manipulation.

Attributes

Attributes within Pro/ENGINEER-related objects are not directly accessible, but can be accessed through **Get** and **Set** methods. These methods are of the following types:

```
Attribute name: int XYZ
Methods:      int GetXYZ();
              void SetXYZ (int i);
```

Some attributes that have been designated as read can only be accessed by the **Get** method.

Methods

You must start Methods from the object in question and you must first initialize that object. For example, the following calls are illegal:

```
Window window;

window.Activate(); // The window has not yet been
                  initialized.

Repaint();        // There is no invoking object.
```

The following calls are legal:

```
Session session = pfcGlobal.GetProESession();
Window window = session.GetCurrentWindow();
                // You have initialized the window object.
window.Activate()
window.Repaint()
```

Inheritance

All Pro/ENGINEER related objects are defined as interfaces so that they can inherit methods from other interfaces. To use these methods, call them directly (no casting is needed). For example:

```
public interface Feature
    extends jobject,
    pfcModelItem.ParameterOwner,
    pfcObject.Parent,
    pfcObject.Object,
```

```

        pfcModelItem.ModelItem

Feature myfeature;           // Previously initialized

String name = myfeature.GetName(); // GetName is in the
                                   // class ModelItem.

```

However, if you have a reverse situation, you need to explicitly cast the object. For example:

```

ModelItem item; // You know this is a Feature -- perhaps
                // you previously checked its type.

int number = ((Feature)item).GetNumber();
                // GetNumber() is a Feature method.

```

Exceptions

Almost every J-Link method can throw an exception of type `com.ptc.cipjava.jxthrowable`. Surround each method you use with a **try-catch-finally** block to handle any exceptions that are generated. See the Exceptions section for more information.

Compact Data Classes

Compact data classes are data-only classes. They are used, as needed, for arguments and return values for some J-Link methods. They do not represent actual objects in Pro/ENGINEER.

Initialization

You can create instances of these classes using a static create method.

```
Example: pfcModel.BOMExportInstructions_Create()
```

This static method usually belongs to the utility class in the specific package that the compact data class belong to.

Attributes

Attributes within compact data related classes are not directly accessible, but can be accessed through **Get** and **Set** methods. These methods are of the following types:

```

Attribute name: int XYZ
Methods:      int GetXYZ();
              void SetXYZ (int i);

```


Methods

You must start Methods from the object in question and you must first initialize that object. For example, the following calls are illegal:

```
SelectionOptions options;

options.SetMaxNumSels(); // The object has not been
                        initialized.
SetOptionsKeywords(); // There is no invoking object
```

Inheritance

Compact objects can inherit methods from other compact interfaces. To use these methods, call them directly (no casting needed).

Exceptions

Almost every J-Link method can throw an exception of type `com.ptc.cipjava.jxthrowable`. Surround each method you use with a **try-catch-finally** block to handle any exceptions that are generated.

Unions

Unions are interface-like objects. Every union has a discriminator method with the pre-defined name `Getdiscr()`. This method returns a value identifying the type of data that the union objects holds. For each union member, a pair of (Get/Set) methods is used to access the different data types. It is illegal to call any Get method except the one that matches the value returned from `Getdiscr()`. However, any Set method can be called. This switches the discriminator to the new value.

The following is an example of a J-Link union:

```
class ParamValue
{
public:
    ParamValueType           Getdiscr ();
    String                   GetStringValue ();
    void                     SetStringValue (String value);
    int                      GetIntValue ();
    void                     SetIntValue (int value);
    boolean                  GetBoolValue ();
    void                     SetBoolValue (boolean value);
    double                   GetDoubleValue ();
    void                     SetDoubleValue (double value);
```

```
int          GetNoteId ();
void        SetNoteId (int value);
};
```

Sequences

Sequences are expandable arrays of primitive data types or objects in J-Link. All sequence classes have the same methods for adding to and accessing the array. Sequence classes are identified by a plural name, or the suffix “*seq*”.

Initialization

You cannot construct one of these objects using the Java keyword **new**. Static create methods for each list type are available. For example, **pfcModel.Models.create()** returns an empty `Models` sequence object for you to fill in.

Attributes

The attributes within sequence objects must be accessed using methods.

Methods

Sequence objects always contain the same methods: **get**, **set**, **getarraysize**, **insert**, **insertseq**, **removerange**, and **create**. Methods must be invoked from an initialized object of the correct type, except for the static **create** method, which is invoked from the sequence class.

Inheritance

Sequence classes do not inherit from any other J-Link classes. Therefore, you cannot cast sequence objects to any other type of J-Link object, including other sequences. For example, if you have a list of model items that happen to be features, you cannot make the following call:

```
Features features = (Features) modelitems;
```

To construct this array of features, you must insert each member of the list separately while casting it to a `Feature`.

Exceptions

If you try to get or remove an object beyond the last object in the sequence, the exception `cipjava.XNoAttribute` is thrown.

Example Code: Sequence Class

The following example code shows the sequence class `com.ptc.pfc.pfcModel.Models`.

```
package com.ptc.pfc.pfcModel;

public class Models extends jxobject_i
{
    public int getarraysize() throws jxthrowable

    public Model get (int idx) throws jxthrowable

    public void                set (
        int                    idx,
        Model                   value
    ) throws jxthrowable

    public void                removerange (
        int                    frominc,
        int                    toexcl
    ) throws jxthrowable

    public void                insert (
        int                    atidx,
        Model                   value
    ) throws jxthrowable
    public void                insertseq (
        int                    atidx,
        pfcModel.Models        value
    ) throws jxthrowable

    public static pfcModel.Models create() throws jxthrowable
}
```

Arrays

Arrays are groups of primitive types or objects of a specified size. An array can be one or two dimensional. The following array classes are in the **pfcBase** package: `Matrix3D`, `Point2D`, `Point3D`, `Outline2D`, `Outline3D`, `UVVector`, `UVParams`, `Vector2D`, and `Vector3D`. See the online reference documentation to determine the exact size of these arrays.

Initialization

You cannot construct one of these objects using the Java keyword **new**. Static creation methods are available for each array type. For example, the method **pfcBase.Point2D.create** returns an empty `Point2D` array object for you to fill in.

Attributes

The attributes within array objects must be accessed using methods.

Methods

Array objects always contain the same methods: **get**, **set**, and **create**. Methods must be invoked from an initialized object of the correct type, except for the **create** method, which is invoked from the name of the array class.

Inheritance

Array classes do not inherit from any other J-Link classes.

Exceptions

If you try to access an object that is not within the size of the array, the exception `cipjava.XNoAttribute` is thrown.

Example Code - Array Class

The following example code shows the array class `com.ptc.pfc.pfcBase.Point2D`.

```
package com.ptc.pfc.pfcBase;

public class Point2D extends jobject_i
{
    public double                get (int idx0) throws jxthrowable

    public void                  set (
        int                      idx0,
        double                    value
    ) throws jxthrowable

    public static Point2D        create() throws jxthrowable
};
```

Enumeration Classes

In J-Link, enumeration classes are used in the same way that an enum is used in C or C++. An enumeration class defines a limited number of static final instances which correspond to the members of the enumeration. Each static final instance has a corresponding static final integer constant. In the **FeatureType** enumeration class the static instance **FEATTYPE_HOLE** has as its integer equivalent **_FEATTYPE_HOLE**. Enumeration classes in J-Link generally have names of the form *XYZType* or *XYZStatus*.

Enumeration instances are passed whenever a method requires you to choose among multiple options. Use the integer constants where an int is required (such as cases in a switch statement).

Initialization

You cannot construct one of these objects. You simply use the name of the static instance or static integer constant.

Attributes

An enumeration class is made up of constant integer attributes and static instances of the enumerated class type. Related integers and instances have the same name, except the integer attribute begins with an underscore (_). The names of these attributes are all uppercase and describe what the attribute represents. For example:

- **PARAM_INTEGER**—An instance of the `ParamValueType` enumeration class that is used to indicate that a parameter stores an integer value. The corresponding integer is `_PARAM_INTEGER`.
- **ITEM_FEATURE**—An instance of the `ModelItemType` enumeration class that is used to indicate that a model item is a feature. The corresponding integer is `_ITEM_FEATURE`.

An enumeration class always has an integer attribute named “`__Last`”, which is one more than the highest acceptable numerical value for that enumeration class.

Methods

Enumeration classes have one method that you are likely to use:

- **getValue**—Returns the integer value of an enumeration instance.

Inheritance

Enumeration classes do not inherit from any other J-Link classes.

Exceptions

Enumeration classes do not throw exceptions.

Example Code: Enumeration Class

The following example code shows the enumeration class `com.ptc.pfc.pfcBase.Placement`.

```
package com.ptc.pfc.pfcBase;

public final class Placement
{
    public static final int _PLACE_INSIDE = 0;

    public static final Placement PLACE_INSIDE =
        new Placement (_PLACE_INSIDE);

    public static final int _PLACE_ON_BOUNDARY = 1;

    public static final Placement PLACE_ON_BOUNDARY =
        new Placement (_PLACE_ON_BOUNDARY);

    public static final int _PLACE_OUTSIDE = 2;

    public static final Placement PLACE_OUTSIDE =
        new Placement (_PLACE_OUTSIDE);

    public static final int __Last = 3;

    public static Placement FromInt (int value)

    public int getValue()
};
```

Action Listeners

Use `ActionListeners` in J-Link to assign programmed reactions to events that occur within Pro/ENGINEER. J-Link defines a set of action listener interfaces that can be implemented enabling Pro/ENGINEER to call your J-Link application when specific events occur. These interfaces are designed to respond to events from action sources in Pro/ENGINEER. Examples of action sources include the session, user-interface commands, models, solids, parameters, and features.

Initialization

For each of its defined `ActionListener` interfaces, J-Link provides a corresponding default implementation class. For example, the `SolidActionListener` interface has a corresponding `DefaultSolidActionListener` implementation. All of the default action listener classes override every listener method with an empty method.

You must use the default implementation to construct applications. You cannot directly implement the `SolidActionListener` interface, as this interface will be missing the routing used internally by J-Link

You implement an action listener class by inheriting the appropriate default class and overriding the methods that respond to specific events. For the other events, Pro/ENGINEER calls the empty methods inherited from the default class.

Construct your `ActionListener` classes using the Java keyword **new**. Then assign your `ActionListener` to an `ActionSource` using the **AddActionListener()** method of the action source.

Attributes

Action listeners do not have any accessible attributes.

Methods

You must override the methods you need in the default class to create an `ActionListener` object correctly. The methods you create can call other methods in the `ActionListener` class or in other classes.

Inheritance

All J-Link `ActionListener` objects inherit from the interface `pfcBase.ActionListener`.

Exceptions

Action listeners cause methods to be called outside of your application start and stop methods. Therefore, you must include exception-handling code inside the `ActionListener` implementation if you want to respond to exceptions. In some methods called before an event, propagating an exception out of your method will cancel the impending event.

Example Code: Listener Class

The following example code shows part of the SolidActionListener interface.

```
package com.ptc.pfc.pfcSolid;

public interface SolidActionListener extends
    jxobject,
    com.ptc.pfc.pfcBase.ActionListener
{
    void OnBeforeRegen (
        com.ptc.pfc.pfcSolid.Solid Sld,
        com.ptc.pfc.pfcFeature.Feature /* optional */ StartFeature
    ) throws jxthrowable;

    void OnAfterRegen (
        com.ptc.pfc.pfcSolid.Solid Sld,
        com.ptc.pfc.pfcFeature.Feature /* optional */ StartFeature,
        boolean WasSuccessful
    ) throws jxthrowable;

    void OnBeforeUnitConvert (
        com.ptc.pfc.pfcSolid.Solid Sld,
        boolean ConvertNumbers
    ) throws jxthrowable;

    void OnAfterUnitConvert (
        com.ptc.pfc.pfcSolid.Solid Sld,
        boolean ConvertNumbers
    ) throws jxthrowable;
};
```

Utilities

Each package in J-Link has one class that contains special static methods used to create and access some of the other classes in the package. These utility classes have the same name as the package, such as `pfcModel.pfcModel`.

Initialization

Because the utility packages have only static methods, you do not need to initialize them. Simply access the methods through the name of the class, as follows:

```
ParamValue pv = pfcModelItem.CreateStringParamValue
("my_param");
```


Attributes

Utilities do not have any accessible attributes.

Methods

Utilities contain only static methods used for initializing certain J-Link objects.

Inheritance

Utilities do not inherit from any other J-Link classes.

Exceptions

Methods in utilities can throw `jxthrowable` type exceptions.

Sample Utility Class

The following code example shows the utility class `com.ptc.pfc.pfcGlobal.pfcGlobal`.

```
package com.ptc.pfc.pfcGlobal;  
  
public class pfcGlobal  
{  
  public static pfcSession.Session GetProESession()  
    throws jxthrowable  
  public static stringseq GetProEArguments()  
    throws jxthrowable  
  public static string GetProEVersion()  
    throws jxthrowable  
  public static string GetProEBuildCode()  
    throws jxthrowable  
}
```

Creating Applications

The following sections describe how to create applications. The topics are as follows:

- Importing Packages
- Application Hierarchy
- Exception Handling

Importing Packages

To use pfc code in your application you must import the necessary packages. Import each class or package with a statement similar to the following:

For the Parameter class only:

```
import com.ptc.pfc.pfcModelItem.Parameter;
```

For the package pfcBase (all classes):

```
import com.ptc.pfc.pfcBase.*;
```

You might also need to import the methods in `com.ptc.cipjava`, which contains the underlying J-Link structure, including exceptions and certain sequences.. Use the following statement:

```
import com.ptc.cipjava.*;
```

Application Hierarchy

The rules of object orientation require a certain hierarchy of object creation when you start a J-Link application. The pfc method invoked must be **pfcGlobal.GetProESession**, which returns a handle to the current session of Pro/ENGINEER.

The application must iterate down to the level of object you want to access. For example, to list all the datum axes contained in the hole features in all models in session, do the following:

1. Get a handle to the session:

```
pfcGlobal.GetProESession();
```

2. Get the models that are active in the session:

```
session.ListModels();
```

3. Get the feature model items in each model:

```
model.ListModelItems  
(ModelItemType.ITEM_FEATURE);
```

4. Filter out the features of type hole:

```
feature.GetFeatureType();
```

5. Get the subitems in each feature that are axes:

```
feature.ListSubItems  
(ModelItemType.ITEM_AXIS);
```

Exception Handling


Nearly all J-Link methods are declared as throwing the `jxthrowable` exception, as shown here in the declaration of **Model.CreateLayer()**.

```
com.ptc.pfc.pfcLayer.Layer    CreateLayer (  
    String                    Name  
) throws jxthrowable;
```

In fact, the `jxthrowable` exception is never actually thrown. It is the parent class of all the exceptions that *are* thrown by J-Link methods and satisfies Java's requirement that a method's declaration include the exceptions that it throws.

The following figure organizes the J-Link exceptions into three categories to facilitate the discussion that follows.

Figure 3-1: J-Link Exception Classes



cipjava Exceptions

The cipjava exceptions are thrown by classes in the `com.ptc.cipjava` package. With the exception of the `intseq`, `realseq`, `boolseq`, and `stringseq` classes, these classes are only used internally.

The following table describes these exceptions.

Exception	Purpose
XInvalidArrayDimIndex, XInvalidArrayIndex, XInvalidDictIndex, XNegativeIndex	Illegal index value used when accessing a <code>cipjava</code> array, sequence, or dictionary. (The J-Link interface does not currently include any dictionary classes.)
XLICENSE	Licensing error (license does not exist, lost, server down, etc.)
XMsgStringTooLong	Communication synchronization problem between Pro/ENGINEER and J-Link application. Restart the J-Link application.
XNativeException	Unknown exception occurred in another language. This usually signals a serious error (such as division by zero or class not found) that is related to the J-Link application.
XCannotConnect, XConnectionClosed, XFlushFailed	Communication problems between Pro/ENGINEER and the J-Link application.
<i>Other, internal errors</i>	Internal assertions that should not append and which need not be caught individually.

PFC Exceptions

The PFC exceptions are thrown by the classes that make up J-Link's public interface. The following table describes these exceptions.

Exception	Purpose
XBadExternalData	An attempt to read contents of an external data object which has been terminated.

Exception	Purpose
XBadGetArgValue	Indicates attempt to read the wrong type of data from the ArgValue union.
XBadGetExternalData	Indicates attempt to read the wrong type of data from the ExternalData union.
XBadGetParamValue	Indicates attempt to read the wrong type of data from the ParamValue union.
XBadOutlineExcludeType	Indicates an invalid type of item was passed to the outline calculation method.
XCancelProEAction	This exception type will not be thrown by J-Link methods, but you may instantiate and throw this from certain ActionListener methods to cancel the corresponding action in Pro/ENGINEER.
XCannotAccess	The contents of a J-Link object cannot be accessed in this situation.
XEmptyString	An empty string was passed to a method that does not accept this type of input.
XInvalidEnumValue	Indicates an invalid value for a specified enumeration class.
XInvalidFileName	Indicates a file name passed to a method was incorrectly structured.
XInvalidFileType	Indicates a model descriptor contained an invalid file type for a requested operation.
XInvalidModelItem	Indicates that the item requested to be used is no longer usable (for example, it may have been deleted).
XInvalidSelection	Indicates that the Selection passed is invalid or is missing a needed piece of information. For example, its component path, drawing view, or parameters.
XJLinkApplicationException	Contains the details when an attempt to call code in an external J-Link application failed due to an exception.

Exception	Purpose
XJLinkApplicationInactive	Unable to operate on the requested JLinkApplication object because it has been shut down.
XJLinkTaskExists	Indicates that a J-Link task with the given name already exists in session.
XJLinkTaskNotFound	Indicates that the J-Link task with the given name could not be found and run.
XModelNotInSession	Indicates that the model is no longer in session; it may have been erased or deleted.
XNegativeNumber	Numeric argument was negative.
XNumberTooLarge	Numeric argument was too large.
XProEWasNotConnected	The Pro/ENGINEER session is not available so the operation failed.
XSequenceTooLong	Sequence argument was too long.
XStringTooLong	String argument was too long.
XUnimplemented	Indicates unimplemented method.
XUnknownModelExtension	Indicates that a file extension does not match a known Pro/ENGINEER model type.

Pro/TOOLKIT Errors

The **XToolkitError** exception provides access to error codes from Pro/TOOLKIT functions that J-Link uses internally and to the names of the functions returning such errors. **XToolkitError** is the exception you are most likely to encounter because J-Link is built on top of Pro/TOOLKIT. The following table lists the integer values that can be returned by the **XToolkitError.GetErrorCode()** method and shows the corresponding Pro/TOOLKIT constant that indicates the cause of the error. Each specific XToolkitError exception is represented by an appropriately named child class, allowing you to catch specific exceptions you need to handle separately.

XToolkitError Child Class	Pro/TOOLKIT Error	#
XToolkitGeneralError	PRO_TK_GENERAL_ERROR	-1
XToolkitBadInputs	PRO_TK_BAD_INPUTS	-2
XToolkitUserAbort	PRO_TK_USER_ABORT	-3

XToolkitError Child Class	Pro/TOOLKIT Error	#
XToolkitNotFound	PRO_TK_E_NOT_FOUND	-4
XToolkitFound	PRO_TK_E_FOUND	-5
XToolkitLineTooLong	PRO_TK_LINE_TOO_LONG	-6
XToolkitContinue	PRO_TK_CONTINUE	-7
XToolkitBadContext	PRO_TK_BAD_CONTEXT	-8
XToolkitNotImplemented	PRO_TK_NOT_IMPLEMENTED	-9
XToolkitOutOfMemory	PRO_TK_OUT_OF_MEMORY	-10
XToolkitCommError	PRO_TK_COMM_ERROR	-11
XToolkitNoChange	PRO_TK_NO_CHANGE	-12
XToolkitSuppressedParents	PRO_TK_SUPP_PARENTS	-13
XToolkitPickAbove	PRO_TK_PICK_ABOVE	-14
XToolkitInvalidDir	PRO_TK_INVALID_DIR	-15
XToolkitInvalidFile	PRO_TK_INVALID_FILE	-16
XToolkitCantWrite	PRO_TK_CANT_WRITE	-17
XToolkitInvalidType	PRO_TK_INVALID_TYPE	-18
XToolkitInvalidPtr	PRO_TK_INVALID_PTR	-19
XToolkitUnavailableSection	PRO_TK_UNAV_SEC	-20
XToolkitInvalidMatrix	PRO_TK_INVALID_MATRIX	-21
XToolkitInvalidName	PRO_TK_INVALID_NAME	-22
XToolkitNotExist	PRO_TK_NOT_EXIST	-23
XToolkitCantOpen	PRO_TK_CANT_OPEN	-24
XToolkitAbort	PRO_TK_ABORT	-25
XToolkitNotValid	PRO_TK_NOT_VALID	-26
XToolkitInvalidItem	PRO_TK_INVALID_ITEM	-27
XToolkitMsgNotFound	PRO_TK_MSG_NOT_FOUND	-28
XToolkitMsgNoTrans	PRO_TK_MSG_NO_TRANS	-29
XToolkitMsgFmtError	PRO_TK_MSG_FMT_ERROR	-30
XToolkitMsgUserQuit	PRO_TK_MSG_USER_QUIT	-31
XToolkitMsgTooLong	PRO_TK_MSG_TOO_LONG	-32
XToolkitCantAccess	PRO_TK_CANT_ACCESS	-33
XToolkitObsoleteFunc	PRO_TK_OBSOLETE_FUNC	-34
XToolkitNoCoordSystem	PRO_TK_NO_COORD_SYSTEM	-35

XToolkitError Child Class	Pro/TOOLKIT Error	#
XToolkitAmbiguous	PRO_TK_E_AMBIGUOUS	-36
XToolkitDeadLock	PRO_TK_E_DEADLOCK	-37
XToolkitBusy	PRO_TK_E_BUSY	-38
XToolkitInUse	PRO_TK_E_IN_USE	-39
XToolkitNoLicense	PRO_TK_NO_LICENSE	-40
XToolkitBsplUnsuitableDegree	PRO_TK_BSPL_UNSUITABLE_DEGREE	-41
XToolkitBsplNonStdEndKnots	PRO_TK_BSPL_NON_STD_END_KNOTS	-42
XToolkitBsplMultiInnerKnots	PRO_TK_BSPL_MULTI_INNER_KNOTS	-43
XToolkitBadSrfCrv	PRO_TK_BAD_SRF_CRV	-44
XToolkitEmpty	PRO_TK_EMPTY	-45
XToolkitBadDimAttach	PRO_TK_BAD_DIM_ATTACH	-46
XToolkitNotDisplayed	PRO_TK_NOT_DISPLAYED	-47
XToolkitCantModify	PRO_TK_CANT_MODIFY	-48
XToolkitCheckoutConflict	PRO_TK_CHECKOUT_CONFLICT	-49
XToolkitCreateViewBadSheet	PRO_TK_CRE_VIEW_BAD_SHEET	-50
XToolkitCreateViewBadModel	PRO_TK_CRE_VIEW_BAD_MODEL	-51
XToolkitCreateViewBadParent	PRO_TK_CRE_VIEW_BAD_PARENT	-52
XToolkitCreateViewBadType	PRO_TK_CRE_VIEW_BAD_TYPE	-53
XToolkitCreateViewBadExplode	PRO_TK_CRE_VIEW_BAD_EXPLODE	-54
XToolkitUnattachedFeats	PRO_TK_UNATTACHED_FEATS	-55
XToolkitRegenerateAgain	PRO_TK_REGEN_AGAIN	-56
XToolkitDrawingCreateErrors	PRO_TK_DWGCREATE_ERRORS	-57
XToolkitUnsupported	PRO_TK_UNSUPPORTED	-58
XToolkitNoPermission	PRO_TK_NO_PERMISSION	-59
XToolkitAuthenticationFailure	PRO_TK_AUTHENTICATION_FAILURE	-60
XToolkitAppNoLicense	PRO_TK_APP_NO_LICENSE	-92
XToolkitAppExcessCallbacks	PRO_TK_APP_XS_CALLBACKS	-93
XToolkitAppStartupFailed	PRO_TK_APP_STARTUP_FAIL	-94

XToolkitError Child Class	Pro/TOOLKIT Error	#
XToolkitAppInitialization Failed	PRO_TK_APP_INIT_FAIL	-95
XToolkitAppVersionMismatch	PRO_TK_APP_VERSION_MISMATCH	-96
XToolkitAppCommunication Failure	PRO_TK_APP_COMM_FAILURE	-97
XToolkitAppNewVersion	PRO_TK_APP_NEW_VERSION	-98

The exception XProdevError represents a general error that occurred while executing a Pro/DEVELOP function and is equivalent to an XZToolkit general Error.

The exception XExternalDataError and it's children are thrown from External Data methods. See the chapter on External Data for more information.

Approaches to J-Link Exception Handling

To deal with the exceptions generated by J-Link methods surround each method with a **try-catch-finally** block. For example:

```

try {
    JLinkObject.DoSomething()
}
catch (jxthrowable x) {
    // Respond to the exception.
}

```

Rather than catching the generic exception, you can set up your code to respond to specific exception types, using multiple **catch** blocks to respond to different situations, as follows:

```

try
{
    Object.DoSomething()
}
catch (XToolkitError x)
{
    // Respond based on the error code.
    x.GetErrorCode();
}
catch (XStringTooLong x)
{
    // Respond to the exception.
}
catch (jxthrowable x) // Do not forget to check for
                       // an unexpected error!

```

```
{  
    // Respond to the exception.  
}
```

If you do not want to surround every block of code with a **try** statement, you can declare your methods to throw the `jxthrowable` object. For example:

```
public class MyClass {  
  
    public void MyMethod() throws jxthrowable  
    {  
        // Includes Pro/J.Link function calls  
    }  
}
```

However, you must surround any calls to `MyMethod()` with a **try** block.

4

J-Link Programming Considerations

This chapter contains information needed to develop an application using J-Link.

Topic	Page
J-Link Thread Restrictions	4 - 2
Optional Arguments to J-Link Methods	4 - 2
Parent-Child Relationships Between J-Link Objects	4 - 3
Run-Time Type Identification in J-Link	4 - 4

J-Link Thread Restrictions

When you run a synchronous J-Link program, you should configure your program so it does not interfere with the main thread of the Pro/ENGINEER program. Because the Java API allows you to run with multiple threads, you should be cautious of using certain Java routines in your program.

The most obvious restriction involves the use of Java language user interfaces. Any Java window that you create must be a dialog box that is blocking (or modal).

Creating a nonblocking frame causes a new thread to begin, which can have unexpected results when running with Pro/ENGINEER. For example, you can use the `javax.swing.JDialog` class and set `modal true`. You cannot use `javax.swing.JWindow`, however, because it starts a thread.

Optional Arguments to J-Link Methods

Many methods in J-Link are shown in the online documentation as having optional arguments.

For example, the `pfModelItem.ModelItemOwner.ListItems` method takes an optional `Type` argument.

```
public interface ModelItemOwner extends
    jobject
{
    com.ptc.pfc.pfcModelItem.ModelItems ListItems (
        com.ptc.pfc.pfcModelItem.ModelItemType
        /* optional */ Type
    ) throws jthrowable;
}
```

You can pass the Java keyword **null** in place of any such optional argument. In addition, a return value of **null** is possible for returns that are declared optional. The J-Link methods that take optional arguments provide default handling for null parameters as is described in the online documentation.

Note:

- If a J-Link method takes an optional primitive type, such as an `int` or `boolean`, the argument will actually be a Java wrapper class, so that it may be set to **null**.
- You can only pass **null** in place of arguments that are shown in the documentation to be optional.

Optional Returns for J-Link Methods

Some methods in J-Link may have an optional return. Usually these correspond to lookup methods that may or may not find an object to return. For example, the **`pfcSession.BaseSession.GetModel`** method returns an optional model:

```
public interface Session
{
    /*optional*/ com.ptc.pfc.pfcModel.ModelGetModel
    (java.lang.String Name,
     com.ptc.pfc.pfcModel.ModelType Type);
}
```

J-Link might return **null** in certain cases where these methods are called. You must use appropriate error checking in your application code.

Parent-Child Relationships Between J-Link Objects

Some J-Link objects inherit from either the interface `com.ptc.pfc.pfcObject.Parent` or `com.ptc.pfc.pfcObject.Child`. These interfaces are used to maintain a relationship between the two objects. This has nothing to do with Java inheritance. In J-Link, the Child is owned by the Parent.

Methods Introduced:

- **pfcObject.Child.GetDBParent**

The method `GetDBParent` returns the owner of the child object. Because the object is returned as a `com.ptc.pfc.pfcObject.Parent` object, the application developer must down cast the return to the appropriate class. The following table lists parent/child relationships in J-Link.

Parent	Child
Session	Model
Session	Window
Model	ModelItem
Solid	Feature
Model	Parameter
Model	ExternalDataAccess
Display	DisplayList2D/3D
Part	Material
Model	View
Model2D	View2D
Solid	XSection
Session	Dll (Pro/TOOLKIT)
Session	Application (J-Link)

Run-Time Type Identification in J-Link

J-Link and the Java language provides several methods to identify the type of an object. Each has its advantages and disadvantages.

Many J-Link classes provide read access to a type enum (for example, the `Feature` class has a **GetFeatType** method, returning a `FeatureType` enumeration value representing the type of the feature). Based upon the type, a user can downcast the `Feature` object to a particular subtype, such as `ComponentFeat`, which is an assembly component.

5

The J-Link Online Browser

This chapter describes how to use the online browser provided with J-Link.

Topic	Page
Online Documentation — J-Link APIWizard	5 - 2

Online Documentation — J-Link APIWizard

J-Link provides an online browser called the J-Link APIWizard that displays detailed documentation. This browser displays information from the *J-Link User's Guide* and API specifications derived from J-Link header file data.

The J-Link APIWizard contains the following items:

- Definitions of J-Link packages and their hierarchical relationships
- Definitions of J-Link classes and interfaces
- Descriptions of J-Link methods
- Declarations of data types used by J-Link methods
- The *J-Link User's Guide*, which you can browse by topic or by class
- Code examples for J-Link methods (taken from the sample applications provided as part of the J-Link installation)

Read the Release Notes and README file for the most up-to-date information on documentation changes.

Note: The *J-Link User's Guide* is also available in PDF format. This file is located at:

```
<proe_loadpoint>/jlink/jlinkug.pdf
```

Installing the APIWizard

The Pro/ENGINEER installation procedure automatically installs the J-Link APIWizard. The files reside in a directory under the Pro/ENGINEER load point. The location for the J-Link APIWizard files is:

```
<proe_loadpoint>/jlink/jlinkdoc
```

Starting the APIWizard

Start the J-Link APIWizard by pointing your browser to:

```
<proe_loadpoint>/jlink/jlinkdoc/index.html
```

Your web browser will display the J-Link APIWizard data in a new window.

Web Browser Environments

The APIWizard supports Netscape Navigator version 4 and later, and Internet Explorer version 5 and later.

For APIWizard use with Internet Explorer, the recommended browser environment requires installation of the Java2 plug-in.

For Netscape Navigator, the recommended browser environment requires installation of the Java Swing foundation class. If this class is not loaded on your computer, the APIWizard can load it for you. This takes several minutes, and is not persistent between sessions. See Loading the Swing Class Library for the procedure on loading Swing permanently.

Loading the Swing Class Library

If you access the APIWizard with Internet Explorer, download and install Internet Explorer's Java2 plug-in. This is preferred over installing the Swing archive, as Swing degrades access time for the APIWizard Search function.

If you access the APIWizard with Netscape Navigator, follow these instructions to download and install the Java Foundation Class (Swing) archive:

- Download the Java Foundation Class (Swing) Archive
- Modifying the Java Class Path on UNIX Platforms
- Modifying the Java Class Path on NT Platforms

Download the Java Foundation Class (Swing) Archive

1. Go to the **Java Foundation Class Download Page**.
2. Go to the heading Downloading the JFC/Swing X.X.X Release, where X.X.X is the latest JFC version.
3. Click on the standard TAR or ZIP file link to go to the heading Download the Standard Version.
4. Do not download the "installer" version.
5. Select a file format, click Continue, and follow the download instructions on the subsequent pages.
6. Uncompress the downloaded bundle.

After downloading the swing-X.X.Xfcs directory (where X.X.X is the version of the downloaded JFC) created when uncompressing the bundle, locate the swingall.jar archive. Add this archive to the Java Class Path as shown in the next sections.

Modifying the Java Class Path on UNIX Platforms

Follow these steps to make the Java Foundation Class (Swing) available in UNIX shell environments:

1. If the CLASSPATH environment variable exists, then add the following line to the end of file ~/.cshrc

```
setenv CLASSPATH "${CLASSPATH}:[path_to_swingall.jar]"
```

Otherwise, add the following line to ~/.cshrc

```
setenv CLASSPATH ":[path_to_swingall.jar]"
```

2. Save and close ~/.cshrc.
3. Enter the following command:

```
source ~/.cshrc
```

This sets the CLASSPATH environment variable in the current shell. All new shells will be also be affected.


4. Close and restart your internet browser from shell that uses the new class path data.

Modifying the Java Class Path on NT Platforms

Follow these steps to make the Java Foundation Class (Swing) available on Windows NT Platforms:

1. Click on **Start -> Settings -> Control Panel**.
2. In the **System Properties** window, select the **Environment** tab.
3. Check in the User Variables display area for the ClassPath variable as shown in the following figure.

Windows NT Environment Variable Display Window



If the ClassPath variable exists, then follow these steps:

1. Click on **ClassPath** in the Variable column. The value of ClassPath will appear in the Value text field.
2. Append the path to the swingall.jar archive to the current value of ClassPath:

```
...;[path_to_swingall_archive];.
```

Use the semicolon as the path delimiter before and after the path to the archive, and the period (.) at the end of the variable definition. There must be only one semicolon-period “;.” entry in the ClassPath variable, and it should appear at the end of the class path.

If the ClassPath variable does not exist, then follow these steps:

1. In the Variable text field, enter ClassPath.
2. In the Value text field, enter:

```
[path_to_swingall_archive];.
```

There must be a semicolon-period “;.” entry at the end of the ClassPath variable.

3. Click the **Set** button.
4. Click the **Apply** button.
5. Click the **OK** button.
6. Close and restart your internet browser. You do not need to reboot your machine.

Automatic Index Tree Updating

With your browser environment configured correctly, following a link in an APIWizard HTML file causes the tree in the Selection frame to update and scroll the tree reference that corresponds to the newly displayed page. This is automatic tree scrolling.

If you access the APIWizard through Netscape’s Java2 plug-in, this feature is not available. You must install the Java foundation class called Swing for this method to work. See Loading the Swing Class Library for the procedure on loading Swing.

If you access the APIWizard with Internet Explorer, download and install the Internet Explorer Java2 plug-in to make automatic tree scrolling available.

APIWizard Interface

The APIWizard interface consists of two frames. The next sections describe how to display and use these frames in your Web browser.

Package/Class/Interface/Exception/Topic Selection Frame

This frame, located on the left of the screen, controls what is presented in the Display frame. Specify what data you want to view by choosing either **Packages**, **Classes**, **Interfaces**, **Exceptions**, or the **J-Link Wildfire 4.0 User’s Guide**.

In **Packages** mode, this frame displays an alphabetical list of the J-Link packages. A package is a logical subdivision of functionality within J-Link; for example, the `pfCFamily` package contains classes related to family table operations. This frame can also display J-Link interfaces, classes, and methods as subnodes of the packages.

In **Classes** mode, this frame displays an alphabetical list of the J-Link Classes. It can also display J-Link methods as subnodes of the classes.

In **Interfaces** mode, this frame displays an alphabetical list of the J-Link interfaces. It can also display J-Link methods as subnodes of the interfaces.

In **Exceptions** mode, this frame displays an alphabetical list of named exceptions in the J-Link library. It can also display the methods for the exceptions as the subnodes.

In **J-Link Wildfire 4.0 User's Guide** mode, this frame displays the *J-Link User's Guide* table of contents in a tree structure. All chapters are displayed as subnodes of the main *J-Link User's Guide* node.

The Package/Class/Interface Selection frame includes a **Find** button for data searches of the *J-Link User's Guide* or of API specifications taken from header files. See the section APIWizard Search Feature (Find) for more information on the Find feature.


Display Frame

This frame, located on the right of the screen, displays:

- J-Link package definitions and their hierarchial relationships.
- J-Link classes and interfaces definitions
- J-Link method descriptions
- User's Guide content
- Code examples for J-Link methods

The following figure displays the APIWizard interface layout.

J-Link APIWizard General Layout



Navigating the Package/Class/Interface/Exception/Topic Selection Tree

Access all J-Link APIWizard online documentation data for packages, classes, interfaces, methods, or the *J-Link User's Guide* from the Package/Class/Interface Selection frame. This frame displays a tree structure of the data. Expand and collapse the tree to navigate this data.

To expand the tree structure, first select **Packages, Classes, Interfaces, Exceptions**, or the **J-Link Wildfire 4.0 User's Guide** at the top of the frame. The APIWizard displays the tree structure in a collapsed form. The switch icon to the far left of a node (i.e. a package, a class, a interface or chapter name) signifies that this node contains subnodes. If a node has no switch icon, it has no subnodes. Clicking the switch icon (or double-clicking on the node text) moves the switch to the down position. The APIWizard then expands the tree to display the subnodes. Select a node or subnode, and the APIWizard displays the online data in the Display frame.

Browsing the J-Link Packages


View the J-Link packages by choosing J-Link **Packages** at the top of the Package/Classes/Interfaces Selection frame. In this mode, the APIWizard displays all the J-Link packages in the alphabetical order.

The Display frame for each J-Link package displays the information about all the classes and interfaces that belong to that package.

Click the switch icon next to the desired package name, or double-click the package name text to view the classes or interfaces that belong to that package. You can also view the methods for each class or interface in the expanded tree by clicking the switch icon next to the class or interface name, or by double-clicking the name.

The following figure shows the collapsed tree layout for the J-Link packages.

J-Link Packages



Browsing the J-Link User's Guide

View the *J-Link User's Guide* by clicking the **J-Link Wildfire 4.0 User's Guide** at the top of the Package/Class/Interface/Exception/Topic Selection frame. In this mode, the APIWizard displays the section headings of the User's Guide.

View a section by clicking the switch icon next to the desired section name or by double-clicking the section name. The APIWizard then displays a tree of subsections under the selected section. The text for the selected section and its subsections appear in the Display frame. Click the switch icon again (or double-click the node text) to collapse the subnodes listed and display only the main nodes.

The following figure shows the collapsed tree layout for the table of contents of the *J-Link User's Guide*.

Table of Contents for the User's Guide

The screenshot displays a software interface for finding documents. At the top is a 'Find' bar. Below it is a 'Filter Flags' dropdown menu. The main content area shows a list of folders under the heading 'J-Link Wildfire 4.0 User's Guide'. Each folder is represented by a folder icon and a small circular expandable symbol. The folders listed are:


- About This Guide
- Setting Up J-Link
- Java Programming Considerations
- Overview of J-Link
- J-Link Programming Considerations
- The J-Link Online Browser
- Session Objects
- Selection
- Models
- Drawings
- Solid
- Windows and Views
- ModelItem
- Features
- Geometry Evaluation
- Dimensions and Parameters
- Assemblies and Components
- Family Tables
- Action Listeners
- Interface
- Simplified Representations
- Asynchronous Mode
- Task Based Application Libraries
- Graphics
- External Data

APIWizard Search Feature (Find)

The APIWizard supports searches for specified strings against both the *J-Link User's Guide* and API definition files. Click the **Find** button on the Package/Class/Interface/Exception/Topic frame to display the APIWizard Search dialog.

Note: The APIWizard Search feature is slow when accessed through Internet Explorer's Default Virtual Machine. For better performance, access the APIWizard through Internet Explorer's Java2 plug-in.

APIWizard Search Dialog Box



The **Search** dialog box contains the following fields, buttons, and frames:

- **Enter Search String(s)**

Enter the specific search string or strings in this field. By default, the browser performs a non-case-sensitive search.
- **Search/Stop**

Select the Search button to begin a search. During a search, this button name changes to Stop. Select the Stop button to stop a search.
- **Help**

Select this button for help about the APIWizard search feature. The APIWizard presents this help data in the Display frame.
- **Case Sensitive**

Select this button to specify a case-sensitive search.
- **Search API References**

Select this button to search for data on API methods. Select the API Names button to search for method names only. Select the Definitions button to search the API method names and definitions for specific strings.
- **Search Manuals**

Select this button to search the *J-Link User's Guide* data. Select the Table of Contents button to search on TOC entries only. Select the Index button to search only the Index. Select the Contents button to search on all text in the *J-Link User's Guide*.
- **Name**

This frame displays a list of strings found by the APIWizard search.
- **Found Under**

This frame displays the location in the online help data where the APIWizard found the string.

Supported Search Types

The APIWizard Search supports the following:

- Case sensitive searches
- Search of API definitions, *J-Link User's Guide* data, or both
- Search of API data by API names only or by API names and definitions
- Search of *J-Link User's Guide* by Table of Contents only, by TOC and section titles, or on the User's Guide contents (the entire text).
- Wildcard searches—valid characters are:
 - * (asterisk) matches zero or more non-whitespace characters
 - ? (question mark) matches one and only one non-whitespace character

To search for any string containing the characters Get, any number of other characters, and the characters Name

Get*Name

To search for any string containing the characters Get, one other character, and the characters Name

Get?Name

To search for any string containing the characters Get, one or more other characters, and the characters Name

Get?*Name

To search on the string Feature, followed by an *

Feature*

To search on the string Feature, followed by a ?

Feature\?

To search on the string Feature, followed by a \

Feature\\

- Search string containing white space— Search on strings that contain space characters (white space) by placing double- or single-quote characters around the string.

```
"family table"  
'Model* methods'
```

- Search on multiple strings—Separate multiple search strings with white space (tabs or spaces). Note that the default logical relationship between multiple search strings is OR.

To return all strings matching GetName OR GetId, enter:

```
Get*Name Get*Id
```

Note: This search specification also returns strings that match both specified search targets.

For example:

```
FullName
```

returns **Model.GetName** and **ModelDescriptor.GetFullName**

If a string matches two or more search strings, the APIWizard displays only one result in the search table, for example:

```
Full* *Name
```

returns only one entry for each **FullName** property found.

Mix quoted and non-quoted strings as follows:

```
Get*Name "family table"
```

returns all instances of strings containing Get and Name, or strings containing family table.

Performing an APIWizard Search

Follow these steps to search for information in the APIWizard online help data:

- Select the Find icon at the top of the Package/Class/Interface/Exception/Topic Selection frame.
- Specify the string or strings to be searched for in the Enter Search String field.
- Select Case Sensitive to specify a case-sensitive search. Note that the default search is non-case-sensitive.
- Select either or both of the Search API References and Search User's Guide buttons. Select the options under these buttons as desired.
- Select the Search button. The APIWizard turns this button red and is renames it **Stop** for the duration of the search.

- If the APIWizard finds the search string in the specified search area(s), it displays the string in the Name frame. In the Where Found frame, the APIWizard displays links to the online help data that contains the found string.
- During the search, or after the search ends, select an entry in the Name or Where Found frames to display the online help data for that string. The APIWizard first updates the Package/Class/Interface/Exception/Topic Selection frame tree, and then presents in the Display frame the online help data for the selected string.

6

Session Objects

This chapter describes how to program on the session level using J-Link.

Topic	Page
Overview of Session Objects	6 - 2
Getting the Session Object	6 - 2
Directories	6 - 5
Accessing the Pro/ENGINEER Interface	6 - 8

Overview of Session Objects

The Pro/ENGINEER `Session` object (contained in the class `com.ptc.pfc.pfcSession.Session`) is the highest level object in J-Link. Any program that accesses data from Pro/ENGINEER must first get a handle to the `Session` object before accessing more specific data.

The `Session` object contains methods to perform the following operations:

- Accessing models and windows (described in the `Models and Windows` chapters).
- Working with the Pro/ENGINEER user interface.
- Allowing interactive selection of items within the session.
- Accessing global settings such as line styles, colors, and configuration options.

The following sections describe these operations in detail.

Getting the Session Object

Method Introduced:

- `pfcGlobal.pfcGlobal.GetProESession`

The method `pfcGlobal.pfcGlobal.GetProESession` gets a `Session` object in synchronous mode.

Note: You can make multiple calls to this method but each call will give you a handle to the same object.

Getting Session Information

Methods Introduced:

- `pfcGlobal.pfcGlobal.GetProEArguments`
- `pfcGlobal.pfcGlobal.GetProEVersion`
- `pfcGlobal.pfcGlobal.GetProEBuildCode`

The method `pfcGlobal.pfcGlobal.GetProEArguments` returns an array containing the command line arguments passed to Pro/ENGINEER if these arguments follow one of two formats:

- Any argument starting with a plus sign (+) followed by a letter character.

- Any argument starting with a minus (-) followed by a capitalized letter.

The first argument passed in the array is the full path to the Pro/ENGINEER executable.

The method **pfcGlobal.pfcGlobal.GetProEVersion** returns a string that represent the Pro/ENGINEER version, for example “Wildfire”.

The method **pfcGlobal.pfcGlobal.GetProEBuildCode** returns a string that represents the build code of the Pro/ENGINEER session.

Note: The preceding methods can only access information in synchronous mode.

Example: Accessing the Pro/ENGINEER Command Line Arguments

The following example describes the use of the **GetProEArguments** method to access the Pro/ENGINEER command line arguments. The first argument is always the full path to the Pro/E executable. For this application the next two arguments can be either (“+runtime” or “+development”) or (“-Unix” or “-NT”). Based on these values 2 boolean variables are set and passed on to another method which makes use of this information.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.*;
public class ProEArgumentExample
{
    public static void start()
    {
        try
        {
            boolean unix;
            boolean runtime;
/*-----*\
    Getting the arguments!
/*-----*\
            stringseq argseq=pfcGlobal.GetProEArguments();
/*-----*\
    Making sure that there are 3 arguments.
/*-----*\
            int size=argseq.getarraysize();
            if (size == 3)
            {
/*-----*\
    First argument is Pro/ENGINEER executable
/*-----*\
        }
    }
}
```

```

        String val=argseq.get(1);
/*-----*\
Setting boolean variable runtime based on value after making sure that
it is one of the 2 specified values.
/*-----*\
        if (val.equalsIgnoreCase("+runtime"))
        {
            runtime=true;
        }
        else if (val.equalsIgnoreCase("+development"))
        {
            runtime=false;
        }
        else
        {
            printMsg("Invalid second argument");
            return;
        }
/*-----*\
Setting boolean variable unix based on value after making sure that it
is one of the 2 specified values.
/*-----*\
        val=argseq.get(2);
        if (val.equalsIgnoreCase("-Unix"))
        {
            unix=true;
        }
        else if (val.equalsIgnoreCase("-NT"))
        {
            unix=false;
        }
        else
        {
            printMsg ("Invalid third argument");
            return;
        }
/*-----*\
Pass the boolean values to the method where they are used for some
application.
/*-----*\
        runApplication(runtime,unix);
    }
    else
    {
        printMsg("Invalid number of arguments");
    }
}
catch(jxthrowable x)
{
    printMsg("Exception in getting session:"+x);
}

```

```
    }  
  }  
  public static void runApplication(boolean rtime, boolean unix)  
  {  
/*-----*\  
Application code goes here...  
/*-----*\  
  }  
  public static void stop()  
  {  
  }  
  public static void printMsg(String str)  
  {  
      System.out.println(str);  
  }  
}
```

Directories

Methods Introduced:

- **pfSession.BaseSession.GetCurrentDirectory**
- **pfSession.BaseSession.ChangeDirectory**

The method **pfSession.BaseSession.GetCurrentDirectory** returns the absolute path name for the current working directory of Pro/ENGINEER.

The method **pfSession.BaseSession.ChangeDirectory** changes Pro/ENGINEER to another working directory.

File Handling

Methods Introduced:

- **pfSession.BaseSession.ListFiles**
- **pfSession.BaseSession.ListSubdirectories**

The method **pfSession.BaseSession.ListFiles** returns a list of files in a directory, given the directory path. You can filter the list to include only files of a particular type, as specified by the file extension. Use the **FILE_LIST_ALL** option to include all versions of a file in the list; use **FILE_LIST_LATEST** to include only the latest version.

Starting with Pro/ENGINEER Wildfire 5.0 M040, the method **pfcSession.BaseSession.ListFiles** can also list instance objects when accessing Windchill workspaces or folders. A PDM location (for workspace or commonspace) must be passed as the directory path. The following options have been added in the `FileListOpt` enumerated type:

- **FILE_LIST_ALL_INST**—Same as the **FILE_LIST_ALL** option. It returns instances only for PDM locations.
- **FILE_LIST_LATEST_INST**—Same as the **FILE_LIST_LATEST** option. It returns instances only for PDM locations.

The method **pfcSession.BaseSession.ListSubdirectories** returns the subdirectories in a given directory location.

Configuration Options

Methods Introduced:

- **pfcSession.BaseSession.GetConfigOptionValues**
- **pfcSession.BaseSession.SetConfigOption**
- **pfcSession.BaseSession.LoadConfigFile**

You can access configuration options programmatically using the methods described in this section.

Use the method **pfcSession.BaseSession.GetConfigOptionValues** to retrieve the value of a specified configuration file option. Pass the *Name* of the configuration file option as the input to this method. The method returns an array of values that the configuration file option is set to. It returns a single value if the configuration file option is not a multi-valued option. The method returns a null if the specified configuration file option does not exist.

The method **pfcSession.BaseSession.SetConfigOption** is used to set the value of a specified configuration file option. If the option is a multi-value option, it adds a new value to the array of values that already exist.

The method **pfcSession.BaseSession.LoadConfigFile** loads an entire configuration file into Pro/ENGINEER.

Macros

Method Introduced:

- **pfcSession.BaseSession.RunMacro**

The method **pfcSession.BaseSession.RunMacro** runs a macro string. A J-Link macro string is equivalent to a Pro/ENGINEER mapkey minus the key sequence and the mapkey name. To generate a macro string, create a mapkey in Pro/ENGINEER. Refer to the Pro/ENGINEER online help for more information about creating a mapkey.

Copy the Value of the generated mapkey Option from the **Tools>Options** dialog box. An example Value is as follows:

```
$F2 @MAPKEY_LABELtest;  
~ Activate `main_dlg_cur` `ProCmdModelNew.file`;  
~ Activate `new` `OK`;
```

The key sequence is \$F2. The mapkey name is @MAPKEY_LABELtest. The remainder of the string following the first semicolon is the macro string that should be passed to the method **pfcSession.BaseSession.RunMacro**.

In this case, it is as follows:

```
~ Activate `main_dlg_cur` `ProCmdModelNew.file`;  
~ Activate `new` `OK`;
```

Note: Creating or editing the macro string manually is not supported as the mapkeys are not a supported scripting language. The syntax is not defined for users and is not guaranteed to remain constant across different datecodes of Pro/ENGINEER.

Macros are executed from synchronous mode only when control returns to Pro/ENGINEER from the J-Link program. Macros in synchronous mode are stored in reverse order (last in, first out).

Macros are executed in asynchronous mode as soon as they are registered. Macros in asynchronous mode are run in the same order that they are saved.

Colors and Line Styles

Methods Introduced:

- **pfcSession.BaseSession.SetStdColorFromRGB**
- **pfcSession.BaseSession.GetRGBFromStdColor**
- **pfcSession.BaseSession.SetTextColor**
- **pfcSession.BaseSession.SetLineStyle**

These methods control the general display of a Pro/ENGINEER session.

Use the method

pfcSession.BaseSession.SetStdColorFromRGB to customize any of the Pro/ENGINEER standard colors.

To change the color of any text in the window, use the method **pfcSession.BaseSession.SetTextColor**.

To change the appearance of nonsolid lines (for example, datums) use the method **pfcSession.BaseSession.SetLineStyle**.

Accessing the Pro/ENGINEER Interface

The `Session` object has methods that work with the Pro/ENGINEER interface. These methods provide access to the menu bar and message window. For more information on accessing menus, refer to the chapter Menus, Commands, and Pop-up Menus.

The Text Message File

A text message file is where you define strings that are displayed in the Pro/ENGINEER user interface. This includes the strings on the command buttons that you add to the Pro/ENGINEER number, the help string that displays when the user's cursor is positioned over such a command button, and text strings that you display in the Message Window. You have the option of including a translation for each string in the text message file.

Restrictions on the Text Message File

You must observe the following restrictions when you name your message file:

- The name of the file must be 30 characters or less, including the extension.
- The name of the file must contain lower case characters only.
- The file extension must be three characters.
- The version number must be in the range 1 to 9999.
- All message file names must be unique, and all message key strings must be unique across all applications that run with Pro/ENGINEER. Duplicate message file names or message key strings can cause Pro/ENGINEER to exhibit unexpected behavior. To avoid conflicts with the names of Pro/ENGINEER or foreign application message files or message key strings, PTC recommends that you choose a prefix unique to your application, and prepend that prefix to each message file name and each message key string corresponding to that application

Note: Message files are loaded into Pro/ENGINEER only once during a session. If you make a change to the message file while Pro/ENGINEER is running you must exit and restart Pro/ENGINEER before the change will take effect.

Contents of the Message File

The message file consists of groups of four lines, one group for each message you want to write. The four lines are as follows:

1. A string that acts as the identifier for the message. This keyword must be unique for all Pro/ENGINEER messages.
2. The string that will be substituted for the identifier.
This string can include placeholders for run-time information stored in a `stringseq` object (shown in Writing Messages to the Message Window).
3. The translation of the message into another language (can be blank).
4. An intentionally blank line reserved for future extensions.

Writing a Message Using a Message Pop-up Dialog Box

Method Introduced:

- **pfcSession.Session.UIShowMessageDialog**

The method **pfcSession.Session.UIShowMessageDialog** displays the UI message dialog. The input arguments to the method are:

- *Message*—The message text to be displayed in the dialog.
- *Options*—An instance of the `pfcUI.MessageDialogOptions` containing other options for the resulting displayed message. If this is not supplied, the dialog will show a default message dialog with an **Info** classification and an **OK** button. If this is not to be null, create an instance of this options type with **pfcUI.pfcUI.MessageDialogOptions_Create()**. You can set the following options:
 - *Buttons*—Specifies an array of buttons to include in the dialog. If not supplied, the dialog will include only the **OK** button. Use the method **pfcUI.MessageDialogOptions.SetButtons** to set this option.
 - *DefaultButton*—Specifies the identifier of the default button for the dialog box. This must match one of the available buttons. Use the method **pfcUI.MessageDialogOptions.SetDefaultButton** to set this option.
 - *DialogLabel*—The text to display as the title of the dialog box. If not supplied, the label will be the english string "Info". Use the method **pfcUI.MessageDialogOptions.SetDialogLabel** to set this option.
 - *MessageDialogType*—The type of icon to be displayed with the dialog box (Info, Prompt, Warning, or Error). If not supplied, an Info icon is used. Use the method **pfcUI.MessageDialogOptions.SetMessageDialogType** to set this option.

Accessing the Message Window

The following sections describe how to access the message window using J-Link. The topics are as follows:

- Writing Messages to the Message Window
- Writing Messages to an Internal Buffer

Writing Messages to the Message Window

Methods Introduced:

- **pfcSession.Session.UIDisplayMessage**
- **pfcSession.Session.UIDisplayLocalizedMessage**
- **pfcSession.Session.UIClearMessage**

These methods enable you to display program information on the screen.

The input arguments to the methods **pfcSession.Session.UIDisplayMessage** and **pfcSession.Session.UIDisplayLocalizedMessage** include the names of the message file, a message identifier, and (optionally) a `stringseq` object that contains up to 10 pieces of run-time information. For **pfcSession.Session.UIDisplayMessage**, the strings in the `stringseq` are identified as `%0s, %1s, ... %9s` based on their location in the sequence. For **pfcSession.Session.UIDisplayLocalizedMessage**, the strings in the `stringseq` are identified as `%0w, %1w, ... %9w` based on their location in the sequence. To include other types of run-time data (such as integers or reals) you must first convert the data to strings and store it in the string sequence.

Writing Messages to an Internal Buffer

Methods Introduced:

- **pfcSession.BaseSession.GetMessageContents**
- **pfcSession.BaseSession.GetLocalizedMessageContents**

The methods **pfcSession.BaseSession.GetMessageContents** and **pfcSession.BaseSession.GetLocalizedMessageContents** enable you to write a message to an internal buffer instead of the Pro/ENGINEER message area.

These methods take the same input arguments and perform exactly the same argument substitution and translation as the **pfcSession.Session.UIDisplayMessage** and **pfcSession.Session.UIDisplayLocalizedMessage** methods described in the previous section.

Message Classification

Messages displayed in J-Link include a symbol that identifies the message type. Every message type is identified by a classification that begins with the characters %C. A message classification requires that the message key line (line one in the message file) must be preceded by the classification code.

Note: Any message key string used in the code should not contain the classification.

J-Link applications can now display any or all of the following message symbols:

- **Prompt**—This J-Link message is preceded by a green arrow. The user must respond to this message type. Responding includes, specifying input information, accepting the default value offered, or canceling the application. If no action is taken, the progress of the application is halted. A response may either be textual or a selection. The classification for Prompt messages is %CP.
- **Info**—This J-Link message is preceded by a blue dot. Info message types contain information such as user requests or feedback from J-Link or Pro/ENGINEER. The classification for Info messages is %CI.

Note: Do not classify messages that display information regarding problems with an operation or process as **Info**. These types of messages must be classified as **Warnings**.

- **Warning**—This J-Link message is preceded by a triangle containing an exclamation point. Warning message types contain information to alert users to situations that could potentially lead to an error during a later stage of the process. Examples of warnings could be a process restriction or a suspected data problem. A Warning will not prevent or interrupt a process. Also, a Warning should not be used to indicate a failed operation. Warnings must only caution a user that the completed operation may not have been performed in a completely desirable way. The classification for Warning messages is %CW.

- **Error**—This J-Link message is preceded by a broken square. An Error message informs the user that a required task was not completed successfully. Depending on the application, a failed task may or may not require intervention or correction before work can continue. Whenever possible redress this situation by providing a path. The classification for Error messages is %CE.
- **Critical**—This J-Link message is preceded by a red X. A Critical message type informs the user of an extremely serious situation that is usually preceded by loss of user data. Options redressing this situation, if available, should be provided within the message. The classification for a Critical messages is %CC.

Example Code: Writing a Message

The following example code demonstrates how to write a message to the message window. The program uses the message file *mymessages.txt*, which contains the following lines:

```
USER Error: %0s of code %1s at %2s
Error: %0s of code %1s at %2s
#
#
```

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;

public class UIDisplayMessage {

    public void printMyError (Session session, String location,
        String error, int errorcode)
    {
        stringseq texts;

        try {
            texts = stringseq.create();
        }
        catch (jxthrowable x) {
            System.out.println ("Exception in creating string sequence:"+x);
            return;
        }

        try {
            texts.set (0, error);
            texts.set (1, new String (errorcode));
            texts.set (2, location);
        }
        catch (jxthrowable x) {
```

```

        System.out.println ("Exception in setting text fields:"+x);
        return;
    }
    try {
        session.UIDisplayMessage ("mymessages.txt",
            "USER Error: %0s of code %1s at %2s", texts);
    }
    catch (jxthrowable x) {
        System.out.println ("Exception in UIDisplayMessage():"+x);
    }
}
}

```

Reading Data from the Message Window

Methods Introduced:

- **pfcSession.Session.UIReadIntMessage**
- **pfcSession.Session.UIReadRealMessage**
- **pfcSession.Session.UIReadStringMessage**

These methods enable a program to get data from the user.

The **pfcSession.Session.UIReadIntMessage** and **pfcSession.Session.UIReadRealMessage** methods contain optional arguments that can be used to limit the value of the data to a certain range.

The method **pfcSession.Session.UIReadStringMessage** includes an optional Boolean argument that specifies whether to echo characters entered onto the screen. You would use this argument when prompting a user to enter a password.

Displaying Feature Parameters

Method Introduced:

- **pfcSession.Session.UIDisplayFeatureParams**

The method **pfcSession.Session.UIDisplayFeatureParams** forces Pro/ENGINEER to show dimensions or other parameters stored on a specific feature. The displayed dimensions may then be interactively selected by the user.

File Dialogs

Methods Introduced:

- **pfcSession.Session.UIOpenFile**
- **pfcUI.pfcUI.FileOpenOptions_Create**
- **pfcUI.FileOpenOptions.SetFilterString**
- **pfcUI.FileOpenOptions.SetPreselectedItem**
- **pfcUI.FileUIOptions.SetDefaultPath**
- **pfcUI.FileUIOptions.SetDialogLabel**
- **pfcUI.FileUIOptions.SetShortcuts**
- **pfcUI.pfcUI.FileOpenShortcut_Create**
- **pfcUI.FileOpenShortcut.SetShortcutName**
- **pfcUI.FileOpenShortcut.SetShortcutPath**
- **pfcSession.Session.UISaveFile**
- **pfcUI.pfcUI.FileSaveOptions_Create**
- **pfcSession.Session.UISelectDirectory**
- **pfcUI.pfcUI.DirectorySelectionOptions_Create**
- **pfcSession.BaseSession.UIRegisterFileOpen**
- **pfcUI.pfcUI.FileOpenRegisterOptions_Create**
- **pfcUI.FileOpenRegisterOptions.SetFileDescription**
- **pfcUI.FileOpenRegisterOptions.SetFileType**
- **pfcUI.FileOpenRegisterListener.FileOpenAccess**
- **pfcUI.FileOpenRegisterListener.OnFileOpenRegister**
- **pfcSession.BaseSession.UIRegisterFileSave**
- **pfcUI.pfcUI.FileSaveRegisterOptions_Create**
- **pfcUI.FileSaveRegisterOptions.SetFileDescription**
- **pfcUI.FileSaveRegisterOptions.SetFileType**
- **pfcUI.FileSaveRegisterListener.FileSaveAccess**
- **pfcUI.FileSaveRegisterListener.OnFileSaveRegister**

The method **pfcSession.Session.UIOpenFile** opens the relevant Pro/ENGINEER dialog box for opening files and browsing directories. The method lets you specify several options through the input arguments `pfcUI.FileOpenOptions` and `pfcUI.FileUIOptions`.

Use the method **pfcUI.pfcUI.FileOpenOptions_Create** to create a new instance of the `pfcUI.FileOpenOptions` object. This object contains the the following options:

- *FilterString*—Specifies the filter string for the type of file accepted by the dialog box. Multiple file types should be listed with wildcards and separated by commas, for example, "*.prt, *.asm". Use the method **pfcUI.FileOpenOptions.SetFilterString** to set this option.
- *PreselectedItem*—Specifies the name of an item to preselect in the dialog box. Use the method **pfcUI.FileOpenOptions.SetPreselectedItem** to set this option.

The `pfcUI.FileUIOptions` object contains the the following options:

- *DefaultPath*—Specifies the name of the path to be opened by default in the dialog box. Use the method **pfcUI.FileUIOptions.SetDefaultPath** to set this option.
- *DialogLabel*—Specifies the title of the dialog box. Use the method **pfcUI.FileUIOptions.SetDialogLabel** to set this option.
- *Shortcuts*—Specifies an array of file shortcuts of the type `pfcUI.FileOpenShortcut`. Create this object using the method **pfcUI.FileOpenShortcut_Create**. This object contains the following attributes:

- *ShortcutName*—Specifies the name of shortcut path to be made available in the dialog box.
- *ShortcutPath*—Specifies the string for the shortcut path.

Use the method **pfcUI.FileUIOptions.SetShortcuts** to set the array of file shortcuts.

The method **pfcSession.Session.UIOpenFile** returns the file selected by you. The application must use other methods or techniques to perform the desired action on the file.

The method **pfcSession.Session.UISaveFile** opens the Pro/ENGINEER dialog box for saving a file. The method accepts options similar to **pfcSession.Session.UIOpenFile** through the `pfcUI.FileSaveOptions` and `pfcUI.FileUIOptions` objects. Use the method **pfcUI.pfcUI.FileSaveOptions_Create** to create a new instance of the `pfcUI.FileSaveOptions` object. When using the **Save** dialog box, you can set the name to a non-existent file. The method **pfcSession.Session.UISaveFile** returns the name of the file selected by you; the application must use other methods or techniques to perform the desired action on the file.

The method **pfcSession.Session.UISelectDirectory** prompts the user to select a directory using the Pro/ENGINEER dialog box for browsing directories. The method accepts options through the `pfcUI.DirectorySelectionOptions` object which is similar to the `pfcUI.FileUIOptions` object (described for the method **pfcSession.Session.UIOpenFile**). Specify the default directory path, the title of the dialog box, and a set of shortcuts to other directories to start browsing. If the default path is specified as NULL, the current directory is used. Use the method **pfcUI.pfcUI.DirectorySelectionOptions_Create** to create a new instance of the `pfcUI.DirectorySelectionOptions` object. The method **pfcSession.Session.UISelectDirectory** returns the selected directory path; the application must use other methods or techniques to perform other relevant tasks with this selected path.

The method **pfcSession.BaseSession.UIRegisterFileOpen** registers a new file type in the **File > Open** dialog box in Pro/ENGINEER. This method takes the `pfcUI.FileOpenRegisterOptions` and `pfcUI.FileOpenRegisterListener` objects as its input arguments. These objects are as follows:

- `pfcUI.FileOpenRegisterOptions`—This object contains the options for registering an open operation. Use the method **pfcUI.pfcUI.FileOpenRegisterOptions_Create** to create a new instance of the object. It contains the following options:
 - *FileDescription*—Specifies the short description of the file type to be opened. This description appears for the file type in the **File > Open** dialog box. Use the method **pfcUI.pfcUI.FileOpenRegisterOptions.SetFileDescription** to modify this option.
 - *FileType*—Specifies the file type to be opened. The file type appears as the file extension in the **File > Open** dialog box. Use the method **pfcUI.pfcUI.FileOpenRegisterOptions.SetFileType** to modify this option.

- `pfcUI.FileOpenRegisterListener`—This object provides the action listener methods for the new file type to be registered. The method **`pfcUI.FileOpenRegisterListener.FileOpenAccess`** is called to determine whether the new file type can be opened using the **File > Open** dialog box. The method **`pfcUI.FileOpenRegisterListener.OnFileOpenRegister`** is called on clicking **Open** for the newly registered file type.

The method `pfcSession.BaseSession.UIRegisterFileSave` registers a new file type in the **File > Save a Copy** dialog box in Pro/ENGINEER. This method takes the `pfcUI.FileSaveRegisterOptions` and `pfcUI.FileSaveRegisterListener` objects as its input arguments. These objects are described as follows:

- `pfcUI.FileSaveRegisterOptions`—This object contains the options for registering a save operation. Use the method **`pfcUI.pfcUI.FileSaveRegisterOptions.Create`** to create a new instance of the object. It contains the following options:
 - *FileDescription*—Specifies the short description of the file type to be saved. This description appears for the file type in the **File > Save a Copy** dialog box. Use the method **`pfcUI.FileSaveRegisterOptions.SetFileDescription`** to modify this option.
 - *FileType*—Specifies the file type to be saved. The file type appears as the file extension in the **File > Save a Copy** dialog box. Use the method **`pfcUI.FileSaveRegisterOptions.SetFileType`** to modify this option.
- `pfcUI.FileSaveRegisterListener`—This object provides the action listener methods for the new file type to be registered. The method **`pfcUI.FileSaveRegisterListener.FileSaveAccess`** is called to determine whether the new file type can be saved using the **File > Save a Copy** dialog box. The method **`pfcUI.FileSaveRegisterListener.OnFileSaveRegister`** is called on clicking **OK** for the newly registered file type.

Customizing the Pro/ENGINEER Navigation Area

The Pro/ENGINEER navigation area includes the Model and Layer Tree pane, Folder browser pane, and Favorites pane. The methods described in this section enable J-Link applications to add custom panes that contain Web pages to the Pro/ENGINEER navigation area.

Adding Custom Web Pages

To add custom Web pages to the navigation area, the J-Link application must:

1. Add a new pane to the navigation area.
2. Set an icon for this pane.
3. Set the URL of the location that will be displayed in the pane.

Methods Introduced:

- **pfcSession.Session.NavigatorPaneBrowserAdd**
- **pfcSession.Session.NavigatorPaneBrowserIconSet**
- **pfcSession.Session.NavigatorPaneBrowserURLSet**

The method **pfcSession.Session.NavigatorPaneBrowserAdd** adds a new pane that can display a Web page to the navigation area. The input parameters are:

- *PaneName*—Specify a unique name for the pane. Use this name in subsequent calls to **pfcSession.Session.NavigatorPaneBrowserIconSet** and **pfcSession.Session.NavigatorPaneBrowserURLSet**.
- *IconFileName*—Specify the name of the icon file, including the extension. A valid format for the icon file is the PTC-proprietary format used by Pro/ENGINEER .BIF, .GIF, .JPG, or .PNG. The new pane is displayed with the icon image. If you specify the value as NULL, the default Pro/ENGINEER icon is used.

The default search paths for finding the icons are:

- <ProENGINEER loadpoint>/text/resource
- <Application text dir>/resource
- <Application text dir>/(<language>)/resource

The location of the application text directory is specified in the registry file.

- *URL*—Specify the URL of the location to be accessed from the pane.

Use the method

pfcSession.Session.NavigatorPaneBrowserIconSet to set or change the icon of a specified browser pane in the navigation area.

Use the method

pfcSession.Session.NavigatorPaneBrowserURLSet to change the URL of the page displayed in the browser pane in the navigation area.

Example: Customizing the Pro/ENGINEER Navigation Pane

The following sample code shows you how to customize the Pro/ENGINEER navigation pane.

```
package com.ptc.jlinkexamples;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import java.lang.Object.*;
import java.io.*;

public class pfcNavigatorPaneExamples
{
    static final String msgTxt = "jlexamples.txt";

    /*=====*\
    FUNCTION: AddPane
    PURPOSE:  Adds a new navigator pane.
    \*=====*/
    public static void AddPane() throws jxthrowable
    {
        Session session = pfcGlobal.GetProESession ();

        /*-----*\
           Get the pane name and url from the user and set the values
        \*-----*/

        session.UIDisplayMessage(msgTxt, "Enter Navigator Pane name :\" ,
                                   null);
        String name = session.UIReadStringMessage(null);
        if(name == null)
            return;

        session.UIDisplayMessage(msgTxt, "Enter path to Navigator Pane icon :\"
                                   , null);
        String icon = session.UIReadStringMessage(null);
    }
}
```

```

    session.UIDisplayMessage(msgTxt, "Enter Navigator Pane URL : " , null);
        String url = session.UIReadStringMessage(null);
    if(url == null)
        return;

    session.NavigatorPaneBrowserAdd (name, icon, url);
}

/*=====*\
FUNCTION: ChangePaneURL
PURPOSE:  Change navigator pane url.
\*=====*/
public static void ChangePaneURL() throws jxthrowable
{
    Session session = pfcGlobal.GetProESession ();

/*-----*\
    Get the pane name and new url from the user
\*-----*/

    session.UIDisplayMessage(msgTxt, "Enter Navigator Pane name : " ,
        null);
        String name = session.UIReadStringMessage(null);
    if(name == null)
        return;

    session.UIDisplayMessage(msgTxt, "Enter new Navigator Pane URL : " ,
        null);
        String url = session.UIReadStringMessage(null);
    if(url == null)
        return;

    session.NavigatorPaneBrowserURLSet (name, url);
}

/*=====*\
FUNCTION: ChangePaneIcon
PURPOSE:  Change navigator pane icon.
\*=====*/
public static void ChangePaneIcon() throws jxthrowable
{
    Session session = pfcGlobal.GetProESession ();

/*-----*\
    Get the pane name and new url from the user
\*-----*/

    session.UIDisplayMessage(msgTxt, "Enter Navigator Pane name : " ,
        null);
        String name = session.UIReadStringMessage(null);
    if(name == null)

```

```
        return;

    session.UIDisplayMessage(msgTxt, "Enter path to Navigator Pane icon :"  
        , null);
    String icon = session.UIReadStringMessage(null);
    if(icon == null)
        return;

    session.NavigatorPaneBrowserIconSet(name, icon);
}
}
```




7

Selection

This chapter describes how to use Interactive Selection in J-Link.

Topic	Page
Interactive Selection	7 - 2
Accessing Selection Data	7 - 4
Programmatic Selection	7 - 6
Selection Buffer	7 - 7

Interactive Selection

Methods Introduced:

- **pfcSession.BaseSession.Select**
- **pfcSelect.pfcSelect.SelectionOptions_Create**
- **pfcSelect.SelectionOptions.SetMaxNumSels**
- **pfcSelect.SelectionOptions.SetOptionKeywords**

The method **pfcSession.BaseSession.Select** activates the standard Pro/ENGINEER menu structure for selecting objects and returns a `pfcSelect.Selections` sequence that contains the objects the user selected. Using the *Options* argument, you can control the type of object that can be selected and the maximum number of selections.

In addition, you can pass in a `pfcSelect.Selections` sequence to the method. The returned `pfcSelect.Selections` sequence will contain the input sequence and any new objects.

The methods **pfcSelect.pfcSelect.SelectionOptions_Create** and **pfcSelect.SelectionOptions.SetOptionKeywords** take a `String` argument made up of one or more of the identifiers listed in the table below, separated by commas.

For example, to allow the selection of features and axes, the arguments would be “feature,axis”.

Pro/ENGINEER Database Item	String Identifier	ModelItemType
Datum point	point	ITEM_POINT
Datum axis	axis	ITEM_AXIS
Datum plane	datum	ITEM_FEATURE
Coordinate system datum	csys	ITEM_COORD_SYS
Feature	feature	ITEM_FEATURE
Edge (solid or datum surface)	edge	ITEM_EDGE
Edge (solid only)	sldedge	ITEM_EDGE
Edge (datum surface only)	qltedge	ITEM_EDGE
Datum curve	curve	ITEM_CURVE
Composite curve	comp_crv	ITEM_CURVE
Surface (solid or quilt)	surface	ITEM_SURFACE

Pro/ENGINEER Database Item	String Identifier	ModelItemType
Surface (solid)	sldface	ITEM_SURFACE
Surface (datum surface)	qltface	ITEM_SURFACE
Quilt	dtmqlt	ITEM_QUILT
Dimension	dimension	ITEM_DIMENSION
Reference dimension	ref_dim	ITEM_REF_DIMENSION
Integer parameter	ipar	ITEM_DIMENSION
Part	part	N/A
Part or subassembly	prt_or_asm	N/A
Assembly component model	component	N/A
Component or feature	membfeat	ITEM_FEATURE
Detail symbol	dtl_symbol	ITEM_DTL_SYM_INSTANCE
Note	any_note	ITEM_NOTE,ITEM_DTL_NOTE
Draft entity	draft_ent	ITEM_DTL_ENTITY
Table	dwg_table	ITEM_TABLE
Table cell	table_cell	ITEM_TABLE
Drawing view	dwg_view	N/A

When you specify the maximum number of selections, the argument to **pfcSelect.SelectionOptions.SetMaxNumSels** must be an Integer. The code will be as follows:

```
sel_options.setMaxNumSels (new Integer (10));
```

The default value assigned when creating a SelectionOptions object is -1, which allows any number of selections by the user.

Accessing Selection Data

Methods Introduced:

- **pfcSelect.Selection.GetSelModel**
- **pfcSelect.Selection.GetSelItem**
- **pfcSelect.Selection.GetPath**
- **pfcSelect.Selection.GetParams**
- **pfcSelect.Selection.GetTParam**
- **pfcSelect.Selection.GetPoint**
- **pfcSelect.Selection.GetDepth**
- **pfcSelect.Selection.GetSelView2D**
- **pfcSelect.Selection.GetSelTableCell**
- **pfcSelect.Selection.GetSelTableSegment**

These methods return objects and data that make up the selection object. Using the appropriate methods, you can access the following data:

- For a selected model or model item use **pfcSelect.Selection.GetSelModel** or **pfcSelect.Selection.GetSelItem**.
- For an assembly component use **pfcSelect.Selection.GetPath**.
- For UV parameters of the selection point on a surface use **pfcSelect.Selection.GetParams**.
- For the T parameter of the selection point on an edge or curve use **pfcSelect.Selection.GetTParam**.
- For a three-dimensional point object that contains the selected point use **pfcSelect.Selection.GetPoint**.
- For selection depth, in screen coordinates use **pfcSelect.Selection.GetDepth**.
- For the selected drawing view, if the selection was from a drawing, use **pfcSelect.Selection.GetSelView2D**.
- For the selected table cell, if the selection was from a table, use **pfcSelect.Selection.GetSelTableCell**.
- For the selected table segment, if the selection was from a table, use **pfcSelect.Selection.GetSelTableSegment**.

Controlling Selection Display

Methods Introduced:

- **pfcSelect.Selection.Highlight**
- **pfcSelect.Selection.UnHighlight**
- **pfcSelect.Selection.Display**

These methods cause a specific selection to be highlighted or dimmed on the screen using the color specified as an argument.

The method **pfcSelect.Selection.Highlight** highlights the selection in the current window. This highlight is the same as the one used by Pro/ENGINEER when selecting an item—it just repaints the wire-frame display in the new color. The highlight is removed if you use the **View, Repaint** command or **pfcWindow.Window.Repaint**; it is not removed if you use **pfcWindow.Window.Refresh**.

The method **pfcSelect.Selection.UnHighlight** removes the highlight.

The method **pfcSelect.Selection.Display** causes a selected object to be displayed on the screen, even if it is suppressed or hidden.

Note: This is a one-time action and the next repaint will erase this display.

Example Code: Using Interactive Selection

The following example code demonstrates how to use J-Link to allow interactive selection.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcFeature.*

public class Select {

/**
 * This example allows the user to interactively select objects.
 * This method initializes a SelectionOptions object that restricts
 * selection to features, with a specified maximum number of selections.
 */

public Selections SelectFeatures (Session session, int max)
{
    Selections      selections;
    SelectionOptions sel_options;
```

```

try {
    sel_options = pfcSelect.SelectionOptions_Create ("feature");
    sel_options.SetMaxNumSels (new Integer (max));
}
catch (jxthrowable x) {
    System.out.println ("Exception caught in initializing options"+x);
    return (null);
}
try {
    selections = session.Select (sel_options, null);
}
catch (jxthrowable x) {
    System.out.println ("Exception caught in selection");
    return (null);
}
return (selections);
}
}

```

Programmatic Selection

J-Link provides methods whereby you can make your own Selection objects, without prompting the user. These Selections are required as inputs to some methods and can also be used to highlight certain objects on the screen.

Methods and Properties Introduced:

- **pfcSelect.pfcSelect.CreateModelItemSelection**
- **pfcSelect.pfcSelect.CreateComponentSelection**
- **pfcSelect.Selection.SetSelItem**
- **pfcSelect.Selection.SetPath**
- **pfcSelect.Selection.SetParams**
- **pfcSelect.Selection.SetTParam**
- **pfcSelect.Selection.SetPoint**
- **pfcSelect.Selection.SetSelTableCell**
- **pfcSelect.Selection.SetSelView2D**

The method **pfcSelect.pfcSelect.CreateModelItemSelection** creates a selection out of any model item object. It takes a `pfcModelItem.ModelItem` and optionally a `pfcAssembly.ComponentPath` object to identify which component in an assembly the Selection Object belongs to.

The method **pfcSelect.pfcSelect.CreateComponentSelection** creates a selection out of any component in an assembly. It takes a `pfcAssembly.ComponentPath` object. For more information about `pfcAssembly.ComponentPath` objects, see the section Getting a Solid Object in the Solid chapter.

Some J-Link methods require more information to be set in the selection object. J-Link methods allow you to set the following:

The selected item using the method **pfcSelect.Selection.SetSelItem**.

The selected component path using the method **pfcSelect.Selection.SetPath**.

The selected UV parameters using the method **pfcSelect.Selection.SetParams**.

The selected T parameter (for a curve or edge), using the method **pfcSelect.Selection.SetTParam**.

The selected XYZ point using the method **pfcSelect.Selection.SetPoint**.

The selected table cell using the method **pfcSelect.Selection.SetSelTableCell**.

The selected drawing view using the method **pfcSelect.Selection.SetSelView2D**.

Selection Buffer

Introduction to Selection Buffers

Selection is the process of choosing items on which you want to perform an operation. In Pro/ENGINEER, before a feature tool is invoked, the user can select items to be used in a given tool's collectors. Collectors are like storage bins of the references of selected items. The location where preselected items are stored is called the selection buffer.

Depending on the situation, different selection buffers may be active at any one time. In Part and Assembly mode, Pro/ENGINEER offers the default selection buffer, the Edit selection buffer, and other more specialized buffers. Other Pro/ENGINEER modes offer different selection buffers.

In the default Part and Assembly buffer there are two levels at which selection is done:

- **First Level Selection**

Provides access to higher-level objects such as features or components. You can make a second level selection only after you select the higher-level object.

- **Second Level Selection**

Provides access to geometric objects such as edges and faces.

Note: First-level and second-level objects are usually incompatible in the selection buffer.

J-Link allows access to the contents of the currently active selection buffer. The available functions allow your application to:

- Get the contents of the active selection buffer.
- Remove the contents of the active selection buffer.
- Add to the contents of the active selection buffer.

Reading the Contents of the Selection Buffer

Methods Introduced:

- **pfcSession.Session.GetCurrentSelectionBuffer()**
- **pfcSelect.SelectionBuffer.GetContents()**

The method **pfcSession.Session.GetCurrentSelectionBuffer** returns the selection buffer object for the current active model in session. The selection buffer contains the items preselected by the user to be used by the selection tool and popup menus.

Use the method **pfcSelect.SelectionBuffer.GetContents** to access the contents of the current selection buffer. The method returns independent copies of the selections in the selection buffer (if the buffer is cleared, this array is still valid).

Removing the Items of the Selection Buffer

Methods Introduced:

- **pfcSelect.SelectionBuffer.RemoveSelection**
- **pfcSelect.SelectionBuffer.Clear**

Use the method **pfcSelect.SelectionBuffer.RemoveSelection** to remove a specific selection from the selection buffer. The input argument is the *IndexToRemove* specifies the index where the item was found in the call to the method **pfcSelect.SelectionBuffer.GetContents**.

Use the method **pfcSelect.SelectionBuffer.Clear** to clear the currently active selection buffer of all contents. After the buffer is cleared, all contents are lost.

Selection

Adding Items to the Selection Buffer

Method Introduced:

- **pfcSelect.SelectionBuffer.AddSelection**

Use the method **pfcSelect.SelectionBuffer.AddSelection** to add an item to the currently active selection buffer.

Note: The selected item must refer to an item that is in the current model such as its owner, component path or drawing view.

This method may fail due to any of the following reasons:

- There is no current selection buffer active.
- The selection does not refer to the current model.
- The item is not currently displayed and so cannot be added to the buffer.
- The selection cannot be added to the buffer in combination with one or more objects that are already in the buffer. For example: geometry and features cannot be selected in the default buffer at the same time.

8

Menus, Commands, and Pop-up Menus

This chapter describes the methods provided by J-Link to create and modify menus, menu buttons, commands, and pop-up menus in the Pro/ENGINEER user interface.

Topic	Page
Introduction	8 - 2
Menu Bar Definitions	8 - 2
Creating New Menus and Buttons	8 - 2
Designating Commands	8 - 12
Pop-up Menus	8 - 15

Introduction

The J-Link menu bar classes enable you to modify existing Pro/ENGINEER menu bar menus and to create new menu bar menus.

Menu Bar Definitions

- **Menu bar**—The top level horizontal bar in the Pro/ENGINEER UI, containing the main menus, such as **File**, **Edit**, and **Applications**.
- **Menu bar menu**—A menu, such as the **File** menu, or a sub-menu, such as the **Export** menu under the **File** menu.
- **Menu bar button**—A named item in a menu bar menu that is used to launch a set of instructions. An example is the **Exit** button in the **File** menu.
- **Tool bar button**—An item with a name or icon or both in a tool bar that is used to launch a set of instructions. An example is the **New File** command shown on the **File** toolbar.
- **Pop-up menu**—A menu invoked by selection of an item in the Pro/ENGINEER graphics window.
- **Command**—A procedure in Pro/ENGINEER that may be activated from a menu bar, tool bar, or pop-up menu button.

Creating New Menus and Buttons

The following methods enable you to create new menu buttons in any location on the menu bar.

Methods Introduced:

- **pfcSession.Session.UICreateCommand**
- **pfcSession.Session.UICreateMaxPriorityCommand**
- **pfcSession.Session.UIAddButton**
- **pfcSession.Session.UIAddMenu**
- **pfcCommand.UICommandActionListener.OnCommand**

The method **`pfcSession.Session.UICreateCommand`** creates a `pfcUICCommand` object that contains a `pfcCommand.UICCommandActionListener`. You should override the **`pfcCommand.UICCommandActionListener.OnCommand`** method with the code that you want to execute when the user clicks a button.

The method **`pfcSession.Session.UICreateMaxPriorityCommand`** creates a `pfcCommand.UICCommand` object having maximum command priority. The priority of the action refers to the level of precedence the added action takes over other Pro/ENGINEER actions. Maximum priority actions dismiss all other actions except asynchronous actions.

Maximum command priority should be used only in commands that open and activate a new model in a window. Create all other commands using the method **`pfcSession.Session.UICreateCommand`**.

The method **`pfcSession.Session.UIAddButton`** enables you to add your command to a menu on the menu bar. It also enables you to specify a help message that is displayed when the user moves the pointer over the button.

The **`pfcSession.Session.UIAddMenu`** method enables you to create new, top-level menus that can contain your own commands or to add submenus to existing menus.

Note: The menu file required when adding a menu or a button must have the same format as the text message file described above.

The listener method **`pfcCommand.UICCommandListener.OnCommand`** is called when the command is activated in Pro/ENGINEER by pressing a button.

Example 1: Adding a Menu Button

The following example code demonstrates how to create a new button on the Pro/ENGINEER menu bar. This method creates a button called `Input Info` on the Utilities menu and assigns the method `gatherInputs()` to activate when the button is pressed.

```
package com.ptc.jlinkexamples;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
```

```

import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcCommand.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcModelItem.*;

/*=====*\
FUNCTION : addInputButton()
PURPOSE  : An example of the creation of a new button on the Pro/E
           menu bar. This method will create a button called "Input
           info" on the utilities menu and assigns the method
           gatherInputs() to activate when the button is pressed.
           Command access check is added by CheckCommandAccess
\*=====*/
public static void addInputButton(Session session)
{
    UICommand inputCommand = null;

/*=====*\
    Add new input command
\*=====*/
    try {
        inputCommand=session.UICreateCommand("INPUT",
            new GatherInputListener (session));
    }
    catch(jxthrowable x) {
        System.out.println("Exception in UICreateCommand():"+x);
        return;
    }

/*=====*\
    Add action listener to check access to the command
\*=====*/
    try {
        inputCommand.AddActionListener(new CheckButtonCommandAccess (session));
    }
    catch(jxthrowable x) {
        System.out.println("Exception in AddActionListener():"+x);
        return;
    }

/*=====*\
    Add new button to "windows" menu
\*=====*/
    try {
        session.UIAddButton(inputCommand, "Windows", null,
            "USER Input info", "USER Gather inputs",
            "jlexamples.txt");
    }

    catch(jxthrowable x){

```

```

    System.out.println("Exception in UIAddButton():"+x);
    return;
}
}

/*=====*\
CLASS      : GatherInputListener()
PURPOSE    : Listener class which implements the added command.
\*=====*/
class GatherInputListener extends DefaultUICommandActionListener
{
    public Session session;

    public GatherInputListener(Session currentSession)
    {
        session = currentSession;
    }

    public void gatherInputs()
    {
        try
        {
            session.UIShowMessageDialog("Example button pressed" , null);
        }
        catch(jxthrowable x)
        {
            System.out.println("Exception in UIShowMessageDialog():"+x);
            return;
        }
    }

    public void OnCommand ()
    {
        gatherInputs();
    }
}

```

The corresponding message file for the example program contains two text messages. The first is used as a button name, the second as its help string.

```

USER#Input#info
Input info
#
#
USER#Gather#inputs
Gather inputs used in my J-Link program
#
#

```

Finding Pro/ENGINEER commands

This method enables you to find existing Pro/ENGINEER commands in order to modify their behavior.

Method Introduced:

- **pfcSession.Session.UIGetCommand**

The method **pfcSession.Session.UIGetCommand** returns a `pfcCommand.UICCommand` object representing an existing Pro/ENGINEER command. The method allows you to find the command ID for an existing command so that you can add an access function or bracket function to the command. You must know the name of the command in order to find its ID.

Use the trail file to find the name of an action command (not a menu button). Click the corresponding icon on the toolbar (not the button in the menu bar) and check the last entry in the trail file. For example, for the Save icon, the trail file will have the corresponding entry:

```
~ Activate 'main_dlg_cur' 'ProCmdModelSave.file'
```

The action name for the Save icon is `ProCmdModelSave`. This string can be used as input to **pfcSession.Session.UIGetCommand** to get the command ID.

You can determine a command ID string for an option without an icon by searching through the resource files located in the `<Pro/ENGINEER Loadpoint>/text/resources` directory. If you search for the menu button name, the line will contain the corresponding action command for the button.

Access Listeners for Commands

These methods allow you to apply an access listener to a command. The access listener determines whether or not the command is visible at the current time in the current session.

Methods Introduced:

- **pfcBase.ActionSource.AddActionListener**
- **pfcCommand.UICCommandAccessListener.OnCommandAccess**

Use the method **pfcBase.ActionSource.AddActionListener** to register a new **pfcCommand.UICCommandAccessListener** on any command (created either by an application or Pro/ENGINEER). This listener will be called when buttons based on the command might be shown.

The listener method

pfCommand.UICCommandAccessListener.OnCommandAccess allows you to impose an access function on a particular command. The method determines if the action or command should be available, unavailable, or hidden.

The potential return values are listed in the enumerated type `CommandAccess` and are as follows:

- **ACCESS_REMOVE**—The button is not visible and if all of the menu buttons in the containing menu possess an access function returning `ACCESS_REMOVE`, the containing menu will also be removed from the Pro/ENGINEER user interface..
- **ACCESS_INVISIBLE**—The button is not visible.
- **ACCESS_UNAVAILABLE**—The button is visible, but gray and cannot be selected.
- **ACCESS_DISALLOW**—The button shows as available, but the command will not be executed when it is chosen.
- **ACCESS_AVAILABLE**—The button is not gray and can be selected by the user. This is the default value.

Example 2: Command Access Listeners

This example code demonstrates the usage of the access listener method for a particular command. The `CommandAccessOnCommandAccess` function returns "ACCESS_UNAVAILABLE" that disables button associated with the command, if the model is not present or if it is not of type PART. Else, the function returns "ACCESS_AVAILABLE" that enables button associated with the command.

```
/*=====*\
CLASS      : CheckCommandAccess ()
PURPOSE    : This class will be used to check if access to command must
              be given.
\*=====*/
class CheckCommandAccess extends DefaultUICCommandAccessListener
{
    private Session session;

    public CheckCommandAccess (Session currentSession)
    {
        session = currentSession;
    }

    public CommandAccess OnCommandAccess (boolean
                                          AllowErrorMessages)
```

```

    {
        Model model = null;
        try
        {

/*=====*\
Get the current model
\*=====*/
            model = session.GetCurrentModel ();

/*=====*\
If model is not present or it is not of type part, return
"ACCESS_UNAVAILABLE" which disables button associated with the command
\*=====*/
            if (model == null)
            {
                return CommandAccess.ACCESS_UNAVAILABLE;
            }
            else if (model.GetType() != ModelType.MDL_PART)
            {
                return CommandAccess.ACCESS_UNAVAILABLE;
            }

/*=====*\
Else, return "ACCESS_AVAILABLE" which enables button associated with
the command
\*=====*/
            else
            {
                return CommandAccess.ACCESS_AVAILABLE;
            }

        }
        catch(jxthrowable x)
        {
            System.out.println("Exception in OnCommandAccess():"+x);
            return CommandAccess.ACCESS_UNAVAILABLE;
        }
    }
}

```

Bracket Listeners for Commands

These methods allow you to apply a bracket listener to a command. The bracket listener is called before and after the command runs, which allows your application to provide custom logic to execute whenever the command is selected.

Methods Introduced:

- **pfcBase.ActionSource.AddActionListener**
- **pfcCommand.UICommandBracketListener.OnBeforeCommand**
- **pfcCommand.UICommandBracketListener.OnAfterCommand**

Use the method **pfcBase.ActionSource.AddActionListener** to register a new **pfcCommand.UICommandBracketListener** on any command (created either by an application or Pro/ENGINEER). This listener will be called when the command is selected by the user.

The listener methods

pfcCommand.UICommandBracketListener.OnBeforeCommand and

pfcCommand.UICommandBracketListener.OnAfterCommand allow the creation of functions that will be called immediately before and after execution of a given command. These methods are used to add the business logic to the start or end (or both) of an existing Pro/ENGINEER command.

The method

pfcCommand.UICommandBracketListener.OnBeforeCommand could also be used to cancel an upcoming command. To do this, throw a **pfcExceptions.XCancelProEAction** exception from the body of the listener method using **pfcExceptions.XCancelProEAction.Throw**.

Example 3: Bracket Listeners

The following example code demonstrates the usage of the bracket listener methods that are called before and after when the user tries to rename the model. If the model contains a certain parameter, the rename attempt will be aborted by this listener.

```

/*=====*\
FUNCTION : addRenameCheck()
PURPOSE  : An example of command bracket listener which prevents model
           rename when a specified parameter is present.
/*=====*/
public static void addRenameCheck(Session session , String paramName)
{
UICommand command = null;

try
{
/*=====*\
Get the command which is invoked by pressing "Rename" button
/*=====*/

```

```

command = session.UIGetCommand("ProCmdModelRename");

/*=====*\
If the command is not null, add action listener to check access to the
command
\*=====*/
if (command != null)
{
command.AddActionListener(new RenameBracketListener(session ,
paramName));
}
}
catch(jxthrowable x)
{
System.out.println("Exception in addRenameCheck():"+x);
return;
}
}
}

/*=====*\
CLASS      : RenameBracketListener()
PURPOSE   : This listener class will be used to check if model rename
should be allowed depending if parameter is present.
\*=====*/
class RenameBracketListener extends DefaultUICommandBracketListener
{
public Session session;
String name;

public RenameBracketListener (Session currentSession , String
paramName)
{
session = currentSession;
name = paramName;
}

/*=====*\
FUNCTION  : OnAfterCommand()
PURPOSE  : Function called after rename execution is complete.
\*=====*/
public void OnAfterCommand()
{
}

/*=====*\
FUNCTION  : OnBeforeCommand()
PURPOSE  : Function called when rename button is pressed.
\*=====*/

```

```

\*=====*/
    public void OnBeforeCommand() throws com.ptc.cipjava.jxthrowable
    {
Model model = null;
Parameter param = null;
boolean cancelRename ;

try
{
/*=====*\
    Get the current model
\*=====*/
    model = session.GetCurrentModel ();

if (model == null)
{
return;
}

/*=====*\
    Get the specified parameter
\*=====*/
param = model.GetParam(name);

/*=====*\
    If parameter is present, rename should not be allowed
\*=====*/
if (param != null)
{
cancelRename = true;
}
else
{
cancelRename = false;
}
}
catch(jxthrowable x)
{
    System.out.println("Exception in OnBeforeCommand():"+x);
return;
}

if (cancelRename == true)
{
XCancelProEAction.Throw();
}
}
}

```

Designating Commands

Using J-Link you can designate Pro/ENGINEER commands to be available to be added to any Pro/ENGINEER toolbar.

To add a command to the toolbar, you must:

1. Define or add the command to be initiated on clicking the icon in the J-Link application.
2. Optionally designate an icon button to be used with the command.
3. Designate the command to appear in the Screen Customization dialog box of Pro/ENGINEER.
4. Finally, enter the **Screen Customization** dialog, and manually add the designated command to the window. Save the configuration in Pro/ENGINEER so that changes to the toolbar appear when a new session of Pro/ENGINEER is started.

Command Icons

Method Introduced:

- **pfcCommand.UICCommand.SetIcon**

The method **pfcCommand.UICCommand.SetIcon** allows you to designate an icon to be used with the command you created. The method adds the icon to the Pro/ENGINEER command. Specify the name of the icon file, including the extension as the input argument for this method. A valid format for the icon file is the PTC-proprietary format used by Pro/ENGINEER *.BIF* or a standard *.GIF*. The Pro/ENGINEER toolbar button is replaced with the image of the image.

Note: While specifying the name of the icon file, do not specify the full path to the icon names.

The default search paths for finding the icons are:

- <ProENGINEER loadpoint>/text/resource
- <Application text dir>/resource
- <Apppplication text dir>/ (language)/resource

The location of the application text directory is specified in the registry file.

Toolbar commands that do not have an icon assigned to them display the button label.

You may also use this method to assign a small icon to a menu button on the menubar. The icon appears to the left of the button label.

Before using the method **pfcCommand.UICommand.SetIcon**, you must place the command in a menu using the method **pfcSession.Session.UIAddButton**.

Designating the Command

Method Introduced:

- **pfcCommand.UICommand.Designate**

This method allows you designate the command as available in the Screen Customization dialog box of Pro/ENGINEER. After a J-Link application has used the method **pfcCommand.UICommand.Designate** on a command, you can interactively drag the toolbar button that you associate with the command, on to the Pro/ENGINEER toolbar. If this method is not called, the toolbar button will not be visible in the Screen Customization dialog box of Pro/ENGINEER.

The arguments to this method are:

- *Label*—The message string that refers to the icon label. This label (stored in the message file) identifies the text seen when the button is displayed. If the command is not assigned an icon, the button label string appears on the toolbar button by default.
- *Help*—The one-line Help for the icon. This label (stored in the message file) identifies the help line seen when the mouse moves over the icon.
- *Description*—The message appears in the Screen Customization dialog and also when "Description" is clicked in Pro/ENGINEER.
- *MessageFile*—The message file name. All the labels including the one-line Help labels must be present in the message file.

Note: This file must be in the directory `<text_path>/text` or `<text_path>/text/<language>`.

Before using the method **pfcCommand.UICommand.Designate**, you must place the command in a menu using the method **pfcSession.Session.UIAddButton**.

Placing the Toolbar Button

Once the toolbar button has been created using the functions discussed above, place the toolbar button on the Pro/ENGINEER toolbar. Click **Tools > Customize Screen**. The designated buttons will be stored under the category “Foreign Applications”. Drag the toolbar button on to the Pro/ENGINEER toolbar as shown in the following figure. Save the window configuration settings in the *config.win* file so that the settings are loaded when a new session of Pro/ENGINEER is launched. For more information, see the Pro/ENGINEER menus portion of the Pro/ENGINEER help.

Figure 8-1: The Customize Screen With The Icons To be Designated




Figure 8-2: The Pro/ENGINEER Toolbar With The Designated Icons



Pop-up Menu

Pro/ENGINEER provides shortcut menus that contain frequently used commands appropriate to the currently selected items. You can access a shortcut menu by right-clicking a selected item. Shortcut menus are accessible in:

- Graphics window
- Model Tree
- Some dialog boxes
- Any area where you can perform an object-action operation by selecting an item and choosing a command to perform on the selected item.

The methods described in this section allow you to add menus to a graphics window pop-up menu.

Adding a Pop-up Menu to the Graphics Window

You can activate different pop-up menus during a given session of Pro/ENGINEER. Every time the Pro/ENGINEER context changes when you open a different model type, enter different tools or special modes such as **Edit**, a different pop-up menu is created. When Pro/ENGINEER moves to the next context, the pop-up menu may be destroyed.

As a result of this, J-Link applications must attach a button to the pop-up menu during initialization of the pop-up menu. The J-Link application is notified each time a particular pop-up menu is created, which then allows the user to add to the pop-up menu.

Use the following procedure to add items to pop-up menus in the graphics window:

1. Obtain the name of the existing pop-up menus to which you want to add a new menu using the trail file.
2. Create commands for the new pop-up menu items.
3. Implement access listeners to provide visibility information for the items.
4. Add an action listener to the session to listen for pop-up menu initialization.
5. In the listener method, if the pop-up menu is the correct menu to which you wish to add the button, then add it.

The following sections describe each of these steps in detail. You can add push buttons and cascade menus to the pop-up menus. You can add pop-up menu items only in the active window. You cannot use this procedure to remove items from existing menus.

Using the Trail File to Determine Existing Pop-up Menu Names

The trail file in Pro/ENGINEER contains a comment that identifies the name of the pop-up menu if the configuration option, `auxapp_popup_menu_info` is set to `yes`.

For example, the pop-up menu, **Edit Properties**, has the following comment in the trail file:

```
~ Close `rmb_popup` `PopupMenu`
~ Activate `rmb_popup` `EditProperties`
!Command ProCmdEditPropertiesDtm was pushed from the
software.
!Item was selected from popup menu 'popup_mnu_edit'
```

Listening for Pop-up Menu Initialization

Methods Introduced:

- `pfcBase.ActionSource.AddActionListener`
- `pfcUI.PopupmenuListener.OnPopupmenuCreate`

Use the method `pfcBase.ActionSource.AddActionListener` to register a new `pfcUI.PopupmenuListener` to the session. This listener will be called when pop-up menus are initialized.

The method **pfcUI.PopupmenuListener.OnPopupmenuCreate** is called after the pop-up menu is created internally in Pro/ENGINEER and may be used to assign application-owned buttons to the pop-up menu.

Accessing the Pop-up Menus

The method described in this section provides the name of the pop-up menus used to access these menus while using other methods.

Method Introduced:

- **pfcUI.Popupmenu.GetName**

The method **pfcUI.Popupmenu.GetName()** returns the name of the pop-up menu.

Adding Content to the Pop-up Menus

Methods Introduced:

- **pfcUI.Popupmenu.AddButton**
- **pfcUI.Popupmenu.AddMenu**

Use **pfcUI.Popupmenu.AddButton** to add a new item to a pop-up menu. The input arguments are:

- *Command*—Specifies the command associated with the pop-up menu.
- *Options* – A `pfcUI.PopupmenuOptions` object containing other options for the method. The options that may be included are:
 - *PositionIndex*—Specifies the position in the pop-up menu at which to add the menu button. Pass null to add the button to the bottom of the menu. Use the method **pfcUI.PopupmenuOptions.SetPositionIndex** to set this option.
 - *Name*—Specifies the name of the added button. The button name is placed in the trail file when the user selects the menu button. Use the method **pfcUI.PopupmenuOptions.SetName** to set this option.
 - *SetLabel*—Specifies the button label. This label identifies the text displayed when the button is displayed. Use the method **pfcUI.PopupmenuOptions.SetLabel** to set this option.

- **Helptext**—Specifies the help message associated with the button. Use the method **pfcUI.PopupmenuOptions.SetHelptext** to set this option.

Use the method **pfcUI.Popupmenu.AddMenu** to add a new cascade menu to an existing pop-up menu.

The argument for this method is a **pfcUI.PopupmenuOptions** object, whose members have the same purpose as described for newly added buttons. This method returns a new **pfcUI.Popupmenu** object to which you may add new buttons.

Example 4: Creating a Pop-up Menu

This example code demonstrates the usage of UI functions to add a new model tree pop-up menu.

```
package com.ptc.jlinkexamples;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcCommand.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcUI.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcComponentFeat.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcSolid.*;

public class pfcPopupExamples
{
    /*=====*\
    FUNCTION: addMenus
    PURPOSE: This function demonstrates the usage of UI functions to add a
             new button to ProE Graphics Window and model tree popup menu.
    \*=====*/
    public static void addMenus(Session session)
    {
        UICommand inputCommand = null;

        try
        {
```

```

/*-----*\
    Add new input command
\*-----*/
inputCommand=session.UICreateCommand("HIGHLIGHT",
    new AssemblyFunction (session));

/*-----*\
    Add action listener to check access to the command
\*-----*/
inputCommand.AddActionListener(new CheckCommandAccess (session));

/*-----*\
    Add new button to action menu
\*-----*/
session.UIAddButton(inputCommand, "ActionMenu", null,
    "USER Highlight Constraint", "USER Highlight Constraint Help",
        "jlexamples.txt");

/*-----*\
    Add action listener which will execute when new popup menus
    are created
\*-----*/
session.AddActionListener(new CreatePopupButton(session) );

}

catch(jxthrowable x)
{
    System.out.println("Exception in addMenus():"+x);
    return;
}
}

/*=====*\
CLASS: AssemblyFunction
PURPOSE: This is the Listener class to implement Highlight command.
\*=====*/
class AssemblyFunction extends DefaultUICommandActionListener
{
    private Session session;

    public AssemblyFunction(Session currentSession)
    {
session = currentSession;
    }

    public void OnCommand ()
        throws com.ptc.cipjava.jxthrowable
    {
highlightConstraints();
}
}

```

```

    }

    public void highlightConstraints()
    throws com.ptc.cipjava.jxthrowable
    {

        Selections selections;
        SelectionBuffer selectionBuffer;
        SelectionOptions options ;
        ModelItem item ;
        Feature feature ;

        ComponentPath modelPath;
        ComponentPath parentPath;
        intseq parentIds;
        Solid modelParent;
        int modelId;

        /*-----*\
        Get selected components
        \*-----*/
        selectionBuffer = session.GetCurrentSelectionBuffer();
        selections = selectionBuffer.GetContents();

        if (selections == null)
        {
            options = pfcSelect.SelectionOptions_Create ("membfeat");
            options.SetMaxNumSels (new Integer (1));
            selections = session.Select (options, null);

            if (selections == null || selections.getarraysize () == 0)
                return;

        }

        /*-----*\
        Get the model item from the selection
        \*-----*/
        item = selections.get(0).GetSelItem();

        /*-----*\
        If item is null, get the model item from the selection model
        \*-----*/
        if (item == null)
        {
            /*-----*\
            Get the component path from the selection model
            \*-----*/
            modelPath = selections.get(0).GetPath();

```

```

modelId =
modelPath.GetComponentIds().get(modelPath.GetComponentIds().getarraysize(
) - 1);

/*-----*\
    Get the parent model of the selection model
\*-----*/
parentIds = modelPath.GetComponentIds();
parentIds.removeRange(parentIds.getarraysize() - 1 ,
parentIds.getarraysize());

if (parentIds.getarraysize() == 0)
{
modelParent = modelPath.GetRoot();
}
else
{
parentPath = pfcAssembly.CreateComponentPath(modelPath.GetRoot(),
parentIds);
modelParent = parentPath.GetLeaf();
}

/*-----*\
    Get the selection model as model item from the parent model
\*-----*/
item = ((ModelItemOwner)modelParent).GetItemById
(ModelItemType.ITEM_FEATURE , modelId);

if (item == null)
return;

}

feature = (Feature)item;

if (feature.GetFeatType () != FeatureType.FEATTYPE_COMPONENT)
return;

ComponentFeat asmcomp = (ComponentFeat) item;

ComponentConstraints constrs = asmcomp.GetConstraints ();

if (constrs == null || constrs.getarraysize() == 0)
return;

for (int i = 0; i < constrs.getarraysize(); i++)
{
/*-----*\
    Highlight the assembly reference geometry
\*-----*/

```

```

ComponentConstraint c = constrs.get (i);

Selection asmRef = c.GetAssemblyReference ();

if (asmRef != null)
    asmRef.Highlight (StdColor.COLOR_ERROR);

/*-----*\
    Highlight the component reference geometry
\*-----*/
Selection compRef = c.GetComponentReference ();

if (compRef != null)
    compRef.Highlight (StdColor.COLOR_WARNING);

/*-----*\
    Prepare and display the message text.
\*-----*/
Double offset = c.GetOffset ();
String offsetString = "";
if (offset != null)
    offsetString = ", offset of "+offset;

ComponentConstraintType cType = c.GetType ();
String cTypeString = constraintTypeToString (cType);

stringseq texts = stringseq.create ();
texts.set (0, new String (""+(i+1)));
texts.set (1, new String (""+constrs.getarraysize()));
texts.set (2, cTypeString);
texts.set (3, offsetString);

session.UIDisplayMessage ("jlexamples.txt",
    "JLEX Showing constraint %0s of %1s %2s%3s. Hit <CR> to continue.",
    texts);
session.UIReadStringMessage (null);

/*-----*\
    Clean up the UI for the next constraint
\*-----*/
if (asmRef != null)
{
asmRef.UnHighlight ();
}

if (compRef != null)
{
compRef.UnHighlight ();
}
}

```



```

    }

/*=====*\
FUNCTION: constraintTypeToString
PURPOSE: Utility to convert the constraint type to a string for printing
\*=====*/
    private static String constraintTypeToString (ComponentConstraintType
type)
    {
switch (type.getValue())
    {
    case ComponentConstraintType._ASM_CONSTRAINT_MATE:
return ("Mate");
    case ComponentConstraintType._ASM_CONSTRAINT_MATE_OFF:
return ("Mate Offset");
    case ComponentConstraintType._ASM_CONSTRAINT_ALIGN:
return ("Align");
    case ComponentConstraintType._ASM_CONSTRAINT_ALIGN_OFF:
return ("Align Offset");
    case ComponentConstraintType._ASM_CONSTRAINT_INSERT:
return ("Insert");
    case ComponentConstraintType._ASM_CONSTRAINT_ORIENT:
return ("Orient");
    case ComponentConstraintType._ASM_CONSTRAINT_CSYS:
return ("Csys");
    case ComponentConstraintType._ASM_CONSTRAINT_TANGENT:
return ("Tangent");
    case ComponentConstraintType._ASM_CONSTRAINT_PNT_ON_SRF:
return ("Point on Surf");
    case ComponentConstraintType._ASM_CONSTRAINT_EDGE_ON_SRF:
return ("Edge on Surf");
    case ComponentConstraintType._ASM_CONSTRAINT_DEF_PLACEMENT:
return ("Default");
    case ComponentConstraintType._ASM_CONSTRAINT_SUBSTITUTE:
return ("Substitute");
    case ComponentConstraintType._ASM_CONSTRAINT_PNT_ON_LINE:
return ("Point on Line");
    case ComponentConstraintType._ASM_CONSTRAINT_FIX:
return ("Fix");
    case ComponentConstraintType._ASM_CONSTRAINT_AUTO:
return ("Auto");
    default:
return ("Unrecognized Type");
    }
    }
}

/*=====*\
CLASS: CreatePopupButton
PURPOSE: Listener class to create Popup menu button when the menu is
    created.

```

```

\*=====*/
class CreatePopupButton extends DefaultPopupMenuListener
{
private Session session;

    public CreatePopupButton(Session currentSession)
    {
        session = currentSession;
    }

public void OnPopupMenuCreate (PopupMenu menu)
    throws com.ptc.cipjava.jxthrowable
    {
    UICommand command = null;
    PopupmenuOptions options;

/*-----*\
    If the created popup menu is "Sel Obj Menu", then get the command for
    highlight constraint added previously and add button
/*-----*\
    if (menu.GetName().equals("Sel Obj Menu"))
    {
    command = session.UIGetCommand("HIGHLIGHT");
    if (command != null)
    {
    options = pfcUI.PopupmenuOptions_Create(new String
("HIGHLIGHT_CONSTRAINTS"));
    options.SetHelptext("Highlight Assembly Constraints");
    options.SetLabel("Highlight Constraint");

    menu.AddButton(command, options);
    }
    }
    }

/*=====*\
CLASS: CreatePopupButton
PURPOSE: This listener class checks if command is accessible to the user.
\*=====*/
class CheckCommandAccess extends DefaultUICommandAccessListener
{
private Session session;

    public CheckCommandAccess (Session currentSession)
    {
session = currentSession;
    }

    public CommandAccessOnCommandAccess (boolean AllowErrorMessages)
    {

```

```

Model model = null;
Selections selections;
    SelectionBuffer selectionBuffer;

try
{
/*-----*\
    Get the current model
\*-----*/
    model = session.GetCurrentModel ();

/*-----*\
    If model is not present or it is not of type assembly, return
    "ACCESS_UNAVAILABLE" which disables button associated with the command
\*-----*/
if (model == null)
{
return CommandAccess.ACCESS_UNAVAILABLE;
}
else if (model.GetType() != ModelType.MDL_ASSEMBLY)
{
return CommandAccess.ACCESS_UNAVAILABLE;
}

/*-----*\
    Get the current selection
\*-----*/
selectionBuffer = session.GetCurrentSelectionBuffer();
selections = selectionBuffer.GetContents();

/*-----*\
    If nothing has been selected or more than one item has been selected,
    return "ACCESS_UNAVAILABLE" which disables button associated with the
    command
\*-----*/
if ((selections == null) || (selections.getarraysize() > 1))
{
return CommandAccess.ACCESS_UNAVAILABLE;
}

/*-----*\
    Else return "ACCESS_AVAILABLE" which enables button associated with
the
    command
\*-----*/
return CommandAccess.ACCESS_AVAILABLE;

}
catch(jxthrowable x)
{
    System.out.println("Exception in OnCommandAccess():"+x);
}


```

```
return CommandAccess.ACCESS_UNAVAILABLE;
}

}
}
```

The corresponding message file for the example program contains two text messages. The first is used as the pop-menu button name, the second as its help string.

```
USER Highlight Constraint
Highlight Constraint
#
#
USER Highlight Constraint Help
Highlight Assembly Constraints
#
#
```



Models

This chapter describes how to program on the model level using J-Link.

Topic	Page
Overview of Model Objects	9 - 2
Getting a Model Object	9 - 2
Model Descriptors	9 - 3
Retrieving Models	9 - 4
Model Information	9 - 6
Model Operations	9 - 9
Running ModelCHECK	9 - 11

Overview of Model Objects

Models can be any Pro/ENGINEER file type, including parts, assemblies, drawings, sections, and layouts. The classes and methods in the package `com.ptc.pfc.pfcModel` provide generic access to models, regardless of their type. The available methods enable you to do the following:

- Access information about a model.
- Open, copy, rename, and save a model.

Getting a Model Object

Methods Introduced:

- `pfcFamily.FamilyTableRow.CreateInstance`
- `pfcSelect.Selection.GetSelModel`
- `pfcSession.BaseSession.GetModel`
- `pfcSession.BaseSession.GetCurrentModel`
- `pfcSession.BaseSession.GetActiveModel`
- `pfcSession.BaseSession.ListModels`
- `pfcSession.BaseSession.GetByRelationId`
- `pfcWindow.Window.GetModel`

These methods get a model object that is already in session.

The method `pfcSelect.Selection.GetSelModel` returns the model that was interactively selected.

The method `pfcSession.BaseSession.GetModel` returns a model based on its name and type, whereas `pfcSession.BaseSession.GetByRelationId` returns a model in an assembly that has the specified integer identifier.

The method `pfcSession.BaseSession.GetCurrentModel` returns the current Pro/ENGINEER model.

The method `pfcSession.BaseSession.GetActiveModel` returns the active Pro/ENGINEER model.

Use the method `pfcSession.BaseSession.ListModels` to return a sequence of all the models in session.

For more methods that return solid models, refer to the chapter Solid.

Model Descriptors

Methods Introduced:

- **pfcModel.pfcModel.ModelDescriptor.Create**
- **pfcModel.pfcModel.ModelDescriptor.CreateFromFileName**
- **pfcModel.ModelDescriptor.SetGenericName**
- **pfcModel.ModelDescriptor.SetInstanceName**
- **pfcModel.ModelDescriptor.SetType**
- **pfcModel.ModelDescriptor.SetHost**
- **pfcModel.ModelDescriptor.SetDevice**
- **pfcModel.ModelDescriptor.SetPath**
- **pfcModel.ModelDescriptor.SetFileVersion**
- **pfcModel.ModelDescriptor.GetFullName**
- **pfcModel.Model.GetFullName**

Model descriptors are data objects used to describe a model file and its location in the system. The methods in the model descriptor enable you to set specific information that enables Pro/ENGINEER to find the specific model you want.

The static utility method **pfcModel.pfcModel.ModelDescriptor.Create** allows you to specify as data to be entered a model type, an instance name, and a generic name. The model descriptor constructs the full name of the model as a string, as follows:

```
String FullName = InstanceName+"<" + GenericName+">";
                    // As long as the
                    // generic name is
                    // not an empty
                    // string ("")
```

If you want to load a model that is not a family table instance, pass an empty string as the generic name argument so that the full name of the model is constructed correctly. If the model is a family table interface, you should specify both the instance and generic names.

Note: You are allowed to set other fields in the model descriptor object, but they may be ignored by some methods.

The static utility method **pfcModel.pfcModel.ModelDescriptor_CreateFromFileName** allows you to create a new model descriptor from a given a file name. The file name is a string in the form "`<name>.<extension>`".

Retrieving Models

Methods Introduced:

- **pfcSession.BaseSession.RetrieveModel**
- **pfcSession.BaseSession.RetrieveModelWithOpts**
- **pfcSession.BaseSession.OpenFile**
- **pfcSolid.Solid.HasRetrievalErrors**

These methods cause Pro/ENGINEER to retrieve the model that corresponds to the *ModelDescriptor* argument.

The method **pfcSession.BaseSession.RetrieveModel** retrieves the specified model into the Pro/ENGINEER session given its model descriptor from a standard directory. But this function does not create a window for it, nor does it display the model anywhere.

The method **pfcSession.BaseSession.RetrieveModelWithOpts** retrieves the specified model into the Pro/ENGINEER session based on the path specified by the model descriptor. The path can be a disk path, a workspace path, or a commonspace path. The *Opts* argument (given by the `pfcSession.RetrieveModelOptions` object) provides the user with the option to specify simplified representations.

The method **pfcSession.BaseSession.OpenFile** brings the model into memory, opens a new window for it (or uses the base window, if it is empty), and displays the model.

Note: **pfcSession.BaseSession.OpenFile** actually returns a handle to the window it has created.

To get a handle to the model you need, use the method **pfcWindow.Window.GetModel**.

The method **pfcSolid.Solid.HasRetrievalErrors** returns a true value if the features in the solid model were suppressed during the **RetrieveModel** or **OpenFile** operations. This method must be called immediately after the **pfcSession.BaseSession.RetrieveModel** method or an equivalent retrieval method.

Example Code: Retrieving a Model

The following example code demonstrates how to retrieve a model.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;

public class pfcModelExamples {

/**
 * An example of retrieving a model using a model descriptor object.
 * This method loads the model identified by modelname and type from a
 * standard directory location.
 */

public Model retrieveModelFromStandardDir (Session session,
String modelname, ModelType type)
{
String          stdpath = "/home/ptc/models/standard";
ModelDescriptor descr;
Model          model;
try {
descr = pfcModel.ModelDescriptor_Create (type, modelname, null);
descr.SetPath (stdpath);
}
catch (jxthrowable x) {
System.out.println ("Error in initializing model descriptor"+x);
return (null);
}
try {
model = session.RetrieveModel (descr);
}
catch (jxthrowable x) {
printMsg ("Exception in retrieving model:"+x);
return (null);
}
return (model);
}
public static void printMsg (String str)
{
System.out.println (str);
}
}
```

Model Information

Methods Introduced:

- **pfcModel.Model.GetFileName**
- **pfcModel.Model.GetCommonName**
- **pfcModel.Model.IsCommonNameModifiable**
- **pfcModel.Model.GetFullName**
- **pfcModel.Model.GetGenericName**
- **pfcModel.Model.GetInstanceName**
- **pfcModel.Model.GetOrigin**
- **pfcModel.Model.GetRelationId**
- **pfcModel.Model.GetDescr**
- **pfcModel.Model.GetType**
- **pfcModel.Model.GetIsModified**
- **pfcModel.Model.GetVersion**
- **pfcModel.Model.GetRevision**
- **pfcModel.Model.GetBranch**
- **pfcModel.Model.GetReleaseLevel**
- **pfcModel.Model.GetVersionStamp**
- **pfcModel.Model.ListDependencies**
- **pfcModel.Model.ListDeclaredModels**
- **pfcModel.Model.CheckIsModifiable**
- **pfcModel.Model.CheckIsSaveAllowed**

The method **pfcModel.Model.GetFileName** retrieves the model file name in the "name"."type" format.

The method **pfcModel.Model.GetCommonName** retrieves the common name for the model. This name is displayed for the model in Windchill PDMLink.

Use the method

pfcModel.Model.GetIsCommonNameModifiable to identify if the common name of the model can be modified. You can modify the name for models that are not yet owned by Windchill PDMLink, or in certain situations if the configuration option

`let_proe_rename_pdm_objects` is set to yes.

The method **pfcModel.Model.GetFullName** retrieves the full name of the model in the instance <generic> format.

The method **pfcModel.Model.GetGenericName** retrieves the name of the generic model. If the model is not an instance, this name must be NULL or an empty string.

The method **pfcModel.Model.GetInstanceName** retrieves the name of the model. If the model is an instance, this method retrieves the instance name.

The method **pfcModel.Model.GetOrigin** returns the complete path to the file from which the model was opened. This path can be a location on disk from a Windchill workspace, or from a downloaded URL.

The method **pfcModel.Model.GetRelationId** retrieves the relation identifier of the specified model. It can be NULL.

The method **pfcModel.Model.GetDescr** returns the descriptor for the specified model. Model descriptors can be used to represent models not currently in session.

Note: From Pro/ENGINEER Wildfire 4.0 onwards, the methods **pfcModel.Model.GetFullName**, **pfcModel.Model.GetGenericName**, and **pfcModel.Model.GetDescr** throw an exception `pfcExceptions.XtoolkitCantOpen` if called on a model instance whose immediate generic is not in session. Handle this exception and typecast the model as `pfcSolid.Solid`, which in turn can be typecast as `pfcFamily.FamilyMember`, and use the method **pfcFamily.FamilyMember.GetImmediateGenericInfo** to get the model descriptor of the immediate generic model. The model descriptor can be used to derive the full name or generic name of the model. If you wish to switch off this behavior and continue to run legacy applications in the pre-Wildfire 4.0 mode, set the configuration option `retrieve_instance_dependencies` to `"instance_and_generic_deps"`.

The method **pfcModel.Model.GetType** returns the type of model in the form of the **pfcModel.ModelType** object. The types of models are as follows:

- MDL_ASSEMBLY—Specifies an assembly.
- MDL_PART—Specifies a part.
- MDL_DRAWING—Specifies a drawing.
- MDL_2D_SECTION—Specifies a 2D section.
- MDL_LAYOUT—Specifies a layout.
- MDL_DWG_FORMAT—Specifies a drawing format.
- MDL_MFG—Specifies a manufacturing model.
- MDL_REPORT—Specifies a report.
- MDL_MARKUP—Specifies a drawing markup.
- MDL_DIAGRAM—Specifies a diagram

The method **pfcModel.Model.GetIsModified** identifies whether the model has been modified since it was last saved.

The method **pfcModel.Model.GetVersion** returns the version of the specified model from the PDM system. It can be NULL, if not set.

The method **pfcModel.Model.GetRevision** returns the revision number of the specified model from the PDM system. It can be NULL, if not set.

The method **pfcModel.Model.GetBranch** returns the branch of the specified model from the PDM system. It can be NULL, if not set.

The method **pfcModel.Model.GetReleaseLevel** returns the release level of the specified model from the PDM system. It can be NULL, if not set.

The method **pfcModel.Model.GetVersionStamp** returns the version stamp of the specified model. The version stamp is a Pro/ENGINEER specific identifier that changes with each change made to the model.

The method **pfcModel.Model.ListDependencies** returns a list of the first-level dependencies for the specified model in the Pro/ENGINEER workspace in the form of the **pfcModel.Dependencies** object.

The method **pfcModel.Model.ListDeclaredModels** returns a list of all the first-level objects declared for the specified model.

The method **pfcModel.Model.CheckIsModifiable** identifies if a given model can be modified without checking for any subordinate models. This method takes a boolean argument *ShowUI* that determines whether the Pro/ENGINEER conflict resolution dialog box should be displayed to resolve conflicts, if detected. If this argument is false, then the conflict resolution dialog box is not displayed, and the model can be modified only if there are no conflicts that cannot be overridden, or are resolved by default resolution actions. For a generic model, if *ShowUI* is true, then all instances of the model are also checked.

The method **pfcModel.Model.CheckIsSaveAllowed** identifies if a given model can be saved along with all of its subordinate models. The subordinate models can be saved based on their modification status and the value of the configuration option *save_objects*. This method also checks the current user interface context to identify if it is currently safe to save the model. Thus, calling this method at different times might return different results. This method takes a boolean argument *ShowUI*. Refer to the previous method for more information on this argument.

Model Operations

Methods Introduced:

- **pfcModel.Model.Backup**
- **pfcModel.Model.Copy**
- **pfcModel.Model.CopyAndRetrieve**
- **pfcModel.Model.Rename**
- **pfcModel.Model.Save**
- **pfcModel.Model.Erase**
- **pfcModel.Model.EraseWithDependencies**
- **pfcModel.Model.Delete**
- **pfcModel.Model.Display**
- **pfcModel.Model.SetCommonName**

These model operations duplicate most of the commands available in the Pro/ENGINEER File menu.

The method **pfcModel.Model.Backup** makes a backup of an object in memory to a disk in a specified directory.

The method **pfcModel.Model.Copy** copies the specified model to another file.

The method **pfcModel.Model.CopyAndRetrieve** copies the model to another name, and retrieves that new model into session.

The method **pfcModel.Model.Rename** renames a specified model.

The method **pfcModel.Model.Save** stores the specified model to a disk.

The method **pfcModel.Model.Erase** erases the specified model from the session. Models used by other models cannot be erased until the models dependent upon them are erased.

The method **pfcModel.Model.EraseWithDependencies** erases the specified model from the session and all the models on which the specified model depends from disk, if the dependencies are not needed by other items in session.

The method **pfcModel.Model.Delete** removes the specified model from memory and disk.

The method **pfcModel.Model.Display** displays the specified model. You must call this method if you create a new window for a model because the model will not be displayed in the window until you call **pfcModel.Model.Display**.

The method **pfcModel.Model.SetCommonName** modifies the common name of the specified model. You can modify this name for models that are not yet owned by Windchill PDMLink, or in certain situations if the configuration option

`let_proe_rename_pdm_objects` is set to yes.

Running ModelCHECK

ModelCHECK is an integrated application that runs transparently within Pro/ENGINEER. ModelCHECK uses a configurable list of company design standards and best modeling practices. You can configure ModelCHECK to run interactively or automatically when you regenerate or save a model.

Methods Introduced:

- **pfcSession.BaseSession.ExecuteModelCheck**
- **pfcModelCheck.pfcModelCheck.ModelCheckInstructions_Create**
- **pfcModelCheck.ModelCheckInstructions.SetConfigDir**
- **pfcModelCheck.ModelCheckInstructions.SetMode**
- **pfcModelCheck.ModelCheckInstructions.SetOutputDir**
- **pfcModelCheck.ModelCheckInstructions.SetShowInBrowser**
- **pfcModelCheck.ModelCheckResults.GetNumberOfErrors**
- **pfcModelCheck.ModelCheckResults.GetNumberOfWarnings**
- **pfcModelCheck.ModelCheckResults.GetWasModelSaved**

You can run ModelCHECK from an external application using the method **pfcSession.BaseSession.ExecuteModelCheck**. This method takes the model *Model* on which you want to run ModelCHECK and instructions in the form of the object **ModelCheckInstructions** as its input parameters. This object contains the following parameters:

- *ConfigDir*—Specifies the location of the configuration files. If this parameter is set to NULL, the default ModelCHECK configuration files are used.
- *Mode*—Specifies the mode in which you want to run ModelCHECK. The modes are:
 - MODELCHECK_GRAPHICS—Interactive mode
 - MODELCHECK_NO_GRAPHICS—Batch mode
- *OutputDir*—Specifies the location for the reports. If you set this parameter to NULL, the default ModelCHECK directory, as per *config_init.mc*, will be used.
- *ShowInBrowser*—Specifies if the results report should be displayed in the Web browser.

The method

pfcModelCheck.pfcModelCheck.ModelCheckInstructions.Create creates the **ModelCheckInstructions** object containing the ModelCHECK instructions described above.

Use the methods

pfcModelCheck.ModelCheckInstructions.SetConfigDir,
pfcModelCheck.ModelCheckInstructions.SetMode,
pfcModelCheck.ModelCheckInstructions.SetOutputDir, and
pfcModelCheck.ModelCheckInstructions.SetShowInBrowser
to modify the ModelCHECK instructions.

The method **pfcSession.BaseSession.ExecuteModelCheck** returns the results of the ModelCHECK run in the form of the **ModelCheckResults** object. This object contains the following parameters:

- *NumberOfErrors*—Specifies the number of errors detected.
- *NumberOfWarnings*—Specifies the number of warnings found.
- *WasModelSaved*—Specifies whether the model is saved with updates.

Use the

methods **pfcModelCheck.ModelCheckResults.GetNumberOfErrors**,
pfcModelCheck.ModelCheckResults.GetNumberOfWarnings,
and **pfcModelCheck.ModelCheckResults.GetWasModelSaved**
to access the results obtained.

Custom Checks

This section describes how to define custom checks in ModelCHECK that users can run using the standard ModelCHECK interface in Pro/ENGINEER.

To define and register a custom check:

1. Set the **CUSTMTK_CHECKS_FILE** configuration option in the start configuration file to a text file that stores the check definition. For example:

```
CUSTMTK_CHECKS_FILE text/custmtk_checks.txt
```
2. Set the contents of the **CUSTMTK_CHECKS_FILE** file to define the checks. Each check should list the following items:
 - **DEF_<checkname>**—Specifies the name of the check. The format must be **CHKTK_<checkname>_<mode>**, where mode is PRT, ASM, or DRW.

- TAB_<checkname>—Specifies the tab category in the ModelCHECK report under which the check is classified. Valid tab values are:
 - INFO
 - PARAMETER
 - LAYER
 - FEATURE
 - RELATION
 - DATUM
 - MISC
 - VDA
 - VIEWS
- MSG_<checkname>—Specifies the description of the check that appears in the lower part of the ModelCHECK report when you select the name.
- DSC_<checkname>—Specifies the name of the check as it appears in the ModelCHECK report table.
- ERM_<checkname>—If set to INFO, the check is considered an INFO check and the report table displays the text from the first item returned by the check, instead of a count of the items. Otherwise, this value must be included, but is ignored by Pro/ENGINEER.

See the Example 1: Text File for Custom Checks for a sample custom checks text file.

3. Add the check and its values to the ModelCHECK configuration file.
4. Register the ModelCHECK check from the J-Link application.

Note: Other than the requirements listed above, J-Link custom checks do not have access to the rest of the values in the ModelCHECK configuration files. All the custom settings specific to the check, such as start parameters, constants, and so on, must be supported by the user application and not ModelCHECK.

Registering Custom Checks

Methods Introduced:

- **pfcSession.BaseSession.RegisterCustomModelCheck**
- **pfcModelCheck.pfcModelCheck.CustomCheckInstructions.Create**
- **pfcModelCheck.CustomCheckInstructions.SetCheckName**
- **pfcModelCheck.CustomCheckInstructions.SetCheckLabel**
- **pfcModelCheck.CustomCheckInstructions.SetListener**
- **pfcModelCheck.CustomCheckInstructions.SetActionButtonLabel**
- **pfcModelCheck.CustomCheckInstructions.SetUpdateButtonLabel**

The method

pfcSession.BaseSession.RegisterCustomModelCheck registers a custom check that can be included in any ModelCHECK run. This method takes the instructions in the form of the **CustomCheckInstructions** object as its input argument. This object contains the following parameters:

- *CheckName*—Specifies the name of the custom check.
- *CheckLabel*—Specifies the label of the custom check.
- *Listener*—Specifies the listener object containing the custom check methods. Refer to the section Custom Check Listeners for more information.
- *ActionButtonLabel*—Specifies the label for the action button. If you specify NULL for this parameter, this button is not shown.
- *UpdateButtonLabel*—Specifies the label for the update button. If you specify NULL for this parameter, this button is not shown.


The method

pfcModelCheck.pfcModelCheck.CustomCheckInstructions.Create creates the **CustomCheckInstructions** object containing the custom check instructions described above.

Use the methods

pfcModelCheck.CustomCheckInstructions.SetCheckName, **pfcModelCheck.CustomCheckInstructions.SetCheckLabel**, **pfcModelCheck.CustomCheckInstructions.SetListener**, **pfcModelCheck.CustomCheckInstructions.SetActionButtonLabel**, and **pfcModelCheck.CustomCheckInstructions.SetUpdateButtonLabel** to modify the instructions.

The following figure illustrates how the results of some custom checks might be displayed in the ModelCHECK report.



Models

Custom Check Listeners

Methods Introduced:

- **pfcModelCheck.ModelCheckCustomCheckListener.OnCustomCheck**
- **pfcModelCheck.pfcModelCheck.CustomCheckResults_Create**
- **pfcModelCheck.CustomCheckResults.SetResultsCount**
- **pfcModelCheck.CustomCheckResults.SetResultsTable**
- **pfcModelCheck.CustomCheckResults.SetResultsUrl**
- **pfcModelCheck.ModelCheckCustomCheckListener.OnCustomCheckAction**
- **pfcModelCheck.ModelCheckCustomCheckListener.OnCustomCheckUpdate**

The interface **pfcModelCheck.ModelCheckCustomCheckListener** provides the method signatures to implement a custom ModelCheck check.

Each listener method takes the following input arguments:

- *CheckName*—The name of the custom check as defined in the original call to the method **pfcSession.BaseSession.RegisterCustomModelCheck**.
- *Mdl*—The model being checked.

The application method that overrides **pfcModelCheck.ModelCheckCustomCheckListener.OnCustomCheck** is used to evaluate a custom defined check. The user application runs the check on the specified model and returns the results in the form of the **CustomCheckResults** object. This object contains the following parameters:

- *ResultsCount*—Specifies an integer indicating the number of errors found by the check. This value is displayed in the ModelCHECK report generated.
- *ResultsTable*—Specifies a list of text descriptions of the problem encountered for each error or warning.
- *ResultsUrl*—Specifies the link to an application-owned page that provides information on the results of the custom check.

The method **pfcModelCheck.pfcModelCheck.CustomCheckResults.Create** creates the **CustomCheckResults** object containing the custom check results described above.


Use the methods **pfcModelCheck.CustomCheckResults.SetResultsCount**, **pfcModelCheck.CustomCheckResults.SetResultsTable**, and **pfcModelCheck.CustomCheckResults.SetResultsUrl** listed above to modify the custom checks results obtained.

The method that overrides **pfcModelCheck.ModelCheckCustomCheckListener.OnCustomCheckAction** is called when the custom check's Action button is pressed. The input supplied includes the text selected by the user from the custom check results.

The function that overrides **pfcModelCheck.ModelCheckCustomCheckListener.OnCustomCheckUpdate** is called when the custom check's Update button is pressed. The input supplied includes the text selected by the user from the custom check results.

Custom ModelCHECK checks can have an Action button to highlight the problem, and possibly an Update button to fix it automatically.

The following figure displays the ModelCHECK report with an Action button that invokes the `pfcModelCheck.ModelCheckCustomCheckListener.OnCustomCheckAction` listener method.



Models

Example 1: Text File for Custom Checks

The following is the text file `custmtk_checks.txt` for custom checks examples.

```
# Custom TK Check File
# def-name of check as registered

# DWGVIEWGENERIC
DEF_UG_DWGVIEW_GENERIC CHKTK_UG_DWGVIEW_GENERIC_DRW
TAB_UG_DWGVIEW_GENERIC VIEWS
MSG_UG_DWGVIEW_GENERIC CUSTOM: J-Link - Report Generic Status
ERM_UG_DWGVIEW_GENERIC CUSTOM: J-Link - Report Generic Status
DSC_UG_DWGVIEW_GENERIC CUSTOM: J-Link - Report Generic Status

# MODEL_PARAM_NAME
DEF_UG_MDLPARAM_NAME CHKTK_UG_MDLPARAM_NAME_PRT
TAB_UG_MDLPARAM_NAME DATUM
MSG_UG_MDLPARAM_NAME CUSTOM: J-Link - Parameter has invalid value
ERM_UG_MDLPARAM_NAME CUSTOM: J-Link - Invalid Parameter value.
DSC_UG_MDLPARAM_NAME CUSTOM: J-Link - Parameter has invalid value

# MODEL_ACCURACY
DEF_UG_MDL_ACC_TYPE CHKTK_UG_MDL_ACC_TYPE_PRT
TAB_UG_MDL_ACC_TYPE INFO
MSG_UG_MDL_ACC_TYPE CUSTOM: J-Link - Report Model accuracy type
ERM_UG_MDL_ACC_TYPE CUSTOM: J-Link - Report Model accuracy type.
DSC_UG_MDL_ACC_TYPE CUSTOM: J-Link - Report Model accuracy type
```

Example 2: Registering Custom ModelCHECK Checks

This example demonstrates how to register custom ModelCHECK checks using J-Link. The following custom checks are registered:

- `CHKTK_UG_MDLPARAM_NAME_PRT`—Determines if the model has a parameter whose name is equal to the model name.
- `CHKTK_UG_MDL_ACC_TYPE`—Checks the type of accuracy defined for the model.
- `CHKTK_UG_DWGVIEW_GENERIC`—Drawing mode check that identifies the drawing views that use generic models.

```
import com.ptc.cipjava.*;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.Session;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcFeature.*;
```

```

import com.ptc.pfc.pfcComponentFeat.*;
import com.ptc.pfc.pfcFamily.FamilyTableRow;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcWindow.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcModelCheck.*;
import com.ptc.pfc.pfcFamily.*;
import com.ptc.pfc.pfcDisplay.*;

import java.util.logging.*;
import java.io.IOException;

import javax.swing.*;

/*****\
CLASS:   pfcModelCheckExamples
PURPOSE: Define all the ModelCHECKs of this example code
\*****/

public class pfcModelCheckExamples
{
    protected Logger logger;
    private FileHandler handler;

    static Session session;
    /*****\
    FUNCTION: SetupNameCheck()
    PURPOSE: Register the ModelCHECK for Parameter name check.
    \*****/
    public static void SetupNameCheck ()
    {
        String Name = "CHKTK_UG_MDLPARAM_NAME";
        String Label = "UG CustomCheck: MDL PARAM NAME";

        try
        {
            /*-----*\
            Define the ModelCHECK Instructions object
            \*-----*/

            CustomCheckInstructions NameCheckInst =
                pfcModelCheck.CustomCheckInstructions_Create (Name, Label,
                    new MCheckNameListen () );

            /*-----*\
            Define the label for the Update button

```

```

\*-----*/

NameCheckInst.SetUpdateButtonLabel ("UG CustomCheckUpdate:
                                     MDL PARAM NAME");
session = pfcGlobal.GetProESession();

/*-----*\
Register the ModelCHECK
\*-----*/

session.RegisterCustomModelCheck ( NameCheckInst );
}
catch (jxthrowable x)
{
}

}
/*****\
FUNCTION: SetupDwgGenericCheck()
PURPOSE: Register the ModelCHECK for checking Generic
         objects in a drawing.
\*****/
public static void SetupDwgGenericCheck ()
{
    String Name = "CHKTK_UG_DWGVIEW_GENERIC";
    String Label = "UG CustomCheck: DWGVIEW GENERIC";

    try
    {
        /*-----*\
        Define the ModelCHECK Instructions object
        \*-----*/

        CustomCheckInstructions DwgGenericCheckInst =
        pfcModelCheck.CustomCheckInstructions_Create (Name, Label,
                                                    new MCheckDwgGenericListen ( ) );

        /*-----*\
        Define the label for the Action button
        \*-----*/
        DwgGenericCheckInst.SetActionButtonLabel ("UG CustomCheckAction:
                                                  DWGVIEW GENERIC");
        session = pfcGlobal.GetProESession();

        /*-----*\
        Register the ModelCHECK
        \*-----*/

        session.RegisterCustomModelCheck ( DwgGenericCheckInst );
    }
    catch (jxthrowable x)

```



```

    {
    }
}
/*****\
FUNCTION: SetupAccuracyCheck()
PURPOSE: Register the ModelCHECK for checking the type of
         accuracy defined for the model.
\*****/
public static void SetupAccuracyCheck ()

{
    String Name = "CHKTK_UG_MDL_ACC_TYPE";
    String Label = "UG CustomCheck: MDL ACC TYPE";

    try
    {
        /*-----*\
        Define the ModelCHECK Instructions object
        \*-----*/
        CustomCheckInstructions AccuracyCheckInst =
        pfcModelCheck.CustomCheckInstructions_Create (
        Name, Label, new MCheckAccuracyListen () );

        session = pfcGlobal.GetProESession();
        /*-----*\
        Register the ModelCHECK
        \*-----*/

        session.RegisterCustomModelCheck ( AccuracyCheckInst );
    }
    catch (jxthrowable x)
    {
    }
}

public pfcModelCheckExamples (Session s)
{
    session = s;
    try
    {
        handler = new FileHandler ("pfcModelCheckExamples.log");
        logger = Logger.global;
        logger.addHandler(handler);
    }
    catch (IOException e)
    {
        System.out.println ("Caught exception initializing log file: " +
                            e);
    }
}
}
}

```

Example 3: Implementing a Model Name Parameter Check

The following example defines the custom ModelCHECK check for the parameter name in a model. This check updates the parameter name to be equal to the model name, if the parameter exists with a different name, or creates the parameter with the model name if it does not exist.

```

/*****\
CLASS:   MCheckNameListen
PURPOSE: Define the ModelCHECK for checking the parameter value on the
         model & Update for changing it to the required value if required.
\*****/
class MCheckNameListen extends
com.ptc.pfc.pfcModelCheck.DefaultModelCheckCustomCheckListener
{

    /*****\
    FUNCTION: OnCustomCheck()
    PURPOSE:  Check name of the parameter
    RETURNS:  CustomCheckResults object
    \*****/
    public CustomCheckResults OnCustomCheck (String CheckName, Model Mdl)
        throws com.ptc.cipjava.jxthrowable
    {
        CustomCheckResults result = null;

        stringseq results_table = stringseq.create();
        int result_count;
        Parameter param;
        ParamValue param_value;
        ParamValueType pvalue_type;

        param = Mdl.GetParam ("MDL_NAME_PARAM");

        if (param == null)
        {
            results_table.append("UG CustomCheck: MDL PARAM NOT FOUND");
            result_count = 1;
        }
        else
        {
            param_value = param.GetScaledValue ();

            pvalue_type = param_value.Getdiscr();

            if (pvalue_type == ParamValueType.PARAM_STRING)
            {
                if( param_value.GetStringValue().equals(Mdl.GetInstanceName()) )
                {
                    result_count = 0;
                }
            }
        }
    }
}

```

```

    }
    else
    {
        results_table.append("UG CustomCheck: MDL PARAM INCORRECT");
        result_count = 1;
    }
}
else
{
    results_table.append("UG CustomCheck: MDL PARAM INV TYPE");
    result_count = 1;
}
}

result = pfcModelCheck.CustomCheckResults_Create (result_count);

result.SetResultsTable (results_table);

return (result);
}

/*****\
FUNCTION: OnCustomCheckUpdate()
PURPOSE: Update the parameter name in case it is wrong or create the
         parameter with required name in case it does not exist.
\*****/
public void OnCustomCheckUpdate (String CheckName , Model Mdl, String
                               SelectedItem) throws com.ptc.cipjava.jxthrowable
{
    Parameter param;
    ParamValue param_value;
    ParamValueType pvalue_type;
    String message_file = "jlexamples.txt";

    Session sess = pfcGlobal.GetProESession();

    if (SelectedItem.equals ("UG CustomCheck: MDL PARAM NOT FOUND"))
    {
        param_value =
            pfcModelItem.CreateStringParamValue (Mdl.GetInstanceName());

        param = Mdl.CreateParam ("MDL_NAME_PARAM", param_value);

        sess.UIDisplayMessage (message_file, "jLMCPaCreated", null);
    }

    if (SelectedItem.equals ("UG CustomCheck: MDL PARAM INCORRECT"))
    {
        param = Mdl.GetParam ("MDL_NAME_PARAM");
        param_value =
            pfcModelItem.CreateStringParamValue (Mdl.GetInstanceName());
    }
}

```

```

        param.SetScaledValue (param_value, null);
        sess.UIDisplayMessage (message_file, "j1MCPaUpdated", null);
    }

    if (SelectedItem.equals ("UG CustomCheck: MDL PARAM INV TYPE"))
    {
        sess.UIDisplayMessage (message_file, "j1MCPaInvalid", null);
    }
}
}
}

```

Example 4: Implementing a Model Accuracy Type Check

The following example defines the custom ModelCHECK check for the type of accuracy whether relative or absolute that has been set for a model. This check has a check listener method, but no action or update listener method since it is an info-only check.

```

/*****\
CLASS:    MCheckDwgAccuracyListen
PURPOSE:  Define the ModelCHECK for checking Generic
          objects in a drawing & Action for highlighting the Generic
          objects found.
\*****/
class MCheckAccuracyListen extends
    com.ptc.pfc.pfcModelCheck.DefaultModelCheckCustomCheckListener
{
    /*****\
    FUNCTION: OnCustomCheck()
    PURPOSE:  Check Accuracy type (Absolute/Relative)
    RETURNS:  CustomCheckResults object
    \*****/
    public CustomCheckResults OnCustomCheck (String CheckName, Model Mdl)
        throws com.ptc.cipjava.jxthrowable
    {
        CustomCheckResults result = null;

        String message_file = "jlexamples.txt";
        stringseq results_table = stringseq.create();
        int result_count;

        Solid Sld = (Solid)Mdl;
        Double accuracy;

        Session sess = pfcGlobal.GetProESession();

        if (Sld.GetAbsoluteAccuracy() != null)
        {
            accuracy = Sld.GetAbsoluteAccuracy();

```

```

        results_table.append("UG CustomCheck: MDL ACC ABS");
        result_count = 1;
        sess.UIDisplayMessage (message_file, "j1MCABSAcc", null);
    }
    else
    {
        accuracy = Sld.GetRelativeAccuracy();
        results_table.append("UG CustomCheck: MDL ACC REL");
        result_count = 1;
        sess.UIDisplayMessage (message_file, "j1MCRELAcc", null);
    }

    result = pfcModelCheck.CustomCheckResults_Create (result_count);

    result.SetResultsTable (results_table);

    return (result);
}
}

```

Example 5: Implementing a Check for Drawing Views Using Generic Models

The following example defines the custom ModelCHECK check for identifying drawing views using generic models. This check has a check listener method and an action listener method to highlight the views that use generic models.

```

/*****\
CLASS:    MCheckDwgGenericListen
PURPOSE:  Define the ModelCHECK for checking Generic objects in a drawing &
          Action for highlighting the Generic objects found.
\*****/
class MCheckDwgGenericListen extends
    com.ptc.pfc.pfcModelCheck.DefaultModelCheckCustomCheckListener
{
    /*****\
    FUNCTION: OnCustomCheck()
    PURPOSE:  Check existence of Generics in the drawing
    RETURNS:  CustomCheckResults object
    \*****/
    public CustomCheckResults OnCustomCheck (String CheckName, Model Mdl)
        throws com.ptc.cipjava.jxthrowable
    {
        CustomCheckResults result = null;

        stringseq results_table = stringseq.create();
        int result_count = 0;

```

```

Drawing draw = (Drawing)Mdl;
View2Ds dwgviews = ((Model2D)draw).List2DViews();

View2D dwgview;
Model viewmodel;
Solid viewsolid;
FamilyMember parent;
String viewname;

for (int i = 0 ; i<dwgviews.getarraysize() ; i++)
{
    dwgview = dwgviews.get(i);
    viewmodel = dwgview.GetModel();
    viewsolid = (Solid)viewmodel;
    parent = viewsolid.GetParent();

/*-----*\
    Generics will have no parent.
\*-----*/

    if (parent == null)
    {
        viewname = dwgview.GetName();
        results_table.append(viewname);
        result_count++;
    }
}

result = pfcModelCheck.CustomCheckResults_Create (result_count);

result.SetResultsTable (results_table);

return (result);
}

/*****\
FUNCTION: OnCustomCheckAction()
PURPOSE: Highlight Generics present in the drawing.
\*****/
public void OnCustomCheckAction (String CheckName , Model Mdl, String
    SelectedItem) throws com.ptc.cipjava.jxthrowable
{
    Session sess = pfcGlobal.GetProESession ();

    Drawing draw = (Drawing)Mdl;

    View2D dwgview = ((Model2D)draw).GetViewByName (SelectedItem);

    Outline3D outline = dwgview.GetOutline();

```

```

Point3D p1 = Point3D.create();
p1.set(0, (outline.get(0).get(0) - 10));
p1.set(1, (outline.get(0).get(1) - 10));
p1.set(2,0);

Point3D p2 = Point3D.create();
p2.set(0, (outline.get(0).get(0) - 10));
p2.set(1, (outline.get(1).get(1) + 10));
p2.set(2,0);

Point3D p3 = Point3D.create();
p3.set(0, (outline.get(1).get(0) + 10));
p3.set(1, (outline.get(1).get(1) + 10));
p3.set(2,0);

Point3D p4 = Point3D.create();
p4.set(0, (outline.get(1).get(0) + 10));
p4.set(1, (outline.get(0).get(1) - 10));
p4.set(2,0);

Point3D p5 = Point3D.create();
p5.set(0, (outline.get(0).get(0) - 10));
p5.set(1, (outline.get(0).get(1) - 10));
p5.set(2,0);

Point3Ds boundary = Point3Ds.create();

boundary.insert(0,p1);
boundary.insert(1,p2);
boundary.insert(2,p3);
boundary.insert(3,p4);
boundary.insert(4,p5);

StdLineStyle oldstyle = sess.SetLineStyle (StdLineStyle.LINE_PHANTOM);

StdColor origcolor = sess.GetCurrentGraphicsColor();
sess.SetCurrentGraphicsColor (StdColor.COLOR_HIGHLIGHT);

sess.DrawPolyline (boundary);

StdLineStyle oldstyle2 = sess.SetLineStyle (oldstyle);
sess.SetCurrentGraphicsColor (origcolor);

dwgview.Regenerate();
}
}

```

Example 6: Changes to the ModelCHECK Configuration Files to enable Custom Checks

Lines added to the ModelCheck configuration file (default_checks.mch)

```
E    Check the item.  If not succeed, report as an error
W    Check the item.  If not succeed, report as a warning
N    Do not check the item.
Y    Check the item.  If not succeed, do not report err or warn
```

```
CHKTK_UG_DWGVIEW_GENERIC_DRW      YNEW  E      E      E      E      Y
CHKTK_UG_MDLPARAM_NAME_PRT        YNEW  E      E      E      E      Y
CHKTK_UG_MDL_ACC_TYPE_PRT          YNEW  Y      Y      Y      Y      Y
```

Lines added to the ModelCheck start file (sample_start.mcs)

```
CUSTOMTK_CHECKS_FILE      custmtk_checks.txt
```


10

Drawings

This chapter describes how to program drawing functions using J-Link.

Topic	Page
Overview of Drawings in J-Link	10 - 2
Creating Drawings from Templates	10 - 2
Obtaining Drawing Models	10 - 6
Drawing Information	10 - 6
Drawing Operations	10 - 7
Drawing Sheets	10 - 10
Drawing Views	10 - 15
Drawing Dimensions	10 - 26
Drawing Tables	10 - 38
Detail Items	10 - 50
Detail Entities	10 - 52
OLE Objects	10 - 57
Detail Notes	10 - 57
Detail Groups	10 - 64
Detail Symbols	10 - 68
Detail Attachments	10 - 89

Overview of Drawings in J-Link

This section describes the functions that deal with drawings. You can create drawings of all Pro/ENGINEER models using the functions in J-Link. You can annotate the drawing, manipulate dimensions, and use layers to manage the display of different items.

Unless otherwise specified, J-Link functions that operate on drawings use world units.

Creating Drawings from Templates

Drawing templates simplify the process of creating a drawing using J-Link. Pro/ENGINEER can create views, set the view display, create snap lines, and show the model dimensions based on the template. Use templates to:

- Define layout views
- Set view display
- Place notes
- Place symbols
- Define tables
- Show dimensions

Method Introduced:

- **pfcSession.BaseSession.CreateDrawingFromTemplate**

Use the method **pfcSession.BaseSession.CreateDrawingFromTemplate** to create a drawing from the drawing template and to return the created drawing. The attributes are:

- New drawing name
- Name of an existing template
- Name and type of the solid model to use while populating template views
- Sequence of options to create the drawing. The options are as follows:
 - DRAWINGCREATE_DISPLAY_DRAWING—display the new drawing.

- DRAWINGCREATE_SHOW_ERROR_DIALOG—display the error dialog box.
- DRAWINGCREATE_WRITE_ERROR_FILE—write the errors to a file.
- DRAWINGCREATE_PROMPT_UNKNOWN_PARAMS—prompt the user on encountering unknown parameters.

Drawing Creation Errors

Methods Introduced:

- `pfcExceptions.XToolkitDrawingCreateErrors.GetErrors`
- `pfcExceptions.DrawingCreateError.GetType`
- `pfcExceptions.DrawingCreateError.GetViewName`
- `pfcExceptions.DrawingCreateError.GetObjectName`
- `pfcExceptions.DrawingCreateError.GetSheetNumber`
- `pfcExceptions.DrawingCreateError.GetView`

The exception **XToolkitDrawingCreateErrors** is thrown if an error is encountered when creating a drawing from a template. This exception contains a list of errors which occurred during drawing creation.

Note: When this exception type is encountered, the drawing is actually created, but some of the contents failed to generate correctly.

The error structure contains an array of drawing creation errors. Each error message may have the following elements:

- *Type*—The type of error as follows:
 - DWGCREATE_ERR_SAVED_VIEW_DOESNT_EXIST—Saved view does not exist.
 - DWGCREATE_ERR_X_SEC_DOESNT_EXIST—Specified cross section does not exist.
 - DWGCREATE_ERR_EXPLODE_DOESNT_EXIST—Exploded state did not exist.
 - DWGCREATE_ERR_MODEL_NOT_EXPLODABLE—Model cannot be exploded.
 - DWGCREATE_ERR_SEC_NOT_PERP—Cross section view not perpendicular to the given view.

- DWGCREATE_ERR_NO_RPT_REGIONS—Repeat regions not available.
 - DWGCREATE_ERR_FIRST_REGION_USED—Repeat region was unable to use the region specified.
 - DWGCREATE_ERR_NOT_PROCESS_ASSEM— Model is not a process assembly view.
 - DWGCREATE_ERR_NO_STEP_NUM—The process step number does not exist.
 - DWGCREATE_ERR_TEMPLATE_USED—The template does not exist.
 - DWGCREATE_ERR_NO_PARENT_VIEW_FOR_PROJ—There is no possible parent view for this projected view.
 - DWGCREATE_ERR_CANT_GET_PROJ_PARENT—Could not get the projected parent for a drawing view.
 - DWGCREATE_ERR_SEC_NOT_PARALLEL—The designated cross section was not parallel to the created view.
 - DWGCREATE_ERR_SIMP_REP_DOESNT_EXIST—The designated simplified representation does not exist.
- *ViewName*—Name of the view where the error occurred.
 - *SheetNumber*—Sheet number where the error occurred.
 - *ObjectName*—Name of the invalid or missing object.
 - *View*—2D view in which the error occurred.

Use the method

pfcExceptions.XToolkitDrawingCreateErrors.GetErrors to obtain the preceding array elements from the error object.

Example: Drawing Creation from a Template

The following code creates a new drawing using a predefined template.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
```

```

import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;
public class pfcDrawingExamples {

/*=====*\
FUNCTION: createDrawingFromTemplate
PURPOSE: Create a new drawing using a predefined template.
\*=====*/
    public static void createDrawingFromTemplate (String newDrawingName)
        throws com.ptc.cipjava.jxthrowable
    {
        String predefinedTemplate = "c_drawing";

        if (newDrawingName == "")
        {
            throw new RuntimeException("Please supply a drawing name.
                Aborting...");
        }

/*-----*\
    Use the current model to create the drawing.
\*-----*/
        Session session = pfcGlobal.GetProESession();
        Model solid = session.GetCurrentModel();
        if (solid == null || (solid.GetType() != ModelType.MDL_PART &&
            solid.GetType() != ModelType.MDL_ASSEMBLY))
        {
            throw new RuntimeException ("Current model is not usable for new
                drawing. Aborting...");
        }

        DrawingCreateOptions options = DrawingCreateOptions.create();
        options.insert (0,
            DrawingCreateOption.DRAWINGCREATE_DISPLAY_DRAWING);
/*-----*\
    Create the required drawing.
\*-----*/
        Drawing drw =
            session.CreateDrawingFromTemplate (newDrawingName,
                predefinedTemplate,
                solid.GetDescr(),
                options);

```

```
}  
}
```

Obtaining Drawing Models

This section describes how to obtain drawing models.

Methods Introduced:

- **pfcSession.BaseSession.RetrieveModel**
- **pfcSession.BaseSession.GetModel**
- **pfcSession.BaseSession.GetModelFromDescr**
- **pfcSession.BaseSession.ListModels**
- **pfcSession.BaseSession.ListModelsByType**

The method **pfcSession.BaseSession.RetrieveModel** retrieves the drawing specified by the model descriptor. Model descriptors are data objects used to describe a model file and its location in the system. The method returns the retrieved drawing.

The method **pfcSession.BaseSession.GetModel** returns a drawing based on its name and type, whereas **pfcSession.BaseSession.GetModelFromDescr** returns a drawing specified by the model descriptor. The model must be in session.

Use the method **pfcSession.BaseSession.ListModels** to return a sequence of all the drawings in session.

Drawing Information

Methods Introduced:

- **pfcModel2D.Model2D.ListModels**
- **pfcModel2D.Model2D.GetCurrentSolid**
- **pfcModel2D.Model2D.ListSimplifiedReps**
- **pfcModel2D.Model2D.GetTextHeight**

The method **pfcModel2D.Model2D.ListModels** returns a list of all the solid models used in the drawing.

The method **pfcModel2D.Model2D.GetCurrentSolid** returns the current solid model of the drawing.

The method **pfcModel2D.Model2D.ListSimplifiedReps** returns the simplified representations of a solid model that are assigned to the drawing.

The method **pfcModel2D.Model2D.GetTextHeight** returns the text height of the drawing.

Drawing Operations

Methods Introduced:

- **pfcModel2D.Model2D.AddModel**
- **pfcModel2D.Model2D.DeleteModel**
- **pfcModel2D.Model2D.ReplaceModel**
- **pfcModel2D.Model2D.SetCurrentSolid**
- **pfcModel2D.Model2D.AddSimplifiedRep**
- **pfcModel2D.Model2D.DeleteSimplifiedRep**
- **pfcModel2D.Model2D.Regenerate**
- **pfcModel2D.Model2D.SetTextHeight**
- **pfcModel2D.Model2D.CreateDrawingDimension**
- **pfcModel2D.Model2D.CreateView**

The method **pfcModel2D.Model2D.AddModel** adds a new solid model to the drawing.

The method **pfcModel2D.Model2D.DeleteModel** removes a model from the drawing. The model to be deleted should not appear in any of the drawing views.

The method **pfcModel2D.Model2D.ReplaceModel** replaces a model in the drawing with a related model (the relationship should be by family table or interchange assembly). It allows you to replace models that are shown in drawing views and regenerates the view.

The method **pfcModel2D.Model2D.SetCurrentSolid** assigns the current solid model for the drawing. Before calling this method, the solid model must be assigned to the drawing using the method **pfcModel2D.Model2D.AddModel**. To see the changes to parameters and fields reflecting the change of the current solid model, regenerate the drawing using the method **pfcSheet.SheetOwner.RegenerateSheet**.

The method **pfcModel2D.Model2D.AddSimplifiedRep** associates the drawing with the simplified representation of an assembly .

The method **pfcModel2D.Model2D.DeleteSimplifiedRep** removes the association of the drawing with an assembly simplified representation. The simplified representation to be deleted should not appear in any of the drawing views.

Use the method **pfcModel2D.Model2D.Regenerate** to regenerate the drawing draft entities and appearance.

The method **pfcModel2D.Model2D.SetTextHeight** sets the value of the text height of the drawing.

The method **pfcModel2D.Model2D.CreateDrawingDimension** creates a new drawing dimension based on the data object that contains information about the location of the dimension. This method returns the created dimension. Refer to the section Drawing Dimensions.

The method **pfcModel2D.Model2D.CreateView** creates a new drawing view based on the data object that contains information about how to create the view. The method returns the created drawing view. Refer to the section Creating Drawing Views.

Example: Replace Drawing Model Solid with its Generic

The following code replaces all solid model instances in a drawing with its generic.

```
import com.ptc.cipjava.*;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
```



```

import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {

/*=====*\
FUNCTION: drawingSolidReplace()
PURPOSE: Replaces all instance solid models in a drawing with their
         generic. Similar to the Pro/ENGINEER behavior, the function
         will not replace models if the target generic
         model is already present in the drawing.
\*=====*/
    public static void replaceModels() throws com.ptc.cipjava.jxthrowable
    {

/*-----*\
    Get the current drawing
\*-----*/
        Session session = pfcGlobal.GetProESession ();
        Model model = session.GetCurrentModel();

        if (model.GetType() != ModelType.MDL_DRAWING)
            throw new RuntimeException ("Current model is not a drawing");

        Drawing drawing = (Drawing) model;

/*-----*\
        Visit the drawing models.
\*-----*/
        Models solids = drawing.ListModels ();

/*-----*\
        Loop on all of the drawing models.
\*-----*/
        for (int i = 0; i < solids.getarraysize(); i++)
        {
            Solid solid = (Solid)solids.get (i);

/*-----*\
            If the generic is not an instance, continue (GetParent() method
            from class FamilyMember)
\*-----*/
            Solid generic = (Solid)solid.GetParent();

            if (generic == null)
                continue;

/*-----*\
            Replace all instances with their (top-level) generic.
\*-----*/

```

```

try
{
    drawing.ReplaceModel (solid, generic, true);
}
catch (XToolkitFound xtef)
{
    // Target generic is already in drawing; do nothing
}
}
}
}

```

Drawing Sheets

A drawing sheet is represented by its number. Drawing sheets in J-Link are identified by the same sheet numbers seen by a Pro/Engineer user.

Note: These identifiers may change if the sheets are moved as a consequence of adding, removing or reordering sheets.

Drawing Sheet Information

Methods Introduced

- **pfcSheet.SheetOwner.GetSheetData**
- **pfcSheet.SheetOwner.GetSheetTransform**
- **pfcSheet.SheetOwner.GetSheetScale**
- **pfcSheet.SheetOwner.GetSheetFormat**
- **pfcSheet.SheetOwner.GetSheetFormatDescr**
- **pfcSheet.SheetOwner.GetSheetBackgroundView**
- **pfcSheet.SheetOwner.GetNumberOfSheets**
- **pfcSheet.SheetOwner.GetCurrentSheetNumber**
- **pfcSheet.SheetOwner.GetSheetUnits**

The method **pfcSheet.SheetOwner.GetSheetData** returns sheet data including the size, orientation, and units of the sheet specified by the sheet number.

The method **pfcSheet.SheetOwner.GetSheetTransform** returns the transformation matrix for the sheet specified by the sheet number. This transformation matrix includes the scaling needed to convert screen coordinates to drawing coordinates (which use the designated drawing units).

The method **pfcSheet.SheetOwner.GetSheetScale** returns the scale of the drawing on a particular sheet based on the drawing model used to measure the scale. If no models are used in the drawing then the default scale value is 1.0.

The method **pfcSheet.SheetOwner.GetSheetFormat** returns the drawing format used for the sheet specified by the sheet number. It returns a null value if no format is assigned to the sheet.

The method **pfcSheet.SheetOwner.GetSheetFormatDescr** returns the model descriptor of the drawing format used for the specified drawing sheet.

The method **pfcSheet.SheetOwner.GetSheetBackgroundView** returns the view object representing the background view of the sheet specified by the sheet number.

The method **pfcSheet.SheetOwner.GetNumberOfSheets** returns the number of sheets in the model.

The method **pfcSheet.SheetOwner.GetCurrentSheetNumber** returns the current sheet number in the model.

Note: The sheet numbers range from 1 to n, where n is the number of sheets.

The method **pfcSheet.SheetOwner.GetSheetUnits** returns the units used by the sheet specified by the sheet number.

Drawing Sheet Operations

Methods Introduced:

- **pfcSheet.SheetOwner.AddSheet**
- **pfcSheet.SheetOwner.DeleteSheet**
- **pfcSheet.SheetOwner.ReorderSheet**
- **pfcSheet.SheetOwner.RegenerateSheet**
- **pfcSheet.SheetOwner.SetSheetScale**
- **pfcSheet.SheetOwner.SetSheetFormat**
- **pfcSheet.SheetOwner.SetCurrentSheetNumber**

The method **pfcSheet.SheetOwner.AddSheet** adds a new sheet to the model and returns the number of the new sheet.

The method **pfcSheet.SheetOwner.DeleteSheet** removes the sheet specified by the sheet number from the model.

Use the method **pfcSheet.SheetOwner.ReorderSheet** to reorder the sheet from a specified sheet number to a new sheet number.

Note: The sheet number of other affected sheets also changes due to reordering or deletion.

The method **pfcSheet.SheetOwner.RegenerateSheet** regenerates the sheet specified by the sheet number.

Note: You can regenerate a sheet only if it is displayed.

Use the method **pfcSheet.SheetOwner.SetSheetScale** to set the scale of a model on the sheet based on the drawing model to scale and the scale to be used. Pass the value of the *DrawingModel* parameter as null to select the current drawing model.

Use the method **pfcSheet.SheetOwner.SetSheetFormat** to apply the specified format to a drawing sheet based on the drawing format, sheet number of the format, and the drawing model.

The sheet number of the format is specified by the *FormatSheetNumber* parameter. This number ranges from 1 to the number of sheets in the format. Pass the value of this parameter as null to use the first format sheet.

The drawing model is specified by the *DrawingModel* parameter. Pass the value of this parameter as null to select the current drawing model.

The method **pfcSheet.SheetOwner.SetCurrentSheetNumber** sets the current sheet to the sheet number specified.

Example: Listing Drawing Sheets

The following example shows how to list the sheets in the current drawing. The information is placed in an external browser window.

```
import com.ptc.cipjava.*;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
```

```

import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;

import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {

/*=====*\
FUNCTION : listSheets()
PURPOSE  : Command to list drawing sheet info in an information window
\*=====*/
    public static void listSheets() throws com.ptc.cipjava.jxthrowable,
java.io.IOException
    {
/*-----*\
        Save an HTML file to contain the information to be displayed
\*-----*/
        String URL = "sheet_info.html";

        PrintWriter writer = new PrintWriter (new FileOutputStream (URL));

        writer.println ("<html><head></head><body>");

/*-----*\
        Get the current drawing
\*-----*/
        Session session = pfcGlobal.GetProESession ();
        Model model = session.GetCurrentModel();

        if (model.GetType() != ModelType.MDL_DRAWING)
            throw new RuntimeException ("Current model is not a drawing");

        Drawing drawing = (Drawing) model;

/*-----*\
        Get the number of sheets
\*-----*/
        int sheets = drawing.GetNumberOfSheets();

        for (int i = 1; i <= sheets; i++)
        {
/*-----*\
            Get the drawing sheet size etc.
\*-----*/
            SheetData info = drawing.GetSheetData (i);

            DrawingFormat format = drawing.GetSheetFormat (i);

```

```

/*-----*\
Print the information to the window
\*-----*/

String unit = "unknown";

switch (info.GetUnits().GetType().getValue())
{
case LengthUnitType._LENGTHUNIT_INCH:
    unit = "inches";
    break;
case LengthUnitType._LENGTHUNIT_FOOT:
    unit = "feet";
    break;
case LengthUnitType._LENGTHUNIT_MM:
    unit = "mm";
    break;
case LengthUnitType._LENGTHUNIT_CM:
    unit = "cm";
    break;
case LengthUnitType._LENGTHUNIT_M:
    unit = "m";
    break;
case LengthUnitType._LENGTHUNIT_MCM:
    unit = "mcm";
    break;
}

writer.println ("<h2>Sheet "+ i + "</h2>");
writer.println ("<table>");
writer.println (" <tr><td> Width </td><td> "+
    info.GetWidth() + " </td></tr> ");
writer.println (" <tr><td> Height </td><td> "+
    info.GetHeight() + " </td></tr> ");
writer.println (" <tr><td> Units </td><td> "+
    unit + " </td></tr> ");

String formatName;
if (format == null)
    formatName = "none";
else
    formatName = format.GetFullName();
writer.println (" <tr><td> Format </td><td> "+
    formatName + " </td></tr> ");
writer.println ("</table>");
writer.println ("<br>");

}
writer.println ("</body></html>");

writer.close ();

```

```
        session.GetCurrentWindow().SetURL (session.GetCurrentDirectory()+
                                          URL);
    }
}
```

Drawing Views

A drawing view is represented by the interface **pfcView2D.View2D**. All model views in the drawing are associative, that is, if you change a dimensional value in one view, the system updates other drawing views accordingly. The model automatically reflects any dimensional changes that you make to a drawing. In addition, corresponding drawings also reflect any changes that you make to a model such as the addition or deletion of features and dimensional changes.

Creating Drawing Views

Method Introduced:

- **pfcModel2D.Model2D.CreateView**

The method **pfcModel2D.Model2D.CreateView** creates a new view in the drawing. Before calling this method, the drawing must be displayed in a window.

The interface **pfcView2D.View2DCreateInstructions** contains details on how to create the view. The types of drawing views supported for creation are:

- DRAWVIEW GENERAL—General drawing views
- DRAWVIEW PROJECTION—Projected drawing views

General Drawing Views

The interface **pfcView2D.GeneralViewCreateInstructions** contains details on how to create general drawing views.

Methods Introduced:

- **pfcView2D.pfcView2D.GeneralViewCreateInstructions_Create**
- **pfcView2D.GeneralViewCreateInstructions.SetViewModel**
- **pfcView2D.GeneralViewCreateInstructions.SetLocation**
- **pfcView2D.GeneralViewCreateInstructions.SetSheetNumber**

- **pfcView2D.GeneralViewCreateInstructions.SetOrientation**
- **pfcView2D.GeneralViewCreateInstructions.SetExploded**
- **pfcView2D.GeneralViewCreateInstructions.SetScale**

The method

pfcView2D.GeneralViewCreateInstructions.Create creates the **pfcView2D.GeneralViewCreateInstructions** data object used for creating general drawing views.

Use the method

pfcView2D.GeneralViewCreateInstructions.SetViewModel to assign the solid model to display in the created general drawing view.

Use the method

pfcView2D.GeneralViewCreateInstructions.SetLocation to assign the location in a drawing sheet to place the created general drawing view.

Use the method

pfcView2D.GeneralViewCreateInstructions.SetSheetNumber to set the number of the drawing sheet in which the general drawing view is created.

The method

pfcView2D.GeneralViewCreateInstructions.SetOrientation assigns the orientation of the model in the general drawing view in the form of the **pfcBase.Transform3D** data object. The transformation matrix must only consist of the rotation to be applied to the model. It must not consist of any displacement or scale components. If necessary, set the displacement to {0, 0, 0} using the method **pfcBase.Transform3D.SetOrigin**, and remove any scaling factor by normalizing the matrix.

Use the method

pfcView2D.GeneralViewCreateInstructions.SetExploded to set the created general drawing view to be an exploded view.

Use the method

pfcView2D.GeneralViewCreateInstructions.SetScale to assign a scale to the created general drawing view. This value is optional, if not assigned, the default drawing scale is used.

Projected Drawing Views

The interface **pfcView2D.ProjectionViewCreateInstructions** contains details on how to create general drawing views.

Methods Introduced:

- **pfcView2D.pfcView2D.ProjectionViewCreateInstructions_Create**
- **pfcView2D.ProjectionViewCreateInstructions.SetParentView**
- **pfcView2D.ProjectionViewCreateInstructions.SetLocation**
- **pfcView2D.ProjectionViewCreateInstructions.SetExploded**

The method **pfcView2D.pfcView2D.ProjectionViewCreateInstructions_Create** creates the **pfcView2D.ProjectionViewCreateInstructions** data object used for creating projected drawing views.

Use the method **pfcView2D.ProjectionViewCreateInstructions.SetParentView** to assign the parent view for the projected drawing view.

Use the method **pfcView2D.ProjectionViewCreateInstructions.SetLocation** to assign the location of the projected drawing view. This location determines how the drawing view will be oriented.

Use the method **pfcView2D.ProjectionViewCreateInstructions.SetExploded** to set the created projected drawing view to be an exploded view.

Example: Creating Drawing Views

The following example code adds a new sheet to a drawing and creates three views of a selected model.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
```

```

import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {
/*=====*\
FUNCTION : createSheetAndViews()
PURPOSE  : Create a new drawing sheet with a general, and two
           projected, views of a selected solid
\*=====*/
    public static void createSheetAndViews(String solidName /* as ????.???
*/)
        throws com.ptc.cipjava.jxthrowable
    {
/*-----*\
        Get the current drawing, create a new sheet
\*-----*/
        Session session =pfcGlobal.GetProESession ();
        Model model = session.GetCurrentModel();

        if (model.GetType() != ModelType.MDL_DRAWING)
            throw new RuntimeException ("Current model is not a drawing");

        Drawing drawing = (Drawing) model;

        int sheetNo = drawing.AddSheet ();
        drawing.SetCurrentSheetNumber (sheetNo);

/*-----*\
        Find the solid model, if its in session
\*-----*/
        ModelDescriptor mdlDescr =
            pfcModel.ModelDescriptor_CreateFromFileName (solidName);
        Model solidMdl = session.GetModelFromDescr (mdlDescr);

        if (solidMdl == null)
            {
/*-----*\
                If its not found, try to retrieve the solid model
\*-----*/
                solidMdl = session.RetrieveModel (mdlDescr);

                if (solidMdl == null)
                    throw new RuntimeException ("Model "+solidName+"
                                                cannot be found or retrieved.");
            }
    }
}

```

```

    }

/*-----*\
    Try to add it to the drawing
/*-----*\
    try
    {
        drawing.AddModel (solidMdl);
    }
    catch (XToolkitInUse xtiu)
    {
        // model is already in this drawing, nothing to do
    }

/*-----*\
    Create a general view from the Z axis direction at a predefined location
/*-----*\
    Matrix3D matrix = Matrix3D.create();
    for (int i = 0; i < 4; i++)
        for (int j = 0; j < 4; j++)
            {
                if (i == j)
                    matrix.set (i, j, 1.0);
                else
                    matrix.set (i, j, 0.0);
            }

    Transform3D transf = pfcBase.Transform3D_Create (matrix);

    Point3D pos = Point3D.create();
    pos.set (0, 200.0);
    pos.set (1, 600.0);
    pos.set (2, 0.0);

    GeneralViewCreateInstructions instrs =
        pfcView2D.GeneralViewCreateInstructions_Create (solidMdl,
                                                        sheetNo,
                                                        pos, transf);

    View2D genView = drawing.CreateView (instrs);

/*-----*\
    Get the position and size of the new view
/*-----*\
    Outline3D outline = genView.GetOutline();

/*-----*\
    Create a projected view to the right of the general view
/*-----*\
    pos.set (0, outline.get (1).get (0) + (outline.get(1).get(0) -
                                         outline.get (0).get (0)));

```

```

pos.set (1, (outline.get (0).get(1) + outline.get (1).get(1))/2);

ProjectionViewCreateInstructions pInstrs =
    pfcView2D.ProjectionViewCreateInstructions_Create (genView,
                                                       pos);

drawing.CreateView (pInstrs);

/*-----*\
Create a projected view below the general view
\*-----*/
pos.set (0, (outline.get (0).get(0) + outline.get (1).get(0))/2);
pos.set (1, outline.get (0).get (1) - (outline.get(1).get(1) -
                                     outline.get (0).get (1)));

pInstrs =
    pfcView2D.ProjectionViewCreateInstructions_Create (genView,
                                                       pos);

drawing.CreateView (pInstrs);
}
}

```

Obtaining Drawing Views

Methods Introduced:

- **pfcSelect.Selection.GetSelView2D**
- **pfcModel2D.Model2D.List2DViews**
- **pfcModel2D.Model2D.GetViewByName**
- **pfcModel2D.Model2D.GetViewDisplaying**
- **pfcSheet.SheetOwner.GetSheetBackgroundView**

The method **pfcSelection.Selection.GetSelView2D** returns the selected drawing view (if the user selected an item from a drawing view). It returns a null value if the selection does not contain a drawing view.

The method **pfcModel2D.Model2D.List2DViews** lists and returns the drawing views found. This method does not include the drawing sheet background views returned by the method **pfcSheet.SheetOwner.GetSheetBackgroundView**.

The method **pfcModel2D.Model2D.GetViewByName** returns the drawing view based on the name. This method returns a null value if the specified view does not exist.

The method **pfcModel2D.Model2D.GetViewDisplaying** returns the drawing view that displays a dimension. This method returns a null value if the dimension is not displayed in the drawing.

Note: This method works for solid and drawing dimensions.

The method **pfcSheet.SheetOwner.GetSheetBackgroundView** returns the drawing sheet background views.

Drawing View Information

Methods Introduced:

- **pfcObject.Child.GetDBParent**
- **pfcView2D.View2D.GetSheetNumber**
- **pfcView2D.View2D.GetIsBackground**
- **pfcView2D.View2D.GetModel**
- **pfcView2D.View2D.GetScale**
- **pfcView2D.View2D.GetIsScaleUserdefined**
- **pfcView2D.View2D.GetOutline**
- **pfcView2D.View2D.GetLayerDisplayStatus**
- **pfcView2D.View2D.GetIsViewdisplayLayerDependent**
- **pfcView2D.View2D.GetDisplay**
- **pfcView2D.View2D.GetTransform**
- **pfcView2D.View2D.GetName**

The inherited method **pfcObject.Child.GetDBParent**, when called on a **View2D** object, provides the drawing model which owns the specified drawing view. The return value of the method can be downcast to a **Model2D** object.

The method **pfcView2D.View2D.GetSheetNumber** returns the sheet number of the sheet that contains the drawing view.

The method **pfcView2D.View2D.GetIsBackground** returns a value that indicates whether the view is a background view or a model view.

The method **pfcView2D.View2D.GetModel** returns the solid model displayed in the drawing view.

The method **pfcView2D.View2D.GetScale** returns the scale of the drawing view.

The method **pfcView2D.View2D.GetIsScaleUserdefined** specifies if the drawing has a user-defined scale.

The method **pfcView2D.View2D.GetOutline** returns the position of the view in the sheet in world units.

The method **pfcView2D.View2D.GetLayerDisplayStatus** returns the display status of the specified layer in the drawing view.

The method **pfcView2D.View2D.GetDisplay** returns an output structure that describes the display settings of the drawing view. The fields in the structure are as follows:

- *Style*—Whether to display as wireframe, hidden lines, no hidden lines, or shaded
- *TangentStyle*—Linestyle used for tangent edges
- *CableStyle*—Linestyle used to display cables
- *RemoveQuiltHiddenLines*—Whether or not to apply hidden-line-removal to quilts
- *ShowConceptModel*—Whether or not to display the skeleton
- *ShowWeldXSection*—Whether or not to include welds in the cross-section

The method **pfcView2D.View2D.GetTransform** returns a matrix that describes the transform between 3D solid coordinates and 2D world units for that drawing view. The transformation matrix is a combination of the following factors:

- The location of the view origin with respect to the drawing origin.
- The scale of the view units with respect to the drawing units
- The rotation of the model with respect to the drawing coordinate system.

The method **pfcView2D.View2D.GetName** returns the name of the specified view in the drawing.

Example: Listing the Views in a Drawing

The following example creates an information window about all the views in a drawing. The information is placed in an external browser window

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;

import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {

    /*=====*\
    FUNCTION : listViews()
    PURPOSE  : Command to list view info in an information window
    \*=====*/
    public static void listViews() throws com.ptc.cipjava.jxthrowable,
        java.io.IOException
    {
        /*-----*\
        Open a browser window to contain the information to be displayed
        \*-----*/
        String URL = "view_info.html";
        PrintWriter writer = new PrintWriter (new FileOutputStream (URL));

        writer.println ("<html><head></head><body>");

        /*-----*\
        Get the current drawing
        \*-----*/
        Session session = pfcGlobal.GetProESession ();
```

```

Model model = session.GetCurrentModel();

if (model.GetType() != ModelType.MDL_DRAWING)
    throw new RuntimeException ("Current model is not a drawing");

    Drawing drawing = (Drawing) model;
/*-----*\
    Collect the views
\*-----*/
    View2Ds views = drawing.List2DViews ();

    for(int i=0; i<views.getarraysize(); i++)
    {
        View2D view = views.get (i);

/*-----*\
        Get the name & sheet number for this view
\*-----*/
        String viewName = view.GetName();
        int sheetNo = view.GetSheetNumber ();

/*-----*\
        Get the name of the solid that the view contains
\*-----*/
        Model solid = view.GetModel ();
        ModelDescriptor descr = solid.GetDescr();

/*-----*\
        Get the outline, scale, and display state
\*-----*/
        Outline3D outline = view.GetOutline();
        double scale = view.GetScale();
        ViewDisplay display = view.GetDisplay();

/*-----*\
        Write the information to the browser window file
\*-----*/

        String dispStyle = "unknown";
        switch(display.GetStyle().getValue())
        {
            case DisplayStyle._DISPSTYLE_DEFAULT:
                dispStyle = "default";
                break;
            case DisplayStyle._DISPSTYLE_WIREFRAME:
                dispStyle = "wireframe";
                break;
            case DisplayStyle._DISPSTYLE_HIDDEN_LINE:
                dispStyle = "hidden line";
                break;
            case DisplayStyle._DISPSTYLE_NO_HIDDEN:
                dispStyle = "no hidden";

```



```

        break;
        case DisplayStyle._DISPSTYLE_SHADED:
            dispStyle = "shaded";
            break;
    }

    writer.println ("<h2>View "+ viewName + "</h2>");
    writer.println ("<table>");
    writer.println (" <tr><td> Sheet </td><td> "+
        sheetNo + " </td></tr> ");
    writer.println (" <tr><td> Model </td><td> "+
        descr.GetFullName() + " </td></tr> ");
    writer.println (" <tr><td> Outline </td><td> ");
    writer.println ("<table><tr><td> <i>Lower left:</i> </td><td>");
    writer.println (outline.get (0).get (0) + ", " +
        outline.get (0).get(1) + ", " +
        outline.get (0).get(2));
    writer.println ("</td></tr><tr><td>
        <i>Upper right:</i></td><td>");
    writer.println (outline.get (1).get (0) + ", " +
        outline.get (1).get(1) + ", " +
        outline.get (1).get(2));
    writer.println ("</td></tr></table></td>");
    writer.println (" <tr><td> Scale </td><td> "+ scale +
        " </td></tr> ");
    writer.println (" <tr><td> Display style </td><td> "+
        dispStyle + " </td></tr>");
    writer.println ("</table>");
    writer.println ("<br>");
    }
    writer.println ("</body></html>");

    writer.close ();

    session.GetCurrentWindow().SetURL (session.GetCurrentDirectory()+URL);
    }
}

```



Drawing Views Operations

Methods Introduced:

- **pfcView2D.View2D.SetScale**
- **pfcView2D.View2D.Translate**
- **pfcView2D.View2D.Delete**
- **pfcView2D.View2D.Regenerate**
- **pfcView2D.View2D.SetLayerDisplayStatus**
- **pfcView2D.View2D.SetDisplay**

The method **pfcView2D.View2D.SetScale** sets the scale of the drawing view.

The method **pfcView2D.View2D.Translate** moves the drawing view by the specified transformation vector.

The method **pfcView2D.View2D.Delete** deletes a specified drawing view. Set the *DeleteChildren* parameter to true to delete the children of the view. Set this parameter to false or null to prevent deletion of the view if it has children.

The method **pfcView2D.View2D.Regenerate** erases the displayed view of the current object, regenerates the view from the current drawing, and redisplay the view.

The method **pfcView2D.View2D.SetLayerDisplayStatus** sets the display status for the layer in the drawing view.

The method **pfcView2D.View2D.SetDisplay** sets the value of the display settings for the drawing view.

Drawing Dimensions

This section describes the J-Link methods that give access to the types of dimensions that can be created in the drawing mode. They do not apply to dimensions created in the solid mode, either those created automatically as a result of feature creation, or reference dimension created in a solid. A drawing dimension or a reference dimension shown in a drawing is represented by the interface **com.ptc.pfc.pfcDimension2D.Dimension2D**.

Obtaining Drawing Dimensions

Methods Introduced:

- **pfcModelItem.ModelItemOwner.ListItems**
- **pfcModelItem.ModelItemOwner.GetItemById**
- **pfcSelect.Selection.GetSelectedItem**

The method **pfcModelItem.ModelItemOwner.ListItems** returns a list of drawing dimensions specified by the parameter *Type* or returns null if no drawing dimensions of the specified type are found. This method lists only those dimensions created in the drawing.

The values of the parameter *Type* for the drawing dimensions are:

- **ITEM_DIMENSION**—Dimension
- **ITEM_REF_DIMENSION**—Reference dimension

Set the parameter *Type* to the type of drawing dimension to retrieve. If this parameter is set to null, then all the dimensions in the drawing are listed.

The method **pfcModelItem.ModelItemOwner.GetItemById** returns a drawing dimension based on the type and the integer identifier. The method returns only those dimensions created in the drawing. It returns a null if a drawing dimension with the specified attributes is not found.

The method **pfcSelect.Selection.GetSelectedItem** returns the value of the selected drawing dimension.

Creating Drawing Dimensions

Methods Introduced:

- **pfcDimension2D.pfcDimension2D.DrawingDimCreateInstructions_Create**
- **pfcModel2D.Model2D.CreateDrawingDimension**
- **pfcDimension2D.pfcDimension2D.EmptyDimensionSense_Create**
- **pfcDimension2D.pfcDimension2D.PointDimensionSense_Create**
- **pfcDimension2D.pfcDimension2D.SplinePointDimensionSense_Create**
- **pfcDimension2D.pfcDimension2D.TangentIndexDimensionSense_Create**

- **pfcDimension2D.pfcDimension2D.LinAOCTangentDimensionSense_Create**
- **pfcDimension2D.pfcDimension2D.AngleDimensionSense_Create**
- **pfcDimension2D.pfcDimension2D.PointToAngleDimensionSense_Create**

The method

pfcDimension2D.pfcDimension2D.DrawingDimCreateInstructions_Create creates an instructions object that describes how to create a drawing dimension using the method **pfcModel2D.Model2D.CreateDrawingDimension**.

The parameters of the instruction object are:

- *Attachments*—The entities that the dimension is attached to. The selections should include the drawing model view.
- *IsRefDimension*—True if the dimension is a reference dimension, otherwise null or false.
- *OrientationHint*—Describes the orientation of the dimensions in cases where this cannot be deduced from the attachments themselves.
- *Senses*—Gives more information about how the dimension attaches to the entity, i.e., to what part of the entity and in what direction the dimension runs. The types of dimension senses are as follows:
 - DIMSENSE_NONE
 - DIMSENSE_POINT
 - DIMSENSE_SPLINE_PT
 - DIMSENSE_TANGENT_INDEX
 - DIMSENSE_LINEAR_TO_ARC_OR_CIRCLE_TANGENT
 - DIMSENSE_ANGLE
 - DIMSENSE_POINT_TO_ANGLE
- *TextLocation*—The location of the dimension text, in world units.

The method **pfcModel2D.Model2D.CreateDrawingDimension** creates a dimension in the drawing based on the instructions data object that contains information needed to place the dimension. It takes as input an array of pfcSelection objects and an array of pfcDimensionSense structures that describe the required attachments. The method returns the created drawing dimension.

The method

pfcDimension2D.pfcDimension2D.EmptyDimensionSense_Create creates a new dimension sense associated with the type DIMSENSE NONE. The "sense" field is set to *Type*. In this case no information such as location or direction is needed to describe the attachment points. For example, if there is a single attachment which is a straight line, the dimension is the length of the straight line. If the attachments are two parallel lines, the dimension is the distance between them.

The method

pfcDimension2D.pfcDimension2D.PointDimensionSense_Create creates a new dimension sense associated with the type DIMSENSE POINT which specifies the part of the entity to which the dimension is attached. The "sense" field is set to the value of the parameter *PointType*.

The possible values of *PointType* are:

- DIMPOINT_END1— The first end of the entity
- DIMPOINT_END2—The second end of the entity
- DIMPOINT_CENTER—The center of an arc or circle
- DIMPOINT_NONE—No information such as location or direction of the attachment is specified. This is similar to setting the *PointType* to DIMSENSE NONE.
- DIMPOINT_MIDPOINT—The mid point of the entity

The method

pfcDimension2D.pfcDimension2D.SplinePointDimensionSense_Create creates a dimension sense associated with the type DIMSENSE SPLINE_PT. This means that the attachment is to a point on a spline. The "sense" field is set to *SplinePointIndex* i.e., the index of the spline point.

The method

pfcDimension2D.pfcDimension2D.TangentIndexDimensionSense_Create creates a new dimension sense associated with the type DIMSENSE TANGENT_INDEX. The attachment is to a tangent of the entity, which is an arc or a circle. The sense field is set to *TangentIndex*, i.e., the index of the tangent of the entity.

The method

pfcDimension2D.pfcDimension2D.LinAOCTangentDimensionSense_Create creates a new dimension sense associated with the type DIMSENSE_LINEAR_TO_ARC_OR_CIRCLE_TANGENT.

The dimension is the perpendicular distance between the a line and a tangent to an arc or a circle that is parallel to the line. The sense field is set to the value of the parameter *TangentType*.

The possible values of *TangentType* are:

- DIMLINAOCTANGENT_LEFT0—The tangent is to the left of the line, and is on the same side, of the center of the arc or circle, as the line.
- DIMLINAOCTANGENT_RIGHT0—The tangent is to the right of the line, and is on the same side, of the center of the arc or circle, as the line.
- DIMLINAOCTANGENT_LEFT1—The tangent is to the left of the line, and is on the opposite side of the line.
- DIMLINAOCTANGENT_RIGHT1— The tangent is to the right of the line, and is on the opposite side of the line.

The method

pfcDimension2D.pfcDimension2D.AngleDimensionSense_Create creates a new dimension sense associated with the type DIMSENSE_ANGLE. The dimension is the angle between two straight entities. The "sense" field is set to the value of the parameter *AngleOptions*.

The possible values of *AngleOptions* are:

- IsFirst—Is set to TRUE if the angle dimension starts from the specified entity in a counterclockwise direction. Is set to FALSE if the dimension ends at the specified entity. The value is TRUE for one entity and FALSE for the other entity forming the angle.
- ShouldFlip—If the value of *ShouldFlip* is FALSE, and the direction of the specified entity is away from the vertex of the angle, then the dimension attaches directly to the entity. If the direction of the entity is away from the vertex of the angle, then the dimension is attached to the a witness line. The witness line is in line with the entity but in the direction opposite to the vertex of the angle. If the value of *ShouldFlip* is TRUE then the above cases are reversed.

The method

pfcDimension2D.Dimension2D.PointToAngleDimensionSense_Create creates a new dimension sense associated with the type DIMSENSE_POINT_TO_ANGLE. The dimension is the angle between a line entity and the tangent to a curved entity. The curve attachment is of the type DIMSENSE_POINT_TO_ANGLE and the line attachment is of the type DIMSENSE_POINT. In this case both the "angle" and the "angle_sense" fields must be set. The field "sense" shows which end of the curve the dimension is attached to and the field "angle_sense" shows the direction in which the dimension rotates and to which side of the tangent it attaches.

Drawing Dimensions Information

Methods Introduced:

- **pfcDimension2D.Dimension2D.GetIsAssociative**
- **pfcDimension2D.Dimension2D.GetIsReference**
- **pfcDimension2D.Dimension2D.GetIsDisplayed**
- **pfcDimension2D.Dimension2D.GetAttachmentPoints**
- **pfcDimension2D.Dimension2D.GetDimensionSenses**
- **pfcDimension2D.Dimension2D.GetOrientationHint**
- **pfcDimension2D.Dimension2D.GetBaselineDimension**
- **pfcDimension2D.Dimension2D.GetLocation**
- **pfcDimension2D.Dimension2D.GetView**
- **pfcDimension2D.Dimension2D.GetTolerance**
- **pfcDimension2D.Dimension2D.GetIsToleranceDisplayed**

The method **pfcDimension2D.Dimension2D.GetIsAssociative** returns whether the dimension or reference dimension in a drawing is associative.

The method **pfcDimension2D.Dimension2D.GetIsReference** determines whether the drawing dimension is a reference dimension.

The method **pfcDimension2D.Dimension2D.GetIsDisplayed** determines whether the dimension will be displayed in the drawing.

The method

pfcDimension2D.Dimension2D.GetAttachmentPoints returns a sequence of attachment points. The dimension senses array returned by the method

pfcDimension2D.Dimension2D.GetDimensionSenses gives more information on how these attachments are interpreted.

The method

pfcDimension2D.Dimension2D.GetDimensionSenses returns a sequence of dimension senses, describing how the dimension is attached to each attachment returned by the method **pfcDimension2D.Dimension2D.GetAttachmentPoints**.

The method

pfcDimension2D.Dimension2D.GetOrientationHint returns the orientation hint for placing the drawing dimensions. The orientation hint determines how Pro/ENGINEER will orient the dimension with respect to the attachment points.

Note: This methods described above are applicable only for dimensions created in the drawing mode. It does not support dimensions created at intersection points of entities.

The method

pfcDimension2D.Dimension2D.GetBaselineDimension returns an ordinate baseline drawing dimension. It returns a null value if the dimension is not an ordinate dimension.

Note: The method updates the display of the dimension only if it is currently displayed.

The method **pfcDimension2D.Dimension2D.GetLocation** returns the placement location of the dimension.

The method **pfcDimension2D.Dimension2D.GetView** returns the drawing view in which the dimension is displayed. This method applies to dimensions stored in the solid or in the drawing.

The method **pfcDimension2D.Dimension2D.GetTolerance** retrieves the upper and lower tolerance limits of the drawing dimension in the form of the **DimTolerance** object. A null value indicates a nominal tolerance.

Use the method

pfcDimension2D.Dimension2D.GetIsToleranceDisplayed determines whether or not the dimension's tolerance is displayed in the drawing.

Drawing Dimensions Operations

Methods Introduced:

- **pfcDimension2D.Dimension2D.ConvertToLinear**
- **pfcDimension2D.Dimension2D.ConvertToOrdinate**
- **pfcDimension2D.Dimension2D.ConvertToBaseline**
- **pfcDimension2D.Dimension2D.SetLocation**
- **pfcDimension2D.Dimension2D.SwitchView**
- **pfcDimension2D.Dimension2D.SetTolerance**
- **pfcDimension2D.Dimension2D.EraseFromModel2D**
- **pfcModel2D.Model2D.SetViewDisplaying**

The method **pfcDimension2D.Dimension2D.ConvertToLinear** converts an ordinate drawing dimension to a linear drawing dimension. The drawing containing the dimension must be displayed.

The method **pfcDimension2D.Dimension2D.ConvertToOrdinate** converts a linear drawing dimension to an ordinate baseline dimension.

The method **pfcDimension2D.Dimension2D.ConvertToBaseline** converts a location on a linear drawing dimension to an ordinate baseline dimension. The method returns the newly created baseline dimension.

Note: The method updates the display of the dimension only if it is currently displayed.

The method **pfcDimension2D.Dimension2D.SetLocation** sets the placement location of a dimension or reference dimension in a drawing.

The method **pfcDimension2D.Dimension2D.SwitchView** changes the view where a dimension created in the drawing is displayed.

The method **pfcDimension2D.Dimension2D.SetTolerance** assigns the upper and lower tolerance limits of the drawing dimension.

The method **pfcDimension2D.Dimension2D.EraseFromModel2D** permanently erases the dimension from the drawing.

The method **pfcModel2D.Model2D.SetViewDisplaying** changes the view where a dimension created in a solid model is displayed.

Example: Command Creation of Dimensions from Model Datum Points

The example below shows a command which creates vertical and horizontal ordinate dimensions from each datum point in a model in a drawing view to a selected coordinate system datum.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {

/*=====*\
FUNCTION: createPointDims()
PURPOSE : Command to create dimensions to each of the models' datum
points
\*=====*/
    public static void createPointDims() throws
com.ptc.cipjava.jxthrowable
    {

Dimension2D hBaseline = null;
Dimension2D vBaseline = null;

/*-----*\
    Select a coordinate system. This defines the model (the top one
    in that view), and the common attachments for the dimensions
\*-----*/
```

```

Session session = pfcGlobal.GetProESession ();

SelectionOptions selOptions =
    pfcSelect.SelectionOptions_Create("csys");
selOptions.SetMaxNumSels (new Integer (1));
Selections selections = session.Select (selOptions, null);

if (selections == null || selections.getarraysize() == 0)
    return;

/*-----*\
    Extract the csys handle, and assembly path, and view handle.
\*-----*/
Selection csysSel = selections.get (0);
ModelItem selItem = csysSel.GetSelItem();
ComponentPath selPath = csysSel.GetPath();
View2D selView = csysSel.GetSelView2D();
Point3D selPos = csysSel.GetPoint();

if (selView == null)
    throw new RuntimeException ("Must select coordinate system from a
                                drawing view.");

Model2D drawing = (Model2D)selView.GetDBParent();

/*-----*\
    Get the root solid, and the transform from the root to the
    component owning the csys
\*-----*/

Transform3D asmTransf = null;
Solid rootSolid = (Solid)selItem.GetDBParent();
if (selPath != null)
{
    rootSolid = (Solid)selPath.GetRoot();
    asmTransf = selPath.GetTransform(true);
}

/*-----*\
    Get a list of datum points in the model
\*-----*/

ModelItems points =
    rootSolid.ListItems (ModelItemType.ITEM_POINT);

if (points == null || points.getarraysize() == 0)
    return;

/*-----*\
    Calculate where the csys is located on the drawing
\*-----*/

Point3D csysPos = selPos;

```



```

if (asmTransf != null)
{
csysPos = asmTransf.TransformPoint (selPos);
}
Transform3D viewTransf = selView.GetTransform();
csysPos = viewTransf.TransformPoint (csysPos);

Vector2D csys3DPos = Vector2D.create ();
csys3DPos.set (0, csysPos.get (0));
csys3DPos.set (1, csysPos.get (1));

/*-----*\
  Get the view outline
  \*-----*/
Outline3D outline = selView.GetOutline();

/*-----*\
  Allocate the attachment arrays
  \*-----*/
DimensionSenses senses = DimensionSenses.create();
Selections attachments = Selections.create();

/*-----*\
  For each datum point...
  \*-----*/
for(int p=0; p<points.getarraysize(); p++)
{

/*-----*\
  Calculate the position of the point on the drawing
  \*-----*/
Point point = (Point)points.get (p);
Point3D pntPos = point.GetPoint ();

pntPos = viewTransf.TransformPoint (pntPos);

/*-----*\
  Set up the "sense" information
  \*-----*/
PointDimensionSense sense1 =
  pfcDimension2D.PointDimensionSense_Create
  (DimensionPointType.DIMPOINT_CENTER);
senses.set (0, sense1);
PointDimensionSense sense2 =
  pfcDimension2D.PointDimensionSense_Create
  (DimensionPointType.DIMPOINT_CENTER);
senses.set (1, sense2);

/*-----*\
  Set the attachment information
  \*-----*/

```

```

Selection pntSel = pfcSelect.CreateModelItemSelection (point, null);
pntSel.SetSelView2D(selView);
attachments.set (0, pntSel);
attachments.set (1, csysSel);

/*-----*\
  Calculate the dim position to be just to the left of the
  drawing view, midway between the point and csys
\*-----*/
Vector2D dimPos = Vector2D.create ();
dimPos.set (0, outline.get (0).get (0) - 20.0);
dimPos.set (1, (csysPos.get (1) + pntPos.get (1))/2.0);

/*-----*\
  Create and display the dimension
\*-----*/
DrawingDimCreateInstructions createInstrs =
    pfcDimension2D.DrawingDimCreateInstructions_Create (attachments,
senses,
dimPos,
OrientationHint.ORIENTHINT_VERTICAL);
Dimension2D dim = drawing.CreateDrawingDimension (createInstrs);

DrawingDimensionShowInstructions showInstrs =
    pfcView2D.DrawingDimensionShowInstructions_Create (selView, null);
dim.Show (showInstrs);

/*-----*\
  If this is the first vertical dim, create an ordinate base
  line from it, else just convert it to ordinate
\*-----*/
if(p==0)
{
//dimPos.set (0, csysPos.get (0));
//dimPos.set (1, csysPos.get (1));
vBaseline = dim.ConvertToBaseline (csys3DPos);
}

else
    dim.ConvertToOrdinate (vBaseline);

/*-----*\
  Set this dimension to be horizontal
\*-----*/
createInstrs.SetOrientationHint (OrientationHint.ORIENTHINT_HORIZONTAL);
/*-----*\
  Calculate the dim position to be just to the bottom of the
  drawing view, midway between the point and csys
\*-----*/
dimPos.set (0, (csysPos.get (0) + pntPos.get (0))/2.0);
dimPos.set (1, outline.get (1).get (1) - 20.0);

```

```

createInstrs.SetTextLocation (dimPos);

/*-----*\
  Create and display the dimension
  \*-----*/
dim = drawing.CreateDrawingDimension (createInstrs);
dim.Show (showInstrs);

/*-----*\
  If this is the first horizontal dim, create an ordinate base line
  from it, else just convert it to ordinate
  \*-----*/
if(p==0)
{
//dimPos.set (0, csysPos.get (0));
//dimPos.set (1, csysPos.get (1));
hBaseline = dim.ConvertToBaseline (csys3DPos);
}
else
  dim.ConvertToOrdinate (hBaseline);
}
}
}

```

Drawing Tables

A drawing table in J-Link is represented by the interface **com.ptc.pfc.pfcTable.Table**. It is a child of the **ModelItem** interface.

Some drawing table methods operate on specific rows or columns. The row and column numbers in J-Link begin with 1 and range up to the total number of rows or columns in the table. Some drawing table methods operate on specific table cells. The interface **com.ptc.pfc.pfcTable.TableCell** is used to represent a drawing table cell.

Creating Drawing Cells

Method Introduced:

- **pfcTable.pfcTable.TableCell_Create**

The method **pfcTable.pfcTable.TableCell_Create** creates the **TableCell** object representing a cell in the drawing table.

Some drawing table methods operate on specific drawing segment. A multisegmented drawing table contains 2 or more areas in the drawing. Inserting or deleting rows in one segment of the table can affect the contents of other segments. Table segments are numbered beginning with 0. If the table has only a single segment, use 0 as the segment id in the relevant methods.

Selecting Drawing Tables and Cells

Methods Introduced:

- **pfcSession.BaseSession.Select**
- **pfcSelect.Selection.GetSelItem**
- **pfcSelect.Selection.GetSelTableCell**
- **pfcSelect.Selection.GetSelTableSegment**

Tables may be selected using the method **pfcSession.BaseSession.Select**. Pass the filter `dwg_table` to select an entire table and the filter `table_cell` to prompt the user to select a particular table cell.

The method **pfcSelect.Selection.GetSelItem** returns the selected table handle. It is a model item that can be cast to a **Table** object.

The method **pfcSelect.Selection.GetSelTableCell** returns the row and column indices of the selected table cell.

The method **pfcSelect.Selection.GetSelTableSegment** returns the table segment identifier for the selected table cell. If the table consists of a single segment, this method returns the identifier 0.

Creating Drawing Tables

Methods Introduced:

- **pfcTable.pfcTable.TableCreateInstructions_Create**
- **pfcTable.TableOwner.CreateTable**

The method **pfcTable.pfcTable.TableCreateInstructions_Create** creates the **TableCreateInstructions** data object that describes how to construct a new table using the method **pfcTable.TableOwner.CreateTable**.

The parameters of the instructions data object are:

- *Origin*—This parameter stores a three dimensional point specifying the location of the table origin. The origin is the position of the top left corner of the table.
- *RowHeights*—Specifies the height of each row of the table.
- *ColumnData*—Specifies the width of each column of the table and its justification.
- *SizeTypes*—Indicates the scale used to measure the column width and row height of the table.

The method **pfcTable.TableOwner.CreateTable** creates a table in the drawing specified by the **TableCreateInstructions** data object.

Retrieving Drawing Tables

Methods Introduced

- **pfcTable.pfcTable.TableRetrieveInstructions_Create**
- **pfcTable.TableOwner.RetrieveTable**

The method **pfcTable.pfcTable.TableRetrieveInstructions_Create** creates the **TableRetrieveInstructions** data object that describes how to retrieve a drawing table using the method **pfcTable.TableOwner.RetrieveTable**. The method returns the created instructions data object.

The parameters of the instruction object are:

- *FileName*—Name of the file containing the drawing table.
- *Position*—The location of left top corner of the retrieved table.

The method **pfcTable.TableOwner.RetrieveTable** retrieves a table specified by the **TableRetrieveInstructions** data object from a file on the disk. It returns the retrieved table. The data object contains information on the table to retrieve and is returned by the method **pfcTable.pfcTable.TableRetrieveInstructions_Create**.

Drawing Tables Information

Methods Introduced:

- **pfcTable.TableOwner.ListTables**
- **pfcTable.TableOwner.GetTable**
- **pfcTable.Table.GetRowCount**
- **pfcTable.Table.GetColumnCount**
- **pfcTable.Table.CheckIfIsFromFormat**
- **pfcTable.Table.GetRowSize**
- **pfcTable.Table.GetColumnSize**
- **pfcTable.Table.GetText**
- **pfcTable.Table.GetCellNote**

The method **pfcTable.TableOwner.ListTables** returns a sequence of tables found in the model.

The method **pfcTable.TableOwner.GetTable** returns a table specified by the table identifier in the model. It returns a null value if the table is not found.

The method **pfcTable.Table.GetRowCount** returns the number of rows in the table.

The method **pfcTable.Table.GetColumnCount** returns the number of columns in the table.

The method **pfcTable.Table.CheckIfIsFromFormat** verifies if the drawing table was created using the format of the drawing sheet specified by the sheet number. The method returns a true value if the table was created by applying the drawing format.

The method **pfcTable.Table.GetRowSize** returns the height of the drawing table row specified by the segment identifier and the row number.

The method **pfcTable.Table.GetColumnSize** returns the width of the drawing table column specified by the segment identifier and the column number.

The method **pfcTable.Table.GetText** returns the sequence of text in a drawing table cell. Set the value of the parameter *Mode* to `DWGTABLE_NORMAL` to get the text as displayed on the screen. Set it to `DWGTABLE_FULL` to get symbolic text, which includes the names of parameter references in the table text.

The method **pfcTable.Table.GetCellNote** returns the detail note item contained in the table cell.

Drawing Tables Operations

Methods Introduced:

- **pfcTable.Table.Erase**
- **pfcTable.Table.Display**
- **pfcTable.Table.RotateClockwise**
- **pfcTable.Table.InsertRow**
- **pfcTable.Table.InsertColumn**
- **pfcTable.Table.MergeRegion**
- **pfcTable.Table.SubdivideRegion**
- **pfcTable.Table.DeleteRow**
- **pfcTable.Table.DeleteColumn**
- **pfcTable.Table.SetText**
- **pfcTable.TableOwner.DeleteTable**

The method **pfcTable.Table.Erase** erases the specified table temporarily from the display. It still exists in the drawing. The erased table can be displayed again using the method **pfcTable.Table.Display**. The table will also be redisplayed by a window repaint or a regeneration of the drawing. Use these methods to hide a table from the display while you are making multiple changes to the table.

The method **pfcTable.Table.RotateClockwise** rotates a table clockwise by the specified amount of rotation.

The method **pfcTable.Table.InsertRow** inserts a new row in the drawing table. Set the value of the parameter *RowHeight* to specify the height of the row. Set the value of the parameter *InsertAfterRow* to specify the row number after which the new row has to be inserted. Specify 0 to insert a new first row.

The method **pfcTable.Table.InsertColumn** inserts a new column in the drawing table. Set the value of the parameter *ColumnWidth* to specify the width of the column. Set the value of the parameter *InsertAfterColumn* to specify the column number after which the new column has to be inserted. Specify 0 to insert a new first column.

The method **pfcTable.Table.MergeRegion** merges table cells within a specified range of rows and columns to form a single cell. The range is a rectangular region specified by the table cell on the upper left of the region and the table cell on the lower right of the region.

The method **pfcTable.Table.SubdivideRegion** removes merges from a region of table cells that were previously merged. The region to remove merges is specified by the table cell on the upper left of the region and the table cell on the lower right of the region.

The methods **pfcTable.Table.DeleteRow** and **pfcTable.Table.DeleteColumn** delete any specified row or column from the table. The methods also remove the text from the affected cells.

The method **pfcTable.Table.SetText** sets text in the table cell.

Use the method **pfcTable.TableOwner.DeleteTable** to delete a specified drawing table from the model permanently. The deleted table cannot be displayed again.

Note: Many of the above methods provide a parameter *Repaint*. If this is set to true the table will be repainted after the change. If set to false or null Pro/ENGINEER will delay the repaint, allowing you to perform several operations before showing changes on the screen.

Example: Creation of a Table Listing Datum Points

The following example creates a drawing table that lists the datum points in a model shown in a drawing view.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
```

```

import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;
public class pfcDrawingExamples {

/*=====*\
FUNCTION : createTableOfPoints()
PURPOSE  : Command to create a table of points
\*=====*/
    public static void createTableOfPoints()
        throws com.ptc.cipjava.jxthrowable
    {

        double[] widths = new double [4];
        widths [0] = 8.0;
        widths [1] = 10.0;
        widths [2] = 10.0;
        widths [3] = 10.0;

/*-----*\
    Select a coordinate system. This defines the model (the top one
    in that view), and the reference for the datum point positions.
\*-----*/
        Session session = pfcGlobal.GetProESession ();

        SelectionOptions selOptions =
            pfcSelect.SelectionOptions_Create("csys");
        selOptions.SetMaxNumSels (new Integer (1));
        Selections selections = session.Select (selOptions, null);

        if (selections == null || selections.getarraysize() == 0)
            return;

/*-----*\
    Extract the csys handle, and assembly path, and view handle.
\*-----*/
        ModelItem selItem = selections.get (0).GetSelItem();
        ComponentPath selPath = selections.get (0).GetPath();
        View2D selView = selections.get (0).GetSelView2D();

        if (selView == null)
            throw new RuntimeException ("Must select coordinate system from a
            drawing view.");

        Model2D drawing = (Model2D)selView.GetDBParent();

/*-----*\
    Extract the csys location (property CoordSys from class CoordSystem)
\*-----*/
        CoordSystem csys = (CoordSystem) selItem;

```

```

    Transform3D csysTransf = csys.GetCoordSys();
    csysTransf.Invert ();

/*-----*\
    Extract the cys name
/*-----*\
    String csysName = selItem.GetName();

/*-----*\
    Get the root solid, and the transform from the root to the
    component owning the csys
/*-----*\

    Transform3D asmTransf = null;
    Solid rootSolid = (Solid)selItem.GetDBParent();
    if (selPath != null)
    {
        rootSolid = (Solid)selPath.GetRoot();
        asmTransf = selPath.GetTransform(false);
    }

/*-----*\
    Get a list of datum points in the model
/*-----*\

    ModelItems points =
        rootSolid.ListItems (ModelItemType.ITEM_POINT);

    if (points == null || points.getarraysize() == 0)
        return;

/*-----*\
    Set the table position
/*-----*\
    Point3D location = Point3D.create();
    location.set (0, 500.0);
    location.set (1, 500.0);
    location.set (2, 0.0);

/*-----*\
    Setup the table creation instructions
/*-----*\
    TableCreateInstructions instrs =
        pfcTable.TableCreateInstructions_Create (location);

    instrs.SetSizeType (TableSizeType.TABLESIZE_BY_NUM_CHARS);

    ColumnCreateOptions columnInfo = ColumnCreateOptions.create();

    for (int i = 0; i < Array.getLength (widths); i++)
    {

```

```

        ColumnCreateOption column =
            pfcTable.ColumnCreateOption_Create
                (ColumnJustification.COL_JUSTIFY_LEFT,
                 widths [i]);
        columnInfo.insert (columnInfo.getarraysize(), column);
    }
instrs.SetColumnData (columnInfo);

realseq rowInfo = realseq.create();

for (int i = 0; i < points.getarraysize() + 2; i++)
{
    rowInfo.insert (rowInfo.getarraysize(), 1.0);
}
instrs.SetRowHeights (rowInfo);

/*-----*\
Create the table
\*-----*/
    Table dwgTable = drawing.CreateTable (instrs);

/*-----*\
Merge the top row cells to form the header
\*-----*/
    TableCell topLeft = pfcTable.TableCell_Create (1, 1);
    TableCell bottomRight = pfcTable.TableCell_Create (1, 4);
    dwgTable.MergeRegion (topLeft, bottomRight, null);

/*-----*\
Write header text specifying model and csys
\*-----*/
    writeTextInCell (dwgTable, 1, 1,
        "Datum points for " + rootSolid.GetFullName() +
        " w.r.t. csys "+csysName);

/*-----*\
Add subheadings to columns
\*-----*/
    writeTextInCell (dwgTable, 2, 1, "Point");
    writeTextInCell (dwgTable, 2, 2, "X");
    writeTextInCell (dwgTable, 2, 3, "Y");
    writeTextInCell (dwgTable, 2, 4, "Z");

/*-----*\
For each datum point...
\*-----*/
    for (int p=0; p<points.getarraysize(); p++)
    {
        Point geomPoint = (Point) points.get(p);
/*-----*\
Add the point name to column 1

```

```

/*-----*/
    writeTextInCell (dwgTable, p+3, 1, geomPoint.GetName());
/*-----*/
/*-----*/
    Transform the location w.r.t to the csys
/*-----*/
    Point3D trfPoint = geomPoint.GetPoint();
    if (asmTransf != null)
        trfPoint =
            asmTransf.TransformPoint (geomPoint.GetPoint());
    trfPoint = csysTransf.TransformPoint (trfPoint);

/*-----*/
    Add the XYZ to column 3,4,5
/*-----*/
    DecimalFormat format = new DecimalFormat ("#,##0.000");
    StringBuffer buffer = new StringBuffer();
    FieldPosition position =
        new FieldPosition (NumberFormat.FRACTION_FIELD);


    format.format (trfPoint.get(0), buffer, position);
    writeTextInCell (dwgTable, p+3, 2, buffer.toString());
    buffer = new StringBuffer();
    format.format (trfPoint.get(1), buffer, position);
    writeTextInCell (dwgTable, p+3, 3, buffer.toString());

    buffer = new StringBuffer();
    format.format (trfPoint.get(2), buffer, position);
    writeTextInCell (dwgTable, p+3, 4, buffer.toString());
}
/*-----*/
    Display the table
/*-----*/
    dwgTable.Display ();
}

/*=====*/
FUNCTION : writeTextInCell()
PURPOSE  : Utility to add one text line to a table cell
/*=====*/
    private static void writeTextInCell(Table table, int row,
        int col, String text)
        throws com.ptc.cipjava.jxthrowable
    {
        TableCell cell = pfcTable.TableCell_Create (row, col);
        stringseq lines = stringseq.create();
        lines.insert (0, text);

        table.SetText (cell, lines);
    }
}

```



Drawing Table Segments

Drawing tables can be constructed with one or more segments. Each segment can be independently placed. The segments are specified by an integer identifier starting with 0.

Methods Introduced:

- **pfcSelect.Selection.GetSelTableSegment**
- **pfcTable.Table.GetSegmentCount**
- **pfcTable.Table.GetSegmentSheet**
- **pfcTable.Table.MoveSegment**
- **pfcTable.Table.GetInfo**

The method **pfcSelect.Selection.GetSelTableSegment** returns the value of the segment identifier of the selected table segment. It returns a null value if the selection does not contain a segment identifier.

The method **pfcTable.Table.GetSegmentCount** returns the number of segments in the table.

The method **pfcTable.Table.GetSegmentSheet** determines the sheet number that contains a specified drawing table segment.

The method **pfcTable.Table.MoveSegment** moves a drawing table segment to a new location. Pass the co-ordinates of the target position in the format x, y, z=0.

Note: Set the value of the parameter *Repaint* to true to repaint the drawing with the changes. Set it to false or null to delay the repaint.

To get information about a drawing table pass the value of the segment identifier as input to the method **pfcTable.Table.GetInfo**. The method returns the table information including the rotation, row and column information, and the 3D outline.

Repeat Regions

Methods Introduced:

- **pfcTable.Table.IsCommentCell**
- **pfcTable.Table.GetCellComponentModel**
- **pfcTable.Table.GetCellReferenceModel**
- **pfcTable.Table.GetCellTopModel**
- **pfcTable.TableOwner.UpdateTables**

The methods **pfcTable.Table.IsCommentCell**, **pfcTable.Table.GetCellComponentModel**, **pfcTable.Table.GetCellReferenceModel**, **pfcTable.Table.GetCellTopModel**, and **pfcTable.TableOwner.UpdateTables** apply to repeat regions in drawing tables.

The method **pfcTable.Table.IsCommentCell** tells you whether a cell in a repeat region contains a comment.

The method **pfcTable.Table.GetCellComponentModel** returns the path to the assembly component model that is being referenced by a cell in a repeat region of a drawing table. It does not return a valid path if the cell attribute is set to "NO DUPLICATE" or "NO DUPLICATE/LEVEL".

The method **pfcTable.Table.GetCellReferenceModel** returns the reference component that is being referred to by a cell in a repeat region of a drawing table, even if cell attribute is set to "NO DUPLICATE" or "NO DUPLICATE/LEVEL".

The method **pfcTable.Table.GetCellTopModel** returns the top model that is being referred to by a cell in a repeat region of a drawing table, even if cell attribute is set to "NO DUPLICATE" or "NO DUPLICATE/LEVEL".

Use the method **pfcTable.TableOwner.UpdateTables** to update the repeat regions in all the tables to account for changes to the model. It is equivalent to the command **Table, Repeat Region, Update**.

Detail Items

The methods described in this section operate on detail items.

In J-Link you can create, delete and modify detail items, control their display, and query what detail items are present in the drawing. The types of detail items available are:

- Draft Entities—Contain graphical items created in Pro/Engineer. The items are as follows:
 - Arc
 - Ellipse
 - Line
 - Point
 - Polygon
 - Spline
- Notes—Textual annotations
- Symbol Definitions—Contained in the drawing's symbol gallery.
- Symbol Instances—Instances of a symbol placed in a drawing.
- Draft Groups—Groups of detail items that contain notes, symbol instances, and draft entities.
- OLE objects—Object Linking and Embedding (OLE) objects embedded in the Pro/ENGINEER drawing file.

Listing Detail Items

Methods Introduced:

- **pfcModelItem.ModelItemOwner.ListItems**
- **pfcDetail.DetailItemOwner.ListDetailItems**
- **pfcModelItem.ModelItemOwner.GetItemById**
- **pfcDetail.DetailItemOwner.CreateDetailItem**

The method **pfcModelItem.ModelItemOwner.ListItems** returns a list of detail items specified by the parameter *Type* or returns null if no detail items of the specified type are found.

The values of the parameter *Type* for detail items are:

- ITEM_DTL_ENTITY—Detail Entity
- ITEM_DTL_NOTE—Detail Note
- ITEM_DTL_GROUP—Draft Group
- ITEM_DTL_SYM_DEFINITION—Detail Symbol Definition
- ITEM_DTL_SYM_INSTANCE—Detail Symbol Instance
- ITEM_DTL_OLE_OBJECT—Drawing embedded OLE object

If this parameter is set to null, then all the model items in the drawing are listed.

The method **pfcDetail.DetailItemOwner.ListDetailItems** also lists the detail items in the model. Pass the type of the detail item and the sheet number that contains the specified detail items.

Set the input parameter *Type* to the type of detail item to be listed. Set it to null to return all the detail items. The input parameter *SheetNumber* determines the sheet that contains the specified detail item. Pass null to search all the sheets. This argument is ignored if the parameter *Type* is set to DETAIL_SYM_DEFINITION.

The method returns a sequence of detail items and returns a null if no items matching the input values are found.

The method **pfcModelItem.ModelItemOwner.GetItemById** returns a detail item based on the type of the detail item and its integer identifier. The method returns a null if a detail item with the specified attributes is not found.

Creating a Detail Item

Methods Introduced:

- **pfcDetail.DetailItemOwner.CreateDetailItem**
- **pfcDetail.pfcDetailGroupInstructions.Create**

The method **pfcDetail.DetailItemOwner.CreateDetailItem** creates a new detail item based on the instruction data object that describes the type and content of the new detail item. The instructions data object is returned by the method **pfcDetail.pfcDetailGroupInstructions.Create**. The method returns the newly created detail item.

Detail Entities

A detail entity in J-Link is represented by the interface **com.ptc.pfc.pfcDetail.DetailEntityItem**. It is a child of the **DetailItem** interface.

The interface **com.ptc.pfc.pfcDetail.DetailEntityInstructions** contains specific information used to describe a detail entity item.

Instructions

Methods Introduced:

- **pfcDetail.pfcDetail.DetailEntityInstructions_Create**
- **pfcDetail.DetailEntityInstructions.GetGeometry**
- **pfcDetail.DetailEntityInstructions.SetGeometry**
- **pfcDetail.DetailEntityInstructions.GetIsConstruction**
- **pfcDetail.DetailEntityInstructions.SetIsConstruction**
- **pfcDetail.DetailEntityInstructions.GetColor**
- **pfcDetail.DetailEntityInstructions.SetColor**
- **pfcDetail.DetailEntityInstructions.GetFontName**
- **pfcDetail.DetailEntityInstructions.SetFontName**
- **pfcDetail.DetailEntityInstructions.GetWidth**
- **pfcDetail.DetailEntityInstructions.SetWidth**
- **pfcDetail.DetailEntityInstructions.GetView**
- **pfcDetail.DetailEntityInstructions.SetView**

The method **pfcDetail.pfcDetail.DetailEntityInstructions_Create** creates an instructions object that describes how to construct a detail entity, for use in the methods **pfcDetail.DetailItemOwner.CreateDetailItem**, **pfcDetail.DetailSymbolDefItem.CreateDetailItem**, and **pfcDetail.DetailEntityItem.Modify**.

The instructions object is created based on the curve geometry and the drawing view associated with the entity. The curve geometry describes the trajectory of the detail entity in world units. The drawing view can be a model view returned by the method **pfcModel2D.Model2D.List2DViews** or a drawing sheet background view returned by the method **pfcSheet.SheetOwner.GetSheetBackgroundView**. The background view indicates that the entity is not associated with a particular model view.

The method returns the created instructions object.

Note: Changes to the values of a **pfcDetail.DetailEntityInstructions** object do not take effect until that instructions object is used to modify the entity using **pfcDetail.DetailEntityItem.Modify**.

The method **pfcDetail.DetailEntityInstructions.GetGeometry** returns the geometry of the detail entity item.

The method **pfcDetail.DetailEntityInstructions.SetGeometry** sets the geometry of the detail entity item. For more information refer to Curve Descriptors.

The method **pfcDetail.DetailEntityInstructions.GetIsConstruction** returns a value that specifies whether the entity is a construction entity.

The method **pfcDetail.DetailEntityInstructions.SetIsConstruction** specifies if the detail entity is a construction entity.

The method **pfcDetail.DetailEntityInstructions.GetColor** returns the color of the detail entity item.

The method **pfcDetail.DetailEntityInstructions.SetColor** sets the color of the detail entity item. Pass null to use the default drawing color.

The method **pfcDetail.DetailEntityInstructions.GetFontName** returns the line style used to draw the entity. The method returns a null value if the default line style is used.

The method **pfcDetail.DetailEntityInstructions.SetFontName** sets the line style for the detail entity item. Pass null to use the default line style.

The method **pfcDetail.DetailEntityInstructions.GetWidth** returns the value of the width of the entity line. The method returns a null value if the default line width is used.

The method **pfcDetail.DetailEntityInstructions.SetWidth** specifies the width of the entity line. Pass null to use the default line width.

The method **pfcDetail.DetailEntityInstructions.GetView** returns the drawing view associated with the entity. The view can either be a model view or a drawing sheet background view.

The method **pfcDetail.DetailEntityInstructions.SetView** sets the drawing view associated with the entity. The view can either be a model view or a drawing sheet background view.

Example: Create a Draft Line with Predefined Color

The following example shows a utility that creates a draft line in one of the colors predefined in Pro/ENGINEER.

```
import com.ptc.cipjava.*;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;

import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {

/*=====*\
FUNCTION : createLineEntity()
PURPOSE  : Utility to create a line entity between specified points
```

```

\*=====*/
public static void createLineEntity() throws
com.ptc.cipjava.jxthrowable
{
    StdColor color = StdColor.COLOR_QUILT;
    Session session = pfcGlobal.GetProESession ();

/*-----*/
    Get the current drawing & its background view
/*-----*/
    Model model = session.GetCurrentModel();

    if (model.GetType() != ModelType.MDL_DRAWING)
        throw new RuntimeException ("Current model is not a drawing");

    Drawing drawing = (Drawing) model;

    int currSheet = drawing.GetCurrentSheetNumber();
    View2D view = drawing.GetSheetBackgroundView (currSheet);

/*-----*/
    Select the endpoints of the line
/*-----*/
    MouseStatus mouse1 =
        session.UIGetNextMousePick (MouseButton.MOUSE_BTN_LEFT);
    Point3D start = mouse1.GetPosition();
    MouseStatus mouse2 =
        session.UIGetNextMousePick (MouseButton.MOUSE_BTN_LEFT);
    Point3D end = mouse2.GetPosition();

/*-----*/
    Allocate and initialize a curve descriptor
/*-----*/
    LineDescriptor geom = pfcGeometry.LineDescriptor_Create (start, end);
/*-----*/
    Allocate data for the draft entity
/*-----*/
    DetailEntityInstructions instrs =
        pfcDetail.DetailEntityInstructions_Create (geom,
                                                    view);

/*-----*/
    Set the color to the specified Pro/ENGINEER predefined color
/*-----*/
    ColorRGB rgb = session.GetRGBFromStdColor (color);
    instrs.SetColor(rgb);

/*-----*/
    Create the entity
/*-----*/
    drawing.CreateDetailItem (instrs);

```

```

/*-----*\
  Display the entity
/*-----*\
    session.GetCurrentWindow().Repaint();
    }
}

```

Detail Entities Information

Methods Introduced:

- **pfcDetail.DetailEntityItem.GetInstructions**
- **pfcDetail.DetailEntityItem.GetSymbolDef**

The method **pfcDetail.DetailEntityItem.GetInstructions** returns the instructions data object that is used to construct the detail entity item.

The method **pfcDetail.DetailEntityItem.GetSymbolDef** returns the symbol definition that contains the entity. This method returns a null value if the entity is not a part of a symbol definition.

Detail Entities Operations

Methods Introduced:

- **pfcDetail.DetailEntityItem.Draw**
- **pfcDetail.DetailEntityItem.Erase**
- **pfcDetail.DetailEntityItem.Modify**

The method **pfcDetail.DetailEntityItem.Draw** temporarily draws a detail entity item, so that it is removed during the next draft regeneration.

The method **pfcDetail.DetailEntityItem.Erase** undraws a detail entity item temporarily, so that it is redrawn during the next draft regeneration.

The method **pfcDetail.DetailEntityItem.Modify** modifies the definition of an entity item using the specified instructions data object.

OLE Objects

An object linking and embedding (OLE) object is an external file, such as a document, graphics file, or video file that is created using an external application and which can be inserted into another application, such as Pro/ENGINEER. You can create and insert supported OLE objects into a two-dimensional Pro/ENGINEER file, such as a drawing, report, format file, layout, or diagram. The functions described in this section enable you to identify and access OLE objects embedded in drawings.

Methods Introduced:

- **pfcDetail.DetailOLEObject.GetApplicationType**
- **pfcDetail.DetailOLEObject.GetOutline**
- **pfcDetail.DetailOLEObject.GetPath**
- **pfcDetail.DetailOLEObject.GetSheet**

The method **pfcDetail.DetailOLEObject.GetApplicationType** returns the type of the OLE object as a string, for example, "Microsoft Word Document".

The method **pfcDetail.DetailOLEObject.GetOutline** returns the extent of the OLE object embedded in the drawing.

The method **pfcDetail.DetailOLEObject.GetPath** returns the path to the external file for each OLE object, if it is linked to an external file.

The method **pfcDetail.DetailOLEObject.GetSheet** returns the sheet number for the OLE object.

Detail Notes

A detail note in J-Link is represented by the interface **com.ptc.pfc.pfcDetail.DetailNoteItem**. It is a child of the **DetailItem** interface.

The interface **com.ptc.pfc.pfcDetail.DetailNoteInstructions** contains specific information that describes a detail note.

Instructions

Methods Introduced:

- **pfcDetail.pfcDetail.DetailNoteInstructions_Create**
- **pfcDetail.DetailNoteInstructions.GetTextLines**
- **pfcDetail.DetailNoteInstructions.SetTextLines**
- **pfcDetail.DetailNoteInstructions.GetIsDisplayed**
- **pfcDetail.DetailNoteInstructions.SetIsDisplayed**
- **pfcDetail.DetailNoteInstructions.GetIsReadOnly**
- **pfcDetail.DetailNoteInstructions.SetIsReadOnly**
- **pfcDetail.DetailNoteInstructions.GetIsMirrored**
- **pfcDetail.DetailNoteInstructions.SetIsMirrored**
- **pfcDetail.DetailNoteInstructions.GetHorizontal**
- **pfcDetail.DetailNoteInstructions.SetHorizontal**
- **pfcDetail.DetailNoteInstructions.GetVertical**
- **pfcDetail.DetailNoteInstructions.SetVertical**
- **pfcDetail.DetailNoteInstructions.GetColor**
- **pfcDetail.DetailNoteInstructions.SetColor**
- **pfcDetail.DetailNoteInstructions.GetLeader**
- **pfcDetail.DetailNoteInstructions.SetLeader**
- **pfcDetail.DetailNoteInstructions.GetTextAngle**
- **pfcDetail.DetailNoteInstructions.SetTextAngle**

The method

pfcDetail.pfcDetail.DetailNoteInstructions_Create creates a data object that describes how a detail note item should be constructed when passed to the methods **pfcDetail.DetailItemOwner.CreateDetailItem**, **pfcDetail.DetailSymbolDefItem.CreateDetailItem**, or **pfcDetail.DetailNoteItem.Modify**. The parameter *inTextLines* specifies the sequence of text line data objects that describe the contents of the note.

Note: Changes to the values of a **pfcDetail.DetailNoteInstructions** object do not take effect until that instructions object is used to modify the note using **pfcDetail.DetailNoteItem.Modify**

The method **pfcDetail.DetailNoteInstructions.GetTextLines** returns the description of text line contents in the note.

The method **pfcDetail.DetailNoteInstructions.SetTextLines** sets the description of the text line contents in the note.

The method **pfcDetail.DetailNoteInstructions.GetIsDisplayed** returns a boolean indicating if the note is currently displayed.

The method **pfcDetail.DetailNoteInstructions.SetIsDisplayed** sets the display flag for the note.

The method **pfcDetail.DetailNoteInstructions.GetIsReadOnly** determines whether the note can be edited by the user, while the method **pfcDetail.DetailNoteInstructions.SetIsReadOnly** toggles the read only status of the note.

The method **pfcDetail.DetailNoteInstructions.GetIsMirrored** determines whether the note is mirrored, while the method **pfcDetail.DetailNoteInstructions.SetIsMirrored** toggles the mirrored status of the note.

The method **pfcDetail.DetailNoteInstructions.GetHorizontal** returns the value of the horizontal justification of the note, while the method **pfcDetail.DetailNoteInstructions.SetHorizontal** sets the value of the horizontal justification of the note.

The method **pfcDetail.DetailNoteInstructions.GetVertical** returns the value of the vertical justification of the note, while the method **pfcDetail.DetailNoteInstructions.SetVertical** sets the value of the vertical justification of the note.

The method **pfcDetail.DetailNoteInstructions.GetColor** returns the color of the detail note item. The method returns a null value to represent the default drawing color.

Use the method **pfcDetail.DetailNoteInstructions.SetColor** to set the color of the detail note item. Pass null to use the default drawing color.

The method **pfcDetail.DetailNoteInstructions.GetLeader** returns the locations of the detail note item and information about the leaders.

The method **pfcDetail.DetailNoteInstructions.SetLeader** sets the values of the location of the detail note item and the locations where the leaders are attached to the drawing.

The method **pfcDetail.DetailNoteInstructions.GetTextAngle** returns the value of the angle of the text used in the note. The method returns a null value if the angle is 0.0.

The method **pfcDetail.DetailNoteInstructions.SetTextAngle** sets the value of the angle of the text used in the note. Pass null to use the angle 0.0.

Example: Create Drawing Note at Specified Location with Leader to Surface and Surface Name

The following example creates a drawing note at a specified location, with a leader attached to a solid surface, and displays the name of the surface.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {

    /*=====*\
    FUNCTION : createSurfNote()
    PURPOSE  : Utility to create a note that documents the surface name or id.
               The note text will be placed at the upper right corner of the
               selected view.
    \*=====*/
    public static void createSurfNote() throws com.ptc.cipjava.jxthrowable
    {
        /*-----*\
        Get the current drawing & its background view
        \*-----*/
        Session session = pfcGlobal.GetProESession ();
        Model model = session.GetCurrentModel ();

        if (model.GetType () != ModelType.MDL_DRAWING)
```

```

        throw new RuntimeException ("Current model is not a drawing");

        Drawing drawing = (Drawing) model;
/*-----*\
    Interactively select a surface in a drawing view
\*-----*/
    SelectionOptions options =
        pfcSelect.SelectionOptions_Create ("surface");
    options.SetMaxNumSels (new Integer (1));

    Selections sels = session.Select (options, null);
    Selection selSurf = sels.get (0);
    ModelItem item = selSurf.GetSelItem();

    String name = item.GetName();
    if (name == null)
        name = new String ("Surface ID "+item.GetId());

/*-----*\
    Allocate a text item, and set its properties
\*-----*/
    DetailText text = pfcDetail.DetailText_Create (name);

/*-----*\
    Allocate a new text line, and add the text item to it
\*-----*/
    DetailTexts texts = DetailTexts.create();
    texts.insert (0, text);

    DetailTextLine textLine = pfcDetail.DetailTextLine_Create (texts);

    DetailTextLines textLines = DetailTextLines.create();
    textLines.insert (0, textLine);

/*-----*\
    Set the location of the note text
\*-----*/
    View2D dwgView = selSurf.GetSelView2D();
    Outline3D outline = dwgView.GetOutline();
    Point3D textPos = outline.get (1);

// Force the note to be slightly beyond the view outline boundary
    textPos.set (0, textPos.get (0) + 0.25 * (textPos.get (0) -
        outline.get (0).get(0)));
    textPos.set (1, textPos.get (1) + 0.25 * (textPos.get (1) -
        outline.get (0).get(1)));

    FreeAttachment position =
        pfcDetail.FreeAttachment_Create (textPos);
    position.SetView (dwgView);

```

```

/*-----*\
  Set the attachment for the note leader
/*-----*\
    ParametricAttachment leaderToSurf =
        pfcDetail.ParametricAttachment_Create (selSurf);

/*-----*\
  Set the attachment structure
/*-----*\
    DetailLeaders allAttachments = pfcDetail.DetailLeaders_Create ();
    allAttachments.SetItemAttachment (position);
    Attachments attaches = Attachments.create ();
    attaches.insert (0, leaderToSurf);
    allAttachments.SetLeaders (attaches);

/*-----*\
  Allocate a note description, and set its properties
/*-----*\
    DetailNoteInstructions instrs =
        pfcDetail.DetailNoteInstructions_Create (textLines);

    instrs.SetLeader (allAttachments);

/*-----*\
  Create the note
/*-----*\
    DetailNoteItem note =
        (DetailNoteItem) drawing.CreateDetailItem (instrs);

/*-----*\
  Display the note
/*-----*\
    note.Show ();
}
}

```

Detail Notes Information

Methods Introduced:


- **pfcDetail.DetailNoteItem.GetInstructions**
- **pfcDetail.DetailNoteItem.GetSymbolDef**
- **pfcDetail.DetailNoteItem.GetLineEnvelope**
- **pfcDetail.DetailNoteItem.GetModelReference**

The method **pfcDetail.DetailNoteItem.GetInstructions** returns an instructions data object that describes how to construct the detail note item. This method takes a *ProBoolean* argument, *GiveParametersAsNames*, which determines whether symbolic representations of parameters and drawing properties in the note text should be displayed, or the actual text seen by the user should be displayed.

Note: Pro/ENGINEER does not resolve and replace symbolic callouts for notes which are not displayed. Therefore, if the note is not displayed or is hidden in a layer, the text retrieved may contain symbolic callouts, even when *GiveParametersAsNames* is false.

The method **pfcDetail.DetailNoteItem.GetSymbolDef** returns the symbol definition that contains the note. The method returns a null value if the note is not a part of a symbol definition.

The method **pfcDetail.DetailNoteItem.GetLineEnvelope** determines the screen coordinates of the envelope around the detail note. This envelope is defined by four points. The following figure illustrates how the point order is determined.



The ordering of the points is maintained even if the notes are mirrored or are at an angle.

The method **pfcDetail.DetailNoteItem.GetModelReference** returns the model referenced by the parameterized text in a note. The model is referenced based on the line number and the text index where the parameterized text appears.

Details Notes Operations

Methods Introduced:

- **pfcDetail.DetailNoteItem.Draw**
- **pfcDetail.DetailNoteItem.Show**
- **pfcDetail.DetailNoteItem.Erase**
- **pfcDetail.DetailNoteItem.Remove**
- **pfcDetail.DetailNoteItem.Modify**

The method **pfcDetail.DetailNoteItem.Draw** temporarily draws a detail note item, so that it is removed during the next draft regeneration.

The method **pfcDetail.DetailNoteItem.Show** displays the note item, such that it is repainted during the next draft regeneration.

The method **pfcDetail.DetailNoteItem.Erase** undraws a detail note item temporarily, so that it is redrawn during the next draft regeneration.

The method **pfcDetail.DetailNoteItem.Remove** undraws a detail note item permanently, so that it is not redrawn during the next draft regeneration.

The method **pfcDetail.DetailNoteItem.Modify** modifies the definition of an existing detail note item based on the instructions object that describes the new detail note item.

Detail Groups

A detail group in J-Link is represented by the interface **com.ptc.pfc.pfcDetail.DetailGroupItem**. It is a child of the **DetailItem** interface.

The interface **com.ptc.pfc.pfcDetail.DetailGroupInstructions** contains information used to describe a detail group item.

Instructions

Method Introduced:

- **pfcDetail.pfcDetail.DetailGroupInstructions.Create**
- **pfcDetail.DetailGroupInstructions.GetName**
- **pfcDetail.DetailGroupInstructions.SetName**

- **pfcDetail.DetailGroupInstructions.GetElements**
- **pfcDetail.DetailGroupInstructions.SetElements**
- **pfcDetail.DetailGroupInstructions.GetIsDisplayed**
- **pfcDetail.DetailGroupInstructions.SetIsDisplayed**

The method

pfcDetail.pfcDetail.DetailGroupInstructions.Create creates an instruction data object that describes how to construct a detail group for use in **pfcDetail.DetailItemOwner.CreateDetailItem** and **pfcDetail.DetailGroupItem.Modify**.

Note: Changes to the values of a **pfcDetail.DetailGroupInstructions** object do not take effect until that instructions object is used to modify the group using **pfcDetail.DetailGroupItem.Modify**.

The method **pfcDetail.DetailGroupInstructions.GetName** returns the name of the detail group.

The method **pfcDetail.DetailGroupInstructions.SetName** sets the name of the detail group.

The method **pfcDetail.DetailGroupInstructions.GetElements** returns the sequence of the detail items (notes, groups and entities) contained in the group.

The method **pfcDetail.DetailGroupInstructions.SetElements** sets the sequence of the detail items contained in the group.

The method

pfcDetail.DetailGroupInstructions.GetIsDisplayed returns whether the detail group is displayed in the drawing.

The method

pfcDetail.DetailGroupInstructions.SetIsDisplayed toggles the display of the detail group.

Detail Groups Information

Method Introduced:

- **pfcDetail.DetailGroupItem.GetInstructions**

The method **pfcDetail.DetailGroupItem.GetInstructions** gets a data object that describes how to construct a detail group item. The method returns the data object describing the detail group item.

Detail Groups Operations

Methods Introduced:

- **pfcDetail.DetailGroupItem.Draw**
- **pfcDetail.DetailGroupItem.Erase**
- **pfcDetail.DetailGroupItem.Modify**

The method **pfcDetail.DetailGroupItem.Draw** temporarily draws a detail group item, so that it is removed during the next draft generation.

The method **pfcDetail.DetailGroupItem.Erase** temporarily undraws a detail group item, so that it is redrawn during the next draft generation.

The method **pfcDetail.DetailGroupItem.Modify** changes the definition of a detail group item based on the data object that describes how to construct a detail group item.

Example: Create New Group of Items

The following example creates a group from a set of selected detail items.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;
public class pfcDrawingExamples {
```

```

/*=====*\
FUNCTION : createGroup()
PURPOSE  : Command to create a new group with selected items
/*=====*\
    public static void createGroup (String groupName)
    throws com.ptc.cipjava.jxthrowable
    {
/*-----*\
    Select notes, draft entities, symbol instances
/*-----*\
        Session session = pfcGlobal.GetProESession ();
        SelectionOptions selOptions =
            pfcSelect.SelectionOptions_Create
("any_note,draft_ent,dtl_symbol");
        Selections selections = session.Select (selOptions, null);

        if (selections == null || selections.getarraysize() == 0)
            return;

/*-----*\
        Allocate and fill a sequence with the detail item handles
/*-----*\
        DetailItems items = DetailItems.create();

        for (int i = 0; i < selections.getarraysize(); i ++)
        {
            items.insert (items.getarraysize(),
                (DetailItem)selections.get (i).GetSelItem());
        }

/*-----*\
        Get the drawing which will own the group
/*-----*\
        Drawing drawing = (Drawing)items.get (0).GetDBParent();

/*-----*\
        Allocate group data and set the group items
/*-----*\
        DetailGroupInstructions instrs =
            pfcDetail.DetailGroupInstructions_Create (groupName, items);

/*-----*\
        Create the group
/*-----*\
        drawing.CreateDetailItem (instrs);
    }
}

```

Detail Symbols

Detail Symbol Definitions

A detail symbol definition in J-Link is represented by the interface **pfcDetail.DetailSymbolDefItem**. It is a child of the **DetailItem** interface.

The interface **pfcDetail.DetailSymbolDefInstructions** contains information that describes a symbol definition. It can be used when creating symbol definition entities or while accessing existing symbol definition entities.

Instructions

Methods Introduced:

- **pfcDetail.pfcDetail.DetailSymbolDefInstructions_Create**
- **pfcDetail.DetailSymbolDefInstructions.GetSymbolHeight**
- **pfcDetail.DetailSymbolDefInstructions.SetSymbolHeight**
- **pfcDetail.DetailSymbolDefInstructions.GetHasElbow**
- **pfcDetail.DetailSymbolDefInstructions.SetHasElbow**
- **pfcDetail.DetailSymbolDefInstructions.GetIsTextAngleFixed**
- **pfcDetail.DetailSymbolDefInstructions.SetIsTextAngleFixed**
- **pfcDetail.DetailSymbolDefInstructions.GetScaledHeight**
- **pfcDetail.DetailSymbolDefInstructions.GetAttachments**
- **pfcDetail.DetailSymbolDefInstructions.SetAttachments**
- **pfcDetail.DetailSymbolDefInstructions.GetFullPath**
- **pfcDetail.DetailSymbolDefInstructions.SetFullPath**
- **pfcDetail.DetailSymbolDefInstructions.GetReference**
- **pfcDetail.DetailSymbolDefInstructions.SetReference**

The method **pfcDetail.pfcDetail.DetailSymbolDefInstructions_Create** creates an instruction data object that describes how to create a symbol definition based on the path and name of the symbol definition. The instructions object is passed to the methods **pfcDetailItemOwner.CreateDetailItem** and **pfcDetailSymbolDefItem.Modify**.

Note: Changes to the values of a **pfcDetail.DetailSymbolDefInstructions** object do not take effect until that instructions object is used to modify the definition using the method **pfcDetail.DetailSymbolDefItem.Modify**.

The method **pfcDetail.DetailSymbolDefInstructions.GetSymbolHeight** returns the value of the height type for the symbol definition. The symbol definition height options are as follows:

- **SYMDEF_FIXED**—Symbol height is fixed.
- **SYMDEF_VARIABLE**—Symbol height is variable.
- **SYMDEF_RELATIVE_TO_TEXT**—Symbol height is determined relative to the text height.

The method **pfcDetail.DetailSymbolDefInstructions.SetSymbolHeight** sets the value of the height type for the symbol definition.

The method **pfcDetail.DetailSymbolDefInstructions.GetHasElbow** determines whether the symbol definition includes an elbow.

The method **pfcDetail.DetailSymbolDefInstructions.SetHasElbow** decides if the symbol definition should include an elbow.

The method **pfcDetail.DetailSymbolDefInstructions.GetIsTextAngleFixed** returns whether the text of the angle is fixed.

The method **pfcDetail.DetailSymbolDefInstructions.SetIsTextAngleFixed** toggles the requirement that the text angle be fixed.

The method **pfcDetail.DetailSymbolDefInstructions.GetScaledHeight** returns the height of the symbol definition in inches.

The method **pfcDetail.DetailSymbolDefInstructions.GetAttachments** returns the value of the sequence of the possible instance attachment points for the symbol definition.

The method **pfcDetail.DetailSymbolDefInstructions.SetAttachments** sets the value of the sequence of the possible instance attachment points for the symbol definition.

The method

pfcDetail.DetailSymbolDefInstructions.GetFullPath returns the value of the complete path of the symbol definition file.

The method

pfcDetail.DetailSymbolDefInstructions.SetFullPath sets the value of the complete path of the symbol definition path.

The method

pfcDetail.DetailSymbolDefInstructions.GetReference returns the text reference information for the symbol definition. It returns a null value if the text reference is not used. The text reference identifies the text item used for a symbol definition which has a height type of SYMDEF_TEXT_RELATED.

The method

pfcDetail.DetailSymbolDefInstructions.SetReference sets the text reference information for the symbol definition.

Detail Symbol Definitions Information

Methods Introduced:

- **pfcDetail.DetailSymbolDefItem.ListDetailItems**
- **pfcDetail.DetailSymbolDefItem.GetInstructions**

The method **pfcDetail.DetailSymbolDefItem.ListDetailItems** lists the detail items in the symbol definition based on the type of the detail item.

The method **pfcDetail.DetailSymbolDefItem.GetInstructions** returns an instruction data object that describes how to construct the symbol definition.

Detail Symbol Definitions Operations

Methods Introduced:

- **pfcDetail.DetailSymbolDefItem.CreateDetailItem**
- **pfcDetail.DetailSymbolDefItem.Modify**

The method

pfcDetail.DetailSymbolDefItem.CreateDetailItem creates a detail item in the symbol definition based on the instructions data object. The method returns the detail item in the symbol definition.

The method **pfcdetail.DetailSymbolDefItem.Modify** modifies a symbol definition based on the instructions data object that contains information about the modifications to be made to the symbol definition.

Retrieving Symbol Definitions

Methods Introduced:

- **pfcdetail.DetailItemOwner.RetrieveSymbolDefinition**

The method **pfcdetail.DetailItemOwner.RetrieveSymbolDefinition** retrieves a symbol definition from the disk.

The input parameters of this method are:

- *FileName*—Name of the symbol definition file
- *FilePath*—Path to the symbol definition file. It is relative to the path specified by the option "pro_symbol_dir" in the configuration file. A null value indicates that the function should search the current directory.
- *Version*—Numerical version of the symbol definition file. A null value retrieves the latest version.
- *UpdateUnconditionally*—True if Pro/ENGINEER should update existing instances of this symbol definition, or false to quit the operation if the definition exists in the model.

The method returns the retrieved symbol definition.

Example : Create Symbol Definition

The following example creates a symbol definition which contains four line entities forming a box, a note at the middle of the box, and a free attachment.

```
import com.ptc.pfc.pfcGlobal.pfcGlobal;  
import com.ptc.pfc.pfcSession.*;  
import com.ptc.pfc.pfcModel.*;  
import com.ptc.pfc.pfcDetail.*;  
import com.ptc.pfc.pfcDrawing.*;  
import com.ptc.pfc.pfcBase.*;  
import com.ptc.pfc.pfcGeometry.*;  
import com.ptc.pfc.pfcSelect.*;  
import com.ptc.pfc.pfcSolid.*;  
import com.ptc.pfc.pfcTable.*;  
import com.ptc.pfc.pfcView2D.*;  
import com.ptc.pfc.pfcModelItem.*;  
import com.ptc.pfc.pfcAssembly.*;
```

```

import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;

public class pfcDrawingExamples {

/*=====*\
FUNCTION : createBoxSymdef()
PURPOSE  : To create a symbol definition with the specified name,
           containing a box and a note with the specified text
\*=====*/
    public static void createBoxSymdef (String name, String text)
        throws com.ptc.cipjava.jxthrowable
    {
/*-----*\
    Get the current drawing & its background view
\*-----*/
        Session session = pfcGlobal.GetProESession ();
        Model model = session.GetCurrentModel();

        if (model.GetType() != ModelType.MDL_DRAWING)
            throw new RuntimeException ("Current model is not a drawing");

        Drawing drawing = (Drawing)model;
/*-----*\
    Allocate symbol definition description data
\*-----*/
        DetailSymbolDefInstructions instrs =
            pfcDetail.DetailSymbolDefInstructions_Create (name);
        instrs.SetSymbolHeight (SymbolDefHeight.SYMDEF_FIXED);

/*-----*\
    Set a FREE attachment at the origin of the symbol
\*-----*/
        Point3D origin = Point3D.create();
        origin.set (0, 0.0);
        origin.set (1, 0.0);
        origin.set (2, 0.0);

        SymbolDefAttachment attachment =
            pfcDetail.SymbolDefAttachment_Create
                (SymbolDefAttachmentType.SYMDEFATTACH_FREE, origin);

        SymbolDefAttachments attachments = SymbolDefAttachments.create();
        attachments.insert (0, attachment);
        instrs.SetAttachments (attachments);

```



```

/*-----*\
  Create the empty symbol
/*-----*\
    DetailSymbolDefItem symDef =
      (DetailSymbolDefItem)drawing.CreateDetailItem (instrs);

/*-----*\
  Calculate the default text height for the symbol based on the drawing
  text height and transform
/*-----*\
    double textHeight = drawing.GetTextHeight();
    Transform3D matrix =
      drawing.GetSheetTransform (drawing.GetCurrentSheetNumber());

    double defHeight = textHeight / matrix.GetMatrix().get (0, 0);

/*-----*\
  Create four lines to form a box, twice the default text height,
  around the origin
/*-----*\
    Point3D end1 = Point3D.create ();
    Point3D end2 = Point3D.create ();
    end1.set (0, -defHeight);
    end1.set (1, -defHeight);
    end1.set (2, 0.0);
    end2.set (0, defHeight);
    end2.set (1, -defHeight);
    end2.set (2, 0.0);

    ColorRGB colorRGB =
      session.GetRGBFromStdColor (StdColor.COLOR_ERROR);

    addLine (symDef, end1, end2, colorRGB);

    end2.set (0, -defHeight);
    end2.set (1, defHeight);

    addLine (symDef, end1, end2, colorRGB);

    end1.set (0, defHeight);
    end1.set (1, defHeight);


    addLine (symDef, end1, end2, colorRGB);

    end2.set (0, defHeight);
    end2.set (1, -defHeight);

    addLine (symDef, end1, end2, colorRGB);

/*-----*\

```



```

    Add a note with the specified text at the origin
\*-----*/
    addNote (symDef, origin, text);
}

/*-----*\
FUNCTION : addNote()
PURPOSE  : To add a note with the specified text and location to a
           symbol definition.
\*-----*/
    private static void  addNote(DetailSymbolDefItem symDef,
                                Point3D location,
                                String text)
        throws com.ptc.cipjava.jxthrowable
    {

/*-----*\
    Allocate a text item, and set its properties
\*-----*/
        DetailText dText = pfcDetail.DetailText_Create (text);

/*-----*\
    Allocate a new text line, and add the text item to it
\*-----*/
        DetailTexts texts = DetailTexts.create();
        texts.insert (0, dText);

        DetailTextLine textLine =
            pfcDetail.DetailTextLine_Create (texts);

        DetailTextLines textLines = DetailTextLines.create();
        textLines.insert (0, textLine);

/*-----*\
    Set the location of the note text
\*-----*/
        FreeAttachment position =
            pfcDetail.FreeAttachment_Create (location);
;
/*-----*\
    Set the attachment structure
\*-----*/
        DetailLeaders allAttachments = pfcDetail.DetailLeaders_Create ();
        allAttachments.SetItemAttachment (position);

/*-----*\
    Allocate a note description, and set its properties
\*-----*/
        DetailNoteInstructions instrs =
            pfcDetail.DetailNoteInstructions_Create (textLines);

```

```

instrs.SetLeader (allAttachments);
instrs.SetHorizontal (HorizontalJustification.H_JUSTIFY_CENTER);
instrs.SetVertical (VerticalJustification.V_JUSTIFY_MIDDLE);

/*-----*\
Create the note
\*-----*/
    symDef.CreateDetailItem (instrs);
}

/*=====*\
FUNCTION : addLine()
PURPOSE  : Utility to add a line entity to a symbol definition
\*=====*/
private static void addLine (DetailSymbolDefItem symDef,
                             Point3D start,
                             Point3D end,
                             ColorRGB color)
    throws com.ptc.cipjava.jxthrowable
{

/*-----*\
Allocate and initialize a curve descriptor
\*-----*/
    LineDescriptor geom =
        pfcGeometry.LineDescriptor_Create (start, end);

/*-----*\
Allocate data for the draft entity
\*-----*/
    DetailEntityInstructions instrs =
        pfcDetail.DetailEntityInstructions_Create (geom,
                                                    null);

    instrs.SetColor(color);

/*-----*\
Create the entity
\*-----*/
    symDef.CreateDetailItem (instrs);

}
}

```



Detail Symbol Instances

A detail symbol instance in J-Link is represented by the interface **pfcDetail.DetailSymbolInstItem**. It is a child of the **DetailItem** interface.

The interface **pfcDetail.DetailSymbolInstInstructions** contains information that describes a symbol instance. It can be used when creating symbol instances and while accessing existing groups.

Instructions

Methods Introduced:

- **pfcDetail.pfcDetail.DetailSymbolInstInstructions_Create**
- **pfcDetail.DetailSymbolInstInstructions.GetIsDisplayed**
- **pfcDetail.DetailSymbolInstInstructions.SetIsDisplayed**
- **pfcDetail.DetailSymbolInstInstructions.GetColor**
- **pfcDetail.DetailSymbolInstInstructions.SetColor**
- **pfcDetail.DetailSymbolInstInstructions.GetSymbolDef**
- **pfcDetail.DetailSymbolInstInstructions.SetSymbolDef**
- **pfcDetail.DetailSymbolInstInstructions.GetAttachOnDefType**
- **pfcDetail.DetailSymbolInstInstructions.SetAttachOnDefType**
- **pfcDetail.DetailSymbolInstInstructions.GetDefAttachment**
- **pfcDetail.DetailSymbolInstInstructions.SetDefAttachment**
- **pfcDetail.DetailSymbolInstInstructions.GetInstAttachment**
- **pfcDetail.DetailSymbolInstInstructions.SetInstAttachment**
- **pfcDetail.DetailSymbolInstInstructions.GetAngle**
- **pfcDetail.DetailSymbolInstInstructions.SetAngle**
- **pfcDetail.DetailSymbolInstInstructions.GetScaledHeight**
- **pfcDetail.DetailSymbolInstInstructions.SetScaledHeight**
- **pfcDetail.DetailSymbolInstInstructions.GetTextValues**
- **pfcDetail.DetailSymbolInstInstructions.SetTextValues**
- **pfcDetail.DetailSymbolInstInstructions.GetCurrentTransform**
- **pfcDetail.DetailSymbolInstInstructions.SetGroups**

The method

pfcDetail.pfcDetail.DetailSymbolInstInstructions.Create creates a data object that contains information about the placement of a symbol instance.

Note: Changes to the values of a **pfcDetail.DetailSymbolInstInstructions** object do not take effect until that instructions object is used to modify the instance using **pfcDetail.DetailSymbolInstItem.Modify**.

The method

pfcDetail.DetailSymbolInstInstructions.GetIsDisplayed returns a value that specifies whether the instance of the symbol is displayed.

Use the method

pfcDetail.DetailSymbolInstInstructions.SetIsDisplayed to switch the display of the symbol instance.

The method

pfcDetail.DetailSymbolInstInstructions.GetColor returns the color of the detail symbol instance. A null value indicates that the default drawing color is used.

The method **pfcDetail.DetailSymbolInstInstructions.SetColor** sets the color of the detail symbol instance. Pass null to use the default drawing color.

The method

pfcDetail.DetailSymbolInstInstructions.GetSymbolDef returns the symbol definition used for the instance.

The method

pfcDetail.DetailSymbolInstInstructions.SetSymbolDef sets the value of the symbol definition used for the instance.

The method

pfcDetail.DetailSymbolInstInstructions.GetAttachOnDefType returns the attachment type of the instance. The method returns a null value if the attachment represents a free attachment. The attachment options are as follows:

- **SYMDEFATTACH_FREE**—Attachment on a free point.
- **SYMDEFATTACH_LEFT_LEADER**—Attachment via a leader on the left side of the symbol.
- **SYMDEFATTACH_RIGHT_LEADER**— Attachment via a leader on the right side of the symbol.

- **SYMDEFATTACH_RADIAL_LEADER**—Attachment via a leader at a radial location.
- **SYMDEFATTACH_ON_ITEM**—Attachment on an item in the symbol definition.
- **SYMDEFATTACH_NORMAL_TO_ITEM**—Attachment normal to an item in the symbol definition.

The method

pfcDetail.DetailSymbolInstInstructions.SetAttachOnDefType sets the attachment type of the instance.

The method

pfcDetail.DetailSymbolInstInstructions.GetDefAttachment returns the value that represents the way in which the instance is attached to the symbol definition.

The method

pfcDetail.DetailSymbolInstInstructions.SetDefAttachment specifies the way in which the instance is attached to the symbol definition.

The method

pfcDetail.DetailSymbolInstInstructions.GetInstAttachment returns the value of the attachment of the instance that includes location and leader information.

The method

pfcDetail.DetailSymbolInstInstructions.SetInstAttachment sets value of the attachment of the instance.

The method

pfcDetail.DetailSymbolInstInstructions.GetAngle returns the value of the angle at which the instance is placed. The method returns a null value if the value of the angle is 0 degrees.

The method **pfcDetail.DetailSymbolInstInstructions.SetAngle** sets the value of the angle at which the instance is placed.

The method

pfcDetail.DetailSymbolInstInstructions.GetScaledHeight returns the height of the symbol instance in the owner drawing or model coordinates. This value is consistent with the height value shown for a symbol instance in the Properties dialog box in the Pro/ENGINEER User Interface.

Note: The scaled height obtained using the above method is partially based on the properties of the symbol definition assigned using the method **pfcDetail.DetailSymbolInstInstructions.GetSymbolDef**. Changing the symbol definition may change the calculated value for the scaled height.

The method **pfcDetail.DetailSymbolInstInstructions.SetScaledHeight** sets the value of the height of the symbol instance in the owner drawing or model coordinates.

The method **pfcDetail.DetailSymbolInstInstructions.GetTextValues** returns the sequence of variant text values used while placing the symbol instance.

The method **pfcDetail.DetailSymbolInstInstructions.SetTextValues** sets the sequence of variant text values while placing the symbol instance.

The method **pfcDetail.DetailSymbolInstInstructions.GetCurrentTransformation** returns the coordinate transformation matrix to place the symbol instance.

The method **pfcDetail.DetailSymbolInstInstructions.SetGroups** sets the *DetailSymbolGroupOption* argument for displaying symbol groups in the symbol instance. This argument can have the following values:

- **DETAIL_SYMBOL_GROUP_INTERACTIVE**—Symbol groups are interactively selected for display. This is the default value in the GRAPHICS mode.
- **DETAIL_SYMBOL_GROUP_ALL**—All non-exclusive symbol groups are included for display.
- **DETAIL_SYMBOL_GROUP_NONE**—None of the non-exclusive symbol groups are included for display.
- **DETAIL_SYMBOL_GROUP_CUSTOM**—Symbol groups specified by the application are displayed.

Refer to the section Detail Symbol Groups for more information on detail symbol groups.

Detail Symbol Instances Information

Method Introduced:

- **pfcDetail.DetailSymbolInstItem.GetInstructions**

The method **pfcDetail.DetailSymbolInstItem.GetInstructions** returns an instructions data object that describes how to construct a symbol instance. This method takes a *ProBoolean* argument, *GiveParametersAsNames*, which determines whether symbolic representations of parameters and drawing properties in the symbol instance should be displayed, or the actual text seen by the user should be displayed.

Detail Symbol Instances Operations

Methods Introduced:

- **pfcDetail.DetailSymbolInstItem.Draw**
- **pfcDetail.DetailSymbolInstItem.Erase**
- **pfcDetail.DetailSymbolInstItem.Show**
- **pfcDetail.DetailSymbolInstItem.Remove**
- **pfcDetail.DetailSymbolInstItem.Modify**

The method **pfcDetail.DetailSymbolInstItem.Draw** draws a symbol instance temporarily to be removed on the next draft regeneration.

The method **pfcDetail.DetailSymbolInstItem.Erase** undraws a symbol instance temporarily from the display to be redrawn on the next draft generation.

The method **pfcDetail.DetailSymbolInstItem.Show** displays a symbol instance to be repainted on the next draft regeneration.

The method **pfcDetail.DetailSymbolInstItem.Remove** deletes a symbol instance permanently.

The method **pfcDetail.DetailSymbolInstItem.Modify** modifies a symbol instance based on the instructions data object that contains information about the modifications to be made to the symbol instance.

Example: Create a Free Instance of Symbol Definition

```
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcDetail.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcTable.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSheet.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcDrawingFormat.*;
import com.ptc.pfc.pfcDimension2D.*;
import java.lang.reflect.Array;
import java.text.*;
import java.io.*;
public class pfcDrawingExamples {

/*=====*\
FUNCTION : placeSymInst()
PURPOSE  : Place a CG symbol with no leaders at a specified location
\*=====*/
    public static void placeInst() throws com.ptc.cipjava.jxthrowable
    {
/*-----*\
    Get the current drawing
\*-----*/
        Session session = pfcGlobal.GetProESession ();
        Model model = session.GetCurrentModel();

        if (model.GetType() != ModelType.MDL_DRAWING)
            throw new RuntimeException ("Current model is not a drawing");

        Drawing drawing = (Drawing) model;

/*-----*\
    Retrieve the symbol definition from the system
\*-----*/
        DetailSymbolDefItem symDef =
            drawing.RetrieveSymbolDefinition ("CG", null, null, null);

/*-----*\
    Select the locations for the symbol
\*-----*/
```

```

boolean stop = false;
Point3Ds points = Point3Ds.create ();
while (!stop)
{
    MouseStatus mouse = session.UIGetNextMousePick (null);
    if (mouse.GetSelectedButton() ==
        MouseButton.MOUSE_BTN_LEFT)
    {
        points.insert (0, mouse.GetPosition());
    }
    else
        stop = true;
}

/*-----*\
Allocate the symbol instance description
\*-----*/
    DetailSymbolInstInstructions instrs =
        pfcDetail.DetailSymbolInstInstructions_Create (symDef);

    for (int i = 0; i < points.getarraysize(); i++)
    {
/*-----*\
Set the location of the note text
\*-----*/
        FreeAttachment position =
            pfcDetail.FreeAttachment_Create (points.get (i));

/*-----*\
Set the attachment structure
\*-----*/
        DetailLeaders allAttachments =
            pfcDetail.DetailLeaders_Create ();
        allAttachments.SetItemAttachment (position);

        instrs.SetInstAttachment (allAttachments);
/*-----*\
Create and display the symbol
\*-----*/
        DetailSymbolInstItem symInst =
            (DetailSymbolInstItem) drawing.CreateDetailItem (instrs);
        symInst.Show();
    }
}

```

Example: Create a Free Instance of a Symbol Definition with drawing unit heights, variable text and groups

```
/*=====*\
FUNCTION : placeDetailSymbol()
PURPOSE  : Creates a free instance of a symbol definition with drawing
           unit heights, variable text and groups. A symbol is placed
           with no leaders at a specified location.
/*=====*\
    public static void placeDetailSymbol(String groupName,
                                         String variableText ,
                                         double height)
        throws com.ptc.cipjava.jxthrowable
    {

/*-----*\
    Get the current drawing
/*-----*\
Session session = pfcGlobal.GetProESession ();

Model model = session.GetCurrentModel();

if (model.GetType() != ModelType.MDL_DRAWING)
    throw new RuntimeException ("Current model is not a drawing");

Drawing drawing = (Drawing) model;

/*-----*\
    Retrieve the symbol definition from the system
/*-----*\
DetailSymbolDefItem symDef =
    drawing.RetrieveSymbolDefinition ("detail_symbol_example", "./", null,
                                     null);

/*-----*\
    Select the locations for the symbol
/*-----*\

boolean stop = false;
Point3D point = Point3D.create ();
while (!stop)
    {
    MouseStatus mouse = session.UIGetNextMousePick (null);
    if (mouse.GetSelectedButton() ==
        MouseButton.MOUSE_BTN_LEFT)
        {
        point = mouse.GetPosition();
        stop = true;
        }
    }
}
```

```

/*-----*\
  Allocate the symbol instance description
\*-----*/
DetailSymbolInstInstructions instrs =
    pfcDetail.DetailSymbolInstInstructions_Create (symDef);

/*-----*\
  Set the symbol height in drawing units
\*-----*/
if (height > 0)
{
instrs.SetScaledHeight(new Double(height));
}

/*-----*\
  Set text to the variable text in the symbol. This will be displayed
  instead of the text defined when creating the symbol
\*-----*/
DetailVariantTexts varTexts;
DetailVariantText varText;

if ((variableText != null) || (!variableText.equals("VAR_TEXT")))
{
varText = pfcDetail.DetailVariantText_Create("VAR_TEXT" , variableText );
varTexts = DetailVariantTexts.create();
varTexts.insert(0,varText);

instrs.SetTextValues(varTexts);
}

/*-----*\
  Display the groups in symbol depending on group name
\*-----*/
DetailSymbolGroups groups, allGroups;
DetailSymbolGroup group = null;

if (groupName.equals("ALL"))
instrs.SetGroups (DetailSymbolGroupOption.DETAIL_SYMBOL_GROUP_ALL ,
    null);
else if (groupName.equals("NONE"))
instrs.SetGroups (DetailSymbolGroupOption.DETAIL_SYMBOL_GROUP_NONE ,
    null);
else
{
allGroups = instrs.GetSymbolDef().ListSubgroups();
group = getGroup(allGroups , groupName );
if (group != null)
{
groups = DetailSymbolGroups.create();
groups.insert(0, group);
instrs.SetGroups (DetailSymbolGroupOption.DETAIL_SYMBOL_GROUP_CUSTOM ,

```

```

    groups);
}
}

/*-----*\
Set the location of the note text
\*-----*/
FreeAttachment position = pfcDetail.FreeAttachment_Create (point);

/*-----*\
Set the attachment structure
\*-----*/
DetailLeaders allAttachments =
    pfcDetail.DetailLeaders_Create ();
allAttachments.SetItemAttachment (position);

instrs.SetInstAttachment (allAttachments);

/*-----*\
Create and display the symbol
\*-----*/
DetailSymbolInstItem symInst =
    (DetailSymbolInstItem) drawing.CreateDetailItem (instrs);
    symInst.Show();

}

/*=====*\
FUNCTION : getGroup()
PURPOSE  : Return the specific group depending on the group name.
\*=====*/
    public static DetailSymbolGroup getGroup(DetailSymbolGroups groups,
                                             String groupName)

        throws com.ptc.cipjava.jxthrowable
        {
            DetailSymbolGroup group = null;
            DetailSymbolGroupInstructions groupInstrs;
            int i;

            if (groups.getarraysize() <=0 )
            {
                return null;
            }

/*-----*\
Loop through all the groups in the symbol and return the group with
the selected name
\*-----*/
            for(i=0;i<groups.getarraysize();i++)
            {
                group = groups.get(i);

```

```

groupInstrs = group.GetInstructions();

if (groupInstrs.GetName().equals(groupName))
return group;
}
return null;
}

```

Detail Symbol Groups

A detail symbol group in J-Link is represented by the interface **pfcDetail.DetailSymbolGroup**. It is a child of the **pfcObject.Object** interface. A detail symbol group is accessible only as a part of the contents of a detail symbol definition or instance.

The interface **pfcDetail.DetailSymbolGroupInstructions** contains information that describes a symbol group. It can be used when creating new symbol groups, or while accessing or modifying existing groups.

Instructions

Methods Introduced:

- **pfcDetail.pfcDetail.DetailSymbolGroupInstructions.Create**
- **pfcDetail.DetailSymbolGroupInstructions.GetItems**
- **pfcDetail.DetailSymbolGroupInstructions.SetItems**
- **pfcDetail.DetailSymbolGroupInstructions.GetName**
- **pfcDetail.DetailSymbolGroupInstructions.SetName**

The method **pfcDetail.pfcDetail.DetailSymbolGroupInstructions.Create** creates the **pfcDetail.DetailSymbolGroupInstructions** data object that stores the name of the symbol group and the list of detail items to be included in the symbol group.

Note: Changes to the values of the **pfcDetail.DetailSymbolGroupInstructions** data object do not take effect until this object is used to modify the instance using the method **pfcDetail.DetailSymbolGroup.Modify**.

The method **pfcDetail.DetailSymbolGroupInstructions.GetItems** returns the list of detail items included in the symbol group.

The method **pfcDetail.DetailSymbolGroupInstructions.SetItems** sets the list of detail items to be included in the symbol group.

The method **pfcDetail.DetailSymbolGroupInstructions.GetName** returns the name of the symbol group.

The method **pfcDetail.DetailSymbolGroupInstructions.SetName** assigns the name of the symbol group.

Detail Symbol Group Information

Methods Introduced:

- **pfcDetail.DetailSymbolGroup.GetInstructions**
- **pfcDetail.DetailSymbolGroup.GetParentGroup**
- **pfcDetail.DetailSymbolGroup.GetParentDefinition**
- **pfcDetail.DetailSymbolGroup.ListChildren**
- **pfcDetail.DetailSymbolDefItem.ListSubgroups**
- **pfcDetail.DetailSymbolDefItem.IsSubgroupLevelExclusive**
- **pfcDetail.DetailSymbolInstItem.ListGroups**

The method **pfcDetail.DetailSymbolGroup.GetInstructions** returns the **pfcDetail.DetailSymbolGroupInstructions** data object that describes how to construct a symbol group.

The method **pfcDetail.DetailSymbolGroup.GetParentGroup** returns the parent symbol group to which a given symbol group belongs.

The method **pfcDetail.DetailSymbolGroup.GetParentDefinition** returns the symbol definition of a given symbol group.

The method **pfcDetail.DetailSymbolGroup.ListChildren** lists the subgroups of a given symbol group.

The method **pfcDetail.DetailSymbolDefItem.ListSubgroups** lists the subgroups of a given symbol group stored in the symbol definition at the indicated level.

The method **pfcDetail.DetailSymbolDefItem.IsSubgroupLevelExclusive** identifies if the subgroups of a given symbol group stored in the symbol definition at the indicated level are exclusive or independent. If groups are exclusive, only one of the groups at this level can be active in the model at any time. If groups are independent, any number of groups can be active.

The method **pfcDetail.DetailSymbolInstItem.ListGroups** lists the symbol groups included in a symbol instance. The *SymbolGroupFilter* argument determines the types of symbol groups that can be listed. It takes the following values:

- **DTLSYMINST_ALL_GROUPS**—Retrieves all groups in the definition of the symbol instance.
- **DTLSYMINST_ACTIVE_GROUPS**—Retrieves only those groups that are actively shown in the symbol instance.
- **DTLSYMINST_INACTIVE_GROUPS**—Retrieves only those groups that are not shown in the symbol instance.

Detail Symbol Group Operations

Methods Introduced:

- **pfcDetail.DetailSymbolGroup.Delete**
- **pfcDetail.DetailSymbolGroup.Modify**
- **pfcDetail.DetailSymbolDefItem.CreateSubgroup**
- **pfcDetail.DetailSymbolDefItem.SetSubgroupLevelExclusive**
- **pfcDetail.DetailSymbolDefItem.SetSubgroupLevelIndependent**

The method **pfcDetail.DetailSymbolGroup.Delete** deletes the specified symbol group from the symbol definition. This method does not delete the entities contained in the group.

The method **pfcDetail.DetailSymbolGroup.Modify** modifies the specified symbol group based on the **pfcDetail.DetailSymbolGroupInstructions** data object that contains information about the modifications that can be made to the symbol group.

The method **pfcDetail.DetailSymbolDefItem.CreateSubgroup** creates a new subgroup in the symbol definition at the indicated level below the parent group.

The method

pfcDetail.DetailSymbolDefItem.SetSubgroupLevelExclusive makes the subgroups of a symbol group exclusive at the indicated level in the symbol definition.

Note: After you set the subgroups of a symbol group as exclusive, only one of the groups at the indicated level can be active in the model at any time.

The method

pfcDetail.DetailSymbolDefItem.SetSubgroupLevelIndependent makes the subgroups of a symbol group independent at the indicated level in the symbol definition.

Note: After you set the subgroups of a symbol group as independent, any number of groups at the indicated level can be active in the model at any time.

Detail Attachments

A detail attachment in J-Link is represented by the interface **pfcDetail.Attachment**. It is used for the following tasks:

- The way in which a drawing note or a symbol instance is placed in a drawing.
- The way in which a leader on a drawing note or symbol instance is attached.

Method Introduced:

- **pfcDetail.Attachment.GetType**

The method **pfcDetail.Attachment.GetType** returns the **pfcDetail.AttachmentType** object containing the types of detail attachments. The detail attachment types are as follows:

- **ATTACH_FREE**—The attachment is at a free point possibly with respect to a given drawing view.
- **ATTACH_PARAMETRIC**—The attachment is to a point on a surface or an edge of a solid.
- **ATTACH_OFFSET**—The attachment is offset to another drawing view, to a model item, or to a 3D model annotation.
- **ATTACH_TYPE_UNSUPPORTED**—The attachment is to an item that cannot be represented in PFC at the current time. However, you can still retrieve the location of the attachment.

Free Attachment

The ATTACH_FREE detail attachment type is represented by the interface **pfcDetail.FreeAttachment**. It is a child of the **pfcDetail.Attachment** interface.

Methods Introduced:

- **pfcDetail.FreeAttachment.GetAttachmentPoint**
- **pfcDetail.FreeAttachment.SetAttachmentPoint**
- **pfcDetail.FreeAttachment.GetView**
- **pfcDetail.FreeAttachment.SetView**

The method **pfcDetail.FreeAttachment.GetAttachmentPoint** returns the attachment point. This location is in screen coordinates for drawing items, symbol instances and surface finishes on flat-to-screen annotation planes, and in model coordinates for symbols and surface finishes on 3D model annotation planes.

The method **pfcDetail.FreeAttachment.SetAttachmentPoint** sets the attachment point.

The method **pfcDetail.FreeAttachment.GetView** returns the drawing view to which the attachment is related. The attachment point is relative to the drawing view, that is the attachment point moves when the drawing view is moved. This method returns a NULL value, if the detail attachment is not related to a drawing view, but is placed at the specified location in the drawing sheet, or if the attachment is offset to a model item or to a 3D model annotation.

The method **pfcDetail.FreeAttachment.SetView** sets the drawing view.

Parametric Attachment

The ATTACH_PARAMETRIC detail attachment type is represented by the interface **pfcDetail.ParametricAttachment**. It is a child of the **pfcDetail.Attachment** interface.

Methods Introduced:

- **pfcDetail.ParametricAttachment.GetAttachedGeometry**
- **pfcDetail.ParametricAttachment.SetAttachedGeometry**

The method

pfcDetail.ParametricAttachment.GetAttachedGeometry returns the **pfcSelect.Selection** object representing the item to which the detail attachment is attached. This includes the drawing view in which the attachment is made.

The method

pfcDetail.ParametricAttachment.SetAttachedGeometry assigns the **pfcSelect.Selection** object representing the item to which the detail attachment is attached. This object must include the target drawing view. The attachment will occur at the selected parameters.

Offset Attachment

The ATTACH_OFFSET detail attachment type is represented by the interface **pfcDetail.OffsetAttachment**. It is a child of the **pfcDetail.Attachment** interface.

Methods Introduced:

- **pfcDetail.OffsetAttachment.GetAttachedGeometry**
- **pfcDetail.OffsetAttachment.SetAttachedGeometry**
- **pfcDetail.OffsetAttachment.GetAttachmentPoint**
- **pfcDetail.OffsetAttachment.SetAttachmentPoint**

The method

pfcDetail.OffsetAttachment.GetAttachedGeometry returns the **pfcSelect.Selection** object representing the item to which the detail attachment is attached. This includes the drawing view where the attachment is made, if the offset reference is in a model.

The method

pfcDetail.OffsetAttachment.SetAttachedGeometry assigns the **pfcSelect.Selection** object representing the item to which the detail attachment is attached. This can include the drawing view. The attachment will occur at the selected parameters.

The method **pfcDetail.OffsetAttachment.GetAttachmentPoint** returns the attachment point. This location is in screen coordinates for drawing items, symbol instances and surface finishes on flat-to-screen annotation planes, and in model coordinates for symbols and surface finishes on 3D model annotation planes. The distance from the attachment point to the location of the item to which the detail attachment is attached is saved as the offset distance.

The method **pfcDetail.OffsetAttachment.SetAttachmentPoint** sets the attachment point in screen coordinates.

Unsupported Attachment

The ATTACH_TYPE_UNSUPPORTED detail attachment type is represented by the interface **pfcDetail.UnsupportedAttachment**. It is a child of the **pfcDetail.Attachment** interface.

Method Introduced:

- **pfcDetail.UnsupportedAttachment.GetAttachmentPoint**
- **pfcDetail.UnsupportedAttachment.SetAttachmentPoint**

The method **pfcDetail.UnsupportedAttachment.GetAttachmentPoint** returns the attachment point. This location is in screen coordinates for drawing items, symbol instances and surface finishes on flat-to-screen annotation planes, and in model coordinates for symbols and surface finishes on 3D model annotation planes.

The method **pfcDetail.UnsupportedAttachment.SetAttachmentPoint** assigns the attachment point in screen coordinates.

11

Solid

Most of the objects and methods in J-Link are used with solid models (parts and assemblies). Because solid objects inherit from the interface `Model`, you can use any of the `Model` methods on any `Solid`, `Part`, or `Assembly` object.

Topic	Page
Getting a Solid Object	11 - 2
Solid Information	11 - 2
Solid Operations	11 - 3
Solid Units	11 - 5
Mass Properties	11 - 12
Annotations	11 - 14
Cross Sections	11 - 15
Materials	11 - 15

Getting a Solid Object

Methods Introduced:

- **pfcSession.BaseSession.CreatePart**
- **pfcSession.BaseSession.CreateAssembly**
- **pfcAssembly.ComponentPath.GetRoot**
- **pfcAssembly.ComponentPath.GetLeaf**
- **pfcMFG.MFG.GetSolid**

The methods **pfcSession.BaseSession.CreatePart** and **pfcSession.BaseSession.CreateAssembly** create new solid models with the names you specify.

The methods **pfcAssembly.ComponentPath.GetRoot** and **pfcAssembly.ComponentPath.GetLeaf** specify the solid objects that make up the component path of an assembly component model. You can get a component path object from any component that has been interactively selected.

The method **pfcMFG.MFG.GetSolid** retrieves the storage solid in which the manufacturing model's features are placed. In order to create a UDF group in the manufacturing model, call the method **pfcSolid.Solid.CreateUDFGroup** on the storage solid.

Solid Information

Methods Introduced:

- **pfcSolid.Solid.GetRelativeAccuracy**
- **pfcSolid.Solid.SetRelativeAccuracy**
- **pfcSolid.Solid.GetAbsoluteAccuracy**
- **pfcSolid.Solid.SetAbsoluteAccuracy**

You can set the relative and absolute accuracy of any solid model using these methods. Relative accuracy is relative to the size of the solid. For example, a relative accuracy of .01 specifies that the solid must be accurate to within 1/100 of its size. Absolute accuracy is measured in absolute units (inches, centimeters, and so on).

Note: For a change in accuracy to take effect, you must regenerate the model.

Solid Operations

Methods Introduced:

- **pfcSolid.Solid.Regenerate**
- **pfcSolid.pfcSolid.RegenInstructions_Create**
- **pfcSolid.RegenInstructions.SetAllowFixUI**
- **pfcSolid.RegenInstructions.SetForceRegen**
- **pfcSolid.RegenInstructions.SetFromFeat**
- **pfcSolid.RegenInstructions.SetRefreshModelTree**
- **pfcSolid.RegenInstructions.SetResumeExcludedComponents**
- **pfcSolid.RegenInstructions.SetUpdateAssemblyOnly**
- **pfcSolid.RegenInstructions.SetUpdateInstances**
- **pfcSolid.Solid.GetGeomOutline**
- **pfcSolid.Solid.EvalOutline**
- **pfcSolid.Solid.GetIsSkeleton**

Solid

The method **pfcSolid.Solid.Regenerate** causes the solid model to regenerate according to the instructions provided in the form of the **pfcSolid.RegenInstructions** object. Passing a null value for the instructions argument causes an automatic regeneration.

Pro/ENGINEER Wildfire 5.0 introduces the No-Resolve mode, wherein if a model and feature regeneration fails, failed features and children of failed features are created and regeneration of other features continues. However, J-Link does not support regeneration in this mode. The method **pfcSolid.Solid.Regenerate** throws an exception `pfcExceptions.XtoolkitBadContext`, if Pro/ENGINEER is running in the No-Resolve mode. To continue with the Pro/ENGINEER Wildfire 4.0 behavior in the Resolve mode, set the configuration option `regen_failure_handling` to `resolve_mode` in the Pro/ENGINEER session.

Note: Setting the configuration option to switch to Resolve mode ensures the old behavior as long as you do not retrieve the models saved under the No-Resolve mode. To consistently preserve the old behavior, use Resolve mode from the beginning and throughout your Pro/ENGINEER session.

The **pfcSolid.RegenInstructions** object contains the following input parameters:

- *AllowFixUI*—Determines whether or not to activate the **Fix Model** user interface, if there is an error.

Use the method

pfcSolid.RegenInstructions.SetAllowFixUI to modify this parameter.

- *ForceRegen*—Forces the solid model to fully regenerate. All the features in the model are regenerated. If this parameter is false, Pro/ENGINEER determines which features to regenerate. By default, it is false.

Use the method

pfcSolid.RegenInstructions.SetForceRegen to modify this parameter.

- *FromFeat*—Not currently used. This parameter is reserved for future use.

Use the method **pfcSolid.RegenInstructions.SetFromFeat** to modify this parameter.

- *RefreshModelTree*—Refreshes the Pro/ENGINEER Model Tree after regeneration. The model must be active to use this attribute. If this attribute is false, the Model Tree is not refreshed. By default, it is false.

Use the method

pfcSolid.RegenInstructions.SetRefreshModelTree to modify this parameter.

- *ResumeExcludedComponents*—Enables Pro/ENGINEER to resume the available excluded components of the simplified representation during regeneration. This results in a more accurate update of the simplified representation.

Use the method

pfcSolid.RegenInstructions.SetResumeExcludedComponents to modify this parameter.

- *UpdateAssemblyOnly*—Updates the placements of an assembly and all its sub-assemblies, and regenerates the assembly features and intersected parts. If the affected assembly is retrieved as a simplified representation, then the locations of the components are updated. If this attribute is false, the component locations are not updated, even if the simplified representation is retrieved. By default, it is false.

Use the method

pfcSolid.RegenInstructions.SetUpdateAssemblyOnly to modify this parameter.

- *UpdateInstances*—Updates the instances of the solid model in memory. This may slow down the regeneration process. By default, this attribute is false.

Use the method

pfcSolid.RegenInstructions.SetUpdateInstances to modify this parameter.

The method **pfcSolid.Solid.GetGeomOutline** returns the three-dimensional bounding box for the specified solid. The method **pfcSolid.Solid.EvalOutline** also returns a three-dimensional bounding box, but you can specify the coordinate system used to compute the extents of the solid object.

The method **pfcSolid.Solid.GetIsSkeleton** determines whether the part model is a skeleton or a concept model. It returns a true value if the model is a skeleton, else it returns a false.

Solid Units

Each model has a basic system of units to ensure all material properties of that model are consistently measured and defined. All models are defined on the basis of the system of units. A part can have only one system of unit.

The following types of quantities govern the definition of units of measurement:

- **Basic Quantities**—The basic units and dimensions of the system of units. For example, consider the Centimeter Gram Second (CGS) system of unit. The basic quantities for this system of units are:
 - Length—cm
 - Mass—g
 - Force—dyne
 - Time—sec
 - Temperature—K
- **Derived Quantities**—The derived units are those that are derived from the basic quantities. For example, consider the Centimeter Gram Second (CGS) system of unit. The derived quantities for this system of unit are as follows:
 - Area—cm²
 - Volume—cm³

- Velocity—cm/sec

In J-Link, individual units in the model are represented by the interface **pfcUnits.Unit**.

Types of Unit Systems

The types of systems of units are as follows:

- Pre-defined system of units—This system of unit is provided by default.
- Custom-defined system of units—This system of unit is defined by the user only if the model does not contain standard metric or nonmetric units, or if the material file contains units that cannot be derived from the predefined system of units or both.

In Pro/ENGINEER, the system of units are categorized as follows:

- Mass Length Time (MLT)—The following systems of units belong to this category:
 - CGS —Centimeter Gram Second
 - MKS—Meter Kilogram Second
 - mmKS—millimeter Kilogram Second
- Force Length Time (FLT)—The following systems of units belong to this category:
 - Pro/ENGINEER Default—Inch lbm Second. This is the default system followed by Pro/ENGINEER.
 - FPS—Foot Pound Second
 - IPS—Inch Pound Second
 - mmNS—Millimeter Newton Second

In J-Link, the system of units followed by the model is represented by the interface **pfcUnits.UnitSystem**.

Accessing Individual Units

Methods Introduced:

- **pfcSolid.Solid.ListUnits**
- **pfcSolid.Solid.GetUnit**
- **pfcUnits.Unit.GetName**
- **pfcUnits.Unit.GetExpression**
- **pfcUnits.Unit.GetType**
- **pfcUnits.Unit.GetIsStandard**
- **pfcUnits.Unit.GetReferenceUnit**
- **pfcUnits.Unit.GetConversionFactor**
- **pfcUnits.UnitConversionFactor.GetOffset**
- **pfcUnits.UnitConversionFactor.GetScale**

The method **pfcSolid.Solid.ListUnits** returns the list of units available to the specified model.

The method **pfcSolid.Solid.GetUnit** retrieves the unit, based on its name or expression for the specified model in the form of the **pfcUnits.Unit** object.

The method **pfcUnits.Unit.GetName** returns the name of the unit.

The method **pfcUnits.Unit.GetExpression** returns a user-friendly unit description in the form of the name (for example, ksi) for ordinary units and the expression (for example, N/m³) for system-generated units.

The method **pfcUnits.Unit.GetType** returns the type of quantity represented by the unit in terms of the **pfcBase.UnitType** object. The types of units are as follows:

- **UNIT_LENGTH**—Specifies length measurement units.
- **UNIT_MASS**—Specifies mass measurement units.
- **UNIT_FORCE**—Specifies force measurement units.
- **UNIT_TIME**—Specifies time measurement units.
- **UNIT_TEMPERATURE**—Specifies temperature measurement units.
- **UNIT_ANGLE**—Specifies angle measurement units.

The method **pfcUnits.Unit.GetIsStandard** identifies whether the unit is system-defined (if the property *IsStandard* is set to true) or user-defined (if the property *IsStandard* is set to false).

The method **pfcUnits.Unit.GetReferenceUnit** returns a reference unit (one of the available system units) in terms of the **pfcUnits.Unit** object.

The method **pfcUnits.Unit.GetConversionFactor** identifies the relation of the unit to its reference unit in terms of the **pfcUnits.UnitConversionFactor** object. The unit conversion factors are as follows:

- *Offset*—Specifies the offset value applied to the values in the reference unit.
- *Scale*—Specifies the scale applied to the values in the reference unit to get the value in the actual unit.

Example - Consider the formula to convert temperature from Centigrade to Fahrenheit

$$F = a + (C * b)$$

where

F is the temperature in Fahrenheit

C is the temperature in Centigrade

a = 32 (constant signifying the offset value)

b = 9/5 (ratio signifying the scale of the unit)

Note: Pro/ENGINEER scales the length dimensions of the model using the factors listed above. If the scale is modified, the model is regenerated. When you scale the model, the model units are not changed. Imported geometry cannot be scaled.

Use the methods **pfcUnits.UnitConversionFactor.GetOffset** and **pfcUnits.UnitConversionFactor.GetScale** to retrieve the unit conversion factors listed above.

Modifying Individual Units

Methods Introduced:

- **pfcUnits.Unit.Modify**
- **pfcUnits.Unit.Delete**
- **pfcUnits.Unit.SetName**
- **pfcUnits.UnitConversionFactor.SetOffset**
- **pfcUnits.UnitConversionFactor.SetScale**

The method **pfcUnits.Unit.Modify** modifies the definition of a unit by applying a new conversion factor specified by the **pfcUnits.UnitConversionFactor** object and a reference unit.

The method **pfcUnits.Unit.Delete** deletes the unit.

Note: You can delete only custom units and not standard units.

The method **pfcUnits.Unit.SetName** modifies the name of the unit.

Use the methods **pfcUnits.UnitConversionFactor.SetOffset** and **pfcUnits.UnitConversionFactor.SetScale** to modify the unit conversion factors.

Creating a New Unit

Methods Introduced:

- **pfcSolid.Solid.CreateCustomUnit**
- **pfcUnits.pfcUnits.UnitConversionFactor_Create**

The method **pfcSolid.Solid.CreateCustomUnit** creates a custom unit based on the specified name, the conversion factor given by the **pfcUnits.UnitConversionFactor** object, and a reference unit.

The method **pfcUnits.pfcUnits.UnitConversionFactor_Create** creates the **pfcUnits.UnitConversionFactor** object containing the unit conversion factors.

Accessing Systems of Units

Methods Introduced:

- **pfcSolid.Solid.ListUnitSystems**
- **pfcSolid.Solid.GetPrincipalUnits**
- **pfcUnits.UnitSystem.GetUnit**
- **pfcUnits.UnitSystem.GetName**
- **pfcUnits.UnitSystem.GetType**
- **pfcUnits.UnitSystem.GetIsStandard**

The method **pfcSolid.Solid.ListUnitSystems** returns the list of unit systems available to the specified model.

The method **pfcSolid.Solid.GetPrincipalUnits** returns the system of units assigned to the specified model in the form of the **pfcUnits.UnitSystem** object.

The method **pfcUnits.UnitSystem.GetUnit** retrieves the unit of a particular type used by the unit system.

The method **pfcUnits.UnitSystem.GetName** returns the name of the unit system.

The method **pfcUnits.UnitSystem.GetType** returns the type of the unit system in the form of the **pfcUnits.UnitSystemType** object. The types of unit systems are as follows:

- **UNIT_SYSTEM_MASS_LENGTH_TIME**—Specifies the Mass Length Time (MLT) unit system.
- **UNIT_SYSTEM_FORCE_LENGTH_TIME**—Specifies the Force Length Time (FLT) unit system.

For more information on these unit systems listed above, refer to the section Types of Unit Systems.

The method **pfcUnits.UnitSystem.GetIsStandard** identifies whether the unit system is system-defined (if the property *IsStandard* is set to true) or user-defined (if the property *IsStandard* is set to false).

Modifying Systems of Units

Methods Introduced:

- **pfcUnits.UnitSystem.Delete**
- **pfcUnits.UnitSystem.SetName**

The method **pfcUnits.UnitSystem.Delete** deletes a custom-defined system of units.

Note: You can delete only a custom-defined system of units and not a standard system of units.

Use the method **pfcUnits.UnitSystem.SetName** to rename a custom-defined system of units. Specify the new name for the system of units as an input parameter for this function.

Creating a New System of Units

Method Introduced:

- **pfcSolid.Solid.CreateUnitSystem**

The method **pfcSolid.Solid.CreateUnitSystem** creates a new system of units in the model based on the specified name, the type of unit system given by the **pfcUnits.UnitSystemType** object, and the types of units specified by the **pfcUnits.Units** sequence to use for each of the base measurement types (length, force or mass, and temperature).

Conversion to a New Unit System

Methods Introduced:

- **pfcSolid.Solid.SetPrincipalUnits**
- **pfcUnits.pfcUnits.UnitConversionOptions_Create**
- **pfcUnits.UnitConversionOptions.SetDimensionOption**
- **pfcUnits.UnitConversionOptions.SetIgnoreParamUnits**

The method **pfcSolid.Solid.SetPrincipalUnits** changes the principal system of units assigned to the solid model based on the the unit conversion options specified by the **pfcUnits.UnitConversionOptions** object. The method **pfcUnits.pfcUnits.UnitConversionOptions_Create** creates the **pfcUnits.UnitConversionOptions** object containing the unit conversion options listed below.

The types of unit conversion options are as follows:

- *DimensionOption*—Use the option while converting the dimensions of the model.

Use the method

pfcUnits.UnitConversionOptions.SetDimensionOption to modify this option.

This option can be of the following types:

- **UNITCONVERT_SAME_DIMS**—Specifies that unit conversion occurs by interpreting the unit value in the new unit system. For example, 1 inch will equal to 1 millimeter.
 - **UNITCONVERT_SAME_SIZE**—Specifies that unit conversion will occur by converting the unit value in the new unit system. For example, 1 inch will equal to 25.4 millimeters.
- *IgnoreParamUnits*—This boolean attribute determines whether or not ignore the parameter units. If it is null or true, parameter values and units do not change when the unit system is changed. If it is false, parameter units are converted according to the rule.

Use the method

pfcUnits.UnitConversionOptions.SetIgnoreParamUnits to modify this attribute.

Mass Properties

Method Introduced:

- **pfcSolid.Solid.GetMassProperty**

The function **pfcSolid.Solid.GetMassProperty** provides information about the distribution of mass in the part or assembly. It can provide the information relative to a coordinate system datum, which you name, or the default one if you provide **null** as the name. It returns a class called `MassProperty`.

The class contains the following fields:

- The volume.
- The surface area.
- The density. The density value is 1.0, unless a material has been assigned.
- The mass.

- The center of gravity (COG).
- The inertia matrix.
- The inertia tensor.
- The inertia about the COG.
- The principal moments of inertia (the eigen values of the COG inertia).
- The principal axes (the eigenvectors of the COG inertia).

Example Code: Retrieving a Mass Property Object

This method retrieves a MassProperty object from a specified solid model. The solid's mass, volume, and center of gravity point are then printed.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcSolid.*;
public class pfcSolidMassPropExample
{
    public static void printMassProperties (Solid solid)
    {
        MassProperty properties; // Data Structure containing mass property
        data.
        Point3D gravity_center;
        try
        {
            properties = solid.GetMassProperty(null); // optional argument in
            this method
            // is the name of a coordinate
            system to use
            // to compute the mass
            properties
            System.out.println("The solid mass is: " + properties.GetMass());
            System.out.println("The solid volume is: " +
            properties.GetVolume());
            gravity_center = properties.GetGravityCenter();
            System.out.println("The Center Of Gravity is at ");
            System.out.println("X: " + gravity_center.get(0) + " Y: "
            + gravity_center.get(1) + " Z: "
            + gravity_center.get(2));
        }
        catch (jxthrowable x)
        {
            System.out.println("Exception caught: "+x);
        }
    }
}
```

}

Annotations

Methods Introduced:

- **pfcNote.Note.GetLines**
- **pfcNote.Note.SetLines**
- **pfcNote.Note.GetURL**
- **pfcNote.Note.SetURL**
- **pfcNote.Note.Display**
- **pfcNote.Note.Delete**
- **pfcNote.Note.GetOwner**

3D model notes are instance of ModelItem objects. They can be located and accessed using methods that locate model items in solid models, and downcast to the Note interface to use the methods in this section.

The method **pfcNote.Note.GetLines** returns the text contained in the 3D model note. The method **pfcNote.Note.SetLines** modifies the note text.

The method **pfcNote.Note.GetURL** returns the URL stored in the 3D model note. The method **pfcNote.Note.SetURL** modifies the note URL.

The method **pfcNote.Note.Display** forces the display of the model note.

The method **pfcNote.Note.Delete** deletes a model note.

The method **pfcNote.Note.GetOwner** returns the solid model owner of the note.

Cross Sections

Methods Introduced:

- **pfcSolid.Solid.ListCrossSections**
- **pfcSolid.Solid.GetCrossSection**
- **pfcXSection.XSection.GetName**
- **pfcXSection.XSection.SetName**
- **pfcXSection.XSection.GetXSecType**
- **pfcXSection.XSection.Delete**
- **pfcXSection.XSection.Display**
- **pfcXSection.XSection.Regenerate**

The method **pfcSolid.Solid.ListCrossSections** returns a sequence of cross section objects represented by the Xsection interface. The method **pfcSolid.Solid.GetCrossSection** searches for a cross section given its name.

The method **pfcXSection.XSection.GetName** returns the name of the cross section in Pro/ENGINEER. The method **pfcXSection.XSection.SetName** modifies the cross section name.

The method **pfcXSection.XSection.GetXSecType** returns the type of cross section, that is planar or offset, and the type of item intersected by the cross section.

The method **pfcXSection.XSection.Delete** deletes a cross section.

The method **pfcXSection.XSection.Display** forces a display of the cross section in the window.

The method **pfcXSection.XSection.Regenerate** regenerates a cross section.

Materials

J-Link enables you to programmatically access the material types and properties of parts. Using the methods described in the following sections, you can perform the following actions:

- Create or delete materials
- Set the current material
- Access and modify the material types and properties

Methods Introduced:

- **pfcPart.Material.Save**
- **pfcPart.Material.Delete**
- **pfcPart.Part.GetCurrentMaterial**
- **pfcPart.Part.SetCurrentMaterial**
- **pfcPart.Part.ListMaterials**
- **pfcPart.Part.CreateMaterial**
- **pfcPart.Part.RetrieveMaterial**

The method **pfcPart.Material.Save** writes to a material file that can be imported into any Pro/ENGINEER part.

The method **pfcPart.Material.Delete** removes material from the part.

The method **pfcPart.Part.GetCurrentMaterial** returns the currently assigned material for the part.

The method **pfcPart.Part.SetCurrentMaterial** sets the material assigned to the part.

Note:

- By default, while assigning a material to a sheetmetal part, the method **pfcPart.Part.SetCurrentMaterial** modifies the values of the sheetmetal properties such as Y factor and bend table according to the material file definition. This modification triggers a regeneration and a modification of the developed length calculations of the sheetmetal part. However, you can avoid this behavior by setting the value of the configuration option `material_update_smt_bend_table` to `never_replace`.
- The method **pfcPart.Part.SetCurrentMaterial** may change the model display, if the new material has a default appearance assigned to it.
- The method may also change the family table, if the parameter `PTC_MATERIAL_NAME` is a part of the family table.

The method **pfcPart.Part.ListMaterials** returns a list of the materials available in the part.

The method **pfcPart.Part.CreateMaterial** creates a new empty material in the specified part.

The method **pfcPart.Part.RetrieveMaterial** imports a material file into the part. The name of the file read can be as either:

- `<name>.mtl`—Specifies the new material file format.
- `<name>.mat`—Specifies the material file format prior to Pro/ENGINEER Wildfire 3.0.

If the material is not already in the part database, **pfcPart.Part.RetrieveMaterial** adds the material to the database after reading the material file. If the material is already in the database, the function replaces the material properties in the database with those contained in the material file.

Accessing Material Types

Methods Introduced:

- **pfcPart.Material.GetStructuralMaterialType**
- **pfcPart.Material.SetStructuralMaterialType**
- **pfcPart.Material.GetThermalMaterialType**
- **pfcPart.Material.SetThermalMaterialType**
- **pfcPart.Material.GetSubType**
- **pfcPart.Material.SetSubType**
- **pfcPart.Material.GetPermittedSubTypes**

The method **pfcPart.Material.GetStructuralMaterialType** returns the material type for the structural properties of the material. The material types are as follows:

- **MTL_ISOTROPIC**—Specifies a material with an infinite number of planes of material symmetry, making the properties equal in all directions.
- **MTL_ORTHOTROPIC**—Specifies a material with symmetry relative to three mutually perpendicular planes.
- **MTL_TRANSVERSELY_ISOTROPIC**—Specifies a material with rotational symmetry about an axis. The properties are equal for all directions in the plane of isotropy.

Use the method **pfcPart.Material.SetStructuralMaterialType** to set the material type for the structural properties of the material.

The method **pfcPart.Material.GetThermalMaterialType** returns the material type for the thermal properties of the material. The material types are as follows:

- **MTL_ISOTROPIC**—Specifies a material with an infinite number of planes of material symmetry, making the properties equal in all directions.
- **MTL_ORTHOTROPIC**—Specifies a material with symmetry relative to three mutually perpendicular planes.
- **MTL_TRANSVERSELY_ISOTROPIC**—Specifies a material with rotational symmetry about an axis. The properties are equal for all directions in the plane of isotropy.

Use the method **pfcPart.Material.SetThermalMaterialType** to set the material type for the thermal properties of the material.

The method **pfcPart.Material.GetSubType** returns the subtype for the **MTL_ISOTROPIC** material type.

Use the method **pfcPart.Material.SetSubType** to set the subtype for the **MTL_ISOTROPIC** material type.

Use the method **pfcPart.Material.GetPermittedSubTypes** to retrieve a list of the permitted string values for the material subtype.

Accessing Material Properties

The methods listed in this section enable you to access material properties.

Methods Introduced:

- **pfcPart.pfcPart.MaterialProperty_Create**
- **pfcPart.Material.GetPropertyValue**
- **pfcPart.Material.SetPropertyValue**
- **pfcPart.Material.SetPropertyUnits**
- **pfcPart.Material.RemoveProperty**
- **pfcPart.Material.GetDescription**
- **pfcPart.Material.SetDescription**
- **pfcPart.Material.GetFatigueType**
- **pfcPart.Material.SetFatigueType**

- **pfcPart.Material.GetPermittedFatigueTypes**
- **pfcPart.Material.GetFatigueMaterialType**
- **pfcPart.Material.SetFatigueMaterialType**
- **pfcPart.Material.GetPermittedFatigueMaterialTypes**
- **pfcPart.Material.GetFatigueMaterialFinish**
- **pfcPart.Material.SetFatigueMaterialFinish**
- **pfcPart.Material.GetPermittedFatigueMaterialFinishes**
- **pfcPart.Material.GetFailureCriterion**
- **pfcPart.Material.SetFailureCriterion**
- **pfcPart.Material.GetPermittedFailureCriteria**
- **pfcPart.Material.GetHardness**
- **pfcPart.Material.SetHardness**
- **pfcPart.Material.GetHardnessType**
- **pfcPart.Material.SetHardnessType**
- **pfcPart.Material.GetCondition**
- **pfcPart.Material.SetCondition**
- **pfcPart.Material.GetBendTable**
- **pfcPart.Material.SetBendTable**
- **pfcPart.Material.GetCrossHatchFile**
- **pfcPart.Material.SetCrossHatchFile**
- **pfcPart.Material.GetMaterialModel**
- **pfcPart.Material.SetMaterialModel**
- **pfcPart.Material.GetPermittedMaterialModels**
- **pfcPart.Material.GetModelDefByTests**
- **pfcPart.Material.SetModelDefByTests**

The method **pfcPart.pfcPart.MaterialProperty_Create** creates a new instance of a material property object.

All numerical material properties are accessed using the same set of APIs. You must provide a property type to indicate the property you want to read or modify.

The method **pfcPart.Material.GetPropertyValue** returns the value and the units of the material property.

Use the method **pfcPart.Material.SetPropertyValue** to set the value and units of the material property. If the property type does not exist for the material, then this method creates it.

Use the method **pfcPart.Material.SetPropertyUnits** to set the units of the material property.

Use the method **pfcPart.Material.RemoveProperty** to remove the material property.

Material properties that are non-numeric can be accessed via property-specific get and set methods.

The methods **pfcPart.Material.GetDescription** and **pfcPart.Material.SetDescription** return and set the description string for the material respectively.

The methods **pfcPart.Material.GetFatigueType** and **pfcPart.Material.SetFatigueType** return and set the valid fatigue type for the material respectively.

Use the method **pfcPart.Material.GetPermittedFatigueTypes** to get a list of the permitted string values for the fatigue type.

The methods **pfcPart.Material.GetFatigueMaterialType** and **pfcPart.Material.SetFatigueMaterialType** return and set the class of material when determining the effect of the fatigue respectively.

Use the method **pfcPart.Material.GetPermittedFatigueMaterialTypes** to retrieve a list of the permitted string values for the fatigue material type.

The methods **pfcPart.Material.GetFatigueMaterialFinish** and **pfcPart.Material.SetFatigueMaterialFinish** return and set the type of surface finish for the fatigue material respectively.

Use the method **pfcPart.Material.GetPermittedFatigueMaterialFinishes** to retrieve a list of permitted string values for the fatigue material finish.

The method **pfcPart.Material.GetFailureCriterion** returns the reduction factor for the failure strength of the material. This factor is used to reduce the endurance limit of the material to account for unmodeled stress concentrations, such as those found in welds. Use the method **pfcPart.Material.SetFailureCriterion** to set the reduction factor for the failure strength of the material.

Use the method

pfcPart.Material.GetPermittedFailureCriteria to retrieve a list of permitted string values for the material failure criterion.

The methods **pfcPart.Material.GetHardness** and **pfcPart.Material.SetHardness** return and set the hardness for the specified material respectively.

The methods **pfcPart.Material.GetHardnessType** and **pfcPart.Material.SetHardnessType** return and set the hardness type for the specified material respectively.

The methods **pfcPart.Material.GetCondition** and **pfcPart.Material.SetCondition** return and set the condition for the specified material respectively.

The methods **pfcPart.Material.GetBendTable** and **pfcPart.Material.SetBendTable** return and set the bend table for the specified material respectively.

The methods **pfcPart.Material.GetCrossHatchFile** and **pfcPart.Material.SetCrossHatchFile** return and set the file containing the crosshatch pattern for the specified material respectively.

The methods **pfcPart.Material.GetMaterialModel** and **pfcPart.Material.SetMaterialModel** return and set the type of hyperelastic isotropic material model respectively.

Use the method

pfcPart.Material.GetPermittedMaterialModels to retrieve a list of the permitted string values for the material model.

The methods **pfcPart.Material.GetModelDefByTests** determines whether the hyperelastic isotropic material model has been defined using experimental data for stress and strain.

Use the method **pfcPart.Material.SetModelDefByTests** to define the hyperelastic isotropic material model using experimental data for stress and strain.

Accessing User-defined Material Properties

Materials permit assignment of user-defined parameters. These parameters allow you to place non-standard properties on a given material. Therefore `pfcPart.Material` is a child of `pfcModelItem.ParameterOwner`, which provides access to user-defined parameters and properties of materials through the methods in that interface.

12

Windows and Views

J-Link provides access to Pro/ENGINEER windows and saved views. This chapter describes the methods that provide this access.

Topic	Page
Windows	12 - 2
Embedded Browser	12 - 4
Views	12 - 4
Coordinate Systems and Transformations	12 - 6

Windows

This section describes the J-Link methods that access Window objects. The topics are as follows:

- Getting a Window Object
- Window Operations

Getting a Window Object

Methods Introduced:

- **pfcSession.BaseSession.GetCurrentWindow**
- **pfcSession.BaseSession.CreateModelWindow**
- **pfcModel.Model.Display**
- **pfcSession.BaseSession.ListWindows**
- **pfcSession.BaseSession.GetWindow**
- **pfcSession.BaseSession.OpenFile**
- **pfcSession.BaseSession.GetModelWindow**

The method **pfcSession.BaseSession.GetCurrentWindow** provides access to the current active window in Pro/ENGINEER.

The method **pfcSession.BaseSession.CreateModelWindow** creates a new window that contains the model that was passed as an argument.

Note: You must call the method **pfcModel.Model.Display** for the model geometry to be displayed in the window.

Use the method **pfcSession.BaseSession.ListWindows** to get a list of all the current windows in session.

The method **pfcSession.BaseSession.GetWindow** gets the handle to a window given its integer identifier.

The method **pfcSession.BaseSession.OpenFile** returns the handle to a newly created window that contains the opened model.

Note: If a model is already open in a window the method returns a handle to the window.

The method **pfcSession.BaseSession.GetModelWindow** returns the handle to the window that contains the opened model, if it is displayed.

Window Operations

Methods Introduced:

- **pfcWindow.Window.GetHeight**
- **pfcWindow.Window.GetWidth**
- **pfcWindow.Window.GetXPos**
- **pfcWindow.Window.GetYPos**
- **pfcWindow.Window.GetGraphicsAreaHeight**
- **pfcWindow.Window.GetGraphicsAreaWidth**
- **pfcWindow.Window.Clear**
- **pfcWindow.Window.Repaint**
- **pfcWindow.Window.Refresh**
- **pfcWindow.Window.Close**
- **pfcWindow.Window.Activate**
- **pfcWindow.Window.GetId**

The methods **pfcWindow.Window.GetHeight**, **pfcWindow.Window.GetWidth**, **pfcWindow.Window.GetXPos**, and **pfcWindow.Window.GetYPos** retrieve the height, width, x-position, and y-position of the window respectively. The values of these parameters are normalized from 0 to 1.

The methods **pfcWindow.Window.GetGraphicsAreaHeight** and **pfcWindow.Window.GetGraphicsAreaWidth** retrieve the height and width of the Pro/ENGINEER graphics area window without the border respectively. The values of these parameters are normalized from 0 to 1. For both the window and graphics area sizes, if the object occupies the whole screen, the window size returned is 1. For example, if the screen is 1024 pixels wide and the graphics area is 512 pixels, then the width of the graphics area window is returned as 0.5.

The method **pfcWindow.Window.Clear** removes geometry from the window.

Both **pfcWindow.Window.Repaint** and **pfcWindow.Window.Refresh** repaint solid geometry. However, the **Refresh** method does not remove highlights from the screen and is used primarily to remove temporary geometry entities from the screen.

Use the method **pfcWindow.Window.Close** to close the window. If the current window is the original window created when Pro/ENGINEER started, this method clears the window. Otherwise, it removes the window from the screen.

The method **pfcWindow.Window.Activate** activates a window. This function is available only in the asynchronous mode.

The method **pfcWindow.Window.GetId** retrieves the ID of the Pro/ENGINEER window.

Embedded Browser

Methods Introduced:

- **pfcWindow.Window.GetURL**
- **pfcWindow.Window.SetURL**
- **pfcWindow.Window.GetBrowserSize**
- **pfcWindow.Window.SetBrowserSize**

The methods **pfcWindow.Window.GetURL** and **pfcWindow.Window.SetURL** enables you to find and change the URL displayed in the embedded browser in the Pro/ENGINEER window.

The methods **pfcWindow.Window.GetBrowserSize** and **pfcWindow.Window.SetBrowserSize** enables you to find and change the size of the embedded browser in the Pro/ENGINEER window.

Views

This section describes the J-Link methods that access `View` objects. The topics are as follows:

- Getting a View Object
- View Operations

Getting a View Object

Methods Introduced:

- **pfcView.ViewOwner.RetrieveView**
- **pfcView.ViewOwner.GetView**
- **pfcView.ViewOwner.ListViews**
- **pfcView.ViewOwner.GetCurrentView**

Any solid model inherits from the interface **ViewOwner**. This will enable you to use these methods on any solid object.

The method **pfcView.ViewOwner.RetrieveView** sets the current view to the orientation previously saved with a specified name.

Use the method **pfcView.ViewOwner.GetView** to get a handle to a named view without making any modifications.

The method **pfcView.ViewOwner.ListViews** returns a list of all the views previously saved in the model.

The method **pfcView.ViewOwner.GetCurrentView** returns a view handle that represents the current orientation. Although this view does not have a name, you can use this view to find or modify the current orientation.

View Operations

Methods Introduced:

- **pfcView.View.GetName**
- **pfcView.View.GetIsCurrent**
- **pfcView.View.Reset**
- **pfcView.ViewOwner.SaveView**

To get the name of a view given its identifier, use the method **pfcView.View.GetName**.

The method **pfcView.View.GetIsCurrent** determines if the View object represents the current view.

The **pfcView.View.Reset** method restores the current view to the default view.

To store the current view under the specified name, call the method **pfcView.ViewOwner.SaveView**.

Coordinate Systems and Transformations

This section describes the various coordinate systems used by Pro/ENGINEER and accessible from J-Link and how to transform from one coordinate system to another.

Coordinate Systems

Pro/ENGINEER and J-Link use the following coordinate systems:

- Solid Coordinate System
- Screen Coordinate System
- Window Coordinate System
- Drawing Coordinate System
- Drawing View Coordinate System
- Assembly Coordinate System
- Datum Coordinate System
- Section Coordinate System

The following sections describe each of these coordinate systems.

Solid Coordinate System

The solid coordinate system is the three-dimensional, Cartesian coordinate system used to describe the geometry of a Pro/ENGINEER solid model. In a part, the solid coordinate system describes the geometry of the surfaces and edges. In an assembly, the solid coordinate system also describes the locations and orientations of the assembly members.

You can visualize the solid coordinate system in Pro/ENGINEER by creating a coordinate system datum with the option **Default**. Distances measured in solid coordinates correspond to the values of dimensions as seen by the Pro/ENGINEER user.

Solid coordinates are used by J-Link for all the methods that look at geometry and most of the methods that draw three-dimensional graphics.

Screen Coordinate System

The screen coordinate system is two-dimensional coordinate system that describes locations in a Pro/ENGINEER window. When the user zooms or pans the view, the screen coordinate system follows the display of the solid so a particular point on the solid always maps to the same screen coordinate. The mapping changes only when the view orientation is changed.

Screen coordinates are nominal pixel counts. The bottom, left corner of the default window is at (0, 0) and the top, right corner is at (1000, 864).

Screen coordinates are used by some of the graphics methods, the mouse input methods, and all methods that draw graphics or manipulate items on a drawing.

Window Coordinate System

The window coordinate system is similar to the screen coordinate system, except it is not affected by zoom and pan. When an object is first displayed in a window, or the option **View, Pan/Zoom, Reset** is used, the screen and window coordinates are the same.

Window coordinates are needed only if you take account of zoom and pan. For example, you can find out whether a point on the solid is visible in the window or you can draw two-dimensional text in a particular window location, regardless of pan and zoom.

Drawing Coordinate System

The drawing coordinate system is a two-dimensional system that describes the location on a drawing relative to the bottom, left corner, and measured in drawing units. For example, on a U.S. letter-sized, landscape-format drawing sheet that uses inches, the top, right-corner is (11, 8.5) in drawing coordinates.

The J-Link methods that manipulate drawings generally use screen coordinates.

Drawing View Coordinate System

The drawing view coordinate system is used to describe the locations of entities in a drawing view.

Assembly Coordinate System

An assembly has its own coordinate system that describes the positions and orientations of the member parts, subassemblies, and the geometry of datum features created in the assembly.

When an assembly is retrieved into memory each member is also loaded and continues to use its own solid coordinate system to describe its geometry.

This is important when you are analyzing the geometry of a subassembly and want to extract or display the results relative to the coordinate system of the parent assembly.

Datum Coordinate System

A coordinate system datum can be created anywhere in any part or assembly, and represents a user-defined coordinate system. It is often a requirement in a J-Link application to describe geometry relative to such a datum.

Section Coordinate System

Every sketch has a coordinate system used to locate entities in that sketch. Sketches used in features will use a coordinate system different from that of the solid model.

Transformations

Methods Introduced:

- `pfcBase.Transform3D.Invert`
- `pfcBase.Transform3D.TransformPoint`
- `pfcBase.Transform3D.TransformVector`
- `pfcBase.Transform3D.GetMatrix`
- `pfcBase.Transform3D.SetMatrix`
- `pfcBase.Transform3D.GetOrigin`
- `pfcBase.Transform3D.GetXAxis`
- `pfcBase.Transform3D.GetYAxis`
- `pfcBase.Transform3D.GetZAxis`

All coordinate systems are treated in J-Link as if they were three-dimensional. Therefore, a point in any of the coordinate systems is always represented by the `pfcBase.Point3D` class:

Vectors store the same data but are represented for clarity by the `ptcBase.Vector3D` class.

Screen coordinates contain a z-value whose positive direction is outwards from the screen. The value of z is not generally important when specifying a screen location as an input to a method, but it is useful in other situations. For example, if you select a datum plane, you can find the direction of the plane by calculating the normal to the plane, transforming to screen coordinates, then looking at the sign of the z-coordinate.

A transformation between two coordinate systems is represented by the `ptcBase.Transform3D` class. This class contains a 4x4 matrix that combines the conventional 3x3 matrix that describes the relative orientation of the two systems, and the vector that describes the shift between them.


The 4x4 matrix used for transformations is as follows:

$$\begin{bmatrix} X' & Y' & Z' & 1 \end{bmatrix} = \begin{bmatrix} X & Y & Z & 1 \end{bmatrix} \begin{bmatrix} \dots & \dots & \dots & 0 \\ \dots & \dots & \dots & 0 \\ \dots & \dots & \dots & 0 \\ X_s & Y_s & Z_s & 1 \end{bmatrix}$$

The utility method **`ptcBase.Transform3D.Invert`** inverts a transformation matrix so that it can be used to transform points in the opposite direction.

J-Link provides two utilities for performing coordinate transformations. The method **`ptcBase.Transform3D.TransformPoint`** transforms a three-dimensional point and **`ptcBase.Transform3D.TransformVector`** transforms a three-dimensional vector.

The following diagram summarizes the coordinate transformations needed when using J-Link and specifies the J-Link methods that provide the transformation matrix.



Transforming to Screen Coordinates

Methods Introduced:

- **pfcView.View.GetTransform**
- **pfcView.View.SetTransform**
- **pfcView.View.Rotate**

The view matrix describes the transformation from solid to screen coordinates. The method **pfcView.View.GetTransform** provides the view matrix for the specified view. The method **pfcView.View.SetTransform** allows you to specify a matrix for the view.

The method **pfcView.View.Rotate** rotates a view, relative to the X, Y, or Z axis, in the amount that you specify.

To transform from screen to solid coordinates, invert the transformation matrix using the method **pfcBase.Transform3D.Invert**.

Transforming to Coordinate System Datum Coordinates

Method Introduced:

- **pfcGeometry.CoordSystem.GetCoordSys**

The method **pfcGeometry.CoordSystem.GetCoordSys** provides the location and orientation of the coordinate system datum in the coordinate system of the solid that contains it. The location is in terms of the directions of the three axes and the position of the origin.

Transforming Window Coordinates

Methods Introduced

- **pfcWindow.Window.GetScreenTransform**
- **pfcWindow.Window.SetScreenTransform**
- **pfcBase.ScreenTransform.SetPanX**
- **pfcBase.ScreenTransform.SetPanY**
- **pfcBase.ScreenTransform.SetZoom**

You can alter the pan and zoom of a window by using a Screen Transform object. This object contains three attributes. PanX and PanY represent the horizontal and vertical movement. Every increment of 1.0 moves the view point one screen width or height. Zoom represents a scaling factor for the view. This number must be greater than zero.

Transforming Coordinates of an Assembly Member

Method Introduced:

- **pfcAssembly.ComponentPath.GetTransform**

The method **pfcAssembly.ComponentPath.GetTransform** provides the matrix for transforming from the solid coordinate system of the assembly member to the solid coordinates of the parent assembly, or the reverse.

Example Code - Normalizing a Coordinate Transformation Matrix

The following example code uses two methods to transfer the view transformation from one view to another. The method ***viewTransfer*** accepts two views and transfers the matrix from the first to the second. This matrix is normalized using the second method, ***matrixNormalize***.

Views can be changed to a normalized matrix only. The example method **UtilMatrixNormalize** takes a `Matrix3D` object and normalizes it.

Note: Both of these methods are declared to throw the exception `jxthrowable`. You need to put your error-handling code in the methods that call the utility methods.

```
import java.lang.Math.*;
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcView.*;
import com.ptc.pfc.pfcBase.*;

public class UtilView
{
    // ViewTransfer method transfers a matrix from one view into the other.

    public static View viewTransfer (View view1, View view2) throws
        jxthrowable
    {
        Transform3D transform;
        Matrix3D matrix;

        transform = view1.GetTransform();
        matrix = transform.GetMatrix();
        matrix = matrixNormalize (matrix);
        transform.SetMatrix (matrix);
        view2.SetTransform (transform);

        return (view2);
    }

    // Normalize function: Normalizes a Matrix3D object

    public static Matrix3D matrixNormalize(Matrix3D m) throws jxthrowable
    {
        double scale;
        int row, col;

        // Set the bottom row to 0.0.

        m.set (3,0, 0.0);
        m.set (3,1, 0.0);
        m.set (3,2, 0.0);

        // Normalization scale

        scale = Math.sqrt (m.get(0,0)*m.get(0,0) +
            m.get(0,1)*m.get(0,1) +
```

```
        m.get(0,2)* m.get(0,2));  
    for (row = 0;row < 3; row++)  
        for (col = 0;col < 3; col++)  
            m.set (row, col, m.get(row, col)/scale);  
    return (m);  
    }  
}
```


13

ModelItem

This chapter describes the J-Link methods that enable you to access and manipulate `ModelItems`.

Topic	Page
Solid Geometry Traversal	13 - 2
Getting ModelItem Objects	13 - 2
ModelItem Information	13 - 3
Layer Objects	13 - 4

Solid Geometry Traversal

Solid models are made up of 11 distinct types of `ModelItem`, as follows:

- `pfcFeature.Feature`
- `pfcGeometry.Surface`
- `pfcGeometry.Edge`
- `pfcGeometry.Curve` (datum curve)
- `pfcGeometry.Axis` (datum axis)
- `pfcGeometry.Point` (datum point)
- `pfcGeometry.Quilt` (datum quilt)
- `pfcLayer.Layer`
- `pfcNote.Note`
- `pfcDimension.Dimension`
- `pfcDimension.RefDimension`

Each model item is assigned a unique identification number that will never change. In addition, each model item can be assigned a string name. Layers, points, axes, dimensions, and reference dimensions are automatically assigned a name that can be changed.

Getting ModelItem Objects

Methods Introduced:

- `pfcModelItem.ModelItemOwner.ListItems`
- `pfcFeature.Feature.ListSubItems`
- `pfcLayer.Layer.ListItems`
- `pfcModelItem.ModelItemOwner.GetItemById`
- `pfcModelItem.ModelItemOwner.GetItemByName`
- `pfcFamily.FamColModelItem.GetRefItem`
- `pfcSelect.Selection.GetSelItem`

All models inherit from the interface `ModelItemOwner`. The method **`pfcModelItem.ModelItemOwner.ListItems`** returns a sequence of `ModelItems` contained in the model. You can specify which type of `ModelItem` to collect by passing in one of the enumerated `ModelItemType` objects, or you can collect all `ModelItems` by passing **`null`** as the model item type.

The methods **`pfcFeature.Feature.ListSubItems`** and **`pfcLayer.Layer.ListItems`** produce similar results for specific features and layers. These methods return a list of subitems in the feature or items in the layer.

To access specific model items, call the method **`pfcModelItem.ModelItemOwner.GetItemById`**. This method enables you to access the model item by identifier.

To access specific model items, call the method **`pfcModelItem.ModelItemOwner.GetItemByName`**. This method enables you to access the model item by name.

The method **`pfcFamily.FamColModelItem.GetRefItem`** returns the dimension or feature used as a header for a family table.

The method **`pfcSelect.Selection.GetSelItem`** returns the item selected interactively by the user.

ModelItem Information

Methods Introduced:

- **`pfcModelItem.ModelItem.GetName`**
- **`pfcModelItem.ModelItem.SetName`**
- **`pfcModelItem.ModelItem.GetId`**
- **`pfcModelItem.ModelItem.GetType`**

Certain `ModelItems` also have a string name that can be changed at any time. The methods **`GetName`** and **`SetName`** access this name.

The method **`GetId`** returns the unique integer identifier for the `ModelItem`.

The **`GetType`** method returns an enumeration object that indicates the model item type of the specified `ModelItem`. See the section “Solid Geometry Traversal” for the list of possible model item types.

Layer Objects

In J-Link, layers are instances of `ModelItem`. The following sections describe how to get layer objects and the operations you can perform on them.

Getting Layer Objects

Method Introduced:

- **`pfcModel.Model.CreateLayer`**

The method **`pfcModel.Model.CreateLayer`** returns a new layer with the name you specify.

See the section “Getting `ModelItem` Objects” for other methods that can return layer objects.

Layer Operations

Methods Introduced:

- **`pfcLayer.Layer.GetStatus`**
- **`pfcLayer.Layer.SetStatus`**
- **`pfcLayer.Layer.ListItems`**
- **`pfcLayer.Layer.AddItem`**
- **`pfcLayer.Layer.RemoveItem`**
- **`pfcLayer.Layer.Delete`**

The methods **`pfcLayer.Layer.GetStatus`** and **`pfcLayer.Layer.SetStatus`** enable you to access the display status of a layer. The corresponding enumeration class is `DisplayStatus` and the possible values are `Normal`, `Displayed`, `Blank`, or `Hidden`.

Use the methods **`pfcLayer.Layer.ListItems`**, **`pfcLayer.Layer.AddItem`**, and **`pfcLayer.Layer.RemoveItem`** to control the contents of a layer.

The method **`pfcLayer.Layer.Delete`** removes the layer (but not the items it contains) from the model.

14

Features

All Pro/ENGINEER solid models are made up of features. This chapter describes how to program on the feature level using J-Link.

Topic	Page
Access to Features	14 - 2
Feature Information	14 - 3
Feature Operations	14 - 4
Feature Groups and Patterns	14 - 6
User Defined Features	14 - 8
Creating Features from UDFs	14 - 9

Access to Features

Methods Introduced:

- **pfcFeature.Feature.ListChildren**
- **pfcFeature.Feature.ListParents**
- **pfcFeature.FeatureGroup.GetGroupLeader**
- **pfcFeature.FeaturePattern.GetPatternLeader**
- **pfcFeature.FeaturePattern.ListMembers**
- **pfcSolid.Solid.ListFailedFeatures**
- **pfcSolid.Solid.ListFeaturesByType**
- **pfcSolid.Solid.GetFeatureById**

The methods **pfcFeature.Feature.ListChildren** and **pfcFeature.Feature.ListParents** return a sequence of features that contain all the children or parents of the specified feature.

To get the first feature in the specified group access the method **pfcFeature.FeatureGroup.GetGroupLeader**.

The methods **pfcFeature.FeaturePattern.GetPatternLeader** and **pfcFeature.FeaturePattern.ListMembers** return features that make up the specified feature pattern. See the section *Feature Groups and Patterns* for more information on feature patterns.

The method **pfcSolid.Solid.ListFailedFeatures** returns a sequence that contains all the features that failed regeneration.

The method **pfcSolid.Solid.ListFeaturesByType** returns a sequence of features contained in the model. You can specify which type of feature to collect by passing in one of the `FeatureType` enumeration objects, or you can collect all features by passing **void null** as the type. If you list all features, the resulting sequence will include invisible features that Pro/ENGINEER creates internally. Use the method's *VisibleOnly* argument to exclude them.

The method **pfcSolid.Solid.GetFeatureById** returns the feature object with the corresponding integer identifier.

Feature Information

Methods Introduced:

- **pfcFeature.Feature.GetFeatType**
- **pfcFeature.Feature.GetStatus**
- **pfcFeature.Feature.GetIsVisible**
- **pfcFeature.Feature.GetIsReadOnly**
- **pfcFeature.Feature.GetIsEmbedded**
- **pfcFeature.Feature.GetNumber**
- **pfcFeature.Feature.GetFeatTypeName**
- **pfcFeature.Feature.GetFeatSubType**
- **pfcRoundFeat.RoundFeat.GetIsAutoRoundMember**

The enumeration classes `FeatureType` and `FeatureStatus` provide information for a specified feature. The following methods specify this information:

- **pfcFeature.Feature.GetFeatType**—Returns the type of a feature.
- **pfcFeature.Feature.GetStatus**—Returns whether the feature is suppressed, active, or failed regeneration.

The other methods that gather feature information include the following:

- **pfcFeature.Feature.GetIsVisible**—Identifies whether the specified feature will be visible on the screen.
- **pfcFeature.Feature.GetIsReadOnly**—Identifies whether the specified feature can be modified.
- **pfcFeature.Feature.GetIsEmbedded**—Specifies whether the specified feature is an embedded datum.
- **pfcFeature.Feature.GetNumber**—Returns the feature regeneration number. This method returns **void null** if the feature is suppressed.

The method **pfcFeature.Feature.GetFeatTypeName** returns a string representation of the feature type.

The method **pfcFeature.Feature.GetFeatSubType** returns a string representation of the feature subtype, for example, "Extrude" for a protrusion feature.

The method **pfcRoundFeat.RoundFeat.GetIsAutoRoundMember** determines whether the specified round feature is a member of an Auto Round feature.

Feature Operations

Methods Introduced:

- **pfcSolid.Solid.ExecuteFeatureOps**
- **pfcFeature.Feature.CreateSuppressOp**
- **pfcFeature.SuppressOperation.SetClip**
- **pfcFeature.SuppressOperation.SetAllowGroupMembers**
- **pfcFeature.SuppressOperation.SetAllowChildGroupMembers**
- **pfcFeature.Feature.CreateDeleteOp**
- **pfcFeature.DeleteOperation.SetClip**
- **pfcFeature.DeleteOperation.SetAllowGroupMembers**
- **pfcFeature.DeleteOperation.SetAllowChildGroupMembers**
- **pfcFeature.DeleteOperation.SetKeepEmbeddedDatums**
- **pfcFeature.Feature.CreateResumeOp**
- **pfcFeature.ResumeOperation.SetWithParents**
- **pfcFeature.Feature.CreateReorderBeforeOp**
- **pfcFeature.ReorderBeforeOperation.SetBeforeFeat**
- **pfcFeature.Feature.CreateReorderAfterOp**
- **pfcFeature.ReorderAfterOperation.SetAfterFeat**
- **pfcFeature.FeatureOperations.create**

The method **pfcSolid.Solid.ExecuteFeatureOps** causes a sequence of feature operations to run in order. Feature operations include suppressing, resuming, reordering, and deleting features. The optional *RegenInstructions* argument specifies whether the user will be allowed to fix the model if a regeneration failure occurs.

Note: The method **pfcSolid.Solid.ExecuteFeatureOps** is not supported in the No-Resolve mode, introduced in Pro/ENGINEER Wildfire 5.0. It throws an exception `pfcExceptions.XtoolkitBadContext`. To continue with the Pro/ENGINEER Wildfire 4.0 behavior in the

Resolve mode, set the configuration option `regen_failure_handling` to `resolve_mode` in the Pro/ENGINEER session. Refer to the "Solid Operations" section in the "Solid" chapter for more information on the No-Resolve mode.

You can create an operation that will delete, suppress, reorder, or resume certain features using the methods in the interface **pfcFeature.Feature**. Each created operation must be passed as a member of the **FeatureOperations** object to the method **pfcSolid.Solid.ExecuteFeatureOps**. You can create a sequence of the **FeatureOperations** object using the method **pfcFeature.FeatureOperations.create**.

Some of the operations have specific options that you can modify to control the behavior of the operation:

- *Clip*—Specifies whether to delete or suppress all features after the selected feature. By default, this option is false. Use the methods **pfcFeature.DeleteOperation.SetClip** and **pfcFeature.SuppressOperation.SetClip** to modify this option.
- *AllowGroupMembers*—If this option is set to true and if the feature to be deleted or suppressed is a member of a group, then the feature will be deleted or suppressed out of the group. If this option is set to false, then the entire group containing the feature is deleted or suppressed. By default, this option is false. It can be set to true only if the option *Clip* is set to true. Use the methods **pfcFeature.SuppressOperation.SetAllowGroupMembers** and **pfcFeature.DeleteOperation.SetAllowGroupMembers** to modify this option.
- *AllowChildGroupMembers*—If this option is set to true and if the children of the feature to be deleted or suppressed are members of a group, then the children of the feature will be individually deleted or suppressed out of the group. If this option is set to false, then the entire group containing the feature and its children is deleted or suppressed. By default, this option is false. It can be set to true only if the options *Clip* and *AllowGroupMembers* are set to true. Use the methods **pfcFeature.SuppressOperation.SetAllowChildGroupMembers** and **pfcFeature.DeleteOperation.SetAllowChildGroupMembers** to modify this option.

- *KeepEmbeddedDatums*—Specifies whether to retain the embedded datums stored in a feature while deleting the feature. By default, this option is false.
Use the method **pfcFeature.DeleteOperation.SetKeepEmbeddedDatums** to modify this option.
- *WithParents*—Specifies whether to resume the parents of the selected feature.
Use the method **pfcFeature.ResumeOperation.SetWithParents** to modify this option.
- *BeforeFeat*—Specifies the feature before which you want to reorder the features.
Use the method **pfcFeature.ReorderBeforeOperation.SetBeforeFeat** to modify this option.
- *AfterFeat*—Specifies the feature after which you want to reorder the features.
Use the method **pfcFeature.ReorderAfterOperation.SetAfterFeat** to modify this option.

Feature Groups and Patterns

Patterns are treated as features in Pro/ENGINEER Wildfire. A feature type, FEATTYPE_PATTERN_HEAD, is used for the pattern header feature.

The result of the pattern header feature for users of previous versions of J-Link is as follows:

- Models that contain patterns get one extra feature of type FEATTYPE_PATTERN_HEAD in the regeneration list. This changes the feature numbers of all subsequent features, including those in the pattern.

Note: The pattern header feature is not treated as a leader or a member of the pattern by the methods described in the following section.

Methods Introduced:

- **pfcFeature.Feature.GetGroup**
- **pfcFeature.Feature.GetPattern**
- **pfcSolid.Solid.CreateLocalGroup**
- **pfcFeature.FeatureGroup.GetPattern**
- **pfcFeature.FeatureGroup.GetGroupLeader**
- **pfcFeature.FeaturePattern.GetPatternLeader**
- **pfcFeature.FeaturePattern.ListMembers**
- **pfcFeature.FeaturePattern.Delete**

The method **pfcFeature.Feature.GetGroup** returns a handle to the local group that contains the specified feature.

To get the first feature in the specified group call the method **pfcFeature.FeatureGroup.GetGroupLeader**.

The methods **pfcFeature.FeaturePattern.GetPatternLeader** and **pfcFeature.FeaturePattern.ListMembers** return features that make up the specified feature pattern.

The methods **pfcFeature.Feature.GetPattern** and **pfcFeature.FeatureGroup.GetPattern** return the `FeaturePattern` object that contains the corresponding `Feature` or `FeatureGroup`. Use the method **pfcSolid.Solid.CreateLocalGroup** to take a sequence of features and create a local group with the specified name. To delete a `FeaturePattern` object, call the method **pfcFeature.FeaturePattern.Delete**.

Changes To Feature Groups

Beginning in Revision 2000i², the structure of feature groups is different than in previous releases. Feature groups now have a group header feature, which shows up in the model information and feature list for the model. This feature will be inserted in the regeneration list to a position just before the first feature in the group. Existing models, when retrieved into Revision 2000i², will have their groups automatically updated to this structure upon retrieval.

The results of these changes are as follows:

- Models that contain groups will get one extra feature in the regeneration list, of type `FeatureType.FEATTYPE_GROUP_HEAD`. This will change the feature numbers of all subsequent features, including those in the group.
- Each group automatically contains one new feature in the list of features returned from **`pfcFeature.FeatureGroup.ListMembers`**.
- Each group automatically gets a different leader feature (the group head feature is the leader). This is returned from **`pfcFeature.FeatureGroup.GetGroupLeader`**.
- Each group pattern contains a series of groups, and each group in the pattern will be similarly altered.

User Defined Features

Groups in Pro/ENGINEER represent sets of contiguous features that act as a single feature for specific operations. Individual features are affected by most operations while some operations apply to an entire group:

- Suppress
- Delete
- Layers
- Patterning

User defined Features (UDFs) are groups of features that are stored in a file. When a UDF is placed in a new model the created features are automatically assigned to a group. A local group is a set of features that have been specifically assigned to a group to make modifications and patterning easier.

Note: All methods in this section can be used for UDFs and local groups.

Read Access to Groups and User Defined Features

Methods Introduced:

- **pfcFeature.FeatureGroup.GetUDFName**
- **pfcFeature.FeatureGroup.GetUDFInstanceName**
- **pfcFeature.FeatureGroup.ListUDFDimensions**
- **pfcUDFGroup.UDFDimension.GetUDFDimensionName**

User defined features (UDF's) are groups of features that can be stored in a file and added to a new model. A local group is similar to a UDF except it is available only in the model in which it was created.

The method **pfcFeature.FeatureGroup.GetUDFName** provides the name of the group for the specified group instance. A particular group definition can be used more than once in a particular model.

If the group is a family table instance, the method **pfcFeature.FeatureGroup.GetUDFInstanceName** supplies the instance name.

The method **pfcFeature.FeatureGroup.ListUDFDimensions** traverses the dimensions that belong to the UDF. These dimensions correspond to the dimensions specified as variables when the UDF was created. Dimensions of the original features that were not variables in the UDF are not included unless the UDF was placed using the **Independent** option.

The method **pfcUDFGroup.UDFDimension.GetUDFDimensionName** provides access to the dimension name specified when the UDF was created, and not the name of the dimension in the current model. This name is required to place the UDF programmatically using the method **pfcSolid.Solid.CreateUDFGroup**.

Creating Features from UDFs

Method Introduced:

- **pfcSolid.Solid.CreateUDFGroup**

The method **pfcSolid.Solid.CreateUDFGroup** is used to create new features by retrieving and applying the contents of an existing UDF file. It is equivalent to the Pro/ENGINEER command **Feature, Create, User Defined**.

To understand the following explanation of this method, you must have a good knowledge and understanding of the use of UDF's in Pro/ENGINEER. PTC recommends that you read about UDF's in the Pro/ENGINEER on-line help, and practice defining and using UDF's in Pro/ENGINEER before you attempt to use this method.

When you create a UDF interactively, Pro/ENGINEER prompts you for the information it needs to fix the properties of the resulting features. When you create a UDF from J-Link, you can provide some or all of this information programmatically by filling several compact data classes that are inputs to the method **pfcSolid.Solid.CreateUDFGroup**.

During the call to **pfcSolid.Solid.CreateUDFGroup**, Pro/ENGINEER prompts you for the following:

- Information required by the UDF that was not provided in the input data structures.
- Correct information to replace erroneous information

Such prompts are a useful way of diagnosing errors when you develop your application. This also means that, in addition to creating UDF's programmatically to provide automatic synthesis of model geometry, you can also use **pfcSolid.Solid.CreateUDFGroup** to create UDF's semi-interactively. This can simplify the interactions needed to place a complex UDF making it easier for the user and less prone to error.

Creating UDFs

Creating a UDF requires the following information:

- Name—The name of the UDF you are creating and the instance name if applicable.
- Dependency—Specify if the UDF is independent of the UDF definition or is modified by the changers made to it.
- Scale—How to scale the UDF relative to the placement model.
- Variable Dimension—The new values of the variables dimensions and pattern parameters, those whose values can be modified each time the UDF is created.
- Dimension Display—Whether to show or blank non-variable dimensions created within the UDF group.

- **References**—The geometrical elements that the UDF needs in order to relate the features it contains to the existing models features. The elements correspond to the picks that Pro/ENGINEER prompts you for when you create a UDF interactively using the prompts defined when the UDF was created. You cannot select an embedded datum as the UDF reference.
- **Parts Intersection**—When a UDF that is being created in an assembly contains features that modify the existing geometry you must define which parts are affected or intersected. You also need to know at what level in an assembly each intersection is going to be visible.
- **Orientations**—When a UDF contains a feature with a direction that is defined in respect to a datum plane Pro/ENGINEER must know what direction the new feature will point to. When you create such a UDF interactively Pro/ENGINEER prompt you for this information with a flip arrow.
- **Quadrants**—When a UDF contains a linearly placed feature that references two datum planes to define it's location in the new model Pro/ENGINEER prompts you to pick the location of the new feature. This is determined by which side of each datum plane the feature must lie. This selection is referred to as the quadrant because there are four possible combinations for each linearly placed feature.

To pass all the above values to Pro/ENGINEER, J-Link uses a special class that prepares and sets all the options and passes them to Pro/ENGINEER.

Creating Interactively Defined UDFs

Method Introduced:

- **pfcUDFGroup.pfcUDFGroup.UDFPromptCreateInstructions_Create**

This static method is used to create an instructions object that can be used to prompt a user for the required values that will create a UDF interactively.

Creating a Custom UDF

Method Introduced:

- **pfcUDFCreate.pfcUDFCreate.UDFCustomCreateInstructions_Create**

This method creates a `UDFCustomCreateInstructions` object with a specified name. To set the UDF creation parameters programmatically you must modify this object as described below. The members of this class relate closely to the prompts Pro/ENGINEER gives you when you create a UDF interactively. PTC recommends that you experiment with creating the UDF interactively using Pro/ENGINEER before you write the J-Link code to fill the structure.

Setting the Family Table Instance Name

Methods Introduced:

- **`pfcUDFCreate.UDFCustomCreateInstructions.SetInstanceName`**
- **`pfcUDFCreate.UDFCustomCreateInstructions.GetInstanceName`**

If the UDF contains a family table, this field can be used to select the instance in the table. If the UDF does not contain a family table, or if the generic instance is to be selected, do not set the string.

Setting Dependency Type

Methods Introduced:

- **`pfcUDFCreate.UDFCustomCreateInstructions.SetDependencyType`**
- **`pfcUDFCreate.UDFCustomCreateInstructions.GetDependencyType`**

The `UDFDependencyType` object represents the dependency type of the UDF. The choices correspond to the choices available when you create a UDF interactively. This enumerated type takes the following values:

- `UDFDEP_INDEPENDENT`
- `UDFDEP_DRIVEN`

Note: `UDFDEP_INDEPENDENT` is the default value, if this option is not set.

Setting Scale and Scale Type

Methods Introduced:

- **`pfcUDFCreate.UDFCustomCreateInstructions.SetScaleType`**
- **`pfcUDFCreate.UDFCustomCreateInstructions.GetScaleType`**
- **`pfcUDFCreate.UDFCustomCreateInstructions.SetScale`**
- **`pfcUDFCreate.UDFCustomCreateInstructions.GetScale`**

ScaleType specifies the length units of the UDF in the form of the *UDFScaleType* object. This enumerated type takes the following values:

- `UDFSCALE_SAME_SIZE`
- `UDFSCALE_SAME_DIMS`
- `UDFSCALE_CUSTOM`
- `UDFSCALE_nil`

Note: The default value is `UDFSCALE_SAME_SIZE` if this option is not set.

Scale specifies the scale factor. If the *ScaleType* is set to `UDFSCALE_CUSTOM`, *SetScale* assigns the user defined scale factor. Otherwise, this attribute is ignored.

Setting the Appearance of the Non UDF Dimensions

Methods Introduced:

- `pfcUDFCreate.UDFCustomCreateInstructions.SetDimDisplayType`
- `pfcUDFCreate.UDFCustomCreateInstructions.GetDimDisplayType`

The `pfcUDFCreate.UDFDimensionDisplayType` object sets the options in Pro/ENGINEER for determining the appearance in the model of UDF dimensions and pattern parameters that were not variable in the UDF, and therefore cannot be modified in the model. This enumerated type takes the following values:

- `UDFDISPLAY_NORMAL`
- `UDFDISPLAY_READ_ONLY`
- `UDFDISPLAY_BLANK`

Note: The default value is `UDFDISPLAY_NORMAL` if this option is not set.

Setting the Variable Dimensions and Parameters

Methods Introduced:

- `pfcUDFCreate.UDFCustomCreateInstructions.SetVariantValues`
- `pfcUDFCreate.UDFVariantValues.create`
- `pfcUDFCreate.UDFVariantValues.insert`
- `pfcUDFCreate.pfcUDFCreate.UDFVariantDimension_Create`
- `pfcUDFCreate.pfcUDFCreate.UDFVariantPatternParam_Create`

`pfcUDFVariantValues` class represents an array of variable dimensions and pattern parameters.

Use **`pfcUDFCreate.UDFVariantValues.create`** to create an empty object and then use **`pfcUDFCreate.UDFVariantValues.insert`** to add `pfcUDFCreate.UDFVariantPatternParam` or `pfcUDFCreate.UDFVariantDimension` objects one by one. **`pfcUDFCreate.pfcUDFCreate.UDFVariantDimension_Create`** is a static method creating a `pfcUDFCreate.UDFVariantDimension`. It accepts the following parameters:

- *Name*—The symbol that the dimension had when the UDF was originally defined not the prompt that the UDF uses when it is created interactively. To make this name easy to remember, before you define the UDF that you plan to create with the J-Link, you should modify the symbols of all the dimensions that you want to select to be variable. If you get the name wrong, **`pfcSolid.Solid.CreateUDFGroup`** will not recognize the dimension and prompts the user for the value in the usual way does not modify the value.
- *DimensionValue*—The new value.

If you do not remember the name, you can find it by creating the UDF interactively in a test model, then using the **`pfcFeature.FeatureGroup.ListUDFDimensions`** and **`pfcUDFGroup.UDFDimension.GetUDFDimensionName`** to find out the name.

`pfcUDFCreate.pfcUDFCreate.UDFVariantPatternParam_Create` is a static method which creates a `pfcUDFCreate.UDFVariantPatternParam`. It accepts the following parameters:

- *name*—The string name that the pattern parameter had when the UDF was originally defined
- *number*—The new value.

After the `pfcUDFCreate.UDFVariantValues` object has been compiled, use **`pfcUDFCreate.UDFCustomCreateInstructions.SetVariantValues`** to add the variable dimensions and parameters to the instructions.

Setting the User Defined References

Methods Introduced:

- **pfcUDFCreate.UDFReferences.create**
- **pfcUDFCreate.UDFReferences.insert**
- **pfcUDFCreate.pfcUDFCreate.UDFReference_Create**
- **pfcUDFCreate.UDFReference.SetIsExternal**
- **pfcUDFCreate.UDFReference.SetReferenceItem**
- **pfcUDFCreate.UDFCustomCreateInstructions.SetReferences**

UDFReferences class represents an array of element references. Use **pfcUDFCreate.UDFReferences.create** to create an empty object and then use **pfcUDFCreate.UDFReferences.insert** to add `UDFReference` objects one by one.

The method **pfcUDFCreate.pfcUDFCreate.UDFReference_Create** is a static method creating a `UDFReference` object. It accepts the following parameters:

- *PromptForReference*—The prompt defined for this reference when the UDF was originally set up. It indicates which reference this structure is providing. If you get the prompt wrong, **pfcSolid.Solid.CreateUDFGroup** will not recognize it and prompts the user for the reference in the usual way.
- *ReferenceItem*—Specifies the `pfcSelect.Selection` object representing the referenced element. You can set `Selection` programmatically or prompt the user for a selection separately. You cannot set an embedded datum as the UDF reference.

There are two types of reference:

- *Internal*—The referenced element belongs directly to the model that will contain the UDF. For an assembly, this means that the element belongs to the top level.
- *External*—The referenced element belongs to an assembly member other than the placement member.

To set the reference type, use the method **pfcUDFCreate.UDFReference.SetIsExternal**.

To set the item to be used for reference, use the method **pfcUDFCreate.UDFReference.SetReferenceItem**.

After the `UDFReferences` object has been set, use **`pfcUDFCreate.UDFCustomCreateInstructions.SetReferences`** to add the program-defined references.

Setting the Assembly Intersections

Methods Introduced:

- **`pfcUDFCreate.UDFAssemblyIntersections.create()`**
- **`pfcUDFCreate.UDFAssemblyIntersections.insert()`**
- **`pfcUDFCreate.pfcUDFCreate.UDFAssemblyIntersection_Create`**
- **`pfcUDFCreate.UDFAssemblyIntersection.SetInstanceNames`**
- **`pfcUDFCreate.UDFCustomCreateInstructions.SetIntersections`**

The `pfcUDFCreate.UDFAssemblyIntersections` class represents an array of element references.

Use

`pfcUDFCreate.pfcUDFCreate.UDFAssemblyIntersections.create` to create an empty object and then use **`pfcUDFCreate.UDFAssemblyIntersections.insert`** to add `pfcUDFCreate.UDFAssemblyIntersection` objects one by one.

`pfcUDFCreate.pfcUDFCreate.UDFAssemblyIntersection_Create` is a static method creating a `pfcUDFCreate.UDFReference` object. It accepts the following parameters:

- *ComponentPath*—Is an `com.ptc.cipjava.intseq` type object representing the component path of the part to be intersected.
- *Visibility level*—The number that corresponds to the visibility level of the intersected part in the assembly. If the number is equal to the length of the component path the feature is visible in the part that it intersects. If *Visibility level* is 0, the feature is visible at the level of the assembly containing the UDF.

`pfcUDFCreate.UDFAssemblyIntersection.SetInstanceNames` sets an array of names for the new instances of parts created to represent the intersection geometry. This method accepts the following parameters:

- *instance names*—is a `com.ptc.cipjava.stringseq` type object representing the array of new instance names.

After the `pfcUDFCreate.UDFAssemblyIntersections` object has been set, use

`pfcUDFCreate.UDFCustomCreateInstructions.SetIntersections` to add the assembly intersections.

Setting Orientations

Methods Introduced:

- **pfcUDFCreate.UDFCustomCreateInstructions.SetOrientations**
- **pfcUDFCreate.UDFOrientations.create**
- **pfcUDFCreate.UDFOrientations.insert**

`pfcUDFCreate.UDFOrientations` class represents an array of orientations that provide the answers to Pro/ENGINEER prompts that use a flip arrow. Each term is a `pfcUDFCreate.UDFOrientation` object that takes the following values:

- **UDFORIENT_INTERACTIVE**—Prompt for the orientation using a flip arrow.
- **UDFORIENT_NO_FLIP**—Accept the default flip orientation.
- **UDFORIENT_FLIP**—Invert the orientation from the default orientation.

Use **pfcUDFCreate.UDFOrientations.create** to create an empty object and then use **pfcUDFCreate.UDFOrientations.insert** to add `pfcUDFCreate.UDFOrientation` objects one by one.

The order of orientations should correspond to the order in which Pro/ENGINEER prompts for them when the UDF is created interactively. If you do not provide an orientation that Pro/ENGINEER needs, it uses the default value **NO_FLIP**.

After the `pfcUDFCreate.UDFOrientations` object has been set use **pfcUDFCreate.UDFCustomCreateInstructions.SetOrientations** to add the orientations.

Setting Quadrants

Methods Introduced:

- **pfcUDFCreate.UDFCustomCreateInstructions.SetQuadrants**

The method **pfcUDFCreate.UDFCustomCreateInstructions.SetQuadrants** sets an array of points, which provide the X, Y, and Z coordinates that correspond to the picks answering the Pro/ENGINEER prompts for the feature positions. The order of quadrants should correspond to the order in which Pro/ENGINEER prompts for them when the UDF is created interactively.

Setting the External References

Methods Introduced:

- **pfcUDFCreate.UDFCustomCreateInstructions.SetExtReferences**

The method **pfcUDFCreate.UDFCustomCreateInstructions.SetExtReferences** sets an external reference assembly to be used when placing the UDF. This will be required when placing the UDF in the component using references outside of that component. References could be to the top level assembly of another component.

Example Code

The example code places copies of a node UDF at a particular coordinate system location in a part. The node UDF is a spherical cut centered at the coordinate system whose diameter is driven by the 'diam' argument to the method. The method returns the **FeatureGroup** object created, or null if an error occurred.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcUDFCreate.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcExceptions.*;

public class pfcUDFCreateExamples {

    public static FeatureGroup createNodeUDFInPart (CoordSystem csys,
                                                    double diam)
        throws com.ptc.cipjava.jxthrowable
    {
        /* The instructions for the UDF creation */
        UDFCustomCreateInstructions instrs =
            pfcUDFCreate.UDFCustomCreateInstructions_Create ("node");

        /* Make non-variant dimensions blank so they cannot be changed */
        instrs.SetDimDisplayType (UDFDimensionDisplayType.UDFDISPLAY_BLANK);

        /* Initialize the UDF reference and assign it to the instructions.
           The string argument is the reference prompt for the particular
           reference. */
        Selection csys_sel = pfcSelect.CreateModelItemSelection (csys,null);

        UDFReference csys_ref =
            pfcUDFCreate.UDFReference_Create ("REF_CSYS", csys_sel);
    }
}
```

```

UDFReferences refs = UDFReferences.create();
refs.set (0, csys_ref);

instrs.SetReferences (refs);

/* Initialize the variant dimension and assign it to the
   instructions. The string argument is the dimension symbol for the
   variant dimension. */

UDFVariantDimension var_diam =
    pfcUDFCreate.UDFVariantDimension_Create ("d11", diam);

UDFVariantValues vals = UDFVariantValues.create();
vals.set (0, var_diam);

instrs.SetVariantValues (vals);

/* We need the placement model for the UDF for the call to
   CreateUDFGroup(). If you were placing the UDF in a model other
   than the owner of the coordinate system, the placement would need
   to be provided separately.*/

Solid placement_model = (Solid)csys.GetDBParent();

FeatureGroup group = null;
try
{
    group = placement_model.CreateUDFGroup (instrs);
}
catch (XToolkitError xte)
{
    System.out.println ("Caught exception: "+xte);
    xte.printStackTrace ();
}
return (group);
}
}

```

Example Code

This example places copies of a hole UDF at a particular location in an assembly. The hole is embedded in a surface of one of the assembly's components, and placed a particular location away from two normal datum planes (the default value for the dimension is used for this example).

The UDF creation requires a quadrant determining the location for the UDF (since it could be one of four areas) and intersection instructions for the assembly members (this example makes the hole visible down to the part level).

The method returns the FeatureGroup object created, or null if an error occurred. A usage error may be detected, causing an exception to be thrown.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcUDFCreate.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcModel.*;

public class pfcUDFCreateExamples {

    public static FeatureGroup
        createHoleUDFInAssembly (int side_ref_feat_ids[],
                                ComponentPath reference_path,
                                int placement_surface_id,
                                Double scale,
                                Point3D quadrant)
        throws java.lang.Exception
    {
        if (side_ref_feat_ids.length != 2)
        {
            throw new Exception ("Error: improper array size.");
        }

        UDFCustomCreateInstructions instrs =
            pfcUDFCreate.UDFCustomCreateInstructions_Create ("hole_quadrant");

        if (scale == null)
        {
            instrs.SetScaleType (UDFScaleType.UDFSCALE_SAME_SIZE);
        }
        else
        {
            instrs.SetScaleType (UDFScaleType.UDFSCALE_CUSTOM);
            instrs.SetScale (scale);
        }

        /* The first UDF reference is a surface from a component model in the
           assembly. This requires using the ComponentPath to initialize the
           Selection, and setting the IsExternal flag to true.
           */
        Solid reference_model = reference_path.GetLeaf ();
        ModelItem placement_surface =
            reference_model.GetItemById (ModelItemType.ITEM_SURFACE,
```



```

        placement_surface_id);

    if (!(placement_surface instanceof com.ptc.pfc.pfcGeometry.Surface))
    {
        throw new Exception("Error: input surface id "+
            placement_surface_id+ " is not a
surface.");
    }

    Selection surf_selection =
        pfcSelect.CreateModelItemSelection (placement_surface,
reference_path);

    UDFReferences refs = UDFReferences.create();

    UDFReference ref_1 =
        pfcUDFCreate.UDFReference_Create ("embedding surface?",
            surf_selection);
    ref_1.SetIsExternal (true);

    refs.set (0, ref_1);

    /* The next two UDF references are expected to be Datum Plane
features in the assembly.
The reference is constructed using the Surface object contained in the
Datum plane feature. */

    Selection [] datum_sel = new Selection [2];

    Solid assembly = reference_path.GetRoot();

    for (int i = 0; i < 2; i++)
    {
        ModelItem side_ref =
            assembly.GetItemById (ModelItemType.ITEM_FEATURE,
                side_ref_feat_ids [i]);

        if (!(side_ref instanceof
            com.ptc.pfc.pfcDatumPlaneFeat.DatumPlaneFeat))
        {
            throw new Exception ("Error: input surface id "+
                side_ref_feat_ids[i]+
                " is not a datum plane.");
        }

        ModelItems surfs =
            ((Feature)side_ref).ListSubItems (ModelItemType.ITEM_SURFACE);

        Surface datum_plane_surf = (Surface) surfs.get (0);
        datum_sel[i] =
            pfcSelect.CreateModelItemSelection (datum_plane_surf, null);
    }

```

```

    }

    UDFReference ref_2 = pfcUDFCreate.UDFReference_Create ("front
surface",
                                                         datum_sel[0]);
    refs.set (1, ref_2);

    UDFReference ref_3 = pfcUDFCreate.UDFReference_Create ("right
surface",
                                                         datum_sel[1]);
    refs.set (2, ref_3);

    instrs.SetReferences (refs);

    /*
If the UDF and the placement both use two normal datum planes as
dimensioned references, Pro/ENGINEER prompts the user for a pick
to define the quadrant where the UDF will be placed. */

    Point3Ds quadrants = Point3Ds.create ();
    quadrants.set (0, quadrant);
    instrs.SetQuadrants (quadrants);

    /*
This hole UDF should be visible down to the component part level.
To direct this, the UDFAssemblyIntersection should be
created with the component ids, and the visibility level argument equal to
the number of component levels. Alternatively, the
visibility level could be 0 to force the UDF to appear in the assembly
only.*/

    UDFAssemblyIntersections inters = UDFAssemblyIntersections.create();
    ComponentPath [] leafs =
        pfcAssemblyUtilities.listEachLeafComponent ((Assembly)assembly);

    for (int i = 0; i < leafs.length; i++)
    {
        intseq ids = leafs[i].GetComponentIds();
        UDFAssemblyIntersection inter =
            pfcUDFCreate.UDFAssemblyIntersection_Create(ids,
                                                         ids.getarraysize());

        inters.set (i, inter);
    }

    instrs.SetIntersections(inters);

    /*
Create the assembly group.
*/
    FeatureGroup group = null;

```

```

        try
        {
            group = assembly.CreateUDFGroup (instrs);
        }
        catch (XToolkitError xte)
        {
            System.out.println ("Caught exception: "+xte);
            xte.printStackTrace ();
        }
        return (group);
    }
}

class pfcAssemblyUtilities
{
    private static Assembly useAsm;
    private static java.util.Vector path_array;

    /*
     * This utility method returns an array of all ComponentPath's to all
     * component parts ('leaves') in an assembly.
     */
    public static ComponentPath [] listEachLeafComponent (Assembly assembly)
        throws com.ptc.cipjava.jxthrowable
    {
        useAsm = assembly;
        path_array = new java.util.Vector ();

        intseq startLevel = intseq.create();
        listSubAsmComponents (startLevel);

        ComponentPath [] ret = new ComponentPath [path_array.size()];

        path_array.copyInto (ret);

        return (ret);
    }

    /*
     * This method is used to recursively visit all levels of the assembly
     * structure.
     */
    private static void listSubAsmComponents (intseq currentLevel)
        throws com.ptc.cipjava.jxthrowable
    {
        Solid currentComponent;
        ComponentPath currentPath = null;
    }
}

```

```

int level = currentLevel.getarraysize();

/* Special case, level = 0 for the top level assembly. */
if (level > 0)
{
    currentPath = pfcAssembly.CreateComponentPath (useAsm,
currentLevel);
    currentComponent = currentPath.GetLeaf();
}
else
{
    currentComponent = useAsm;
}

if (currentComponent.GetType ().equals (ModelType.MDL_PART) && level
> 0)
{
    path_array.addElement (currentPath);
}
else
{
    /*
    Find all component features in the current component object.
    Visit each (adjusting the component id paths accordingly).
    */
    Features subComponents =
        currentComponent.ListFeaturesByType (Boolean.TRUE,
            FeatureType.FEATTYPE_COMPONENT);

    for (int i = 0; i < subComponents.getarraysize(); i++)
    {
        Feature componentFeat = subComponents.get (i);
        int id = componentFeat.GetId ();

        currentLevel.set (level, id);

        listSubAsmComponents (currentLevel);
    }
}

/* Clean up current level of component ids before returning up one
level. */
if (level != 0)
{
    currentLevel.removeRange (level-1, level);
}
return;
}
}

```

15

Datum Features

This chapter describes the J-Link methods that provide read access to the properties of datum features.

Topic	Page
Datum Plane Features	15 - 2
Datum Axis Features	15 - 6
General Datum Point Features	15 - 7
Datum Coordinate System Features	15 - 9

Datum Plane Features

The properties of the Datum Plane feature are defined in the `pfcDatumPlaneFeat.DatumPlaneFeat` data object.

Methods Introduced:

- `pfcDatumPlaneFeat.DatumPlaneFeat.GetFlip`
- `pfcDatumPlaneFeat.DatumPlaneFeat.GetConstraints`
- `pfcDatumPlaneFeat.DatumPlaneConstraint.GetConstraintType`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneThroughConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneThroughConstraint.GetThroughRef`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneNormalConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneNormalConstraint.GetNormalRef`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneParallelConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneParallelConstraint.GetParallelRef`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneTangentConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneTangentConstraint.GetTangentRef`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneOffsetConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneOffsetConstraint.GetOffsetRef`
- `pfcDatumPlaneFeat.DatumPlaneOffsetConstraint.GetOffsetValue`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneOffsetCoordSysConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneOffsetCoordSysConstraint.GetCsysAxis`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneAngleConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneAngleConstraint.GetAngleRef`
- `pfcDatumPlaneFeat.DatumPlaneAngleConstraint.GetAngleValue`
- `pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneSectionConstraint_Create`
- `pfcDatumPlaneFeat.DatumPlaneSectionConstraint.GetSectionRef`
- `pfcDatumPlaneFeat.DatumPlaneSectionConstraint.GetSectionIndex`
- `pfcDatumPlaneFeat.DatumPlaneDefaultXConstraint.DatumPlaneDefaultXConstraint_Create`

- **pfcDatumPlaneFeat.DatumPlaneDefaultYConstraint.DatumPlaneDefaultYConstraint_Create**
- **pfcDatumPlaneFeat.DatumPlaneDefaultZConstraint.DatumPlaneDefaultZConstraint_Create**

The properties of the `pfcDatumPlaneFeat.DatumPlaneFeat` object are described as follows:

- *Flip*—Specifies whether the datum plane was flipped during creation. Use the method **pfcDatumPlaneFeat.DatumPlaneFeat.GetFlip** to determine if the datum plane was flipped during creation.
- *Constraints*—Specifies a collection of constraints (given by the `pfcDatumPlaneFeat.DatumPlaneConstraint` object). The method **pfcDatumPlaneFeat.DatumPlaneFeat.GetConstraints** obtains the collection of constraints defined for the datum plane.

Use the method

pfcDatumPlaneFeat.DatumPlaneConstraint.GetConstraintType to obtain the type of constraint. The type of constraint is given by the `pfcDatumPlaneFeat.DatumPlaneConstraintType` enumerated type. The available types are as follows:

- **DTMPLN_THRU**—Specifies the Through constraint. The `pfcDatumPlaneFeat.DatumPlaneThroughConstraint` object specifies this constraint. Use the method **pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneThroughConstraint_Create** to create a new object. Use the method **pfcDatumPlaneFeat.DatumPlaneThroughConstraint.GetThroughRef** to get the reference selection handle for the Through constraint.
- **DTMPLN_NORM**—Specifies the Normal constraint. The `pfcDatumPlaneFeat.DatumPlaneNormalConstraint` object specifies this constraint. Use the method **pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneNormalConstraint_Create** to create a new object. Use the method **pfcDatumPlaneFeat.DatumPlaneNormalConstraint.GetNormalRef** to get the reference selection handle for the Normal constraint.

- DTMPLN_PRL—Specifies the Parallel constraint. The `pfcDatumPlaneFeat.DatumPlaneParallelConstraint` object specifies this constraint. Use the method **`pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneParallelConstraint_Create`** to create a new object. Use the method **`pfcDatumPlaneFeat.DatumPlaneParallelConstraint.GetParallelRef`** to get the reference selection handle for the Parallel constraint.
- DTMPLN_TANG—Specifies the Tangent constraint. The `pfcDatumPlaneFeat.DatumPlaneTangentConstraint` specifies this constraint. Use the method **`pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneTangentConstraint_Create`** to create a new object. Use the method **`pfcDatumPlaneFeat.DatumPlaneTangentConstraint.GetTangentRef`** to get the reference selection handle for the Tangent constraint.
- DTMPLN_OFFS—Specifies the Offset constraint. The `pfcDatumPlaneFeat.DatumPlaneOffsetConstraint` object specifies this constraint. Use the method **`pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneOffsetConstraint_Create`** to create a new object. Use the method **`pfcDatumPlaneFeat.DatumPlaneOffsetConstraint.GetOffsetRef`** to get the reference selection handle for the Offset constraint. Use the method **`pfcDatumPlaneFeat.DatumPlaneOffsetConstraint.GetOffsetValue`** to get the offset value.
An Offset constraint where the offset reference is a coordinate system is given by the `pfcDatumPlaneFeat.DatumPlaneOffsetCoordSysConstraint` object. Use the method **`pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneOffsetCoordSysConstraint_Create`** to create a new object. Use the method **`pfcDatumPlaneFeat.DatumPlaneOffsetCoordSysConstraint.GetCsysAxis`** to get the reference coordinate axis.
- DTMPLN_ANG—Specifies the Angle constraint. The `pfcDatumPlaneFeat.DatumPlaneAngleConstraint` object specifies this constraint. Use the method **`pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneAngleConstraint_Create`** to create a new object. Use the method

pfcDatumPlaneFeat.DatumPlaneAngleConstraint.GetAngleRef to get the reference selection handle for the Angle constraint. Use the method **pfcDatumPlaneFeat.DatumPlaneAngleConstraint.GetAngleValue** to get the angle value.

- **DTMPLN_SEC**—Specifies the Section constraint. The `pfcDatumPlaneFeat.DatumPlaneSectionConstraint` object specifies this constraint. Use the method **pfcDatumPlaneFeat.DatumPlaneSectionConstraint.Create** to create a new object. Use the method **pfcDatumPlaneFeat.DatumPlaneSectionConstraint.GetSectionRef** to get the reference selection for the Section constraint. Use the method **pfcDatumPlaneFeat.DatumPlaneSectionConstraint.GetSectionIndex** to get the section index.
- **DTMPLN_DEF_X**—Specifies the default RIGHT constraint for the datum plane. The `pfcDatumPlaneFeat.DatumPlaneDefaultXConstraint` object specifies this constraint. Use the method **pfcDatumPlaneFeat.DatumPlaneDefaultXConstraint.Create** to create a new object.
- **DTMPLN_DEF_Y**—Specifies the default TOP constraint for the datum plane. The `pfcDatumPlaneFeat.DatumPlaneDefaultYConstraint` object specifies this constraint. Use the method **pfcDatumPlaneFeat.DatumPlaneDefaultYConstraint.Create** to create a new object.
- **DTMPLN_DEF_Z**—Specifies the default FRONT constraint for the datum plane. The `pfcDatumPlaneFeat.DatumPlaneDefaultZConstraint` object specifies this constraint. Use the method **pfcDatumPlaneFeat.DatumPlaneDefaultZConstraint.Create** to create a new object.

Datum Axis Features

The properties of the Datum Axis feature are defined in the `pfcDatumAxisFeat.DatumAxisFeat` data object.

Methods Introduced:

- `pfcDatumAxisFeat.DatumAxisFeat.GetConstraints`
- `pfcDatumAxisFeat.pfcDatumAxisFeat.DatumAxisConstraint_Create`
- `pfcDatumAxisFeat.DatumAxisConstraint.GetConstraintType`
- `pfcDatumAxisFeat.DatumAxisConstraint.GetConstraintRef`
- `pfcDatumAxisFeat.DatumAxisFeat.GetDimConstraints`
- `pfcDatumAxisFeat.pfcDatumAxisFeat.DatumAxisDimensionConstraint_Create`
- `pfcDatumAxisFeat.DatumAxisDimensionConstraint.GetDimOffset`
- `pfcDatumAxisFeat.DatumAxisDimensionConstraint.GetDimRef`

The properties of the `pfcDatumAxisFeat.DatumAxisFeat` object are described as follows:

- *Constraints*—Specifies a collection of constraints (given by the `pfcDatumAxisFeat.DatumAxisConstraint` object). The method **`pfcDatumAxisFeat.DatumAxisFeat.GetConstraints`** obtains the collection of constraints applied to the Datum Axis feature.

Use the method

`pfcDatumAxisFeat.pfcDatumAxisFeat.DatumAxisConstraint_Create` to create a new

`pfcDatumAxisFeat.DatumAxisConstraint` object. This object contains the following attributes:

- *ConstraintType*—Specifies the type of constraint in terms of the `pfcDatumAxisFeat.DatumAxisConstraintType` enumerated type. The constraint type determines the type of datum axis. The constraint types are:
 - `DTMAXIS_NORMAL`—Specifies the Normal datum constraint.
 - `DTMAXIS_THRU`—Specifies the Through datum constraint.
 - `DTMAXIS_TANGENT`—Specifies the Tangent datum constraint.

- **DTMAXIS_CENTER**—Specifies the Center datum constraint.

Use the method

pfcDatumAxisFeat.DatumAxisConstraint.GetConstraintType to get the constraint type.

- *ConstraintRef*—Specifies the reference selection for the constraint. Use the method **pfcDatumAxisFeat.DatumAxisConstraint.GetConstraintRef** to get the reference selection handle.
- *DimConstraints*—Specifies a collection of dimension constraints (given by the `pfcDatumAxisFeat.DatumAxisDimensionConstraint` object). The method **pfcDatumAxisFeat.DatumAxisFeat.GetDimConstraints** obtains the collection of dimension constraints applied to the Datum Axis feature.

Use the method

pfcDatumAxisFeat.DatumAxisFeat.DatumAxisDimensionConstraint.Create to create a new

`pfcDatumAxisFeat.DatumAxisDimensionConstraint` object. This object contains the following attributes:

- *DimOffset*—Specifies the offset value for the dimension constraint. Use the method **pfcDatumAxisFeat.DatumAxisDimensionConstraint.GetDimOffset** to get the offset value.
- *DimRef*—Specifies the reference selection for the dimension constraint. Use the method **pfcDatumAxisFeat.DatumAxisDimensionConstraint.GetDimRef** to get the reference selection handle.

General Datum Point Features

The properties of the General Datum Point feature are defined in the `pfcDatumPointFeat.DatumPointFeat` data object.

Methods Introduced:

- **pfcDatumPointFeat.DatumPointFeat.GetFeatName**
- **pfcDatumPointFeat.DatumPointFeat.GetPoints**
- **pfcDatumPointFeat.GeneralDatumPoint.GetName**
- **pfcDatumPointFeat.pfcDatumPointFeat.DatumPointPlacementConstraint_Create**
- **pfcDatumPointFeat.GeneralDatumPoint.GetPlaceConstraints**
- **pfcDatumPointFeat.pfcDatumPointFeat.DatumPointDimensionConstraint_Create**
- **pfcDatumPointFeat.GeneralDatumPoint.GetDimConstraints**
- **pfcDatumPointFeat.DatumPointConstraint.GetConstraintRef**
- **pfcDatumPointFeat.DatumPointConstraint.GetConstraintType**
- **pfcDatumPointFeat.DatumPointConstraint.GetValue**

The properties of the `pfcDatumPointFeat.DatumPointFeat` object are described as follows:

- *FeatName*—Specifies the name of the General Datum Point feature. Use the method **pfcDatumPointFeat.DatumPointFeat.GetFeatName** to get the name.
- *GeneralDatumPoints*—Specifies a collection of general datum points (given by the `pfcDatumPointFeat.GeneralDatumPoint` object). Use the method **pfcDatumPointFeat.DatumPointFeat.GetPoints** to obtain the collection of general datum points. The `pfcDatumPointFeat.GeneralDatumPoint` object consists of the following attributes:
 - *Name*—Specifies the name of the general datum point. Use the method **pfcDatumPointFeat.GeneralDatumPoint.GetName** to get the name.
 - *PlaceConstraints*—Specifies a collection of placement constraints (given by the `pfcDatumPointFeat.DatumPointPlacementConstraint` object). Use the method **pfcDatumPointFeat.pfcDatumPointFeat.DatumPointPlacementConstraint_Create** to create a new object. Use the method **pfcDatumPointFeat.GeneralDatumPoint.GetPlaceConstraints** to obtain the collection of placement constraints.

- *DimConstraints*—Specifies a collection of dimension constraints (given by the `pfcDatumPointFeat.DatumPointDimensionConstraint` object). Use the method **`pfcDatumPointFeat.DatumPointDimensionConstraint.Create`** to create a new object. Use the method **`pfcDatumPointFeat.GeneralDatumPoint.GetDimConstraints`** to obtain the collection of dimension constraints.

The constraints for a datum point are given by the `pfcDatumPointFeat.DatumPointConstraint` object. This object contains the following attributes:

- *ConstraintRef*—Specifies the reference selection for the datum point constraint. Use the method **`pfcDatumPointFeat.DatumPointConstraint.ConstraintRef`** to get the reference selection handle.
- *ConstraintType*—Specifies the type of datum point constraint, in terms of the `pfcDatumPointFeat.DatumPointConstraintType` enumerated type. Use the method **`pfcDatumPointFeat.DatumPointConstraint.ConstraintType`** to get the constraint type.
- *Value*—Specifies the constraint reference value with respect to the datum point. Use the method **`pfcDatumPointFeat.DatumPointConstraint.Value`** to get the value of the constraint reference with respect to the datum point.

The `pfcDatumPointFeat.DatumPointPlacementConstraint` and `pfcDatumPointFeat.DatumPointDimensionConstraint` objects inherit from the `pfcDatumPointFeat.DatumPointConstraint` object. Use the methods of the `pfcDatumPointFeat.DatumPointConstraint` object for the inherited objects.

Datum Coordinate System Features

The properties of the Datum Coordinate System feature are defined in the `pfcCoordSysFeat.CoordSysFeat` object.

Methods Introduced:

- **pfcCoordSysFeat.CoordSysFeat.GetOriginConstraints**
- **pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysOriginConstraint_Create**
- **pfcCoordSysFeat.DatumCsysOriginConstraint.GetOriginRef**
- **pfcCoordSysFeat.CoordSysFeat.GetDimensionConstraints**
- **pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysDimensionConstraint_Create**
- **pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimRef**
- **pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimValue**
- **pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimConstraintType**
- **pfcCoordSysFeat.CoordSysFeat.GetOrientationConstraints**
- **pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysOrientMoveConstraint_Create**
- **pfcCoordSysFeat.DatumCsysOrientMoveConstraint.GetOrientMoveConstraintType**
- **pfcCoordSysFeat.DatumCsysOrientMoveConstraint.GetOrientMoveValue**
- **pfcCoordSysFeat.CoordSysFeat.GetIsNormalToScreen**
- **pfcCoordSysFeat.CoordSysFeat.GetOffsetType**
- **pfcCoordSysFeat.CoordSysFeat.GetOnSurfaceType**
- **pfcCoordSysFeat.CoordSysFeat.GetOrientByMethod**

The properties of the `pfcCoordSysFeat.CoordSysFeat` object are described as follows:

- *OriginConstraints*—Specifies a collection of origin constraints (given by the `pfcCoordSysFeat.DatumCsysOriginConstraint` object). Use the method **pfcCoordSysFeat.CoordSysFeat.GetOriginConstraints** to obtain the collection of origin constraints for the coordinate system. Use the method **pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysOriginConstraint_Create** to create a new `pfcCoordSysFeat.DatumCsysOriginConstraint` object. This object contains the following attribute:
 - *OriginRef*—Specifies the selection reference for the origin. Use the method **pfcCoordSysFeat.DatumCsysOriginConstraint.GetOriginRef** to get the selection reference handle.

- *DimensionConstraints*—Specifies a collection of dimension constraints (given by the `pfcCoordSysFeat.DatumCsysDimensionConstraint` object). Use the method **`pfcCoordSysFeat.CoordSysFeat.GetDimensionConstraints`** to obtain the collection of dimension constraints for the coordinate system. Use the method **`pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysDimensionConstraint.Create`** to create a new `pfcCoordSysFeat.DatumCsysDimensionConstraint` object. This object contains the following attributes:
 - *DimRef*—Specifies the reference selection for the dimension constraint. Use the method **`pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimRef`** to get the reference selection handle.
 - *DimValue*—Specifies the value of the reference. Use the method **`pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimValue`** to get the value.
 - *DimConstraintType*—Specifies the type of dimension constraint in terms of the `pfcCoordSysFeat.DatumCsysDimConstraintType` enumerated type. Use the method **`pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimConstraintType`** to get the constraint type. The constraint types are:
 - `DTMCSYS_DIM_OFFSET`—Specifies the offset type constraint.
 - `DTMCSYS_DIM_ALIGN`—Specifies the align type constraint.
- *OrientationConstraints*—Specifies a collection of orientation constraints (given by the `pfcCoordSysFeat.DatumCsysOrientMoveConstraint` object) Use the method **`pfcCoordSysFeat.CoordSysFeat.GetOrientationConstraints`** to obtain the collection of orientation constraints for the coordinate system. Use the method **`pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysOrientMoveConstraint.Create`** to create a new `pfcCoordSysFeat.DatumCsysOrientMoveConstraints` object. This object contains the following attributes:

- *OrientMoveConstraintType*—Specifies the type of orientation for the constraint. The orientation type is given by the `pfcCoordSysFeat.DatumCsysOrientMoveConstraintType` enumerated type. Use the method **`pfcCoordSysFeat.DatumCsysOrientMoveConstraint.GetOrientMoveConstraintType`** to get the orientation type.
- *OrientMoveValue*—Specifies the reference value for the constraint. Use the method **`pfcCoordSysFeat.DatumCsysOrientMoveConstraint.GetOrientMoveValue`** to get the reference value.
- *IsNormalToScreen*—Specifies if the coordinate system is normal to screen. Use the method **`pfcCoordSysFeat.CoordSysFeat.GetIsNormalToScreen`** to determine if the coordinate system is normal to screen.
- *OffsetType*—Specifies the offset type of the coordinate system in terms of the `pfcCoordSysFeat.DatumCsysOffsetType` enumerated type. Use the method **`pfcCoordSysFeat.CoordSysFeat.GetOffsetType`** to get the offset type. The offset types are:
 - `DTMCSYS_OFFSET_CARTESIAN`—Specifies a cartesian coordinate system that has been defined by setting the values for the `DTMCSYS_MOVE_TRAN_X`, `DTMCSYS_MOVE_TRAN_Y`, and `DTMCSYS_MOVE_TRAN_Z` or `DTMCSYS_MOVE_ROT_X`, `DTMCSYS_MOVE_ROT_Y`, and `DTMCSYS_MOVE_ROT_Z` orientation constants.
 - `DTMCSYS_OFFSET_CYLINDRICAL`—Specifies a cylindrical coordinate system that has been defined by setting the values for the `DTMCSYS_MOVE_RAD`, `DTMCSYS_MOVE_THETA`, and `DTMCSYS_MOVE_TRAN_ZI` orientation constants.
 - `DTMCSYS_OFFSET_SPHERICAL`—Specifies a spherical coordinate system that has been defined by setting the values for the `DTMCSYS_MOVE_RAD`, `DTMCSYS_MOVE_THETA`, and `DTMCSYS_MOVE_TRAN_PHI` orientation constants.

- *OnSurfaceType*—Specifies the on surface type for the coordinate system in terms of the `pfcCoordSysFeat.DatumCsysOffsetType` enumerated type. Use the method **`pfcCoordSysFeat.CoordSysFeat.GetOnSurfaceType`** to get the on surface type property of the coordinate system. The on surface types are:
 - `DTMCSYS_ONSURF_LINEAR`—Specifies a coordinate system placed on the selected surface by using two linear dimensions.
 - `DTMCSYS_ONSURF_RADIAL`—Specifies a coordinate system placed on the selected surface by using a linear dimension and an angular dimension. The radius value is used to specify the linear dimension.
 - `DTMCSYS_ONSURF_DIAMETER`—This type is similar to the `DTMCSYS_ONSURF_RADIAL` type, except that the diameter value is used to specify the linear dimension. It is available only when planar surfaces are used as the reference.
- *OrientByMethod*—Specifies the orientation method in terms of the `pfcCoordSysFeat.DatumCsysOrientByMethod` enumerated type. Use the method **`pfcCoordSysFeat.CoordSysFeat.GetOrientByMethod`** to get the orientation method. The available orientation types are:
 - `DTMCSYS_ORIENT_BY_SEL_REFS`—Specifies the orientation by selected references.
 - `DTMCSYS_ORIENT_BY_SEL_CSYS_AXES`—Specifies the orientation by coordinate system axes.

Example: Reading Properties of Datum Features

This example code demonstrates how to read the basic properties of datum features.

```
import com.ptc.cipjava.*;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.Session;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcComponentFeat.*;
import com.ptc.pfc.pfcFamily.FamilyTableRow;
import com.ptc.pfc.pfcBase.*;
```

```

import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcWindow.*;
import com.ptc.pfc.pfcView2D.*;
import com.ptc.pfc.pfcDrawing.*;
import com.ptc.pfc.pfcModelCheck.*;
import com.ptc.pfc.pfcFamily.*;
import com.ptc.pfc.pfcDisplay.*;
import com.ptc.pfc.pfcDatumPlaneFeat.*;
import com.ptc.pfc.pfcDatumAxisFeat.*;
import com.ptc.pfc.pfcDatumPointFeat.*;
import com.ptc.pfc.pfcCoordSysFeat.*;

import java.util.logging.*;
import java.io.*;

import javax.swing.*;

/*****\
CLASS:   pfcReadBasicFeatPropertiesExamples
PURPOSE: Read basic feature properties
\*****/
public class pfcReadBasicFeatPropertiesExamples
{
    static protected Logger logger;
    private FileHandler handler;

    static Session session;

    private static final String messageFile = "jlexamples.txt";
    static PrintWriter pr;

    public static void printMsg(String msg)
    {
        try
        {
            pr.println(msg);
            pr.flush();
        }
        catch (Exception e)
        {
        }
    }

    public static void ReadDatumProperties() throws java.io.IOException
    {
        try
        {

```

```

pr = new PrintWriter(new BufferedWriter(new
    FileWriter("DatumProperties.txt", false)));

Session session = pfcGlobal.GetProESession ();

Models models = session.ListModels();

int no_of_models = models.getarraysize();

if (no_of_models == 0)
{
    session.UIDisplayMessage(messageFile, "RBFNoModelOpen",
        null);

    return;
}

for (int i=0 ; i<no_of_models ; i++)
{
    Model mdl = models.get(i);

    printMsg("For MODEL :- " +mdl.GetFullName() );

    ModelItems feature_items =
        mdl.ListItems(ModelItemType.ITEM_FEATURE);

    int no_of_feats = feature_items.getarraysize();

    for (int j=0 ; j<no_of_feats ; j++)
    {
        Feature feat = (Feature)feature_items.get(j);

        switch ( feat.GetFeatType().getValue() )
        {
            case FeatureType._FEATTYPE_DATUM_PLANE :

                writeDatumPlaneFeatureProperties(feat);

                break;

            case FeatureType._FEATTYPE_DATUM_AXIS :

                writeDatumAxisFeatureProperties(feat);

                break;

            case FeatureType._FEATTYPE_DATUM_POINT :

                writeDatumPointFeatureProperties (feat);

                break;
        }
    }
}

```

```

        case FeatureType._FEATTYPE_COORD_SYS :

            writeDatumCoordSysFeatureProperties (feat);

            break;

        }
    }
}

catch (jxthrowable x)
{
    logger.log(Level.SEVERE, "Caught exception: ", x);
}
}

/* Write datum plane feature properties */
private static void writeDatumPlaneFeatureProperties (Feature feat)
{

    try
    {
        DatumPlaneFeat datumplane = (DatumPlaneFeat)feat;

        String datumname = ((Feature)datumplane).GetName();

        printMsg("+++++++ " );

        printMsg("    Datum Plane Name: " +datumname);

        Boolean flip = datumplane.GetFlip();

        if (flip != null)
        {
            printMsg("    - Datum Plane Flipped during creation: " +flip);
        }

        /* Getting constraints */
        DatumPlaneConstraints constraints = datumplane.GetConstraints();

        if (constraints == null)
            printMsg("    - No Constraints (null)");
        else if (constraints.getarraysize() < 0)
            printMsg("    - No Constraints");
        else
        {
            printMsg("    - No of Constraints = " +constraints.getarraysize());

            for (int j = 0 ; j<constraints.getarraysize() ; j++)

```

```

{
printMsg("+ ----- +" );

switch(((DatumPlaneConstraint)constraints.get(j)).
        GetConstraintType().getValue() )
{
case (DatumPlaneConstraintType._DTMPLN_THRU):
{
printMsg(
    "      - Constraint type = DTMPLN_THRU");

printMsg ("      Through Ref Name = "
    +((DatumPlaneThroughConstraint)constraints.get(j)).
    GetThroughRef().GetSelItem().GetName());

printMsg ("      Through Ref Id = "
    +((DatumPlaneThroughConstraint)constraints.get(j)).
    GetThroughRef().GetSelItem().GetId());

break;
}

case (DatumPlaneConstraintType._DTMPLN_NORM):
{
printMsg("      - Constraint type = DTMPLN_NORM");

printMsg ("      Normal Ref Name = "
    +((DatumPlaneNormalConstraint)constraints.get(j)).
    GetNormalRef().GetSelItem().GetName());

printMsg ("      Normal Ref Id = "
    +((DatumPlaneNormalConstraint)constraints.get(j)).
    GetNormalRef().GetSelItem().GetId());

break;
}

case (DatumPlaneConstraintType._DTMPLN_PRL):
{
printMsg("      - Constraint type = DTMPLN_PRL");

printMsg ("      Parallel Ref Name = "
    +((DatumPlaneParallelConstraint)constraints.get(j)).
    GetParallelRef().GetSelItem().GetName());

printMsg ("      Parallel Ref Id = "
    +((DatumPlaneParallelConstraint)constraints.get(j)).
    GetParallelRef().GetSelItem().GetId());

break;
}
}

```

```

case (DatumPlaneConstraintType._DTMPLN_OFFS):
{
  printMsg("      - Constraint type = DTMPLN_OFFS");

  printMsg ("      Offset Ref Name = "
            +((DatumPlaneOffsetConstraint)constraints.get(j)).
            GetOffsetRef().GetSelItem().GetName());

  printMsg ("      Offset Ref Id = "
            +((DatumPlaneOffsetConstraint)constraints.get(j)).
            GetOffsetRef().GetSelItem().GetId());

  if (((DatumPlaneOffsetConstraint)constraints.get(j)).
      GetOffsetRef().GetSelItem().GetType() ==
      ModelItemType.ITEM_COORD_SYS)
  {
    printMsg ("      Offset Csys Axis = "
              +((DatumPlaneOffsetCoordSysConstraint)constraints.get(j)).
              GetCsysAxis().getValue());

    printMsg ("      Offset Csys Value = "
              +((DatumPlaneOffsetCoordSysConstraint)constraints.get(j)).
              GetOffsetValue());

  }

  printMsg ("      Offset Value = "
            +((DatumPlaneOffsetConstraint)constraints.get(j)).
            GetOffsetValue());

  break;
}

case (DatumPlaneConstraintType._DTMPLN_ANG):
{
  printMsg("      - Constraint type = DTMPLN_ANG");

  printMsg ("      Angle Ref Name = "
            +((DatumPlaneAngleConstraint)constraints.get(j)).
            GetAngleRef().GetSelItem().GetName());

  printMsg ("      Angle Ref Id = "
            +((DatumPlaneAngleConstraint)constraints.get(j)).
            GetAngleRef().GetSelItem().GetId());

  printMsg ("      Angle Value = "
            +((DatumPlaneAngleConstraint)constraints.get(j)).
            GetAngleValue());

  break;
}

```

```
case (DatumPlaneConstraintType._DTMPLN_TANG):
{
    printMsg("    - Constraint type = DTMPLN_TANG");

    printMsg ("        Tangent Ref Name = "
        +((DatumPlaneTangentConstraint)constraints.get(j)).
        GetTangentRef().GetSelItem().GetName());

    printMsg ("        Tangent Ref Id = "
        +((DatumPlaneTangentConstraint)constraints.get(j)).
        GetTangentRef().GetSelItem().GetId());

    break;
}

case (DatumPlaneConstraintType._DTMPLN_SEC):
{
    printMsg("    - Constraint type = DTMPLN_SEC");

    printMsg ("        Section Ref Name = "
        +((DatumPlaneSectionConstraint)constraints.get(j)).
        GetSectionRef().GetSelItem().GetName());

    printMsg ("        Section Ref Id = "
        +((DatumPlaneSectionConstraint)constraints.get(j)).
        GetSectionRef().GetSelItem().GetId());

    printMsg ("        Section Index Value = "
        +((DatumPlaneSectionConstraint)constraints.get(j)).
        GetSectionIndex());

    break;
}

case (DatumPlaneConstraintType._DTMPLN_DEF_X):
{
    printMsg("    - Constraint type = DTMPLN_DEF_X");

    break;
}

case (DatumPlaneConstraintType._DTMPLN_DEF_Y):
{
    printMsg("    - Constraint type = DTMPLN_DEF_Y");

    break;
}

case (DatumPlaneConstraintType._DTMPLN_DEF_Z):
{
    printMsg("    - Constraint type = DTMPLN_DEF_Z");
```

```

        break;
    }
}/* End of switch case */
}
}

catch (jxthrowable x)
{
    logger.log(Level.SEVERE, "Caught exception: ", x);
}
}

/* Write datum axis feature properties */
private static void writeDatumAxisFeatureProperties (Feature feat)
{

    try
    {
        DatumAxisFeat datumaxis = (DatumAxisFeat)feat;

        String datumaxisname = ((Feature)datumaxis).GetName();

        printMsg("++++++++++++++++++++++++++++++++++++" );

        printMsg ("          DatumAxisName = " +datumaxisname);

        /* Getting constraints */
        DatumAxisConstraints constraints = datumaxis.GetConstraints();

        if (constraints == null)
            printMsg ("          No Constraints (null)");

        else if (constraints.getarraysize() < 0)
            printMsg ("          No Constraints");

        else
        {
            printMsg ("          No of Constraints = "
                +constraints.getarraysize() );

            for (int j = 0 ; j< constraints.getarraysize() ; j++)
            {

                printMsg("+ ----- +");
                printMsg ("          - Constraint Type = "
                    +constraints.get(j).GetConstraintType().getValue());

                if (constraints.get(j).GetConstraintRef()!=null)
                {

```



```

    printMsg ("          - DatumAxis Constrainttype Name = "
              +constraints.get(j).GetConstraintRef().
              GetSelItem().GetName());

    printMsg ("          - ConstraintRef Id = "
              +constraints.get(j).GetConstraintRef().
              GetSelItem().GetId());

    }
  }
}

/* Getting dimension constraints */
DatumAxisDimensionConstraints dimconstraints =
    datumaxis.GetDimConstraints();

if (dimconstraints == null)
    printMsg ("          - No Dimension Constraints (null)");

else if (dimconstraints.getarraysize() < 0)
    printMsg ("          - No Dimension Constraints");

else
{
    printMsg ("          - Number of Dimension Constraints = "
              +dimconstraints.getarraysize() );

    for (int k = 0 ; k< dimconstraints.getarraysize() ; k++)
    {
        printMsg("+ ----- +" );

        printMsg ("          - DatumAxis Dimension Constrainttype Name = "
                  +dimconstraints.get(k).GetDimRef().
                  GetSelItem().GetName());

        printMsg ("          - DatumAxis Dimension ConstraintRef Id = "
                  +dimconstraints.get(k).GetDimRef().
                  GetSelItem().GetId());

        printMsg ("          - Offset value set by the dimension = "
                  +dimconstraints.get(k).GetDimOffset());
    }
}

}

catch (jxthrowable x)
{
    logger.log(Level.SEVERE, "Caught exception: ", x);
}

```

```

}
/* Write datum point feature properties */
public static void writeDatumPointFeatureProperties(Feature feat)
{
    try
    {
        DatumPointFeat pointfeat = (DatumPointFeat) feat;

        String datumpointfeatname = (pointfeat.GetFeatName());

        printMsg("+++++++ " );
        printMsg (" DatumFeatPointName =" +datumpointfeatname);

        /* Getting points */
        GeneralDatumPoints points = pointfeat.GetPoints();

        if (points == null)
            printMsg (" - No General Datum Points (null)");

        else if (points.getarraysize() < 0)
            printMsg (" - No General Datum Points");

        else
        {
            printMsg (" - No of points = " +points.getarraysize() );
            for (int j = 0 ; j< points.getarraysize() ; j++)
            {
                printMsg("+ ----- +" );

                String datumpointname = (points.get(j).GetName());

                printMsg (" - DatumPointName =" +datumpointname);

                /* Getting placement constraints */
                DatumPointPlacementConstraints placeconst =
                points.get(j).GetPlaceConstraints();

                printMsg (" - No of Placement Constraints ="
                    +placeconst.getarraysize());

                for (int k = 0 ; k< placeconst.getarraysize() ; k++)
                {
                    printMsg("+ ----- +" );

                    printMsg (" - Placement Constraint Ref Id ="
                        +placeconst.get(k).GetConstraintRef().
                        GetSelItem().GetId());

                    printMsg (" - Placement Constraint Ref Name ="
                        +placeconst.get(k).GetConstraintRef().

```

```

        GetSelItem().GetName());

        printMsg ("          - Placement Constraint Type ="
            +placeconst.get(k).GetConstraintType()
            .getValue());

        printMsg ("          - Placement Constraint Value ="
            +placeconst.get(k).GetValue());
    }

    /* Getting dimension constraints */
    DatumPointDimensionConstraints dimconst =
    points.get(j).GetDimConstraints();

    printMsg ("          - Number of Dimension Constraints ="
        +dimconst.getarraysize());

    for (int m = 0 ; m< dimconst.getarraysize() ; m++)
    {
        printMsg("+ ----- +" );

        printMsg ("          - Dimension Constraint Ref Id ="
            +dimconst.get(m).GetConstraintRef().
            GetSelItem().GetId());

        printMsg ("          - Dimension Constraint Ref Name ="
            +dimconst.get(m).GetConstraintRef().
            GetSelItem().GetName());

        printMsg ("          - Dimension Constraint Type ="
            +dimconst.get(m).GetConstraintType().
            getValue());

        printMsg ("          - Dimension Constraint Value ="
            +dimconst.get(m).GetValue());
    }
    }
}/* end of else if */
}

catch (jxthrowable x)
{
    logger.log(Level.SEVERE, "Caught exception: ", x);
}

}

/* Write datum coordinate system feature properties */
public static void writeDatumCoordSysFeatureProperties(Feature feat)
{
    try

```

```

{
CoordSysFeat coordsys = (CoordSysFeat)feat;

String CoordSysName = ((Feature)coordsys).GetName();

printMsg("++++++++++++++++++++++++++++++++++++" );

printMsg ("          - Coordinate System Name ="
          +CoordSysName);

/* Getting origin constraints */
DatumCsysOriginConstraints originconstraint =
          coordsys.GetOriginConstraints();

printMsg ("          - Number of Origin Constraints ="
          +originconstraint.getarraysize());

for(int j=0 ;j<originconstraint.getarraysize();j++)
{
printMsg("+ ----- +" );

printMsg ("          - Origin Constraints Ref Name ="
          +originconstraint.get(j).GetOriginRef().
          GetSelItem().GetName());

printMsg ("          - Origin Constraints Ref Id ="
          +originconstraint.get(j).GetOriginRef().
          GetSelItem().GetId());
}

/* Getting dimension constraints */
DatumCsysDimensionConstraints dimconstraint =
          coordsys.GetDimensionConstraints();

printMsg ("          - No of Dimension Constraints ="
          +dimconstraint.getarraysize());

for(int k=0 ;k<dimconstraint.getarraysize();k++)
{
printMsg("+ ----- +" );

printMsg ("          - Dimension Constraints Ref Name ="
          +dimconstraint.get(k).GetDimRef().
          GetSelItem().GetName());

printMsg ("          - Dimension Constraints Ref Id ="
          +dimconstraint.get(k).GetDimRef().
          GetSelItem().GetId());

printMsg ("          - Dimension Constraints Type ="
          +dimconstraint.get(k).GetDimConstraintType()).

```

```

    getValue());

    printMsg ("          - Dimension Constraints Value ="
              +dimconstraint.get(k).GetDimValue());
}

/*  Getting orientation constraints */
DatumCsysOrientMoveConstraints orientConstraint =
    coordsys.GetOrientationConstraints();

printMsg ("          - No of Orientation Constraints  ="
          +orientConstraint.getarraysize());

for(int l=0 ;l<orientConstraint.getarraysize();l++)
{
    printMsg("+ ----- + " );

    printMsg ("          - Orientation Constraints Type ="
              +orientConstraint.get(l).GetOrientMoveConstraintType().getValue());

    printMsg ("          - Orientation Constraints Value ="
              +orientConstraint.get(l).GetOrientMoveValue());
}

printMsg ("          - Is Normal To screen ? : "
          +coordsys.GetIsNormalToScreen());

printMsg ("          - OffsetType ="
          +coordsys.GetOffsetType().getValue());

printMsg ("          - Orientation Method ="
          +coordsys.GetOrientByMethod().getValue());
}

catch (jxthrowable x)
{
    logger.log(Level.SEVERE, "Caught exception: ", x);
}

}

public pfcReadBasicFeatPropertiesExamples (Session s)
{
    session = s;

    try
    {
        handler = new FileHandler
            ("pfcReadBasicFeatPropertiesExamples.log");
        logger = Logger.global;
        logger.addHandler(handler);
    }
}

```

```
}  
catch (IOException e)  
{  
    printMsg ("Caught exception initializing log file: " + e);  
}  
}
```

16

Geometry Evaluation

This chapter describes geometry representation and discusses how to evaluate geometry using J-Link.

Topic	Page
Geometry Traversal	16 - 2
Curves and Edges	16 - 3
Contours	16 - 7
Surfaces	16 - 8
Axes, Coordinate Systems, and Points	16 - 12
Interference	16 - 13

Geometry Traversal

Note:

- A simple rectangular face has one contour and four edges.
- A contour will traverse a boundary so that the part face is always on the right-hand side (RHS). For an external contour the direction of traversal is clockwise. For an internal contour the direction of traversal is counterclockwise.
- If a part is extruded from a sketch that has a U-shaped cross section there will be separate surfaces at each leg of the U-channel.
- If a part is extruded from a sketch that has a square-shaped cross section, and a slot feature is then cut into the part to make it look like a U-channel, there will be one surface across the legs of the U-channel. The original surface of the part is represented as one surface with a cut through it.

Geometry Terms

Following are definitions for some geometric terms:

- **Surface**—An ideal geometric representation, that is, an infinite plane.
- **Face**—A trimmed surface. A face has one or more contours.
- **Contour**—A closed loop on a face. A contour consists of multiple edges. A contour can belong to one face only.
- **Edge**—The boundary of a trimmed surface.

An edge of a solid is the intersection of two surfaces. The edge belongs to those two surfaces and to two contours. An edge of a datum surface can be either the intersection of two datum surfaces or the external boundary of the surface.

If the edge is the intersection of two datum surfaces it will belong to those two surfaces and to two contours. If the edge is the external boundary of the datum surface it will belong to that surface alone and to a single contour.

Traversing the Geometry of a Solid Block

Methods Introduced:

- **pfcModelItem.ModelItemOwner.ListItems**
- **pfcGeometry.Surface.ListContours**
- **pfcGeometry.Contour.ListElements**

To traverse the geometry, follow these steps:

1. Starting at the top-level model, use **pfcModelItem.ModelItemOwner.ListItems** with an argument of `ModelItemType.ITEM_SURFACE`.
2. Use **pfcGeometry.Surface.ListContours** to list the contours contained in a specified surface.
3. Use **pfcGeometry.Contour.ListElements** to list the edges contained in the contour.


Curves and Edges

Datum curves, surface edges, and solid edges are represented in the same way in J-Link. You can get edges through geometry traversal or get a list of edges using the methods presented in the chapter “ModelItem”.

The t Parameter

The geometry of each edge or curve is represented as a set of three parametric equations that represent the values of x, y, and z as functions of an independent parameter, t. The t parameter varies from 0.0 at the start of the curve to 1.0 at the end of it.

The following figure illustrates curve and edge parameterization.



Curve and Edge Types

Solid edges and datum curves can be any of the following types:

- **LINE**—A straight line represented by the class `pfcGeometry.Line`.
- **ARC**—A circular curve represented by the class `pfcGeometry.Arc`.
- **SPLINE**—A nonuniform cubic spline, represented by the class `pfcGeometry.Spline`.
- **B-SPLINE**—A nonuniform rational B-spline curve or edge, represented by the class `pfcGeometry.BSpline`.
- **COMPOSITE CURVE**—A combination of two or more curves, represented by the class `pfcGeometry.CompositeCurve`. This is used for datum curves only.

See the appendix, Geometry Representations, for the parameterization of each curve type. To determine what type of curve a `pfcGeometry.Edge` or `pfcGeometry.Curve` object represents, use the Java **instanceof** operator.

Because each curve class inherits from `pfcGeometry.GeomCurve`, you can use all the evaluation methods in `GeomCurve` on any edge or curve.

The following curve types are not used in solid geometry and are reserved for future expansion:

- **CIRCLE** (`pfcGeometry.Circle`)
- **ELLIPSE** (`pfcGeometry.Ellipse`)
- **POLYGON** (`pfcGeometry.Polygon`)
- **ARROW** (`pfcGeometry.Arrow`)
- **TEXT** (`pfcGeometry.Text`)

Evaluation of Curves and Edges

Methods Introduced:

- `pfcGeometry.GeomCurve.Eval3DData`
- `pfcGeometry.GeomCurve.EvalFromLength`
- `pfcGeometry.GeomCurve.EvalParameter`
- `pfcGeometry.GeomCurve.EvalLength`
- `pfcGeometry.GeomCurve.EvalLengthBetween`

The methods in `GeomCurve` provide information about any curve or edge.

The method `pfcGeometry.GeomCurve.Eval3DData` returns a `CurveXYZData` object with information on the point represented by the input parameter `t`. The method `pfcGeometry.GeomCurve.EvalFromLength` returns a similar object with information on the point that is a specified distance from the starting point.

The method `pfcGeometry.GeomCurve.EvalParameter` returns the `t` parameter that represents the input `Point3D` object.

Both `pfcGeometry.GeomCurve.EvalLength` and `pfcGeometry.GeomCurve.EvalLengthBetween` return numerical values for the length of the curve or edge.

Solid Edge Geometry

Methods Introduced:

- **pfcGeometry.Edge.GetSurface1**
- **pfcGeometry.Edge.GetSurface2**
- **pfcGeometry.Edge.GetEdge1**
- **pfcGeometry.Edge.GetEdge2**
- **pfcGeometry.Edge.EvalUV**
- **pfcGeometry.Edge.GetDirection**

Note: The methods in the interface `Edge` provide information only for solid or surface edges.

The methods **pfcGeometry.Edge.GetSurface1** and **pfcGeometry.Edge.GetSurface2** return the surfaces bounded by this edge. The methods **pfcGeometry.Edge.GetEdge1** and **pfcGeometry.Edge.GetEdge2** return the next edges in the two contours that contain this edge.

The method **pfcGeometry.Edge.EvalUV** evaluates geometry information based on the UV parameters of one of the bounding surfaces.

The method **pfcGeometry.Edge.GetDirection** returns a positive 1 if the edge is parameterized in the same direction as the containing contour, and -1 if the edge is parameterized opposite to the containing contour.

Curve Descriptors

A curve descriptor is a data object that describes the geometry of a curve or edge. A curve descriptor describes the geometry of a curve without being a part of a specific model.

Methods Introduced:

- **pfcGeometry.GeomCurve.GetCurveDescriptor**
- **pfcGeometry.GeomCurve.GetNURBSRepresentation**

Note: To get geometric information for an edge, access the `CurveDescriptor` object for one edge using **pfcGeometry.GeomCurve.GetCurveDescriptor**.

The method **pfcGeometry.GeomCurve.GetCurveDescriptor** returns a curve's geometry as a data object.

The method **pfcGeometry.GeomCurve.GetNURBSRepresentation** returns a Non-Uniform Rational B-Spline Representation of a curve.

Contours

Methods Introduced:

- **pfcGeometry.Surface.ListContours**
- **pfcGeometry.Contour.GetInternalTraversal**
- **pfcGeometry.Contour.FindContainingContour**
- **pfcGeometry.Contour.EvalArea**
- **pfcGeometry.Contour.EvalOutline**
- **pfcGeometry.Contour.VerifyUV**

Contours are a series of edges that completely bound a surface. A contour is *not* a `ModelItem`. You cannot get contours using the methods that get different types of `ModelItem`. Use the method **pfcGeometry.Surface.ListContours** to get contours from their containing surfaces.

The method **pfcGeometry.Contour.GetInternalTraversal** returns a `ContourTraversal` enumerated type that identifies whether a given contour is on the outside or inside of a containing surface.

Use the method **pfcGeometry.Contour.FindContainingContour** to find the contour that entirely encloses the specified contour.

The method **pfcGeometry.Contour.EvalArea** provides the area enclosed by the contour.

The method **pfcGeometry.Contour.EvalOutline** returns the points that make up the bounding rectangle of the contour.

Use the method **pfcGeometry.Contour.VerifyUV** to determine whether the given `UVParams` argument lies inside the contour, on the boundary, or outside the contour.


Surfaces

Using J-Link you access datum and solid surfaces in the same way.

UV Parameterization

A surface in Pro/ENGINEER is described as a series of parametric equations where two parameters, u and v , determine the x , y , and z coordinates. Unlike the edge parameter, t , these parameters need not start at 0.0, nor are they limited to 1.0.

The figure on the following page illustrates surface parameterization.



Surface Types

Surfaces within Pro/ENGINEER can be any of the following types:

- **PLANE**—A planar surface represented by the class `pfcGeometry.Plane`.
- **CYLINDER**—A cylindrical surface represented by the class `pfcGeometry.Cylinder`.
- **CONE**—A conic surface region represented by the class `pfcGeometry.Cone`.
- **TORUS**—A toroidal surface region represented by the class `pfcGeometry.Torus`.
- **REVOLVED SURFACE**—Generated by revolving a curve about an axis. This is represented by the class `pfcGeometry.RevSurface`.
- **RULED SURFACE**—Generated by interpolating linearly between two curve entities. This is represented by the class `pfcGeometry.RuledSurface`.
- **TABULATED CYLINDER**—Generated by extruding a curve linearly. This is represented by the class `pfcGeometry.TabulatedCylinder`.
- **QUILT**—A combination of two or more surfaces. This is represented by the class `pfcGeometry.Quilt`.
Note: This is used only for datum surfaces.
- **COONS PATCH**—A coons patch is used to blend surfaces together. It is represented by the class `pfcGeometry.CoonsPatch`.
- **FILLET SURFACE**—A filleted surface is found where a round or fillet is placed on a curved edge or an edge with a non-constant arc radii. On a straight edge a cylinder is used to represent a fillet. This is represented by the class `pfcGeometry.FilletedSurface`.
- **SPLINE SURFACE**— A nonuniform bicubic spline surface that passes through a grid with tangent vectors given at each point. This is represented by the class `pfcGeometry.SplineSurface`.
- **NURBS SURFACE**—A NURBS surface is defined by basic functions (in u and v), expandable arrays of knots, weights, and control points. This is represented by the class `pfcGeometry.NURBSurface`.

- **CYLINDRICAL SPLINE SURFACE**— A cylindrical spline surface is a nonuniform bicubic spline surface that passes through a grid with tangent vectors given at each point. This is represented by the class `pfcGeometry.CylindricalSplineSurface`.

To determine which type of surface a `pfcGeometry.Surface` object represents, access the surface type using `pfcGeometry.Geometry.GetSurfaceType`.

Surface Information

Methods Introduced:

- `pfcGeometry.Surface.GetSurfaceType`
- `pfcGeometry.Surface.GetXYZExtents`
- `pfcGeometry.Surface.GetUVEExtents`
- `pfcGeometry.Surface.GetOrientation`

Evaluation of Surfaces

Surface methods allow you to use multiple surface information to calculate, evaluate, determine, and examine surface functions and problems.

Methods Introduced:

- `pfcGeometry.Surface.GetOwnerQuilt`
- `pfcGeometry.Surface.EvalClosestPoint`
- `pfcGeometry.Surface.EvalClosestPointOnSurface`
- `pfcGeometry.Surface.Eval3DData`
- `pfcGeometry.Surface.EvalParameters`
- `pfcGeometry.Surface.EvalArea`
- `pfcGeometry.Surface.EvalDiameter`
- `pfcGeometry.Surface.EvalPrincipalCurv`
- `pfcGeometry.Surface.VerifyUV`
- `pfcGeometry.Surface.EvalMaximum`
- `pfcGeometry.Surface.EvalMinimum`
- `pfcGeometry.Surface.ListSameSurfaces`

The method `pfcGeometry.Surface.GetOwnerQuilt` returns the `Quilt` object that contains the datum surface.

The method **pfcGeometry.Surface.EvalClosestPoint** projects a three-dimensional point onto the surface. Use the method **pfcGeometry.Surface.EvalClosestPointOnSurface** to determine whether the specified three-dimensional point is on the surface, within the accuracy of the part. If it is, the method returns the point that is exactly on the surface. Otherwise the method returns null.

The method **pfcGeometry.Surface.Eval3DData** returns a `ISurfXYZData` object that contains information about the surface at the specified u and v parameters. The method **pfcGeometry.Surface.EvalParameters** returns the u and v parameters that correspond to the specified three-dimensional point.

The method **pfcGeometry.Surface.EvalArea** returns the area of the surface, whereas **pfcGeometry.Surface.EvalDiameter** returns the diameter of the surface. If the diameter varies the optional `UVParams` argument identifies where the diameter should be evaluated.

The method **pfcGeometry.Surface.EvalPrincipalCurv** returns a `CurvatureData` object with information regarding the curvature of the surface at the specified u and v parameters.

Use the method **pfcGeometry.Surface.VerifyUV** to determine whether the `UVParams` are actually within the boundary of the surface.

The methods **pfcGeometry.Surface.EvalMaximum** and **pfcGeometry.Surface.EvalMinimum** return the three-dimensional point on the surface that is the furthest in the direction of (or away from) the specified vector.

The method **pfcGeometry.Surface.ListSameSurfaces** identifies other surfaces that are tangent and connect to the given surface.

Surface Descriptors

A surface descriptor is a data object that describes the shape and geometry of a specified surface. A surface descriptor allows you to describe a surface in 3D without an owner ID.

Methods Introduced:

- **pfcGeometry.Surface.GetSurfaceDescriptor**
- **pfcGeometry.Surface.GetNURBSRepresentation**

The method **pfcGeometry.Surface.GetSurfaceDescriptor** returns a surface's geometry as a data object.

The method **pfcGeometry.Surface.GetNURBSRepresentation** returns a Non-Uniform Rational B-Spline Representation of a surface.

Axes, Coordinate Systems, and Points

Coordinate axes, datum points, and coordinate systems are all model items. Use the methods that return `ModelItems` to get one of these geometry objects. Refer to the chapter “ModelItem” for additional information.

Evaluation of ModelItems

Methods Introduced:

- **pfcGeometry.Axis.GetSurf**
- **pfcGeometry.CoordSystem.GetCoordSys**
- **pfcGeometry.Point.GetPoint**

The method **pfcGeometry.Axis.GetSurf** returns the revolved surface that uses the axis.

The method **pfcGeometry.CoordSystem.GetCoordSys** returns the `Transform3D` object (which includes the origin and x-, y-, and z- axes) that defines the coordinate system.

The method **pfcGeometry.Point.GetPoint** returns the xyz coordinates of the datum point.

Interference

Pro/ENGINEER assemblies can contain interferences between components when constrained by certain rules defined by the user. The `com.ptc.pfc.pfcInterference` package allows the user to detect and analyze any interferences within the assembly. The analysis of this functionality should be looked at from two standpoints: global and selection based analysis.

Methods Introduced:

- `pfcInterference.pfcInterference.CreateGlobalEvaluator`
- `pfcInterference.GlobalEvaluator.ComputeGlobalInterference`
- `pfcInterference.GlobalEvaluator.GetAssem`
- `pfcInterference.GlobalEvaluator.SetAssem`
- `pfcInterference.GlobalInterference.GetVolume`
- `pfcInterference.GlobalInterference.GetSelParts`

To compute all the interferences within an Assembly one has to call `pfcInterference.pfcInterference.CreateGlobalEvaluator` with a `Assembly.Assembly` object as an argument. This call returns a `GlobalEvaluator` object. The `GlobalEvaluator` can be used to extract an assembly object or to set an assembly object for the interference computation.

The methods `pfcInterference.GlobalEvaluator.GetAssem` and `pfcInterference.GlobalEvaluator.SetAssem` with `pfcAssembly.Assembly` as an argument allow you to do exactly that.

The method `pfcInterference.GlobalEvaluator.ComputeGlobalInterference` determines the set of all the interferences within the assembly.

This method will return a sequence of `pfcInterference.GlobalInterference` objects or null if there are no interfering parts. Each object contains a pair of intersecting parts and an object representing the interference volume, which can be extracted by using `pfcInterference.GlobalInterference.GetSelParts` and `pfcInterference.GlobalInterference.GetVolume` respectively.

Analyzing Interference Information

Methods Introduced:

- **pfcSelect.pfcSelect.SelectionPair_Create**
- **pfcInterference.pfcInterference.CreateSelectionEvaluator**
- **pfcInterference.SelectionEvaluator.GetSelections**
- **pfcInterference.SelectionEvaluator.SetSelections**
- **pfcInterference.SelectionEvaluator.ComputeInterference**
- **pfcInterference.SelectionEvaluator.ComputeClearance**
- **pfcInterference.SelectionEvaluator.ComputeNearestCriticalDistance**

The method **pfcSelect.pfcSelect.SelectionPair_Create** creates a `pfcSelect.SelectionPair` object using two `pfcSelect.Selection` objects as arguments.

A return from this method will serve as an argument to **pfcInterference.pfcInterference.CreateSelectionEvaluator**, which will provide a way to determine the interference data between the two selections.

pfcInterference.SelectionEvaluator.GetSelections and **pfcInterference.SelectionEvaluator.SetSelections** will extract and set the object to be evaluated respectively.

pfcInterference.SelectionEvaluator.ComputeInterference determines the interfering information about the provided selections. This method will return the `pfcInterference.InterferenceVolume` object or null if the selections do no interfere.

pfcInterference.SelectionEvaluator.ComputeClearance computes the clearance data for the two selection. This method returns a `pfcInterference.ClearanceData` object, which can be used to obtain and set clearance distance, nearest points between selections, and a boolean `IsInterferening` variable.

pfcInterference.SelectionEvaluator.ComputeNearestCriticalDistance finds a critical point of the distance function between two selections.

This method returns a `pfcInterference.CriticalDistanceData` object, which is used to determine and set critical points, surface parameters, and critical distance between points.

Analyzing Interference Volume

Methods Introduced:

- **pfcInterference.InterferenceVolume.ComputeVolume**
- **pfcInterference.InterferenceVolume.Highlight**
- **pfcInterference.InterferenceVolume.GetBoundaries**

The method **pfcInterference.InterferenceVolume.ComputeVolume** will calculate a value for interfering volume.

The method **pfcInterference.InterferenceVolume.Highlight** will highlight the interfering volume with the color provided in the argument to the function.

The method **pfcInterference.InterferenceVolume.GetBoundaries** will return a set of boundary surface descriptors for the interference volume.

Example Code

This application finds the interference in an assembly, highlights the interfering surfaces, and highlights calculates the interference volume.

```
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcInterference.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcWindow.*;
import com.ptc.cipjava.*;
public class UsrInterference {

    public static void showInterferences(com.ptc.pfc.pfcAssembly.Assembly
assembly)
    {

        try {
            BaseSession session = null; //The Pro/ENGINEER Session Object
            Assembly inter_assem = null; //The Assembly with interferences.
            GlobalEvaluator gbl_eval; //The GlobalEvaluator Object
            GlobalInterferences gbl_inters;//A List of Interferences in the
                Model
            GlobalInterference gbl_inter;//an pfcInterference object
            SelectionPair select_pair;//A pfcSelectionPair Object.
            Selection sel1, sel2;//Two Selection object
```

```

        InterferenceVolume vol;//The interference volume object.
        double total_volume;//The interference volume for a particular
            interference
        gbl_eval = pfcInterference.CreateGlobalEvaluator(assembly);
        //Setting this parameter to TRUE will select only the solid geometry
        //Setting it to false will through an exception.
        gbl_inters = gbl_eval.ComputeGlobalInterference(true);
        if (gbl_inters == null)
System.out.println("No Interferences detected in " +
assembly.GetFullName());
        else
        {
        //Find out how many interferences exist in an assembly
        int size = gbl_inters.getarraysize();
        //Then for each interference object display the interfering surfaces
        //and compute the interference volume
        System.out.println("The Total Interference Volume: ");
        for (int i = 0; i < size; i++)
        {
            gbl_inter = gbl_inters.get(i);

            select_pair = gbl_inter.GetSelParts();
            sel1 = select_pair.GetSel1();
            sel2 = select_pair.GetSel2();
            sel1.Highlight(StdColor.COLOR_HIGHLIGHT);
            sel2.Highlight(StdColor.COLOR_HIGHLIGHT);

            vol = gbl_inter.GetVolume();
            total_volume = vol.ComputeVolume();
            System.out.println("Interference " + i + " = " + total_volume);
            vol.Highlight(StdColor.COLOR_ERROR);
        }
        }
    }
    catch (jxthrowable x)
    {
        System.out.println("Caught Exception: " + x);
        x.printStackTrace();
    }
    return;
}
}

```

17

Dimensions and Parameters

This chapter describes the J-Link methods and classes that affect dimensions and parameters.

Topic	Page
Overview	17 - 2
The ParamValue Object	17 - 2
Parameter Objects	17 - 3
Dimension Objects	17 - 13

Overview

Dimensions and parameters in Pro/ENGINEER have similar characteristics but also have significant differences. In J-Link, the similarities between dimensions and parameters are contained in the `pfcModelItem.BaseParameter` interface. This interface allows access to the parameter or dimension value and to information regarding a parameter's designation and modification. The differences between parameters and dimensions are recognizable because `Dimension` inherits from the interface `ModelItem`, and can be assigned tolerances, whereas parameters are not `ModelItems` and cannot have tolerances.

The ParamValue Object

Both parameters and dimension objects contain an object of type `pfcModelItem.ParamValue`. This object contains the integer, real, string, or Boolean value of the parameter or dimension. Because of the different possible value types that can be associated with a `ParamValue` object there are different methods used to access each value type and some methods will not be applicable for some `ParamValue` objects. If you try to use an incorrect method an exception will be thrown.

Accessing a ParamValue Object

Methods Introduced:

- `pfcModelItem.pfcModelItem.CreateIntParamValue`
- `pfcModelItem.pfcModelItem.CreateDoubleParamValue`
- `pfcModelItem.pfcModelItem.CreateStringParamValue`
- `pfcModelItem.pfcModelItem.CreateBoolParamValue`
- `pfcModelItem.pfcModelItem.CreateNoteParamValue`
- `pfcModelItem.BaseParameter.GetValue`

The `pfcModelItem` utility class contains methods for creating each type of `ParamValue` object. Once you have established the value type in the object, you can change it. The method `pfcModelItem.BaseParameter.GetValue` returns the `ParamValue` associated with a particular parameter or dimension.

A `NoteParamValue` is an integer value that refers to the ID of a specified note. To create a parameter of this type the identified note must already exist in the model.

Accessing the ParamValue Value

Methods Introduced:

- `pfcModelItem.ParamValue.Getdiscr`
- `pfcModelItem.ParamValue.GetIntValue`
- `pfcModelItem.ParamValue.SetIntValue`
- `pfcModelItem.ParamValue.GetDoubleValue`
- `pfcModelItem.ParamValue.SetDoubleValue`
- `pfcModelItem.ParamValue.GetStringValue`
- `pfcModelItem.ParamValue.SetStringValue`
- `pfcModelItem.ParamValue.GetBoolValue`
- `pfcModelItem.ParamValue.SetBoolValue`
- `pfcModelItem.ParamValue.GetNotelD`

The method `pfcModelItem.ParamValue.Getdiscr` returns an enumeration object that identifies the type of value contained in the `ParamValue` object. Use this information with the **Get** and **Set** methods to access the value. If you use an incorrect **Get** or **Set** method an exception of type `pfcExceptions.XBadGetParamValue` will be thrown.

Parameter Objects

The following sections describe the J-Link methods that access parameters. The topics are as follows:

- Creating and Accessing Parameters
- Parameter Selection Options
- Parameter Information
- Parameter Restrictions

Creating and Accessing Parameters

Methods Introduced:

- **pfcModelItem.ParameterOwner.CreateParam**
- **pfcModelItem.ParameterOwner.CreateParamWithUnits**
- **pfcModelItem.ParameterOwner.GetParam**
- **pfcModelItem.ParameterOwner.ListParams**
- **pfcModelItem.ParameterOwner.SelectParam**
- **pfcModelItem.ParameterOwner.SelectParameters**
- **pfcFamily.FamColParam.GetRefParam**

In J-Link, models, features, surfaces, and edges inherit from the **pfcModelItem.ParameterOwner** interface, because each of the objects can be assigned parameters in Pro/ENGINEER.

The method **pfcModelItem.ParameterOwner.GetParam** gets a parameter given its name.

The method **pfcModelItem.ParameterOwner.ListParams** returns a sequence of all parameters assigned to the object.

To create a new parameter with a name and a specific value, call the method **pfcModelItem.ParameterOwner.CreateParam**.

To create a new parameter with a name, a specific value, and units, call the method **pfcModelItem.ParameterOwner.CreateParamWithUnits**.

The method **pfcModelItem.ParameterOwner.SelectParam** allows you to select a parameter from the Pro/ENGINEER user interface. The top model from which the parameters are selected must be displayed in the current window.

The method **pfcModelItem.ParameterOwner.SelectParameters** allows you to interactively select parameters from the Pro/ENGINEER Parameter dialog box based on the parameter selection options specified by the **pfcModelItem.ParameterSelectionOptions** object. The top model from which the parameters are selected must be displayed in the current window. Refer to the section Parameter Selection Options for more information.

The method **pfcFamily.FamColParam.GetRefParam** returns the reference parameter from the parameter column in a family table.

Parameter Selection Options

Parameter selection options in J-Link are represented by the **pfcModelItem.ParameterSelectionOptions** interface.

Methods Introduced:

- **pfcModelItem.pfcModelItem.ParameterSelectionOptions_Create**
- **pfcModelItem.ParameterSelectionOptions.SetAllowContextSelection**
- **pfcModelItem.ParameterSelectionOptions.SetContexts**
- **pfcModelItem.ParameterSelectionOptions.SetAllowMultipleSelections**
- **pfcModelItem.ParameterSelectionOptions.SetSelectButtonLabel**

The method **pfcModelItem.pfcModelItem.ParameterSelectionOptions_Create** creates a new instance of the **ParameterSelectionOptions** object that is used by the method **pfcModelItem.ParameterOwner.SelectParameters()**.

The parameter selection options are as follows:

- *AllowContextSelection*—This boolean attribute indicates whether to allow parameter selection from multiple contexts, or from the invoking parameter owner. By default, it is false and allows selection only from the invoking parameter owner. If it is true and if specific selection contexts are not yet assigned, then you can select the parameters from any context. Use the method **pfcModelItem.ParameterSelectionOptions.SetAllowContextSelection** to modify the value of this attribute.
- *Contexts*—The permitted parameter selection contexts in the form of the **pfcModelItem.ParameterSelectionContexts** object. Use the method **pfcModelItem.ParameterSelectionOptions.SetContexts** to assign the parameter selection context. By default, you can select parameters from any context.

The types of parameter selection contexts are as follows:

- **PARAMSELECT_MODEL**—Specifies that the top level model parameters can be selected.
- **PARAMSELECT_PART**—Specifies that any part's parameters (at any level of the top model) can be selected.
- **PARAMSELECT_ASM**—Specifies that any assembly's parameters (at any level of the top model) can be selected.

- PARAMSELECT_FEATURE—Specifies that any feature’s parameters can be selected.
 - PARAMSELECT_EDGE—Specifies that any edge’s parameters can be selected.
 - PARAMSELECT_SURFACE—Specifies that any surface’s parameters can be selected.
 - PARAMSELECT_QUILT—Specifies that any quilt’s parameters can be selected.
 - PARAMSELECT_CURVE—Specifies that any curve’s parameters can be selected.
 - PARAMSELECT_COMPOSITE_CURVE—Specifies that any composite curve’s parameters can be selected.
 - PARAMSELECT_INHERITED—Specifies that any inheritance feature’s parameters can be selected.
 - PARAMSELECT_SKELETON—Specifies that any skeleton’s parameters can be selected.
 - PARAMSELECT_COMPONENT—Specifies that any component’s parameters can be selected.
- *AllowMultipleSelections*—This boolean attribute indicates whether or not to allow multiple parameters to be selected from the dialog box, or only a single parameter. By default, it is true and allows selection of multiple parameters.
Use the method
pfcModelItem.ParameterSelectionOptions.SetAllowMultipleSelections to modify this attribute.
 - *SelectButtonLabel*—The visible label for the select button in the dialog box.
Use the method
pfcModelItem.ParameterSelectionOptions.SetSelectButtonLabel to set the label. If not set, the default label in the language of the active Pro/ENGINEER session is displayed.

Parameter Information

Methods Introduced:

- **pfcModelItem.BaseParameter.GetValue**
- **pfcModelItem.BaseParameter.SetValue**
- **pfcModelItem.Parameter.GetScaledValue**
- **pfcModelItem.Parameter.SetScaledValue**
- **pfcModelItem.Parameter.GetUnits**
- **pfcModelItem.BaseParameter.GetIsDesignated**
- **pfcModelItem.BaseParameter.SetIsDesignated**
- **pfcModelItem.BaseParameter.GetIsModified**
- **pfcModelItem.BaseParameter.ResetFromBackup**
- **pfcModelItem.Parameter.GetDescription**
- **pfcModelItem.Parameter.SetDescription**
- **pfcModelItem.Parameter.GetRestriction**
- **pfcModelItem.Parameter.GetDriverType**
- **pfcModelItem.Parameter.Reorder**
- **pfcModelItem.Parameter.Delete**
- **pfcModelItem.NamedModelItem.GetName**

Parameters inherit methods from the **BaseParameter**, **Parameter**, and **NamedModelItem** interfaces.

The method **pfcModelItem.BaseParameter.GetValue** returns the value of the parameter or dimension.

The method **pfcModelItem.BaseParameter.SetValue** assigns a particular value to a parameter or dimension.

The method **pfcModelItem.Parameter.GetScaledValue** returns the parameter value in the units of the parameter, instead of the units of the owner model as returned by **pfcModelItem.BaseParameter.GetValue**.

The method **pfcModelItem.Parameter.SetScaledValue** assigns the parameter value in the units provided, instead of using the units of the owner model as assumed by **pfcModelItem.BaseParameter.GetValue**.

The method **pfcModelItem.Parameter.GetUnits** returns the units assigned to the parameter.

You can access the designation status of the parameter using the methods **pfcModelItem.BaseParameter.GetIsDesignated** and **pfcModelItem.BaseParameter.SetIsDesignated**.

The methods **pfcModelItem.BaseParameter.GetIsModified** and **pfcModelItem.BaseParameter.ResetFromBackup** enable you to identify a modified parameter or dimension, and reset it to the last stored value. A parameter is said to be "modified" when the value has been changed but the parameter's owner has not yet been regenerated.

The method **pfcModelItem.Parameter.GetDescription** returns the parameter description, or null, if no description is assigned.

The method **pfcModelItem.Parameter.SetDescription** assigns the parameter description.

The method **pfcModelItem.Parameter.GetRestriction** identifies if the parameter's value is restricted to a certain range or enumeration. It returns the **pfcModelItem.ParameterRestriction** object. Refer to the section Parameter Restrictions for more information.

The method **pfcModelItem.Parameter.GetDriverType** returns the driver type for a material parameter. The driver types are as follows:

- **PARAMDRIVER_PARAM**—Specifies that the parameter value is driven by another parameter.
- **PARAMDRIVER_FUNCTION**—Specifies that the parameter value is driven by a function.
- **PARAMDRIVER_RELATION**—Specifies that the parameter value is driven by a relation. This is equivalent to the value obtained using **pfcModelItem.BaseParameter.GetIsRelationDriven** for a parameter object type.

The method **pfcModelItem.Parameter.Reorder** reorders the given parameter to come immediately after the indicated parameter in the Parameter dialog box and information files generated by Pro/ENGINEER.

The method **pfcModelItem.Parameter.Delete** permanently removes a specified parameter.

The method **pfcModelItem.NamedModelItem.GetName** accesses the name of the specified parameter.

Parameter Restrictions

Pro/ENGINEER allows users to assign specified limitations to the value allowed for a given parameter (wherever the parameter appears in the model). You can only read the details of the permitted restrictions from J-Link, but not modify the permitted values or range of values. Parameter restrictions in J-Link are represented by the interface **pfcModelItem.ParameterRestriction**.

Method Introduced:

- **pfcModelItem.ParameterRestriction.GetType**

The method **pfcModelItem.ParameterRestriction.GetType** returns the **pfcModelItem.RestrictionType** object containing the types of parameter restrictions. The parameter restrictions are of the following types:

- **PARAMSELECT_ENUMERATION**—Specifies that the parameter is restricted to a list of permitted values.
- **PARAMSELECT_RANGE**—Specifies that the parameter is limited to a specified range of numeric values.

Enumeration Restriction

The **PARAMSELECT_ENUMERATION** type of parameter restriction is represented by the interface **pfcModelItem.ParameterEnumeration**. It is a child of the **pfcModelItem.ParameterRestriction** interface.

Method Introduced:

- **pfcModelItem.ParameterEnumeration.GetPermittedValues**

The method **pfcModelItem.ParameterEnumeration.GetPermittedValues** returns a list of permitted parameter values allowed by this restriction in the form of a sequence of the **pfcModelItem.ParamValue** objects.

Range Restriction

The **PARAMSELECT_RANGE** type of parameter restriction is represented by the interface **pfcModelItem.ParameterRange**. It is a child of the **pfcModelItem.ParameterRestriction** interface.

Methods Introduced:

- **pfcModelItem.ParameterRange.GetMaximum**
- **pfcModelItem.ParameterRange.GetMinimum**
- **pfcModelItem.ParameterLimit.GetType**
- **pfcModelItem.ParameterLimit.GetValue**

The method **pfcModelItem.ParameterRange.GetMaximum** returns the maximum value limit for the parameter in the form of the **pfcModelItem.ParameterLimit** object.

The method **pfcModelItem.ParameterRange.GetMinimum** returns the minimum value limit for the parameter in the form of the **pfcModelItem.ParameterLimit** object.

The method **pfcModelItem.ParameterLimit.GetType** returns the **pfcModelItem.ParameterLimitType** containing the types of parameter limits. The parameter limits are of the following types:

- **PARAMLIMIT_LESS_THAN**—Specifies that the parameter must be less than the indicated value.
- **PARAMLIMIT_LESS_THAN_OR_EQUAL**—Specifies that the parameter must be less than or equal to the indicated value.
- **PARAMLIMIT_GREATER_THAN**—Specifies that the parameter must be greater than the indicated value.
- **PARAMLIMIT_GREATER_THAN_OR_EQUAL**—Specifies that the parameter must be greater than or equal to the indicated value.

The method **pfcModelItem.ParameterLimit.GetValue** returns the boundary value of the parameter limit in the form of the **pfcModelItem.ParamValue** object.

Example Code: Updating Model Parameters

The following example code contains a single static utility method. This method reads a Java "properties" file and creates or updates model parameters for each property which exists in the file. Since each property value is returned as a String, a utility method parses the String into int, double, or boolean values if possible.


```

import com.ptc.pfc.pfcModelItem.*;
import com.ptc.cipjava.jxthrowable;

import com.ptc.pfcu.pfcuParamValue; // utility method - create param
//value from String

import java.util.*; //contains Properties and Enumeration classes
import java.io.*; // needed for read from file
public class pfcParameterExamples {

    /** createParametersFromProperties () demonstrates how
    Java can read in *system-dependent stored information
    using a "properties" file. Note that the *ParameterOwner
    argument could refer to a model, a feature, a surface, or
    an *edge.**/
    public static void createParametersFromProperties
    (ParameterOwner p_owner) throws com.ptc.cipjava.jxthrowable {
        String prop_value;
        String propsfile = "params.properties";
        ParamValue pv;
        Parameter p;

        Properties props = new Properties (); //empty properties object

        try {
            props.load (new BufferedInputStream( new FileInputStream
            (propsfile)));
        }
        catch (IOException e)
        {
            System.out.println ("File: "+propsfile+ "cannot be opened.");
            System.out.println ("Cannot load parameters.");
            return;
        }
        Enumeration e = props.propertyNames (); /* Enumeration allows you to
        loop through all properties without determining
        how many there are*/
        for (String prop_name = (String)e.nextElement();
        e.hasMoreElements();
        prop_name = (String)e.nextElement())
        {
            prop_value = props.getProperty(prop_name);
            pv = pfcuParamValue.createParamValueFromString(prop_value);
            p = p_owner.GetParam(prop_name);
            if (p == null) // GetParam returns null if it can't find the param.
            {
                p_owner.CreateParam (prop_name, pv);
            }
            else
            {
                p.SetValue (pv);
            }
        }
    }
}

```



```
}  
}  
}  
}  
}
```

Dimension Objects

Dimension objects include standard Pro/ENGINEER dimensions as well as reference dimensions. Dimension objects enable you to access dimension tolerances and enable you to set the value for the dimension. Reference dimensions allow neither of these actions.

Getting Dimensions

Dimensions and reference dimensions are Pro/ENGINEER model items. See the section “Getting ModelItem Objects” for methods that can return `Dimension` and `RefDimension` objects.

Dimension Information

Methods Introduced:

- `pfcModelItem.BaseParameter.GetValue`
- `pfcModelItem.BaseParameter.SetValue`
- `pfcModelItem.BaseDimension.GetDimValue`
- `pfcModelItem.BaseDimension.SetDimValue`
- `pfcModelItem.BaseParameter.GetIsDesignated`
- `pfcModelItem.BaseParameter.SetIsDesignated`
- `pfcModelItem.BaseParameter.GetIsModified`
- `pfcModelItem.BaseParameter.ResetFromBackup`
- `pfcModelItem.BaseParameter.GetIsRelationDriven`
- `pfcDimension.BaseDimension.GetDimType`
- `pfcDimension.BaseDimension.GetSymbol`
- `pfcDimension.BaseDimension.GetTexts`
- `pfcDimension.BaseDimension.SetTexts`

All the `BaseParameter` methods are accessible to `Dimensions` as well as `Parameters`. See the section “Parameter Objects” for brief descriptions.

Note: You cannot set the value or designation status of reference dimension objects.

The methods **pfcModelItem.BaseDimension.GetDimValue** and **pfcModelItem.BaseDimension.SetDimValue** access the dimension value as a double. These methods provide a shortcut for accessing the dimensions' values without using a ParamValue object.

The **pfcModelItem.BaseParameter.GetIsRelationDriven** method identifies whether the part or assembly relations control a dimension.

The method **pfcDimension.BaseDimension.GetDimType** returns an enumeration object that identifies whether a dimension is linear, radial, angular, or diametrical.

The method **pfcDimension.BaseDimension.GetSymbol** returns the dimension or reference dimension symbol (that is, “d#” or “rd#”).

The **pfcDimension.BaseDimension.GetTexts** and **pfcDimension.BaseDimension.SetTexts** methods allow access to the text strings that precede or follow the dimension value.

Dimension Tolerances

Methods Introduced:

- **pfcDimension.Dimension.GetTolerance**
- **pfcDimension.Dimension.SetTolerance**
- **pfcDimension.pfcDimension.DimTolPlusMinus_Create**
- **pfcDimension.pfcDimension.DimTolSymmetric_Create**
- **pfcDimension.pfcDimension.DimTolLimits_Create**
- **pfcDimension.pfcDimension.DimTolSymSuperscript_Create**
- **pfcDimension.pfcDimension.DimTolISODIN_Create**

Only true dimension objects can have geometric tolerances.

The methods **pfcDimension.Dimension.GetTolerance** and **pfcDimension.Dimension.SetTolerance** enable you to access the dimension tolerance. The object types for the dimension tolerance are:

- **DimTolLimits**—Displays dimension tolerances as upper and lower limits.

Note: This format is not available when only the tolerance value for a dimension is displayed.

- `DimTolPlusMinus`—Displays dimensions as nominal with plus-minus tolerances. The positive and negative values are independent.
- `DimTolSymmetric`—Displays dimensions as nominal with a single value for both the positive and the negative tolerance.
- `DimTolSymSuperscript`—Displays dimensions as nominal with a single value for positive and negative tolerance. The text of the tolerance is displayed in a superscript format with respect to the dimension text.
- `DimTolISODIN`—Displays the tolerance table type, table column, and table name, if the dimension tolerance is set to a hole or shaft table (DIN/ISO standard).

A *null* value is similar to the nominal option in Pro/ENGINEER.

To determine whether a given tolerance is plus/minus, symmetric, limits, or superscript use **instanceof**.

Example Code: Setting Tolerances to a Specified Range

The following example code shows a utility method that sets angular tolerances to a specified range. First, the program determines whether the dimension passed to it is angular. If it is, the method gets the dimension value and adds or subtracts the range to it to get the upper and lower limits. The program then initializes a `DimTolLimits` tolerance object and assigns it to the dimension.

Because the `BaseParameter` used in this example is a dimension, you know that its `ParamValue` object must contain a double value. Therefore, you do not have to check the `ParamValueType` using the method **`pfcModelItem.pfcParamValue.Getdiscr`**.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcDimension.*;

public class UtilDim {

    public static Dimension setAngularToleranceToLimits (
        Dimension dimension, double range)
    {
        DimensionType    dtype;
        ParamValue        pvalue;

        DimTolLimits      limits;
```

```

double          dvalue, upper, lower;

try {
    dtype = dimension.GetDimType(); // from interface BaseDimension

    if (dtype.equals (DimensionType.DIM_ANGULAR))
    {
        pvalue = dimension.GetValue(); //from interface BaseParameter
        dvalue = pvalue.GetDoubleValue();

        upper = dvalue + range/2.0;
        lower = dvalue - range/2.0;

        limits = pfcDimension.DimTolLimits_Create (new Double (upper),
            new Double (lower));

        dimension.SetTolerance (limits); // from interface Dimension
    }
}
catch (jxthrowable x)
{
    System.out.println ("Exception caught: "+x);
    System.out.println ("Unable to set angular tolerance");
}
finally {
    return (dimension);
}
}
}

```

18

Relations

This chapter describes how to access relations on all models and model items in Pro/ENGINEER using the methods provided in J-Link.

Topic	Page
Accessing Relations	18 - 2
Adding a Customized Function to the Relations Dialog Box in Pro/ENGINEER	18 - 4

Accessing Relations

In J-Link, the set of relations on any model or model item is represented by the **pfcModelItem.RelationOwner** interface. Models, features, surfaces, and edges inherit from this interface, because each object can be assigned relations in Pro/ENGINEER.

Methods Introduced:

- **pfcModelItem.RelationOwner.RegenerateRelations**
- **pfcModelItem.RelationOwner.DeleteRelations**
- **pfcModelItem.RelationOwner.GetRelations**
- **pfcModelItem.RelationOwner.SetRelations**
- **pfcModelItem.RelationOwner.EvaluateExpression**

The method **pfcModelItem.RelationOwner.RegenerateRelations** regenerates the relations assigned to the owner item. It also determines whether the specified relation set is valid.

The method **pfcModelItem.RelationOwner.DeleteRelations** deletes all the relations assigned to the owner item.

The method **pfcModelItem.RelationOwner.GetRelations** returns the list of actual relations assigned to the owner item as a sequence of strings.

The method **pfcModelItem.RelationOwner.SetRelations** assigns the sequence of strings as the new relations to the owner item.

The method **pfcModelItem.RelationOwner.EvaluateExpression** evaluates the given relations-based expression, and returns the resulting value in the form of the **pfcModelItem.ParamValue** object. Refer to the section, The ParamValue Object in the chapter, Dimensions and Parameters for more information on this object.

Example 1: Adding Relations between Parameters in a Solid Model

```
/*=====*\nFUNCTION: createParamDimRelation\nPURPOSE: This function creates parameters for all dimensions in the\n          input features of a part model and adds relation between them.\n/*=====*/\npublic static void createParamDimRelation(Features features)\n{\n    Feature feature;
```



```

int i,j;
stringseq relations;
ModelItems items;
ModelItem item;
String dimName , paramName;
double dimValue;
Boolean paramAdded;
Parameter param ;
ParamValue paramValue;

try
{
    for(i=0;i<features.getarraysize();i++)
    {
/*=====*\
    Get the selected feature
/*=====*\
        feature = features.get(i);
        if (feature == null)
        {
            continue;
        }

/*=====*\
    Get the dimensions in the current feature
/*=====*\
        items = feature.ListSubItems(ModelItemType.ITEM_DIMENSION);
        if ((items == null) || (items.getarraysize() == 0))
        {
            continue;
        }

        relations = stringseq.create();

/*=====*\
    Loop through all the dimensions and create relations
/*=====*\
        for(j=0;j<items.getarraysize(); j++)
        {
            item = items.get(j);
            dimName = item.GetName();
            paramName = "PARAM_" + dimName;
            dimValue = ((Dimension)item).GetDimValue();

            param = feature.GetParam(paramName);
            paramAdded = Boolean.FALSE;
            if (param == null)
            {
                paramValue = pfcModelItem.CreateDoubleParamValue(dimValue);
                feature.CreateParam (paramName, paramValue);
                paramAdded = Boolean.TRUE;
            }
        }
    }
}

```

```

    }
    else
    {
        if (param.GetValue().Getdiscr() == ParamValueType.PARAM_DOUBLE)
        {
            paramValue = pfcModelItem.CreateDoubleParamValue(dimValue);
            param.SetValue(paramValue);
            paramAdded = Boolean.TRUE;
        }
    }

    if (paramAdded == Boolean.TRUE)
    {
        relations.append(dimName + " = " + paramName);
    }
    param = null ;
}
feature.SetRelations(relations);
}
catch(jxthrowable x)
{
    System.out.println("Exception in createParamDimRelation(): "+x);
    return;
}
}
}

```

Adding a Customized Function to the Relations Dialog Box in Pro/ENGINEER

Methods Introduced:

- **pfcSession.BaseSession.RegisterRelationFunction**

The method **pfcSession.BaseSession.RegisterRelationFunction** registers a custom function that is included in the function list of the Relations dialog box in Pro/ENGINEER. You can add the custom function to relations that are added to models, features, or other relation owners. The registration method takes the following input arguments:

- *Name*—The name of the custom function.
- *RelationFunctionOptions*—This object contains the options that determine the behavior of the custom relation function. Refer to the section 'Relation Function Options' for more information.

- *RelationFunctionListener*—This object contains the action listener methods for the implementation of the custom function. Refer to the section ‘Relation Function Listeners’ for more information.

Note: J-Link relation functions are valid only when the custom function has been registered by the application. If the application is not running or not present, models that contain user-defined relations cannot evaluate these relations. In this situation, the relations are marked as errors. However, these errors can be commented until needed at a later time when the relations functions are reactivated in a Pro/ENGINEER session.

Relation Function Options

Methods Introduced:

- **pfcRelations.pfcRelations.RelationFunctionOptions_Create**
- **pfcRelations.RelationFunctionOptions.SetArgumentTypes**
- **pfcRelations.pfcRelations.RelationFunctionArgument_Create**
- **pfcRelations.RelationFunctionArgument.SetType**
- **pfcRelations.RelationFunctionArgument.SetIsOptional**
- **pfcRelations.RelationFunctionOptions.SetEnableTypeChecking**
- **pfcRelations.RelationFunctionOptions.SetEnableArgumentCheckMethod**
- **pfcRelations.RelationFunctionOptions.SetEnableExpressionEvaluationMethod**
- **pfcRelations.RelationFunctionOptions.SetEnableValueAssignmentMethod**

Use the method

pfcRelations.pfcRelations.RelationFunctionOptions_Create to create the **pfcRelations.RelationFunctionOptions** object containing the options to enable or disable various relation function related features. Use the methods listed above to access and modify the options. These options are as follows:

- *ArgumentTypes*—The types of arguments in the form of the **pfcRelations.RelationFunctionArgument** object. By default, this parameter is null, indicating that no arguments are permitted.

Use the method

pfcrelations.pfcrelations.RelationFunctionArgument_Create to create the **pfcrelations.RelationFunctionArgument** object containing the attributes of the arguments passed to the custom relation function. These attributes are as follows:

- *Type*—The type of argument value such as double, integer, and so on in the form of the **pfcrelationmodelitem.paramvaluetype** object.
- *IsOptional*—This boolean attribute specifies whether the argument is optional, indicating that it can be skipped when a call to the custom relation function is made. The optional arguments must fall at the end of the argument list. By default, this attribute is false.
- *EnableTypeChecking*—This boolean attribute determines whether or not to check the argument types internally. By default, it is false. If this attribute is set to false, Pro/ENGINEER does not need to know the contents of the arguments array. The custom function must handle all user errors in such a situation.
- *EnableArgumentCheckMethod*—This boolean attribute determines whether or not to enable the arguments check listener function. By default, it is false.
- *EnableExpressionEvaluationMethod*—This boolean attribute determines whether or not to enable the evaluate listener function. By default, it is true.
- *EnableValueAssignmentMethod*—This boolean attribute determines whether or not to enable the value assignment listener function. By default, it is false.

Relation Function Listeners

The interface **pfcrelations.RelationFunctionListener** provides the method signatures to implement a custom relation function.

Methods Introduced:

- **pfcrelations.RelationFunctionListener.CheckArguments**
- **pfcrelations.RelationFunctionListener.AssignValue**
- **pfcrelations.RelationFunctionListener.EvaluateFunction**

The method

pfcRelations.RelationFunctionListener.CheckArguments

checks the validity of the arguments passed to the custom function.

This listener method takes the following input arguments:

- The owner of the relation being evaluated
- The custom function name
- A sequence of arguments passed to the custom function

If the implementation of this method determines that the arguments are not valid for the custom function, then the listener method returns false. Otherwise, it returns true.

The method

pfcRelations.RelationFunctionListener.EvaluateFunction

evaluates a custom relation function invoked on the right hand side of a relation. This listener method takes the following input arguments:

- The owner of the relation being evaluated
- The custom function name
- A sequence of arguments passed to the custom function

You must return the computed result of the custom relation function.

The method

pfcRelations.RelationFunctionListener.AssignValue

evaluates a custom relation function invoked on the left hand side of a relation. It allows you to initialize properties to be stored and used by your application. This listener method takes the following input arguments:

- The owner of the relation being evaluated
- The custom function name
- A sequence of arguments passed to the custom function
- The value obtained by Pro/ENGINEER from evaluating the right hand side of the relation

Example 2: Adding and Implementing a New Custom Relation Function

This example code consists two classes such as `pfcRelationExamples` and `RelationListener`. The `pfcRelationExamples` class contains methods that define the options for the custom relation function and register it in the current session. The `RelationListener` class contains the `AssignValue` and `EvaluateFunction` listener methods that are called when the custom function is used.

```
package com.ptc.jlinkexamples;

import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcCommand.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcDimension.*;
import com.ptc.pfc.pfcExceptions.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcRelations.*;

public class pfcRelationExamples
{
    /*=====*\
    FUNCTION: addCustomRelation
    PURPOSE:  This function adds new custom relation functions.
    \*=====*/
    public static void addCustomRelation(Session session)
    {
        RelationListener listenerObj;
        RelationFunctionOptions setOptions , getOptions;
        RelationFunctionArgument arg;
        RelationFunctionArguments args;
        try
        {
            listenerObj = new RelationListener();

            /*-----*\
            Create options for custom functions and register them in current session
            \*-----*/
            setOptions = pfcRelations.RelationFunctionOptions_Create ();
            setOptions.SetEnableArgumentCheckMethod(Boolean.FALSE);
        }
    }
}
```

```

setOptions.SetEnableExpressionEvaluationMethod(Boolean.FALSE);
setOptions.SetEnableTypeChecking (Boolean.FALSE);
setOptions.SetEnableValueAssignmentMethod (Boolean.TRUE);

session.RegisterRelationFunction("SET_A", listenerObj, setOptions );
session.RegisterRelationFunction("SET_B", listenerObj, setOptions );
getOptions = pfcRelations.RelationFunctionOptions_Create ();
args = RelationFunctionArguments.create();
arg = pfcRelations.RelationFunctionArgument_Create
        (ParamValueType.PARAM_DOUBLE);
args.set ( 0, arg);
getOptions.SetArgumentTypes(args);

getOptions.SetEnableExpressionEvaluationMethod(Boolean.TRUE);
getOptions.SetEnableTypeChecking (Boolean.FALSE);
getOptions.SetEnableValueAssignmentMethod (Boolean.FALSE);

session.RegisterRelationFunction("EVAL_AX_B", listenerObj,
        getOptions);
}
catch (Throwable e)
{
    System.out.println ("Exception caught in addCustomRelation() : "+e);
    e.printStackTrace ();
}
}

/*=====*\
CLASS:   RelationListener
PURPOSE: This class implemented method will be called when the custom
        relation function is used
\*=====*/
class RelationListener extends DefaultRelationFunctionListener
{
    double aValue = 1;
    double bValue = 0;

/*=====*\
FUNCTION: AssignValue
PURPOSE: Function called when value is assigned to custom relation
        function
\*=====*/

    public void AssignValue (RelationOwner Owner, String FunctionName,
        ParamValues Arguments, ParamValue Assignment)
        throws com.ptc.cipjava.jxthrowable
    {
        if(Assignment.Getdiscr() != ParamValueType.PARAM_DOUBLE)
        {
            return;

```

```

    }

    if (FunctionName.equals("SET_A") )
    {
        aValue = Assignment.GetDoubleValue();
    }

    if (FunctionName.equals("SET_B"))
    {
        bValue = Assignment.GetDoubleValue();
    }
}

/*=====*\
FUNCTION: EvaluateFunction
PURPOSE:  Function called when value is to be returned from custom
          relation function.
\*=====*/
public ParamValue EvaluateFunction (RelationOwner Owner, String
                                   FunctionName, ParamValues Arguments)
                                   throws com.ptc.cipjava.jxthrowable
{
    ParamValue paramValue = null;
    double ret;

    if (FunctionName.equals("EVAL_AX_B"))
    {
        ret = (aValue * (Arguments.get(0).GetDoubleValue())) + bValue;
        paramValue = pfcModelItem.CreateDoubleParamValue(ret);
    }
    return paramValue;
}
}

```


19

Assemblies and Components

This chapter describes the J-Link functions that access the functions of a Pro/ENGINEER assembly. You must be familiar with the following before you read this section:

- The Selection Object
- Coordinate Systems
- The Geometry section

Topic	Page
Structure of Assemblies and Assembly Objects	19 - 2
Assembling Components	19 - 9
Redefining and Rerouting Assembly Components	19 - 14
Exploded Assemblies	19 - 20
Skeleton Models	19 - 21

Structure of Assemblies and Assembly Objects

The object `Assembly` is an instance of `Solid`. The `Assembly` object can therefore be used as input to any of the `Solid` and `Model` methods applicable to assemblies. However assemblies do not contain solid geometry items. The only geometry in the assembly is datums (points, planes, axes, coordinate systems, curves, and surfaces). Therefore solid assembly features such as holes and slots will not contain active surfaces or edges in the assembly model.

The solid geometry of an assembly is contained in its components. A component is a feature of type `pfcComponentFeat.ComponentFeat`, which is a reference to a part or another assembly, and a set of parametric constraints for determining its geometrical location within the parent assembly.


Assembly features that are solid, such as holes and slots, and therefore affect the solid geometry of parts in the assembly hierarchy, do not themselves contain the geometry items that describe those modifications. These items are always contained in the parts whose geometry is modified, within local features created for that purpose.

The important J-Link functions for assemblies are those that operate on the components of an assembly. The object `ComponentFeat`, which is an instance of `Feature` is defined for that purpose. Each assembly component is treated as a variety of feature, and the integer identifier of the component is also the feature identifier.

An assembly can contain a hierarchy of assemblies and parts at many levels, in which some assemblies and parts may appear more than once. To identify the role of any database item in the context of the root assembly, it is not sufficient to have the integer identifier of the item and the handle to its owning part or assembly, as would be provided by its `Feature` description.

It is also necessary to give the full path of the assembly-component references down from the root assembly to the part or assembly that owns the database item. This is the purpose of the object `ComponentPath`, which is used as the input to J-Link assembly functions.

The following figure shows an assembly hierarchy with two examples of the contents of a `ComponentPath` object.



In the assembly shown in the figure, subassembly C is component identifier 11 within assembly A, Part B is component identifier 3 within assembly AB, and so on. The subassembly AB occurs twice. To refer to the two occurrences of part B, use the following:

(?)Component B'	Component B''
ComponentIds.get(0) = 2	ComponentIds.get(1) = 11
ComponentIds.get(1) = 2	ComponentIds.get(2) = 6
ComponentIds.get(2) = 5	ComponentIds.get(3) = 12
ComponentIds.get(3) = 2	ComponentIds.get(4) = 3
ComponentIds.get(4) = 3	

The object `ComponentPath` is one of the main portions of the `Selection` object.

Assembly Components

Methods Introduced:

- **pfcComponentFeat.ComponentFeat.GetIsBulkitem**
- **pfcComponentFeat.ComponentFeat.GetIsSubstitute**
- **pfcComponentFeat.ComponentFeat.GetCompType**
- **pfcComponentFeat.ComponentFeat.SetCompType**
- **pfcComponentFeat.ComponentFeat.GetModelDescr**
- **pfcComponentFeat.ComponentFeat.GetIsPlaced**
- **pfcComponentFeat.ComponentFeat.SetIsPlaced**
- **pfcComponentFeat.ComponentFeat.GetIsPackaged**
- **pfcComponentFeat.ComponentFeat.GetIsUnderconstrained**
- **pfcComponentFeat.ComponentFeat.GetIsFrozen**
- **pfcComponentFeat.ComponentFeat.GetPosition**
- **pfcComponentFeat.ComponentFeat.CopyTemplateContents**
- **pfcComponentFeat.ComponentFeat.CreateReplaceOp**

The method **pfcComponentFeat.ComponentFeat.GetIsBulkitem** identifies whether an assembly component is a bulk item. A bulk item is a non-geometric assembly feature that should appear in an assembly bill of materials.

The method **pfcComponentFeat.ComponentFeat.GetIsSubstitute** returns a true value if the component is substituted, else it returns a false. When you substitute a component in a simplified representation, you temporarily exclude the substituted component and superimpose the substituting component in its place.

The method **pfcComponentFeat.ComponentFeat.GetCompType** returns the type of the assembly component.

The method **pfcComponentFeat.ComponentFeat.SetCompType** enables you to set the type of the assembly component. The component type identifies the purpose of the component in a manufacturing assembly.

The method

pfcComponentFeat.ComponentFeat.GetModelDescr returns the model descriptor of the component part or subassembly.

Note: From Pro/ENGINEER Wildfire 4.0 onwards, the method **pfcComponentFeat.ComponentFeat.GetModelDescr** throws an exception `pfcExceptions.XtoolkitCantOpen` if called on an assembly component whose immediate generic is not in session. Handle this exception and typecast the assembly component as `pfcSolid.Solid`, which in turn can be typecast as `pfcFamily.FamilyMember`, and use the method **pfcFamily.FamilyMember.GetImmediateGenericInfo** to get the model descriptor of the immediate generic model. If you wish to switch off this behavior and continue to run legacy applications in the pre-Wildfire 4.0 mode, set the configuration option `retrieve_instance_dependencies` to `"instance_and_generic_deps"`.

The method

pfcComponentFeat.ComponentFeat.GetIsPlaced determines whether the component is placed.

The method **pfcComponentFeat.ComponentFeat.SetIsPlaced** forces the component to be considered placed. The value of this parameter is important in assembly Bill of Materials.

Note: Once a component is constrained or packaged, it cannot be made unplaced again.

A component of an assembly that is either partially constrained or unconstrained is known as a packaged component. Use the method **pfcComponentFeat.ComponentFeat.GetIsPackaged** to determine if the specified component is packaged.

The method

pfcComponentFeat.ComponentFeat.GetIsUnderconstrained determines if the specified component is underconstrained, that is, it possesses some constraints but is not fully constrained.

The method

pfcComponentFeat.ComponentFeat.GetIsFrozen determines if the specified component is frozen. The frozen component behaves similar to the packaged component and does not follow the constraints that you specify.

The method **pfcComponentFeat.ComponentFeat.GetPosition** retrieves the component's initial position before constraints and movements have been applied. If the component is packaged this position is the same as the constraint's actual position. This method modifies the assembly component data but does not regenerate the assembly component. To regenerate the component, use the method **pfcComponentFeat.ComponentFeat.Regenerate**.

The method **pfcComponentFeat.ComponentFeat.CopyTemplateContents** copies the template model into the model of the specified component.

The method **pfcComponentFeat.ComponentFeat.CreateReplaceOp** creates a replacement operation used to swap a component automatically with a related component. The replacement operation can be used as an argument to **pfcSolid.Solid.ExecuteFeatureOps**.

Example Code: Replacing Instances

The following example code contains a single static utility method. This method takes an assembly for an argument. It searches through the assembly for all components that are instances of the model "bolt". It then replaces all such occurrences with a different instance of bolt.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.Session;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcSolid.Solid;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcComponentFeat.*;
import com.ptc.pfc.pfcFamily.FamilyTableRow;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;

public class pfcComponentFeatExamples {

    /**
     * replaceBolts automatically replaces all occurrences of the
     * bolt "phillips7_8" with a new instance "slot7_8". It uses
     * the methods available in the ComponentFeat class, including
     * CreateModelReplace (), which creates a replacement operation
     * for a component, and GetModelDescr (), which returns the model
     * descr corresponding to a particular component feature.
     */
}
```

```

*/

public static void replaceBolts (com.ptc.pfc.pfcAssembly.Assembly
                                assembly)
{
    Session session = null;    //The Pro/ENGINEER session object
    Solid bolt = null;        // The bolt solid model
    FamilyTableRow row = null; // The family table row corresponding
                                // to the new instance
    Solid newBolt;            // The new bolt instance
    Features components;      //List of components in the assembly
    ComponentFeat component;
    ModelDescriptor desc;     // Component model descriptor
    CompModelReplace replace;
    FeatureOperations replaceOps;
    String oldInstance = "PHILLIPS7_8";
    String newInstance = "SLOT7_8";
    try {
        session = pfcGlobal.GetProESession();
        bolt = (Solid)session.GetModel ("BOLT", ModelType.MDL_PART);
    }
    catch (jxthrowable x)
    {
        System.out.println ("Caught exception: "+x);
        x.printStackTrace();
        return;
    }
    try {
        row = bolt.GetRow (newInstance);
        newBolt = (Solid)row.CreateInstance();
        replaceOps = FeatureOperations.create();
        components = assembly.ListFeaturesByType (Boolean.FALSE,
                                                  FeatureType.FEATTYPE_COMPONENT);
        for (int ii = 0; ii < components.getarraysize(); ii++)
        {
            component = (ComponentFeat)components.get(ii);
            desc = component.GetModelDescr();
            if (desc.GetInstanceName().equals(oldInstance))
            {
                replace = component.CreateReplaceOp (newBolt);
                replaceOps.insert(0, replace);
            }
        }
        assembly.ExecuteFeatureOps (replaceOps, null);
    }
    catch (jxthrowable x)
    {
        System.out.println ("Caught exception: "+x);
        x.printStackTrace();
        return;
    }
}

```

```
        return;  
    }  
}
```

Regenerating an Assembly Component

Method Introduced:

- **pfcComponentFeat.ComponentFeat.Regenerate**

The method **pfcComponentFeat.ComponentFeat.Regenerate** regenerates an assembly component. The method regenerates the assembly component just as in an interactive Pro/ENGINEER session.

Creating a Component Path

Methods Introduced

- **pfcAssembly.pfcAssembly.CreateComponentPath**

The method **pfcAssembly.pfcAssembly.CreateComponentPath** returns a component path object, given the Assembly model and the integer id path to the desired component.

Component Path Information

Methods Introduced:

- **pfcAssembly.ComponentPath.GetRoot**
- **pfcAssembly.ComponentPath.SetRoot**
- **pfcAssembly.ComponentPath.GetComponentIds**
- **pfcAssembly.ComponentPath.SetComponentIds**
- **pfcAssembly.ComponentPath.GetLeaf**
- **pfcAssembly.ComponentPath.GetTransform**
- **pfcAssembly.ComponentPath.SetTransform**
- **pfcAssembly.ComponentPath.GetIsVisible**

The method **pfcAssembly.ComponentPath.GetRoot** returns the assembly at the head of the component path object.

The method **pfcAssembly.ComponentPath.SetRoot** sets the assembly at the head of the component path object as the root assembly.

The method **pfcAssembly.ComponentPath.GetComponentIds** returns the sequence of ids which is the path to the particular component.

The method **pfcAssembly.ComponentPath.SetComponentIds** sets the path from the root assembly to the component through various subassemblies containing this component.

The method **pfcAssembly.ComponentPath.GetLeaf** returns the solid model at the end of the component path.

The method **pfcAssembly.ComponentPath.GetTransform** returns the coordinate system transformation between the assembly and the particular component. It has an option to provide the transformation from bottom to top, or from top to bottom. This method describes the current position and the orientation of the assembly component in the root assembly.

The method **pfcAssembly.ComponentPath.SetTransform** applies a temporary transformation to the assembly component, similar to the transformation that takes place in an exploded state. The transformation will only be applied if the assembly is using **DynamicPositioning**.

The method **pfcAssembly.ComponentPath.GetIsVisible** identifies if a particular component is visible in any simplified representation.

Assembling Components

Methods Introduced:

- **pfcAssembly.Assembly.AssembleComponent**
- **pfcAssembly.Assembly.AssembleByCopy**
- **pfcComponentFeat.ComponentFeat.GetConstraints**
- **pfcComponentFeat.ComponentFeat.SetConstraints**

The method **pfcAssembly.Assembly.AssembleComponent** adds a specified component model to the assembly at the specified initial position. The position is specified in the format defined by the interface **pfcBase.Transform3D**. Specify the orientation of the three axes and the position of the origin of the component coordinate system, with respect to the target assembly coordinate system.

The method **pfcAssembly.Assembly.AssembleByCopy** creates a new component in the specified assembly by copying from the specified component. If no model is specified, then the new component is created empty. The input parameters for this method are:

- *LeaveUnplaced*—If true the component is unplaced. If false the component is placed at a default location in the assembly. Unplaced components belong to an assembly without being assembled or packaged. These components appear in the model tree, but not in the graphic window. Unplaced components can be constrained or packaged by selecting them from the model tree for redefinition. When its parent assembly is retrieved into memory, an unplaced component is also retrieved.
- *ModelToCopy*—Specify the model to be copied into the assembly
- *NewModelName*—Specify a name for the copied model

The method **pfcComponentFeat.ComponentFeat.GetConstraints** retrieves the constraints for a given assembly component.

The method **pfcComponentFeat.ComponentFeat.SetConstraints** allows you to set the constraints for a specified assembly component. The input parameters for this method are:

- *Constraints*—Constraints for the assembly component. These constraints are explained in detail in the later sections.
- *ReferenceAssembly*—The path to the owner assembly, if the constraints have external references to other members of the top level assembly. If the constraints are applied only to the assembly component then the value of this parameter should be null.

This method modifies the component feature data but does not regenerate the assembly component. To regenerate the assembly use the method **pfcSolid.Solid.Regenerate**.

Constraint Attributes

Methods Introduced:

- **pfcComponentFeat.pfcComponentFeat.ConstraintAttributes_Create**
- **pfcComponentFeat.ConstraintAttributes.GetForce**
- **pfcComponentFeat.ConstraintAttributes.SetForce**
- **pfcComponentFeat.ConstraintAttributes.GetIgnore**
- **pfcComponentFeat.ConstraintAttributes.SetIgnore**

The method **pfcComponentFeat.pfcComponentFeat.ConstraintAttributes_Create** returns the constraint attributes object based on the values of the following input parameters:

- *Ignore*—Constraint is ignored during regeneration. Use this capability to store extra constraints on the component, which allows you to quickly toggle between different constraints.
- *Force*—Constraint has to be forced for line and point alignment.
- *None*—No constraint attributes. This is the default value.

Use the Get methods to retrieve the values of the input parameters specified above and the Set methods to modify the values of these input parameters.

Assembling a Component Parametrically

You can position a component relative to its neighbors (components or assembly features) so that its position is updated as its neighbors move or change. This is called parametric assembly.

Pro/ENGINEER allows you to specify constraints to determine how and where the component relates to the assembly. You can add as many constraints as you need to make sure that the assembly meets the design intent.

Methods Introduced:

- **pfcComponentFeat.pfcComponentFeat.ComponentConstraint_Create**
- **pfcComponentFeat.ComponentConstraint.GetType**
- **pfcComponentFeat.ComponentConstraint.SetType**
- **pfcComponentFeat.ComponentConstraint.SetAssemblyReference**
- **pfcComponentFeat.ComponentConstraint.GetAssemblyReference**
- **pfcComponentFeat.ComponentConstraint.SetAssemblyDatumSide**
- **pfcComponentFeat.ComponentConstraint.GetAssemblyDatumSide**
- **pfcComponentFeat.ComponentConstraint.SetComponentReference**
- **pfcComponentFeat.ComponentConstraint.GetComponentReference**
- **pfcComponentFeat.ComponentConstraint.SetComponentDatumSide**
- **pfcComponentFeat.ComponentConstraint.GetComponentDatumSide**
- **pfcComponentFeat.ComponentConstraint.SetOffset**
- **pfcComponentFeat.ComponentConstraint.GetOffset**
- **pfcComponentFeat.ComponentConstraint.SetAttributes**
- **pfcComponentFeat.ComponentConstraint.GetAttributes**
- **pfcComponentFeat.ComponentConstraint.SetUserDefinedData**
- **pfcComponentFeat.ComponentConstraint.GetUserDefinedData**

The method

pfcComponentFeat.pfcComponentFeat.ComponentConstraint_Create returns the component constraint object having the following parameters:

- *ComponentConstraintType*—Using the TYPE options, you can specify the placement constraint types. They are as follows:
 - **ASM_CONSTRAINT_MATE**—Use this option to make two surfaces touch one another, that is coincident and facing each other.
 - **ASM_CONSTRAINT_MATE_OFF**—Use this option to make two planar surfaces parallel and facing each other.
 - **ASM_CONSTRAINT_ALIGN**—Use this option to make two planes coplanar, two axes coaxial and two points coincident. You can also align revolved surfaces or edges.
 - **ASM_CONSTRAINT_ALIGN_OFF**—Use this option to align two planar surfaces at an offset.

- ASM_CONSTRAINT_INSERT—Use this option to insert a "male" revolved surface into a "female" revolved surface, making their respective axes coaxial.
 - ASM_CONSTRAINT_ORIENT—Use this option to make two planar surfaces to be parallel in the same direction.
 - ASM_CONSTRAINT_CSYS—Use this option to place a component in an assembly by aligning the coordinate system of the component with the coordinate system of the assembly.
 - ASM_CONSTRAINT_TANGENT—Use this option to control the contact of two surfaces at their tangents.
 - ASM_CONSTRAINT_PNT_ON_SRF—Use this option to control the contact of a surface with a point.
 - ASM_CONSTRAINT_EDGE_ON_SRF—Use this option to control the contact of a surface with a straight edge.
 - ASM_CONSTRAINT_DEF_PLACEMENT—Use this option to align the default coordinate system of the component to the default coordinate system of the assembly.
 - ASM_CONSTRAINT_SUBSTITUTE—Use this option in simplified representations when a component has been substituted with some other model
 - ASM_CONSTRAINT_PNT_ON_LINE—Use this option to control the contact of a line with a point.
 - ASM_CONSTRAINT_FIX—Use this option to force the component to remain in its current packaged position.
 - ASM_CONSTRAINT_AUTO—Use this option in the user interface to allow an automatic choice of constraint type based upon the references.
- *AssemblyReference*—A reference in the assembly.
 - *AssemblyDatumSide*—Orientation of the assembly. This can have the following values:
 - Yellow—The primary side of the datum plane which is the default direction of the arrow.
 - Red—The secondary side of the datum plane which is the direction opposite to that of the arrow.
 - *ComponentReference*—A reference on the placed component.
 - *ComponentDatumSide*—Orientation of the assembly component. This can have the following values:

- Yellow—The primary side of the datum plane which is the default direction of the arrow.
- Red—The secondary side of the datum plane which is the direction opposite to that of the arrow.
- *Offset*—The mate or align offset value from the reference.
- *Attributes*—Constraint attributes for a given constraint
- *UserDefinedData*—A string that specifies user data for the given constraint.

Use the Get methods to retrieve the values of the input parameters specified above and the Set methods to modify the values of these input parameters.

Redefining and Rerouting Assembly Components

These functions enable you to reroute previously assembled components, just as in an interactive Pro/ENGINEER session.

Methods Introduced:

- **pfcComponentFeat.ComponentFeat.RedefineThroughUI**
- **pfcComponentFeat.ComponentFeat.MoveThroughUI**

The method **pfcComponentFeat.ComponentFeat.RedefineThroughUI** must be used in interactive J-Link applications. This method displays the Pro/ENGINEER Constraint dialog box. This enables the end user to redefine the constraints interactively. The control returns to J-Link application when the user selects **OK** or **Cancel** and the dialog box is closed.

The method **pfcComponentFeat.ComponentFeat.MoveThroughUI** invokes a dialog box that prompts the user to interactively reposition the components. This interface enables the user to specify the translation and rotation values. The control returns to J-Link application when the user selects **OK** or **Cancel** and the dialog box is closed.

Example: Component Constraints

This function displays each constraint of the component visually on the screen, and includes a text explanation for each constraint.

```

import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.Session;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcSolid.Solid;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcComponentFeat.*;
import com.ptc.pfc.pfcFamily.FamilyTableRow;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
public class pfcComponentFeatExamples {

/*=====*\
FUNCTION: highlightConstraints
PURPOSE: Highlights and labels a component's constraints
\*=====*/
    public static void highlightConstraints ()
        throws com.ptc.cipjava.jxthrowable
    {
/*-----*\
    Get the constraints for the component.
\*-----*/
        Session session = pfcGlobal.GetProESession ();
        SelectionOptions options = pfcSelect.SelectionOptions_Create
            ("membfeat");
        options.SetMaxNumSels (new Integer (1));
        Selections selections = session.Select (options, null);
        if (selections == null || selections.getarraysize () == 0)
            return;
        ModelItem item = selections.get (0).GetSelItem ();
        Feature feature = (Feature)item;
        if (feature.GetFeatType () != FeatureType.FEATTYPE_COMPONENT)
            return;
        ComponentFeat asmcomp = (ComponentFeat) item;
        ComponentConstraints constrs = asmcomp.GetConstraints ();
        if (constrs == null || constrs.getarraysize() == 0)
            return;
        for (int i = 0; i < constrs.getarraysize(); i++)
        {
/*-----*\
            Highlight the assembly reference geometry
\*-----*/
                ComponentConstraint c = constrs.get (i);
                Selection asmRef = c.GetAssemblyReference ();
                if (asmRef != null)
                    asmRef.Highlight (StdColor.COLOR_ERROR);
/*-----*\
            Highlight the component reference geometry
\*-----*/
        }
    }
}

```

```

        Selection compRef = c.GetComponentReference ();
        if (compRef != null)
            compRef.Highlight (StdColor.COLOR_WARNING);
/*-----*\
    Prepare and display the message text.
\*-----*/
    Double offset = c.GetOffset ();
    String offsetString = "";
    if (offset != null)
        offsetString = ", offset of "+offset;
    ComponentConstraintType cType = c.GetType ();
    String cTypeString = constraintTypeToString (cType);
    stringseq texts = stringseq.create ();
    texts.set (0, new String (""+(i+1)));
    texts.set (1, new String (""+constrs.getarraysize()));
    texts.set (2, cTypeString);
    texts.set (3, offsetString);
    session.UIDisplayMessage ("jlexamples.txt",
        "JLEX Showing constraint %0s of %1s %2s%3s.
        Hit <CR> to continue.", texts);
    session.UIReadStringMessage (null);
/*-----*\
    Clean up the UI for the next constraint
\*-----*/
    if (asmRef != null)
        {
            asmRef.UnHighlight ();
        }
    if (compRef != null)
        {
            compRef.UnHighlight ();
        }
    }
}
/*=====*\
FUNCTION: constraintTypeToString
PURPOSE: Utility: convert the constraint type to a string for printing
\*=====*/
private static String constraintTypeToString (ComponentConstraintType
                                             type)
{
    switch (type.getValue())
    {
        case ComponentConstraintType._ASM_CONSTRAINT_MATE:
            return ("Mate");
        case ComponentConstraintType._ASM_CONSTRAINT_MATE_OFF:
            return ("Mate Offset");
        case ComponentConstraintType._ASM_CONSTRAINT_ALIGN:
            return ("Align");
        case ComponentConstraintType._ASM_CONSTRAINT_ALIGN_OFF:
            return ("Align Offset");
    }
}

```



```

case ComponentConstraintType._ASM_CONSTRAINT_INSERT:
    return ("Insert");
case ComponentConstraintType._ASM_CONSTRAINT_ORIENT:
    return ("Orient");
case ComponentConstraintType._ASM_CONSTRAINT_CSYS:
    return ("Csys");
case ComponentConstraintType._ASM_CONSTRAINT_TANGENT:
    return ("Tangent");
case ComponentConstraintType._ASM_CONSTRAINT_PNT_ON_SRF:
    return ("Point on Surf");
case ComponentConstraintType._ASM_CONSTRAINT_EDGE_ON_SRF:
    return ("Edge on Surf");
case ComponentConstraintType._ASM_CONSTRAINT_DEF_PLACEMENT:
    return ("Default");
case ComponentConstraintType._ASM_CONSTRAINT_SUBSTITUTE:
    return ("Substitute");
case ComponentConstraintType._ASM_CONSTRAINT_PNT_ON_LINE:
    return ("Point on Line");
case ComponentConstraintType._ASM_CONSTRAINT_FIX:
    return ("Fix");
case ComponentConstraintType._ASM_CONSTRAINT_AUTO:
    return ("Auto");
default:
    return ("Unrecognized Type");
}
}
}

```

Example: Assembling Components

The following example demonstrates how to assemble a component into an assembly, and how to constrain the component by aligning datum planes. If the complete set of datum planes is not found, the function will show the component constraint dialog to the user to allow them to adjust the placement.

```

import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.pfcGlobal;
import com.ptc.pfc.pfcSession.Session;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcSolid.Solid;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcComponentFeat.*;
import com.ptc.pfc.pfcFamily.FamilyTableRow;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcSelect.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcAssembly.*;
public class pfcComponentFeatExamples {

```

```

/*=====*\
FUNCTION: UserAssembleByDatums
PURPOSE: Assemble a component by aligning named datums.
\*=====*/
public static void assembleByDatums (String componentFilename )
    throws com.ptc.cipjava.jxthrowable
{
    boolean interactFlag = false;
    Matrix3D identityMatrix = Matrix3D.create ();
    for (int x = 0; x < 4; x++)
        for (int y = 0; y < 4; y++)
            {
                if (x == y)
                    identityMatrix.set (x, y, 1.0);
                else
                    identityMatrix.set (x, y, 0.0);
            }
    Transform3D transf = pfcBase.Transform3D_Create (identityMatrix);
/*-----*\
    Get the current assembly
\*-----*/
    Session session = pfcGlobal.GetProESession ();
    Model model = session.GetCurrentModel ();
    if (model == null || model.GetType() != ModelType.MDL_ASSEMBLY)
        throw new RuntimeException ("Current model is not an
            assembly.");

    Assembly assembly = (Assembly) model;
    ModelDescriptor descr =
        pfcModel.ModelDescriptor_CreateFromFileName
            (componentFilename);
    Solid componentModel = (Solid)session.GetModelFromDescr (descr);
    if (componentModel == null)
        {
            componentModel = (Solid) session.RetrieveModel (descr);
        }

/*-----*\
    Set up the arrays of datum names
\*-----*/
    String [] asmDatums = {"ASM_D_FRONT", "ASM_D_TOP", "ASM_D_RIGHT"};
    String [] compDatums = {"COMP_D_FRONT",
        "COMP_D_TOP",
        "COMP_D_RIGHT"};

/*-----*\
    Package the component initially
\*-----*/
    ComponentFeat asmcomp =
        (ComponentFeat) assembly.AssembleComponent (componentModel,
            transf);
/*-----*\

```

```
    Prepare the constraints array
/*-----*/
    ComponentConstraints constrs = ComponentConstraints.create ();
    for (int i = 0; i < 3; i++)
    {
/*-----*\
    Find the assembly datum
/*-----*/
        ModelItem asmItem =
            assembly.GetItemByName (ModelItemType.ITEM_SURFACE,
                                    asmDatums [i]);

        if (asmItem == null)
        {
            interactFlag = true;
            continue;
        }
/*-----*\
    Find the component datum
/*-----*/
        ModelItem compItem =
            componentModel.GetItemByName (ModelItemType.ITEM_SURFACE,
                                          compDatums [i]);

        if (compItem == null)
        {
            interactFlag = true;
            continue;
        }

/*-----*\
    For the assembly reference, initialize a component path.
    This is necessary even if the reference geometry is in the assembly.
/*-----*/
        intseq ids = intseq.create ();
        ComponentPath path = pfcAssembly.CreateComponentPath (assembly,
                                                                ids);
/*-----*\
    Allocate the references
/*-----*/
        Selection asmSel =
            pfcSelect.CreateModelItemSelection (asmItem, path);
        Selection compSel =
            pfcSelect.CreateModelItemSelection (compItem, null);
/*-----*\
    Allocate and fill the constraint.
/*-----*/
        ComponentConstraint constr =
            pfcComponentFeat.ComponentConstraint_Create
                (ComponentConstraintType.ASM_CONSTRAINT_ALIGN);
        constr.SetAssemblyReference (asmSel);
        constr.SetComponentReference (compSel);
        constrs.insert (constrs.getarraysize(), constr);
    }
}
```

```

    }
/*-----*\
    Set the assembly component constraints and regenerate the assembly.
/*-----*\
    asmcomp.SetConstraints (constrs, null);
    assembly.Regenerate (null);
    session.GetModelWindow (assembly).Repaint();
/*-----*\
    If any of the expect datums was not found, prompt the user to constrain
    the new component.
/*-----*\
    if (interactFlag)
    {
        session.UIDisplayMessage ("jlexamples.txt",
        "JLEX Unable to locate all required datum references.
        New component is packaged.", null);
        asmcomp.RedefineThroughUI ();
    }
}
}

```

Exploded Assemblies

These methods enable you to determine and change the explode status of the assembly object.

Methods Introduced:

- **pfcAssembly.Assembly.GetIsExploded**
- **pfcAssembly.Assembly.Explode**
- **pfcAssembly.Assembly.UnExplode**
- **pfcAssembly.Assembly.GetActiveExplodedState**
- **pfcAssembly.Assembly.GetDefaultExplodedState**
- **pfcAssembly.ExplodedState.Activate**

The methods **pfcAssembly.Assembly.Explode** and **pfcAssembly.Assembly.UnExplode** enable you to determine and change the explode status of the assembly object.

The method **pfcAssembly.Assembly.GetIsExploded** reports whether the specified assembly is currently exploded.

The method **pfcAssembly.Assembly.GetActiveExplodedState** returns the current active explode state.

The method **pfcAssembly.Assembly.GetDefaultExplodedState** returns the default explode state.

The method **pfcAssembly.ExplodedState.Activate** activates the specified explode state representation.

Skeleton Models

Skeleton models are a 3-dimensional layout of the assembly. These models are holders or distributors of critical design information, and can represent space requirements, important mounting locations, and motion.

Methods Introduced:

- **pfcAssembly.Assembly.AssembleSkeleton**
- **pfcAssembly.Assembly.AssembleSkeletonByCopy**
- **pfcAssembly.Assembly.GetSkeleton**
- **pfcAssembly.Assembly.DeleteSkeleton**
- **pfcSolid.Solid.GetIsSkeleton**

The method **pfcAssembly.Assembly.AssembleSkeleton** adds an existing skeleton model to the specified assembly.

The method **pfcAssembly.Assembly.GetSkeleton** returns the skeleton model of the specified assembly.

The method **pfcAssembly.Assembly.DeleteSkeleton** deletes a skeleton model component from the specified assembly.

The method **pfcAssembly.Assembly.AssembleSkeletonByCopy** adds a specified skeleton model to the assembly. The input parameters for this method are:

- *SkeletonToCopy*—Specify the skeleton model to be copied into the assembly
- *NewSkeletonName*—Specify a name for the copied skeleton model

The method **pfcSolid.Solid.GetIsSkeleton** determines if the specified part model is a skeleton model or a concept model. It returns a true if the model is a skeleton else it returns a false.

20

Family Tables

This chapter describes how to use J-Link classes and methods to access and manipulate family table information.

Topic	Page
Working with Family Tables	20 - 2
Creating Family Table Instances	20 - 5
Creating Family Table Columns	20 - 5

Working with Family Tables

J-Link provides several methods for accessing family table information. Because every model inherits from the interface `pfcFamily.FamilyMember`, every model can have a family table associated with it.

Accessing Instances

Methods Introduced:

- `pfcFamily.FamilyMember.GetParent`
- `pfcFamily.FamilyMember.GetImmediateGenericInfo`
- `pfcFamily.FamilyMember.GetTopGenericInfo`
- `pfcFamily.FamilyTableRow.CreateInstance`
- `pfcFamily.FamilyMember.ListRows`
- `pfcFamily.FamilyMember.GetRow`
- `pfcFamily.FamilyMember.RemoveRow`
- `pfcFamily.FamilyTableRow.GetInstanceName`
- `pfcFamily.FamilyTableRow.GetIsLocked`
- `pfcFamily.FamilyTableRow.SetIsLocked`

To get the generic model for an instance, call the method **`pfcFamily.FamilyMember.GetParent`**.

From Pro/ENGINEER Wildfire 4.0 onwards, the behavior of the method **`pfcFamily.FamilyMember.GetParent`** has changed as a result of performance improvement in family table retrieval mechanism. When you now call the method **`pfcFamily.FamilyMember.GetParent`**, it throws an exception `pfcExceptions.XToolkitCantOpen`, if the immediate generic of a model instance in a nested family table is currently not in session. Handle this exception and use the method **`pfcFamily.FamilyMember.GetImmediateGenericInfo`** to get the model descriptor of the immediate generic model. This information can be used to retrieve the immediate generic model.

If you wish to switch off the above behavior and continue to run legacy applications in the pre-Wildfire 4.0 mode, set the configuration option `retrieve_instance_dependencies` to `"instance_and_generic_deps"`.

To get the model descriptor of the top generic model, call the method **`pfcFamily.FamilyMember.GetTopGenericInfo`**.

Similarly, the method **pfcFamily.FamilyTableRow.CreateInstance** returns an instance model created from the information stored in the `FamilyTableRow` object.

The method **pfcFamily.FamilyMember.ListRows** returns a sequence of all rows in the family table, whereas **pfcFamily.FamilyMember.GetRow** gets the row object with the name you specify.

Use the method **pfcFamily.FamilyMember.RemoveRow** to permanently delete the row from the family table.

The method **pfcFamily.FamilyTableRow.GetInstanceName** returns the name that corresponds to the invoking row object.

To control whether the instance can be changed or removed, call the methods **pfcFamily.FamilyTableRow.GetIsLocked** and **pfcFamily.FamilyTableRow.SetIsLocked**.

Accessing Columns

Methods Introduced:

- **pfcFamily.FamilyMember.ListColumns**
- **pfcFamily.FamilyMember.GetColumn**
- **pfcFamily.FamilyMember.RemoveColumn**
- **pfcFamily.FamilyTableColumn.GetSymbol**
- **pfcFamily.FamilyTableColumn.GetType**
- **pfcFamily.FamColModelItem.GetRefItem**
- **pfcFamily.FamColParam.GetRefParam**

The method **pfcFamily.FamilyMember.ListColumns** returns a sequence of all columns in the family table.

The method **pfcFamily.FamilyMember.GetColumn** returns a family table column, given its symbolic name.

To permanently delete the column from the family table and all changed values in all instances, call the method **pfcFamily.FamilyMember.RemoveColumn**.

The method **pfcFamily.FamilyTableColumn.GetSymbol** returns the string symbol at the top of the column, such as *D4* or *F5*.

The method **pfcFamily.FamilyTableColumn.GetType** returns an enumerated value indicating the type of parameter governed by the column in the family table.

The method **pfcFamily.FamColModelItem.GetRefItem** returns the `ModelItem` (Feature or Dimension) controlled by the column, whereas **pfcFamily.FamColParam.GetRefParam** returns the `Parameter` controlled by the column.

Accessing Cell Information

Methods Introduced:

- **pfcFamily.FamilyMember.GetCell**
- **pfcFamily.FamilyMember.GetCellsDefault**
- **pfcFamily.FamilyMember.SetCell**
- **pfcModelItem.ParamValue.GetStringValue**
- **pfcModelItem.ParamValue.GetIntValue**
- **pfcModelItem.ParamValue.GetDoubleValue**
- **pfcModelItem.ParamValue.GetBoolValue**

The method **pfcFamily.FamilyMember.GetCell** returns a string `ParamValue` that corresponds to the cell at the intersection of the row and column arguments. Use the method **pfcFamily.FamilyMember.GetCellsDefault** to check if the value of the specified cell is the default value, which is the value of the specified cell in the generic model.

The method **pfcFamily.FamilyMember.SetCell** assigns a value to a column in a particular family table instance.

The **pfcModelItem.ParamValue.GetStringValue**, **pfcModelItem.ParamValue.GetIntValue**, **pfcModelItem.ParamValue.GetDoubleValue**, and **pfcModelItem.ParamValue.GetBoolValue** methods are used to get the different types of parameter values.

Creating Family Table Instances

Methods Introduced:

- **pfcFamily.FamilyMember.AddRow**
- **pfcModelItem.pfcModelItem.CreateStringParamValue**
- **pfcModelItem.pfcModelItem.CreateIntParamValue**
- **pfcModelItem.pfcModelItem.CreateDoubleParamValue**
- **pfcModelItem.pfcModelItem.CreateBoolParamValue**

Use the method **pfcFamily.FamilyMember.AddRow** to create a new instance with the specified name, and, optionally, the specified values for each column. If you do not pass in a set of values, the value "*" will be assigned to each column. This value indicates that the instance uses the generic value.

Creating Family Table Columns

Methods Introduced:

- **pfcFamily.FamilyMember.CreateDimensionColumn**
- **pfcFamily.FamilyMember.CreateParamColumn**
- **pfcFamily.FamilyMember.CreateFeatureColumn**
- **pfcFamily.FamilyMember.CreateComponentColumn**
- **pfcFamily.FamilyMember.CreateCompModelColumn**
- **pfcFamily.FamilyMember.CreateGroupColumn**
- **pfcFamily.FamilyMember.CreateMergePartColumn**
- **pfcFamily.FamilyMember.CreateColumn**
- **pfcFamily.FamilyMember.AddColumn**
- **pfcModelItem.pfcModelItem.CreateStringParamValue**
- **pfcModelItem.ParamValues.create**

The above methods initialize a column based on the input argument. These methods assign the proper symbol to the column header.

The method **pfcFamily.FamilyMember.CreateColumn** creates a new column given a properly defined symbol and column type. The results of this call should be passed to the method **pfcFamily.FamilyMember.AddColumn** to add the column to the model's family table.

The method **pfcFamily.FamilyMember.AddColumn** adds the column to the family table. You can specify the values; if you pass nothing for the values, the method assigns the value "*" to each instance to accept the column's default value.

Example Code: Adding Dimensions to a Family Table

The following example code shows a utility method that adds all the dimensions to a family table. The program lists the dependencies of the assembly and loops through each dependency, assigning the model to a new FamColDimension column object. All the dimensions, parameters, features, and components could be added to the family table using a similar method.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcDimension.*;
import com.ptc.pfc.pfcFamily.*;
public class pfcFamilyMemberExamples {

    public static void addHoleDiameterColumns (Solid solid)
    {
        Session session;
        Features hole_features; //hole features in the model
        Feature hole_feat; //a hole feature
        ModelItems dimensions; //dimensions in the hole_feat
        Dimension dim; //a dimension
        FamColDimension dim_column; // dimension column in the family table

        try {
            session = pfcGlobal.GetProESession();
        }
        catch (jxthrowable x)
        {
            System.out.println("Unable to initialize Pro/ENGINEER session:
"+x);
            return;
        }
        try {
            // list all holes in the solid model
```

```

        hole_features = solid.ListFeaturesByType (Boolean.TRUE,
FeatureType.FEATTYPE_HOLE);
        for (int ii =0; ii<hole_features.getarraysize(); ii++)
        {
            hole_feat = hole_features.get(ii);
            // list all dimensions int the feature
            dimensions = hole_feat.ListSubItems (ModelItemType.ITEM_DIMENSION);

            for (int jj = 0; jj<dimensions.getarraysize(); jj++)
            {
                dim = (Dimension) dimensions.get(jj);
                // determine if the dimension is a diameter dim.
                if (dim.GetDimType().equals(DimensionType.DIM_DIAMETER))
                {
                    // create the family table column
                    //(method from interface FamilyMember)
                    dim_column = solid.CreateDimensionColumn(dim);
                    // add the column to the Solid
                    // instead of null, you could pass any array of
                    ParamValues
                    // for the initial column values
                    solid.AddColumn(dim_column, null);
                }
            }
        }
    }
}
catch (jxthrowable x)
{
    System.out.println("Exception caught: "+x);
    return;
}
}
}
/*=====*\
FUNCTION: addHoleDiameterColumns
PURPOSE: Add all hole diameters to the family table of a model.
\*=====*/
function addHoleDiameterColumns ()
{
/*-----*\
    Use the current solid model.
\*-----*/
    var session = pfcCreate ("MpfCOMGlobal").GetProESession ();
    var solid = session.CurrentModel;
    modelTypeClass = pfcCreate ("pfcModelType");

    if (solid == void null || (solid.Type != modelTypeClass.MDL_PART &&
        solid.Type != modelTypeClass.MDL_ASSEMBLY))
    {
        throw new Error (0, "Current model is not a part or assembly.");
    }
}

```

```

/*-----*\
  List all holes in the solid model
/*-----*/
var holeFeatures = solid.ListFeaturesByType (true,
                                             pfcCreate ("pfcFeatureType").FEATTYPE_HOLE);
for (var ii =0; ii < holeFeatures.Count; ii++)
{
    var holeFeat = holeFeatures.Item(ii);

/*-----*\
  List all dimensions in the feature
/*-----*/
    dimensions =
    holeFeat.ListSubItems(pfcCreate
("pfcModelItemType").ITEM_DIMENSION);

    for (var jj = 0; jj < dimensions.Count; jj++)
    {
        var dim = dimensions.Item(jj);

/*-----*\
  Determine if the dimension is a diameter dimension
/*-----*/
        if (dim.DimType == pfcCreate
("pfcDimensionType").DIM_DIAMETER)
        {
/*-----*\
  Create the family table column (from pfcFamilyMember class)
/*-----*/
            var dimColumn = solid.CreateDimensionColumn(dim);
/*-----*\
  Add the column to the family table.  Second argument could be
  a sequence of pfcParamValues to use for each family table instance.
/*-----*/
            solid.AddColumn(dimColumn, void null);
        }
    }
}
}
}

```

21

Action Listeners

This chapter describes the J-Link methods that enable you to use action listeners.

Topic	Page
J-Link Action Listeners	21 - 2
Creating an ActionListener Implementation	21 - 2
Action Sources	21 - 3
Types of Action Listeners	21 - 4
Cancelling an ActionListener Operation	21 - 11

J-Link Action Listeners

An `ActionListener` in Java is a class that is assigned to respond to certain events. In J-Link, you can assign action listeners to respond to events involving the following tasks:

- Changing windows
- Changing working directories
- Model operations
- Regenerating
- Creating, deleting, and redefining features
- Checking for regeneration failures

All action listeners in J-Link are defined by these classes:

- Interface—`Named <Object>ActionListener`. This interface defines the methods that can respond to various events.
- Default class—`Named Default<Object>ActionListener`. This class has every available method overridden by an empty implementation. You create your own action listeners by extending the default class and overriding the methods for events that interest you.

Creating an ActionListener Implementation

You can create a proper `ActionListener` class using either of the following methods:

Define a separate class within the java file.

Example:

```
public class MyApp {
    session.AddActionListener (new SolidAL1());
}

class SolidAL1 extends DefaultSolidActionListener {
    // Include overridden methods here
}
```


To use your action listener in different Java applications, define it in a separate file.

Example:

```
MyApp.java:
import solidAL1;

public class MyApp {
    session.AddActionListener (new SolidAL1());
}

SolidAL1.java:
public class SolidAL1 extends DefaultSolidActionListener {
    // Include overridden methods here.
}
```

Action Sources

Methods introduced:

- **pfcbase.ActionSource.AddActionListener**
- **pfcbase.ActionSource.RemoveActionListener**

Many J-Link classes inherit the `ActionSource` interface, but only the following classes currently make calls to the methods of registered `ActionListeners`:

- `pfcsession.Session`
 - Session Action Listener
 - Model Action Listener
 - Solid Action Listener
 - Model Event Action Listener
 - Feature Action Listener
- `pfccommand.UICommand`
 - UI Action Listener
- `pfcmodel.Model` (and its subclasses)
 - Model Action Listener
 - Parameter Action Listener
- `pfcsolid.Solid` (and its subclasses)
 - Solid Action Listener
 - Feature Action Listener

- `pfcFeature.Feature` (and its subclasses)
 - Feature Action Listener
- Note:** Assigning an action listener to a source not related to it will not cause an error but the listener method will never be called.

Types of Action Listeners

The following sections describe the different kinds of action listeners: session, UI command, solid, and feature.

Session Level Action Listeners

Methods introduced:

- `pfcSession.SessionActionListener.OnAfterDirectoryChange`
- `pfcSession.SessionActionListener.OnAfterWindowChange`
- `pfcSession.SessionActionListener.OnAfterModelDisplay`
- `pfcSession.SessionActionListener.OnBeforeModelErase`
- `pfcSession.SessionActionListener.OnBeforeModelDelete`
- `pfcSession.SessionActionListener.OnBeforeModelRename`
- `pfcSession.SessionActionListener.OnBeforeModelSave`
- `pfcSession.SessionActionListener.OnBeforeModelPurge`
- `pfcSession.SessionActionListener.OnBeforeModelCopy`
- `pfcSession.SessionActionListener.OnAfterModelPurge`

The `pfcSession.SessionActionListener.OnAfterDirectoryChange` method activates after the user changes the working directory. This method takes the new directory path as an argument.

The `pfcSession.SessionActionListener.OnAfterWindowChange` method activates when the user activates a window other than the current one. Pass the new window to the method as an argument.

The **pfcSession.SessionActionListener.OnAfterModelDisplay** method activates every time a model is displayed in a window.

Note: Model display events happen when windows are moved, opened and closed, repainted, or the model is regenerated. The event can occur more than once in succession.

The methods

pfcSession.SessionActionListener.OnBeforeModelErase, **pfcSession.SessionActionListener.OnBeforeModelRename**, **pfcSession.SessionActionListener.OnBeforeModelSave**, and **pfcSession.SessionActionListener.OnBeforeModelCopy** take special arguments. They are designed to allow you to fill in the arguments and pass this data back to Pro/ENGINEER. The model names placed in the descriptors will be used by Pro/ENGINEER as the default names in the user interface.

UI Command Action Listeners

Methods introduced:

- **pfcSession.Session.UICreateCommand**
- **pfcCommand.UICommandActionListener.OnCommand**

The **pfcSession.Session.UICreateCommand** method takes a **UICommandActionListener** argument and returns a **UICommand** action source with that action listener already registered. This **UICommand** object is subsequently passed as an argument to the **Session.AddUIButton** method that adds a command button to a Pro/ENGINEER menu. The **pfcCommand.UICommandActionListener.OnCommand** method of the registered **UICommandActionListener** is called whenever the command button is clicked.

Model Level Action listeners

Methods introduced:

- **pfcModel.ModelActionListener.OnAfterModelSave**
- **pfcModel.ModelEventActionListener.OnAfterModelCopy**
- **pfcModel.ModelEventActionListener.OnAfterModelRename**
- **pfcModel.ModelEventActionListener.OnAfterModelErase**
- **pfcModel.ModelEventActionListener.OnAfterModelDelete**
- **pfcModel.ModelActionListener.OnAfterModelRetrieve**

- **pfcModel.ModelActionListener.OnBeforeModelDisplay**
- **pfcModel.ModelActionListener.OnAfterModelCreate**
- **pfcModel.ModelActionListener.OnAfterModelSaveAll**
- **pfcModel.ModelEventActionListener.OnAfterModelCopyAll**
- **pfcModel.ModelActionListener.OnAfterModelEraseAll**
- **pfcModel.ModelActionListener.OnAfterModelDeleteAll**
- **pfcModel.ModelActionListener.OnAfterModelRetrieveAll**

Methods ending in `All` are called after any event of the specified type. The call is made even if the user did not explicitly request that the action take place. Methods that **do not** end in `All` are only called when the user specifically requests that the event occurs.

The method **pfcModel.ModelActionListener.OnAfterModelSave** is called after successfully saving a model.

The method **pfcModel.ModelEventActionListener.OnAfterModelCopy** is called after successfully copying a model.

The method **pfcModel.ModelEventActionListener.OnAfterModelRename** is called after successfully renaming a model.

The method **pfcModel.ModelEventActionListener.OnAfterModelErase** is called after successfully erasing a model.

The method **pfcModel.ModelEventActionListener.OnAfterModelDelete** is called after successfully deleting a model.

The method **pfcModel.ModelActionListener.OnAfterModelRetrieve** is called after successfully retrieving a model.

The method **pfcModel.ModelActionListener.OnBeforeModelDisplay** is called before displaying a model.

The method **pfcModel.ModelActionListener.OnAfterModelCreate** is called after the successful creation of a model.

Example Code

This example demonstrates the use of two J-Link listener methods (OnAfterModelCopy and OnAfterModelRename in ModelEventActionListener). It uses these listeners to create or update parameters in the copied or renamed models which tell the history of the last event that happened to the model.

```
package com.ptc.jlinkexamples;

import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcModelItem.*;

public class pfcModelEventExamples
{

    public static void addEventListener (Session s) throws jxthrowable
    {
        s.AddActionListener (new ModelEventListenerExample ());
    }
}

class ModelEventListenerExample
    extends com.ptc.pfc.pfcModel.DefaultModelEventActionListener
{
    public void OnAfterModelCopy (ModelDescriptor From,
                                  ModelDescriptor To) throws jxthrowable
    {
        Session s = pfcGlobal.GetProESession ();
        Model m = s.GetModelFromDescr (To);

        if (m == null)
        {
            /* Couldn't find the new model handle - might happen, for
            example, when a copy is saved to disk but not retrieved into
            memory */
            return;
        }

        ParamValue pv =
            pfcModelItem.CreateStringParamValue
            (From.GetFullName().toUpperCase());
        Parameter p = m.GetParam ("COPIED_FROM");
        if (p == null)
            m.CreateParam ("COPIED_FROM", pv);
        else
            p.SetValue (pv);
    }
}
```

```

public void OnAfterModelRename (ModelDescriptor From,
ModelDescriptor To) throws jxthrowable
{
    Session s = pfcGlobal.GetProESession ();
    Model m = s.GetModelFromDescr (To);

    if (m == null)
    {
        /* Couldn't find the new model handle in memory */
        return;
    }

    ParamValue pv =
    pfcModelItem.CreateStringValue
    (From.GetFullName().toUpperCase());
    Parameter p = m.GetParam ("RENAMED_FROM");
    if (p == null)
    m.CreateParam ("RENAMED_FROM", pv);
    else
        p.SetValue (pv);
}
}

```

Solid Level Action Listeners

Methods introduced:

- **pfcSolid.SolidActionListener.OnBeforeRegen**
- **pfcSolid.SolidActionListener.OnAfterRegen**
- **pfcSolid.SolidActionListener.OnBeforeUnitConvert**
- **pfcSolid.SolidActionListener.OnAfterUnitConvert**
- **pfcSolid.SolidActionListener.OnBeforeFeatureCreate**
- **pfcSolid.SolidActionListener.OnAfterFeatureCreate**
- **pfcSolid.SolidActionListener.OnAfterFeatureDelete**

The **pfcSolid.SolidActionListener.OnBeforeRegen** and **pfcSolid.SolidActionListener.OnAfterRegen** methods occur when the user regenerates a solid object within the `ActionSource` to which the listener is assigned. These methods take the first feature to be regenerated and a handle to the `Solid` object as arguments.

In addition, the method **pfcSolid.SolidActionListener.OnAfterRegenerate** includes a Boolean argument that indicates whether regeneration was successful.

Note:

- It is not recommended to modify geometry or dimensions using the **pfcSolid.SolidActionListener.OnBeforeRegenerate** method call.
- A regeneration that did not take place because nothing was modified is identified as a regeneration failure.

The **pfcSolid.SolidActionListener.OnBeforeUnitConvert** and **pfcSolid.SolidActionListener.OnAfterUnitConvert** methods activate when a user modifies the unit scheme (by selecting the Pro/ENGINEER command **Set Up, Units**). The methods receive the `Solid` object to be converted and a Boolean flag that identifies whether the conversion changed the dimension values to keep the object the same size.

Note: `SolidActionListeners` can be registered with the session object so that its methods are called when these events occur for any solid model that is in session.

The **pfcSolid.SolidActionListener.OnBeforeFeatureCreate** method activates when the user starts to create a feature that requires the Feature Creation dialog box. Because this event occurs only after the dialog box is displayed, it will not occur at all for datums and other features that do not use this dialog box. This method takes two arguments: the solid model that will contain the feature and the `ModelItem` identifier.

The **pfcSolid.SolidActionListener.OnAfterFeatureCreate** method activates after any feature, including datums, has been created. This method takes the new `Feature` object as an argument.

The **pfcSolid.SolidActionListener.OnAfterFeatureDelete** method activates after any feature has been deleted. The method receives the solid that contained the feature and the (now defunct) `ModelItem` identifier.

Feature Level Action Listeners

Methods Introduced:

- **pfcFeature.FeatureActionListener.OnBeforeDelete**
- **pfcFeature.FeatureActionListener.OnBeforeSuppress**
- **pfcFeature.FeatureActionListener.OnAfterSuppress**
- **pfcFeature.FeatureActionListener.OnBeforeRegen**
- **pfcFeature.FeatureActionListener.OnAfterRegen**
- **pfcFeature.FeatureActionListener.OnRegenFailure**
- **pfcFeature.FeatureActionListener.OnBeforeRedefine**
- **pfcFeature.FeatureActionListener.OnAfterCopy**
- **pfcFeature.FeatureActionListener.OnBeforeParameterDelete**

Each method in `FeatureActionListener` takes as an argument the feature that triggered the event.

`FeatureActionListeners` can be registered with the `Session` object so that the action listener's methods are called whenever these events occur for any feature that is in session or with a solid model to react to changes only in that model.

The method **pfcFeature.FeatureActionListener.OnBeforeDelete** is called before a feature is deleted.

The method **pfcFeature.FeatureActionListener.OnBeforeSuppress** is called before a feature is suppressed.

The method **pfcFeature.FeatureActionListener.OnAfterSuppress** is called after a successful feature suppression.

The method **pfcFeature.FeatureActionListener.OnBeforeRegen** is called before a feature is regenerated.

The method **pfcFeature.FeatureActionListener.OnAfterRegen** is called after a successful feature regeneration.

The method **pfcFeature.FeatureActionListener.OnRegenFailure** is called when a feature fails regeneration.

The method **pfcFeature.FeatureActionListener.OnBeforeRedefine** is called before a feature is redefined.

The method **pfcFeature.FeatureActionListener.OnAfterCopy** is called after a feature has been successfully copied.

The method **pfcFeature.FeatureActionListener.OnBeforeParameterDelete** is called before a feature parameter is deleted.

Cancelling an ActionListener Operation

J-Link allows you to cancel certain notification events, registered by the action listeners.

Methods Introduced:

- **pfcExceptions.XCancelProEAction.Throw**

The static method **pfcExceptions.XCancelProEAction.Throw** must be called from the body of an action listener to cancel the impending Pro/ENGINEER operation. This method will throw a J-Link exception signalling to Pro/ENGINEER to cancel the listener event.

Note: Your application should not catch the J-Link exception, or should rethrow it if caught, so that Pro/ENGINEER is forced to handle it.

The following events can be cancelled using this technique:

- **pfcSession.SessionActionListener.OnBeforeModelErase**
- **pfcSession.SessionActionListener.OnBeforeModelDelete**
- **pfcSession.SessionActionListener.OnBeforeModelRename**
- **pfcSession.SessionActionListener.OnBeforeModelSave**
- **pfcSession.SessionActionListener.OnBeforeModelPurge**
- **pfcSession.SessionActionListener.OnBeforeModelCopy**
- **pfcModel.ModelActionListener.OnBeforeParameterCreate**
- **pfcModel.ModelActionListener.OnBeforeParameterDelete**
- **pfcModel.ModelActionListener.OnBeforeParameterModify**
- **pfcFeature.FeatureActionListener.OnBeforeDelete**
- **pfcFeature.FeatureActionListener.OnBeforeSuppress**

- `pfcFeature.FeatureActionListener.OnBeforeParameterDelete`
- `pfcFeature.FeatureActionListener.OnBeforeParameterCreate`
- `pfcFeature.FeatureActionListener.OnBeforeRedefine`

22

Interface

This chapter describes various methods of importing and exporting files in J-Link.

Topic	Page
Exporting Files and 2D Models	22 - 2
Exporting to PDF and U3D	22 - 6
Exporting 3D Geometry	22 - 13
Shrinkwrap Export	22 - 18
Importing Files	22 - 26
Importing 3D Geometry	22 - 29
Plotting Files	22 - 32
Printing Files	22 - 33
Solid Operations	22 - 41
Window Operations	22 - 43

Exporting Files and 2D Models

Method Introduced:

- **pfcModel.Model.Export**

The method **pfcModel.Model.Export** exports model data to a file. The exported files are placed in the current Pro/ENGINEER working directory. The input parameters are:

- *filename*—Output file name including extensions
- *exportdata*—The `pfcModel.ExportInstructions` object that controls the export operation. The type of data that is exported is given by the `pfcModel.ExportType` object.

There are four general categories of files to which you can export models:

- File types whose instructions inherit from `pfcModel.GeoExportInstructions`.
These instructions export files that contain precise geometric information used by other CAD systems.
- File types whose instructions inherit from `pfcModel.CoordSysExportInstructions`.
These instructions export files that contain coordinate information describing faceted, solid models (without datums and surfaces).
- File types whose instructions inherit from `pfcModel.FeatIdExportInstructions`.
These instructions export information about a specific feature.
- General file types that inherit only from `pfcModel.ExportInstructions`.
These instructions provide conversions to file types such as BOM (bill of materials).

For information on exporting to a specific format, see the J-Link API Wizard and online help for the Pro/ENGINEER interface.

Export Instructions

Methods Introduced:

- **pfcModel.pfcModel.RelationExportInstructions_Create**
- **pfcModel.pfcModel.ModelInfoExportInstructions_Create**
- **pfcModel.pfcModel.ProgramExportInstructions_Create**
- **pfcModel.pfcModel.IGESFileExportInstructions_Create**
- **pfcModel.pfcModel.DXFExportInstructions_Create**
- **pfcModel.pfcModel.RenderExportInstructions_Create**
- **pfcModel.pfcModel.STLASCIIExportInstructions_Create**
- **pfcModel.pfcModel.STLBinaryExportInstructions_Create**
- **pfcModel.pfcModel.BOMExportInstructions_Create**
- **pfcModel.pfcModel.DWGSetupExportInstructions_Create**
- **pfcModel.pfcModel.FeatInfoExportInstructions_Create**
- **pfcModel.pfcModel.MFGFeatCLExportInstructions_Create**
- **pfcModel.pfcModel.MFGOperCLExportInstructions_Create**
- **pfcModel.pfcModel.MaterialExportInstructions_Create**
- **pfcModel.pfcModel.CGMFILEExportInstructions_Create**
- **pfcModel.pfcModel.InventorExportInstructions_Create**
- **pfcModel.pfcModel.FIATExportInstructions_Create**
- **pfcModel.pfcModel.ConnectorParamExportInstructions_Create**
- **pfcModel.pfcModel.CableParamsFileInstructions_Create**
- **pfcModel.pfcModel.CATIAFacetsExportInstructions_Create**
- **pfcModel.pfcModel.VRMLModelExportInstructions_Create**
- **pfcModel.pfcModel.STEP2DExportInstructions_Create**
- **pfcModel.pfcModel.MedusaExportInstructions_Create**
- **pfcExport.pfcExport.CADDSExportInstructions_Create**
- **pfcExport.pfcExport.NEUTRALFileExportInstructions_Create**
- **pfcExport.pfcExport.ProductViewExportInstructions_Create**
- **pfcSession.BaseSession.ExportDirectVRML**

Interface

Export Instructions Table

Interface	Used to Export
RelationExportInstructions	A list of the relations and parameters in a part or assembly
ModelInfoExportInstructions	Information about a model, including units information, features, and children
ProgramExportInstructions	A program file for a part or assembly that can be edited to change the model
IGESEExportInstructions	A drawing in IGES format
DXFExportInstructions	A drawing in DXF format
RenderExportInstructions	A part or assembly in RENDER format
STLASCIIExportInstructions	A part or assembly to an ASCII STL file
STLBinaryExportInstructions	A part or assembly in a binary STL file
BOMExportInstructions	A BOM for an assembly
DWGSetupExportInstructions	A drawing setup file
FeatInfoExportInstructions	Information about one feature in a part or assembly
MfgFeatCLExportInstructions	A cutter location (CL) file for one NC sequence in a manufacturing assembly
MfgOperCLExportInstructions	A cutter location (CL) file for all the NC sequences in a manufacturing assembly
MaterialExportInstructions	A material from a part
CGMFILEEExportInstructions	A drawing in CGM format
InventorExportInstructions	A part or assembly in Inventor format
FIATExportInstructions	A part or assembly in FIAT format
ConnectorParamExportInstructions	The parameters of a connector to a text file
CableParamsFileInstructions	Cable parameters from an assembly
CATIAFacetsExportInstructions	A part or assembly in CATIA format (as a faceted model)
VRMLModelExportInstructions	A part or assembly in VRML format
STEP2DExportInstructions	A two-dimensional STEP format file
MedusaExportInstructions	A drawing in MEDUSA file
CADDSEExportInstructions	A CADD5 solid model

Interface	Used to Export
NEUTRALFileExportInstructions	A Pro/ENGINEER part to neutral format
ProductViewExportInstructions	A part, assembly, or drawing in ProductView format

Note: The **New Instruction Classes** replace the following **Deprecated Classes**:

Deprecated Classes	New Instruction Classes
IGES3DExportInstructions	IGES3DNewExportInstructions
STEPExportInstructions	STEP3DExportInstructions
VDAExportInstructions	VDA3DExportInstructions
SETExportInstructions	SET3DExportInstructions
CATIAExportInstructions	CATIA3DExportInstructions

Exporting Drawing Sheets

The options required to export multiple sheets of a drawing are given by the `pfcModel.Export2DOption` object.

Methods Introduced:

- `pfcModel.pfcModel.Export2DOption_Create`
- `pfcModel.Export2DOption.SetExportSheetOption`
- `pfcModel.Export2DOption.SetModelSpaceSheet`
- `pfcModel.Export2DOption.SetSheets`

The method `pfcModel.pfcModel.Export2DOptions_Create` creates a new instance of the `pfcModel.Export2DOption` object. This object contains the following options:

- *ExportSheetOption*—Specifies the option for exporting multiple drawing sheets. Use the method `pfcModel.Export2DOption.SetExportSheetOption` to set the option for exporting multiple drawing sheets. The options are given by the `pfcModel.Export2DSheetOption` class and can be of the following types:
 - `EXPORT_CURRENT_TO_MODEL_SPACE`—Exports only the drawing's current sheet as model space to a single file. This is the default type.

- EXPORT_CURRENT_TO_PAPER_SPACE—Exports only the drawing’s current sheet as paper space to a single file. This type is the same as EXPORT_CURRENT_TO_MODEL_SPACE for formats that do not support the concept of model space and paper space.
- EXPORT_ALL—Exports all the sheets in a drawing to a single file as paper space, if applicable for the format type.
- EXPORT_SELECTED—Exports selected sheets in a drawing as paper space and one sheet as model space.
- *ModelSpaceSheet*—Specifies the sheet number that needs be exported as model space. This option is applicable only if the export formats support the concept of model space and paper space and if *ExportSheetOption* is set to EXPORT_SELECTED. Use the method **pfcModel.Export2DOption.SetModelSpaceSheet** to set this option.
- *Sheets*—Specifies the sheet numbers that need to be exported as paper space. This option is applicable only if *ExportSheetOption* is set to EXPORT_SELECTED. Use the method **pfcModel.Export2DOption.SetSheets** to set this option.

Exporting to PDF and U3D

The methods described in this section support the export of Pro/ENGINEER drawings and solid models to Portable Document Format (PDF) and U3D format. You can export a drawing or a 2D model as a 2D raster image embedded in a PDF file. You can export Pro/ENGINEER solid models in the following ways:

- As a U3D model embedded in a one-page PDF file
- As 2D raster images embedded in the pages of a PDF file representing saved views
- As a standalone U3D file

While exporting multiple sheets of a Pro/ENGINEER drawing to a PDF file, you can choose to export all sheets, the current sheet, or selected sheets.

These methods also allow you to insert a variety of non-geometric information to improve document content, navigation, and search.

Methods Introduced:

- **pfcExport.pfcExport.PDFExportInstructions_Create**
- **pfcExport.PDFExportInstructions.SetFilePath**
- **pfcExport.PDFExportInstructions.SetOptions**
- **pfcExport.pfcExport.PDFOption_Create**
- **pfcExport.PDFOption.SetOptionType**
- **pfcExport.PDFOption.SetOptionValue**

The method

pfcExport.pfcExport.PDFExportInstructions_Create creates a new instance of the `pfcExport.PDFExportInstructions` data object that describes how to export Pro/ENGINEER drawings or solid models to the PDF and U3D formats. The options in this object are described as follows:

- *FilePath*—Specifies the name of the output file. Use the method **pfcExport.PDFExportInstructions.SetFilePath** to set the name of the output file.
- *Options*—Specifies a collection of PDF export options of the type `pfcExport.PDFOption`. Create a new instance of this object using the method **pfcExport.pfcExport.PDFOption_Create**. This object contains the following attributes:
 - *OptionType*—Specifies the type of option in terms of the `pfcExport.PDFOptionType` class. Set this option using the method **pfcExport.PDFOption.SetOptionType**.
 - *OptionValue*—Specifies the value of the option in terms of the `pfcArgument.ArgValue` object. Set this option using the method **pfcExport.PDFOption.SetOptionValue**.

Use the method

pfcExport.PDFExportInstructions.SetOptions to set the collection of PDF export options.

The types of options (given by the `pfcExport.PDFOptionType` class) available for export to PDF and U3D formats are described as follows:

- **PDFOPT_FONT_STROKE**—Allows you to switch between using TrueType fonts or “stroking” text in the resulting document. This option is given by the `pfcExport.PDFFontStrokeMode` class and takes the following values:
 - **PDF_USE_TRUE_TYPE_FONTS**—Specifies TrueType fonts. This is the default type.

- PDF_STROKE_ALL_FONTS—Specifies the option to stroke all fonts.
- PDFOPT_COLOR_DEPTH—Allows you to choose between color, grayscale, or monochrome output. This option is given by the `pfcExport.PDFColorDepth` class and takes the following values:
 - PDF_CD_COLOR—Specifies color output. This is the default value.
 - PDF_CD_GRAY—Specifies grayscale output.
 - PDF_CD_MONO—Specifies monochrome output.
- PDFOPT_HIDDENLINE_MODE—Enables you to set the style for hidden lines in the resulting PDF document. This option is given by the `pfcExport.PDFHiddenLineMode` class and takes the following values:
 - PDF_HLM_SOLID—Specifies solid hidden lines.
 - PDF_HLM_DASHED—Specifies dashed hidden lines. This is the default type.
- PDFOPT_SEARCHABLE_TEXT—If true, stroked text is searchable. The default value is true.
- PDFOPT_RASTER_DPI—Allows you to set the resolution for the output of any shaded views in DPI. It can take a value between 100 and 600. The default value is 300.
- PDFOPT_LAUNCH_VIEWER—If true, launches the Adobe Acrobat Reader. The default value is true.
- PDFOPT_LAYER_MODE—Enables you to set the availability of layers in the document. It is given by the `pfcExport.PDFLayerMode` class and takes the following values:
 - PDF_LAYERS_ALL—Exports the visible layers and entities. This is the default.
 - PDF_LAYERS_VISIBLE—Exports only visible layers in a drawing.
 - PDF_LAYERS_NONE—Exports only the visible entities in the drawing, but not the layers on which they are placed.
- PDFOPT_PARAM_MODE—Enables you to set the availability of model parameters as searchable metadata in the PDF document. It is given by the `pfcExport.PDFParameterMode` class and takes the following values:

- PDF_PARAMS_ALL—Exports the drawing and the model parameters to PDF. This is the default.
- PDF_PARAMS_DESIGNATED—Exports only the specified model parameters in the PDF metadata.
- PDF_PARAMS_NONE—Exports the drawing to PDF without the model parameters.
- PDFOPT_HYPERLINKS—Sets hyperlinks to be exported as label text only or sets the underlying hyperlink URLs as active. The default value is true, specifying that the hyperlinks are active.
- PDFOPT_BOOKMARK_ZONES—If true, adds bookmarks to the PDF showing zoomed in regions or zones in the drawing sheet. The zone on an A4-size drawing sheet is ignored.
- PDFOPT_BOOKMARK_VIEWS—If true, adds bookmarks to the PDF document showing zoomed in views on the drawing.
- PDFOPT_BOOKMARK_SHEETS—If true, adds bookmarks to the PDF document showing each of the drawing sheets.
- PDFOPT_BOOKMARK_FLAG_NOTES—If true, adds bookmarks to the PDF document showing the text of the flag note.
- PDFOPT_TITLE—Specifies a title for the PDF document.
- PDFOPT_AUTHOR—Specifies the name of the person generating the PDF document.
- PDFOPT_SUBJECT—Specifies the subject of the PDF document.
- PDFOPT_KEYWORDS—Specifies relevant keywords in the PDF document.
- PDFOPT_PASSWORD_TO_OPEN—Sets a password to open the PDF document. By default, this option is NULL, which means anyone can open the PDF document without a password.
- PDFOPT_MASTER_PASSWORD—Sets a password to restrict or limit the operations that the viewer can perform on the opened PDF document. By default, this option is NULL, which means you can make any changes to the PDF document regardless of the settings of the modification flags PDFOPT_ALLOW_*.
- PDFOPT_RESTRICT_OPERATIONS—If true, enables you to restrict or limit operations on the PDF document. By default, is is false.

- **PDFOPT_ALLOW_MODE**—Enables you to set the security settings for the PDF document. This option must be set if **PDFOPT_RESTRICT_OPERATIONS** is set to true. It is given by the `pfcExport.PDFRestrictOperationsMode` class and takes the following values:
 - **PDF_RESTRICT_NONE**—Specifies that the user can perform any of the permitted viewer operations on the PDF document. This is the default value.
 - **PDF_RESTRICT_FORMS_SIGNING**—Restricts the user from adding digital signatures to the PDF document.
 - **PDF_RESTRICT_INSERT_DELETE_ROTATE**—Restricts the user from inserting, deleting, or rotating the pages in the PDF document.
 - **PDF_RESTRICT_COMMENT_FORM_SIGNING**—Restricts the user from adding or editing comments in the PDF document.
 - **PDF_RESTRICT_EXTRACTING**—Restricts the user from extracting pages from the PDF document.
- **PDFOPT_ALLOW_PRINTING**—If true, allows you to print the PDF document. By default, it is true.
- **PDFOPT_ALLOW_PRINTING_MODE**—Enables you to set the print resolution. It is given by the `pfcExport.PDFPrintingMode` class and takes the following values:
 - **PDF_PRINTING_LOW_RES**—Specifies low resolution for printing.
 - **PDF_PRINTING_HIGH_RES**—Specifies high resolution for printing. This is the default value.
- **PDFOPT_ALLOW_COPYING**—If true, allows you to copy content from the PDF document. By default, it is true.
- **PDFOPT_ALLOW_ACCESSIBILITY**—If true, enables visually-impaired screen reader devices to extract data independent of the value given by the `pfcExport.PDFRestrictOperationsMode` class. The default value is true.
- **PDFOPT_PENTABLE**—If true, uses the standard Pro/ENGINEER pentable to control the line weight, line style, and line color of the exported geometry. The default value is false.

- **PDFOPT_LINECAP**—Enables you to control the treatment of the ends of the geometry lines exported to PDF. It is given by the `pfcExport.PDFLinecap` class and takes the following values:
 - **PDF_LINECAP_BUTT**—Specifies the butt cap square end. This is the default value.
 - **PDF_LINECAP_ROUND**—Specifies the round cap end.
 - **PDF_LINECAP_PROJECTING_SQUARE**—Specifies the projecting square cap end.
- **PDFOPT_LINEJOIN**—Enables you to control the treatment of the joined corners of connected lines exported to PDF. It is given by the `pfcExport.PDFLinejoin` class and takes the following values:
 - **PDF_LINEJOIN_MITER**—Specifies the miter join. This is the default.
 - **PDF_LINEJOIN_ROUND**—Specifies the round join.
 - **PDF_LINEJOIN_BEVEL**—Specifies the bevel join.
- **PDFOPT_SHEETS**—Allows you to specify the sheets from a Pro/ENGINEER drawing that are to be exported to PDF. It is given by the `pfcExport.PrintSheets` class and takes the following values:
 - **PRINT_CURRENT_SHEET**—Only the current sheet is exported to PDF.
 - **PRINT_ALL_SHEETS**—All the sheets are exported to PDF. This is the default value.
 - **PRINT_SELECTED_SHEETS**—Sheets of a specified range are exported to PDF. If this value is assigned, then the value of the option **PDFOPT_SHEET_RANGE** must also be known.
- **PDFOPT_SHEET_RANGE**—Specifies the range of sheets in a drawing that are to be exported to PDF. If this option is set, then the option **PDFOPT_SHEETS** must be set to the value **PRINT_SELECTED_SHEETS**.
- **PDFOPT_EXPORT_MODE**—Enables you to select the object to be exported to PDF and the export format. It is given by the `pfcExport.PDFExportMode` class and takes the following values:
 - **PDF_2D_DRAWING**—Only drawings are exported to PDF. This is the default value.

- PDF_3D_AS_NAMED_VIEWS—3D models are exported as 2D raster images embedded in PDF files.
- PDF_3D_AS_U3D_PDF—3D models are exported as U3D models embedded in one-page PDF files.
- PDF_3D_AS_U3D—A 3D model is exported as a U3D (.u3d) file. This value ignores the options set for the `pfcExport.PDFOptionType` class.
- PDFOPT_LIGHT_DEFAULT—Enables you to set the default lighting style used while exporting 3D models in the U3D format to a one-page PDF file, that is when the option PDFOPT_EXPORT_MODE is set to PDF_3D_AS_U3D. The values for this option are given by the `pfcExport.PDFU3DLightingMode` class.
- PDFOPT_RENDER_STYLE_DEFAULT—Enables you to set the default rendering style used while exporting Pro/ENGINEER models in the U3D format to a one-page PDF file, that is when the option PDFOPT_EXPORT_MODE is set to PDF_3D_AS_U3D. The values for this option are given by the `pfcModel.PDFU3DRenderMode` class.
- PDFOPT_SIZE—Allows you to specify the page size of the exported PDF file. The values for this option are given by the `pfcExport.PlotPaperSize` class. If the value is set to VARIABLESIZEPLOT, you also need to set the options PDFOPT_HEIGHT and PDFOPT_WIDTH.
- PDFOPT_HEIGHT—Enables you to set the height for a user-defined page size of the exported PDF file. The default value is 0.0.
- PDFOPT_WIDTH—Enables you to set the width for a user-defined page size of the exported PDF file. The default value is 0.0.
- PDFOPT_ORIENTATION—Enables you to specify the orientation of the pages in the exported PDF file. It is given by the `pfcSheet.SheetOrientation` class.
 - ORIENT_PORTRAIT—Exports the pages in portrait orientation. This is the default value.
 - ORIENT_LANDSCAPE—Exports the pages in landscape orientation.
- PDFOPT_TOP_MARGIN—Allows you to specify the top margin of the view port. The default value is 0.0.
- PDFOPT_LEFT_MARGIN—Allows you to specify the left margin of the view port. The default value is 0.0.

- `PDFOPT_BACKGROUND_COLOR_RED`—Specifies the default red background color that appears behind the U3D model. You can set any value within the range of 0.0 to 1.0. The default value is 1.0.
- `PDFOPT_BACKGROUND_COLOR_GREEN`—Specifies the default green background color that appears behind the U3D model. You can set any value within the range of 0.0 to 1.0. The default value is 1.0.
- `PDFOPT_BACKGROUND_COLOR_BLUE`—Specifies the default blue background color that appears behind the U3D model. You can set any value within the range of 0.0 to 1.0. The default value is 1.0.
- `PDFOPT_ADD_VIEWS`—If true, allows you to add view definitions to the U3D model from a file. By default, it is true.
- `PDFOPT_VIEW_TO_EXPORT`—Specifies the view or views to be exported to the PDF file. It is given by the `pfcExport.PDFSelectedViewMode` class and takes the following values:
 - `PDF_VIEW_SELECT_CURRENT`—Exports the current graphical area to a one-page PDF file.
 - `PDF_VIEW_SELECT_ALL`—Exports all the views to a multi-page PDF file. Each page contains one view with the view name displayed at the bottom center of the view port.
 - `PDF_VIEW_SELECT_BY_NAME`—Exports the selected view to a one-page PDF file with the view name printed at the bottom center of the view port. If this value is assigned, then the option `PDFOPT_SELECTED_VIEW` must also be set.
- `PDFOPT_SELECTED_VIEW`—Sets the option `PDFOPT_VIEW_TO_EXPORT` to the value `PDF_VIEW_SELECT_BY_NAME`, if the corresponding view is successfully found.

Exporting 3D Geometry

J-Link allows you to export three dimensional geometry to various formats. Pass the instructions object containing information about the desired export file to the method **`pfcModel.Model.Export`**.

Export Instructions

Methods Introduced:

- **pfcExport.Export3DInstructions.GetConfiguration**
- **pfcExport.Export3DInstructions.SetConfiguration**
- **pfcExport.Export3DInstructions.GetReferenceSystem**
- **pfcExport.Export3DInstructions.SetReferenceSystem**
- **pfcExport.Export3DInstructions.GetGeometry**
- **pfcExport.Export3DInstructions.SetGeometry**
- **pfcExport.Export3DInstructions.GetIncludedEntities**
- **pfcExport.Export3DInstructions.SetIncludedEntities**
- **pfcExport.Export3DInstructions.GetLayerOptions**
- **pfcExport.Export3DInstructions.SetLayerOptions**
- **pfcExport.pfcExport.GeometryFlags_Create**
- **pfcExport.pfcExport.InclusionFlags_Create**
- **pfcExport.pfcExport.LayerExportOptions_Create**
- **pfcExport.pfcExport.STEP3DExportInstructions_Create**
- **pfcExport.pfcExport.SET3DExportInstructions_Create**
- **pfcExport.pfcExport.VDA3DExportInstructions_Create**
- **pfcExport.pfcExport.IGES3DNewExportInstructions_Create**
- **pfcExport.pfcExport.CATIA3DExportInstructions_Create**
- **pfcExport.pfcExport.CATIAModel3DExportInstructions_Create**
- **pfcExport.pfcExport.PDGS3DExportInstructions_Create**
- **pfcExport.pfcExport.ACIS3DExportInstructions_Create**
- **pfcExport.pfcExport.CatiaPart3DExportInstructions_Create**
- **pfcExport.pfcExport.CatiaProduct3DExportInstructions_Create**
- **pfcExport.pfcExport.CatiaCGR3DExportInstructions_Create**
- **pfcExport.pfcExport.JT3DExportInstructions_Create**
- **pfcExport.pfcExport.ParaSolid3DExportInstructions_Create**
- **pfcExport.Export.UG3DExportInstructions_Create**

The interface **pfcExport.Export3DInstructions** contains data to export a part or an assembly to a specified 3D format. The fields of this interface are:

- **AssemblyConfiguration**—While exporting an assembly you can specify the structure and contents of the output files. The options are:
 - **EXPORT_ASM_FLAT_FILE**—Exports all the geometry of the assembly to a single file as if it were a part.
 - **EXPORT_ASM_SINGLE_FILE**—Exports an assembly structure to a file with external references to component files. This file contains only top-level geometry.
 - **EXPORT_ASM_MULTI_FILE**—Exports an assembly structure to a single file and the components to component files. It creates component parts and subassemblies with their respective geometry and external references. This option supports all levels of hierarchy.
 - **EXPORT_ASM_ASSEMBLY_FILE**—Exports an assembly as multiple files containing geometry information of its components and assembly features.
- **CoordSystem**—The reference coordinate system used for export. If this value is null, the system uses the default coordinate system.
- **GeometryFlags**—The object describing the type of geometry to export. The **pfcExport.pfcExport.GeometryFlags_Create** returns this instruction object. The types of geometry supported by the export operation are:
 - **Wireframe**—Export edges only.
 - **Solid**—Export surfaces along with topology.
 - **Surfaces**—Export all model surfaces.
 - **Quilts**—Export as quilt.
- **InclusionFlags**—The object returned by the method **pfcExport.pfcExport.InclusionFlags_Create** that determines whether to include certain entities. The entities are:
 - **Datums**—Determines whether datum curves are included when exporting files. If true the datum curve information is included during export. The default value is false.
 - **Blanked**—Determines whether entities on blanked layers are exported. If true entities on blanked layers are exported. The default value is false.

- **LayerExportOptions**—The instructions object returned by the method **pfcExport.pfcExport.LayerExportOptions_Create** that describes how to export layers. To export layers you can specify the following:
 - *UseAutoId*—Enables you to set or remove an interface layer ID. A layer is recognized with this ID when exporting the file to a specified output format. If true, automatically assigns interface IDs to layers not assigned IDs and exports them. The default value is false.
 - *LayerSetupFile*—Specifies the name and complete path of the layer setup file. This file contains the layer assignment information which includes the name of the layer, its display status, the interface ID and number of sub layers.

Export 3D Instructions Table

Interface	Used to Export
STEP3DExportInstructions	A part or assembly in STEP format
VDA3DExportInstructions	A part or assembly in VDA format
SET3DExportInstructions	A class that defines a ruled surface
IGES3DNewExportInstructions	A part or assembly in IGES format
CATIA3DExportInstructions	A part or assembly in CATIA format (as precise geometry)
CATIAModel3DExportInstructions	A part or assembly in CATIA MODEL format
PDGS3DExportInstructions	A part or assembly in PDGS format
ACIS3DExportInstructions	A part or assembly in ACIS format
CatiaPart3DExportInstructions	A part or assembly in CATIA PART format
CatiaProduct3DExportInstructions	A part or assembly in CATIA PRODUCT format
CatiaCGR3DExportInstructions	A part or assembly in CATIA CGR format
JT3DExportInstructions	A part or assembly in JT format
ParaSolid3DExportInstructions	A part or assembly in PARASOLID format
UG3DExportInstructions	A part or assembly in UG format

Export Utilities

Methods Introduced:

- **pfcSession.BaseSession.IsConfigurationSupported**
- **pfcSession.BaseSession.IsGeometryRepSupported**

The method

pfcSession.BaseSession.IsConfigurationSupported checks whether the specified assembly configuration is valid for a particular model and the specified export format. The input parameters for this method are:

- *Configuration*—Specifies the structure and content of the output files.
- *Type*—Specifies the output file type to create.

The method returns a true value if the configuration is supported for the specified export type.

The method

pfcSession.BaseSession.IsGeometryRepSupported checks whether the specified geometric representation is valid for a particular export format. The input parameters are :

- *Flags*—The type of geometry supported by the export operation.
- *Type*—The output file type to create.

The method returns a true value if the geometry combination is valid for the specified model and export type.

The methods

pfcSession.BaseSession.IsConfigurationSupported and **pfcSession.BaseSession.IsGeometryRepSupported()** must be called before exporting an assembly to the specified export formats except for the CADDs and STEP2D formats. The return values of both the methods must be true for the export operation to be successful.

Use the method **Model.Model.Export** to export the assembly to the specified output format.

Shrinkwrap Export

To improve performance in a large assembly design, you can export lightweight representations of models called shrinkwrap models. A shrinkwrap model is based on the external surfaces of the source part or assembly model and captures the outer shape of the source model.

You can create the following types of nonassociative exported shrinkwrap models:

- **Surface Subset**—This type consists of a subset of the original model's surfaces.
- **Faceted Solid**—This type is a faceted solid representing the original solid.
- **Merged Solid**—The external components from the reference assembly model are merged into a single part representing the solid geometry in all collected components.

Methods Introduced:

- **pfcSolid.Solid.ExportShrinkwrap**

You can export the specified solid model as a shrinkwrap model using the method **pfcSolid.Solid.ExportShrinkwrap**. This method takes the **ShrinkwrapExportInstruction** object as an argument.

Use the appropriate interface given in the following table to create the required type of shrinkwrap. All the interfaces have their own static method to create an object of the specified type. The object created by these interfaces can be used as an object of type **ShrinkwrapExportInstructions** or **ShrinkwrapModelExportInstructions**.

Type of Shrinkwrap Model	Interface to Use
Surface Subset	ShrinkwrapSurfaceSubsetInstructions
Faceted Part	ShrinkwrapFacetedPartInstructions
Faceted VRML	ShrinkwrapFacetedVRMLInstructions
Faceted STL	ShrinkwrapFacetedSTLInstructions
Merged Solid	ShrinkwrapMergedSolidInstructions

Setting Shrinkwrap Options

The interface **ShrinkwrapModelExportInstructions** contains the general methods available for all the types of shrinkwrap models. The object created by any of the interfaces specified in the preceding table can be used with these methods.

Methods Introduced:

- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetMethod**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetQuality**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetQuality**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetAutoHoleFilling**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetAutoHoleFilling**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreSkeleton**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreSkeleton**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreQuilts**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreQuilts**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetAssignMassProperties**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetAssignMassProperties**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreSmallSurfaces**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreSmallSurfaces**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetSmallSurfPercentage**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetSmallSurfPercentage**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetDatumReferences**
- **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetDatumReferences**

The method **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetMethod** returns the method used to create the shrinkwrap. The types of shrinkwrap methods are:

- **SWCREATE_SURF_SUBSET**—Surface Subset
- **SWCREATE_FACETED_SOLID**—Faceted Solid
- **SWCREATE_MERGED_SOLID**—Merged Solid

Interface

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetQuality specifies the quality level for the system to use when identifying surfaces or components that contribute to the shrinkwrap model. Quality ranges from 1 which produces the coarsest representation of the model in the fastest time, to 10 which produces the most exact representation. Use the method **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetQuality** to set the quality level for the system during the shrinkwrap export. The default value is 1.

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetAutoHoleFilling returns true if auto hole filling is enabled during Shrinkwrap export. The method **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetAutoHoleFilling** sets a flag that forces Pro/ENGINEER to identify all holes and surfaces that intersect a single surface and fills those holes during shrinkwrap. The default value is true.

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreSkeleton and **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreSkeleton** determine whether the skeleton model geometry must be included in the shrinkwrap model.

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreQuilts and **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreQuilts** determines whether external quilts must be included in the shrinkwrap model.

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetAssignMassProperties determines the mass property of the model.

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetAssignMassProperties assigns mass properties to the shrinkwrap model. The default value is false and the mass properties of the original model is assigned to the shrinkwrap model. If the value is set to true, the user must assign a value for the mass properties.

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreSmallSurfaces specifies whether small surfaces are ignored during the creation of a shrinkwrap model. The method **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreSmallSurfaces** sets a flag that forces Pro/ENGINEER to skip surfaces smaller than a certain size. The default value is false. The size of the surface is specified as a percentage of the model's size. This size can be modified using the methods **pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetSmallSurfPercentage** and **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetSmallSurfPercentage**.

The method

pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetDatumReferences and **pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetDatumReferences** specify and select the datum planes, points, curves, axes, and coordinate system references to be included in the shrinkwrap model.

Surface Subset Options

Methods Introduced:

- **pfcShrinkwrap.pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.Create**
- **pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.GetAdditionalSurfaces**
- **pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.SetAdditionalSurfaces**
- **pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.GetOutputModel**
- **pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.SetOutputModel**

The static method

pfcShrinkwrap.Shrinkwrap.ShrinkwrapSurfaceSubsetInstructions.Create returns an object used to create a shrinkwrap model of surface subset type. Specify the name of the output model in which the shrinkwrap is to be created as an input to this method.

The method

pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.GetAdditionalSurfaces specifies the surfaces included in the shrinkwrap model while the method **pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.SetAdditionalSurfaces** selects individual surfaces to be included in the shrinkwrap model.

The method **pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.GetOutputModel** returns the template model where the shrinkwrap geometry is to be created while the method **pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.SetOutputModel** sets the template model.

Faceted Solid Options

The **ShrinkwrapFacetedFormatInstructions** interface consists of the following types:

- **SWFACETED_PART**—Pro/ENGINEER part with normal geometry. This is the default format type.
- **SWFACETED_STL**—An STL file.
- **SWFACETED_VRML**—A VRML file.

Use the **Create** method to create the object of the specified type. Upcast the object to use the general methods available in this interface.

Methods Introduced:

- **pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.GetFormat**
- **pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.GetFramesFile**
- **pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.SetFramesFile**

The method **pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.GetFormat** returns the the output file format of the shrinkwrap model.

The methods **pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.GetFramesFile** and **pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.SetFramesFile** enable you to select a frame file to create a faceted solid motion envelope model that represents the full motion of the mechanism captured in the frame file. Specify the name and complete path of the frame file.

Faceted Part Options

Methods Introduced:

- **pfcShrinkwrap.pfcShrinkwrap.ShrinkwrapFacetedPartInstructions_Create**
- **pfcShrinkwrap.ShrinkwrapFacetedPartInstructions.GetLightweight**
- **pfcShrinkwrap.ShrinkwrapFacetedPartInstructions.SetLightweight**

The static method

pfcShrinkwrap.Shrinkwrap.ShrinkwrapFacetedPartInstructions_Create returns an object used to create a shrinkwrap model of shrinkwrap faceted type. The input parameters of this method are:

- *OutputModel*—Specify the output model where the shrinkwrap must be created.
- *Lightweight*—Specify this value as True if the shrinkwrap model is a Lightweight Pro/ENGINEER part.

The method

pfcShrinkwrap.ShrinkwrapFacetedPartInstructions.GetLightweight returns a *true* value if the output file format of the shrinkwrap model is a Lightweight Pro/ENGINEER part. The method

pfcShrinkwrap.ShrinkwrapFacetedPartInstructions.SetLightweight specifies if the Pro/ENGINEER part is exported as a light weight faceted geometry.

VRML Export Options

Methods Introduced:

- **pfcShrinkwrap.pfcShrinkwrap.ShrinkwrapVRMLInstructions_Create**
- **pfcShrinkwrap.ShrinkwrapVRMLInstructions.GetOutputFile**
- **pfcShrinkwrap.ShrinkwrapVRMLInstructions.SetOutputFile**

The static method

pfcShrinkwrap.Shrinkwrap.ShrinkwrapVRMLInstructions_Create returns an object used to create a shrinkwrap model of shrinkwrap VRML format. Specify the name of the output model as an input to this method.

The method

pfcShrinkwrap.ShrinkwrapVRMLInstructions.GetOutputFile returns the name of the output file to be created and the method **pfcShrinkwrap.ShrinkwrapVRMLInstructions.SetOutputFile** specifies the name of the output file to be created.

STL Export Options

Methods Introduced:

- **pfcShrinkwrap.pfcShrinkwrap.ShrinkwrapVRMLInstructions_Create**
- **pfcShrinkwrap.ShrinkwrapVRMLInstructions.GetOutputFile**
- **pfcShrinkwrap.ShrinkwrapVRMLInstructions.SetOutputFile**

The static method

pfcShrinkwrap.Shrinkwrap.ShrinkwrapVRMLInstructions_Create returns an object used to create a shrinkwrap model of shrinkwrap STL format. Specify the name of the output model as an input to this method.

The method

pfcShrinkwrap.ShrinkwrapSTLInstructions.GetOutputFile returns the name of the output file to be created and the method **pfcShrinkwrap.ShrinkwrapSTLInstructions.SetOutputFile** specifies the name of the output file to be created.

Merged Solid Options

Methods Introduced:

- **pfcShrinkwrap.pfcShrinkwrap.ShrinkwrapMergedSolidInstructions_Create**
- **pfcShrinkwrap.ShrinkwrapMergedSolidInstructions.GetAdditionalComponents**
- **pfcShrinkwrap.ShrinkwrapMergedSolidInstructions.SetAdditionalComponents**

The static method

pfcShrinkwrap.Shrinkwrap.ShrinkwrapMergedSolidInstructions_Create returns an object used to create a shrinkwrap model of merged solids format. Specify the name of the output model as an input to this method.

The methods

pfcShrinkwrap.ShrinkwrapMergedSolidInstructions.GetAdditionalComponents specifies individual components of the assembly to be merged into the shrinkwrap model. Use the method **pfcShrinkwrap.ShrinkwrapMergedSolidInstructions.SetAdditionalComponents** to select individual components of the assembly to be merged into the shrinkwrap model.

VRML Representation

Example Code

The following example code leverages the fact that when a model with a model program attached is erased or deleted the stop method of the model program is called. This example code uses the stop method to produce a VRML representation of the model in a standard directory for Web publishing.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcGlobal.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;

/**
 * The class MakeVRMLOnEraseExample is intended to be used as a model
 * program. The program automatically creates VRML file(s) in a standard
 * directory when the model is erased. The "stop" method will be called
 * when the model is erased.*/

public class MakeVRMLOnEraseExample {
static final String VRMLdirectory = "w:\\www\\engineering\\models";
// NT/Win95 directory structure. Use double "\\" because '\' signals a
special character.
// Unix directory would look like: "/www/engineering/models"
static Session session;
static Model model;
// static variables for access within start/stop methods
public static void start ()
{
ModelType modelType = ModelType.MDL_PART;
String modelName = "starter";

try {
session = pfcGlobal.GetProESession();
/* GetModel when the model program is activated (start). Even if
the model is renamed, the model variable reference will still
be valid. */
model = session.GetModel (modelName, modelType);
}
catch (jxthrowable x)
{
System.out.println ("Caught exception: "+x);
x.printStackTrace ();
}
}
public static void stop ()
{
try {
```

Interface

```

VRMLModelExportInstructions vrmI_instrs;

vrmI_instrs =
pfcModel.VRMLModelExportInstructions_Create(VRMLdirectory);
model.Export("", vrmI_instrs); // Export() ignores filename for VRML
export
}
catch (jxthrowable x)
{
System.out.println ("Caught exception :"+x);
x.printStackTrace ();
}
}
}

```

Importing Files

Method Introduced:

- **pfcModel.Model.Import**

The method **pfcModel.Model.Import** reads a file into Pro/ENGINEER. The format must be the same as it would be if these files were created by Pro/ENGINEER. The parameters are:

- *FilePath*—Absolute path of the file to be imported along with its extension.
- *ImportData*—The `ImportInstructions` object that controls the import operation.

Import Instructions

Methods Introduced:

- **pfcModel.pfcModel.RelationImportInstructions_Create**
- **pfcModel.pfcModel.IGESSectionImportInstructions_Create**
- **pfcModel.pfcModel.ProgramImportInstructions_Create**
- **pfcModel.pfcModel.ConfigImportInstructions_Create**
- **pfcModel.pfcModel.DWGSetupImportInstructions_Create**
- **pfcModel.pfcModel.SpoolsImportInstructions_Create**
- **pfcModel.pfcModel.ConnectorParamsImportInstructions_Create**
- **pfcModel.pfcModel.ASSEMBTreeCFGImportInstructions_Create**
- **pfcModel.pfcModel.WireListImportInstructions_Create**

- **pfcModel.pfcModel.CableParamsImportInstructions_Create**
- **pfcModel.pfcModel.STEPImport2DInstructions_Create**
- **pfcModel.pfcModel.IGESImport2DInstructions_Create**
- **pfcModel.pfcModel.DXFImport2DInstructions_Create**
- **pfcModel.pfcModel.DWGImport2DInstructions_Create**
- **pfcModel.pfcModel.SETImport2DInstructions_Create**

The methods described in this section create an instructions data object to import a file of a specified type into Pro/ENGINEER. The details are as shown in the table below:

Interface	Used to Import
RelationImportInstructions	A list of relations and parameters in a part or assembly.
IGESSectionImportInstructions	A section model in IGES format.
ProgramImportInstructions	A program file for a part or assembly that can be edited to change the model.
ConfigImportInstructions	Configuration instructions.
DWGSetupImportInstructions	A drawing s/u file.
SpoolImportInstructions	Spool instructions.
ConnectorParamsImportInstructions	Connector parameter instructions.
ASSEMBTreeCFGImportInstructions	Assembly tree CFG instructions.
WireListImportInstructions	Wirelist instructions.
CableParamsImportInstructions	Cable parameters from an assembly.
STEPImport2DInstructions	A part or assembly in STEP format.
IGESImport2DInstructions	A part or assembly in IGES format.
DXFImport2DInstructions	A drawing in DXF format.
DWGImport2DInstructions	A drawing in DWG format.
SETImport2DInstructions	A class that defines a ruled surface.

Note:

- The method **pfcModel.Model.Import** does not support importing of CADAM type of files.

- If a model or the file type STEP, IGES, DWX, or SET already exists, the imported model is appended to the current model. For more information on methods that return models of the types STEP, IGES, DWX, and SET, refer to Getting a Model Object.

Importing 2D Models

Method Introduced:

- **pfcSession.BaseSession.Import2DModel**

The method **pfcSession.BaseSession.Import2DModel** imports a two dimensional model based on the following parameters:

- *NewModelName*—Specifies the name of the new model.
- *Type*—Specifies the type of the model. The type can be one of the following:
 - STEP
 - IGES
 - DXF
 - DWG
 - SET
- *FilePath*—Specifies the location of the file to be imported along with the file extension
- *Instructions*—Specifies the `pfcModel.Import2DInstructions` object that controls the import operation.

The interface `pfcModel.Import2DInstructions` contains the following attributes:

- *Import2DViews*—Defines whether to import 2D drawing views.
- *ScaleToFit*—If the current model has a different sheet size than that specified by the imported file, set the parameter to true to retain the current sheet size. Set the parameter to false to retain the sheet size of the imported file.
- *FitToLeftCorner*—If this parameter is set to true, the bottom left corner of the imported file is adjusted to the bottom left corner of the current model. If it is set to false, the size of imported file is retained.

Note: The method **pfcSession.BaseSession.Import2DModel** does not support importing of CADAM type of files.

Importing 3D Geometry

Methods Introduced:

- **pfcSession.BaseSession.GetImportSourceType**
- **pfcSession.BaseSession.ImportNewModel**
- **pfcImport.LayerImportFilter.OnLayerImport**

For some input formats, the method **pfcSession.BaseSession.GetImportSourceType** returns the type of model that can be imported using a designated file. The input parameters of this method are:

- *FileToImport*—Specifies the path of the file along with its name and extension
- *NewModelImportType*—Specifies the type of model to be imported.

The method **pfcSession.BaseSession.ImportNewModel** is used to import an external 3D format file and creates a new model or set of models of type `pfcModel.Model`. The input parameters of this method are:

- *FileToImport*—Specifies the path to the file along with its name and extension
- *NewModelImportType*—Specifies the type of model to be imported. The types of models that can be imported are as follows:
 - `IMPORT_NEW_IGES`
 - `IMPORT_NEW_SET`
 - `IMPORT_NEW_VDA`
 - `IMPORT_NEW_NEUTRAL`
 - `IMPORT_NEW_CADDS`
 - `IMPORT_NEW_STEP`
 - `IMPORT_NEW_STL`
 - `IMPORT_NEW_VRML`
 - `IMPORT_NEW_POLTXT`

- IMPORT_NEW_CATIA_SESSION
- IMPORT_NEW_CATIA_MODEL
- IMPORT_NEW_DXF
- IMPORT_NEW_ACIS
- IMPORT_NEW_PARASOLID
- IMPORT_NEW_ICEM
- IMPORT_NEW_DESKTOP
- IMPORT_NEW_CATIA_PART
- IMPORT_NEW_UG
- IMPORT_NEW_PRODUCTVIEW
- IMPORT_NEW_CATIA_CGR
- IMPORT_NEW_JT
- *ModelType*—Specifies the type of the model. It can be a part, assembly or drawing.
- *NewModelName*—Specifies a name for the imported model.
- *LayerImportFilter*—Specifies the layer filter. This parameter is optional.

The interface `pfcImport.LayerImportFilter` has a call back function **`pfcImport.LayerImportFilter.OnLayerImport`**. Pro/ENGINEER passes the object `pfcImport.ImportedLayer` describing each imported layer to the layer filter to allow you to perform changes on each layer as it is imported.

The method **`pfcExceptions.XCancelProEAction.Throw`** can be called from the body of the method **`pfcImport.LayerImportFilter.OnLayerImport`** to end the filtering of the layers.

Modifying the Imported Layers

Layers help you organize model items so that you can perform operations on those items collectively. These operations primarily include ways of showing the items in the model, such as displaying or blanking, selecting, and suppressing. The methods described in this section modify the attributes of the imported layers.

Methods Introduced:

- **pfclImport.ImportedLayer.GetName**
- **pfclImport.ImportedLayer.SetNewName**
- **pfclImport.ImportedLayer.GetSurfaceCount**
- **pfclImport.ImportedLayer.GetCurveCount**
- **pfclImport.ImportedLayer.GetTrimmedSurfaceCount**
- **pfclImport.ImportedLayer.SetAction**

Layers are identified by their names. The method **pfclImport.ImportedLayer.GetName** returns the name of the layer while the method **pfclImport.ImportedLayer.SetNewName** can be used to set the name of the layer. The name can be numeric or alphanumeric.

The method **pfclImport.ImportedLayer.GetSurfaceCount** returns the number of curves on the layer.

The method **pfclImport.ImportedLayer.GetTrimmedSurfaceCount** returns the number of trimmed surfaces on the layer and the method **pfclImport.ImportedLayer.GetCurveCount** returns the number of curves on the layer.

The method **pfclImport.ImportedLayer.SetAction** sets the display of the imported layers. The input parameter for this method is `ImportAction`. The types of actions that can be performed on the imported layers are:

- `IMPORT_LAYER_DISPLAY`—Displays the imported layer.
- `IMPORT_LAYER_SKIP`—Does not import entities on this layer.
- `IMPORT_LAYER_BLANK`—Blanks the selected layer.
- `IMPORT_LAYER_IGNORE`—Imports only entities on this layer but not the layer.

The default action type is `IMPORT_LAYER_DISPLAY`.

Plotting Files

From Pro/ENGINEER Wildfire 5.0 onwards, the `pfcModel.PlotInstructions` object containing the instructions for plotting files has been deprecated. All the methods listed below for creating and accessing the instruction attributes in `pfcModel.PlotInstructions` have also been deprecated. Use the new interface type `pfcExport.PrinterInstructions` and its methods described in the next section.

Methods Deprecated:

- `pfcModel.pfcModel.PlotInstructions_Create`
- `pfcModel.PlotInstructions.GetPlotterName`
- `pfcModel.PlotInstructions.SetPlotterName`
- `pfcModel.PlotInstructions.GetOutputQuality`
- `pfcModel.PlotInstructions.SetOutputQuality`
- `pfcModel.PlotInstructions.GetUserScale`
- `pfcModel.PlotInstructions.SetUserScale`
- `pfcModel.PlotInstructions.GetPenSlew`
- `pfcModel.PlotInstructions.SetPenSlew`
- `pfcModel.PlotInstructions.GetPenVelocityX`
- `pfcModel.PlotInstructions.SetPenVelocityX`
- `pfcModel.PlotInstructions.GetPenVelocityY`
- `pfcModel.PlotInstructions.SetPenVelocityY`
- `pfcModel.PlotInstructions.GetSegmentedOutput`
- `pfcModel.PlotInstructions.SetSegmentedOutput`
- `pfcModel.PlotInstructions.GetLabelPlot`
- `pfcModel.PlotInstructions.SetLabelPlot`
- `pfcModel.PlotInstructions.GetSeparatePlotFiles`
- `pfcModel.PlotInstructions.SetSeparatePlotFiles`
- `pfcModel.PlotInstructions.GetPaperSize`
- `pfcModel.PlotInstructions.SetPaperSize`

- `pfcModel.PlotInstructions.GetPageRangeChoice`
- `pfcModel.PlotInstructions.SetPageRangeChoice`
- `pfcModel.PlotInstructions.GetPaperSizeX`
- `pfcModel.PlotInstructions.SetPaperSizeY`
- `pfcModel.PlotInstructions.GetFirstPage`
- `pfcModel.PlotInstructions.SetFirstPage`
- `pfcModel.PlotInstructions.GetLastPage`
- `pfcModel.PlotInstructions.SetLastPage`

Printing Files

The printer instructions for printing a file are defined in `pfcExport.PrinterInstructions` data object.

Methods Introduced:

- `pfcExport.pfcExport.PrinterInstructions_Create`
- `pfcExport.PrinterInstructions.SetPrinterOption`
- `pfcExport.PrinterInstructions.SetPlacementOption`
- `pfcExport.PrinterInstructions.SetModelOption`
- `pfcExport.PrinterInstructions.SetWindowId`

The method `pfcExport.pfcExport.PrinterInstructions_Create` creates a new instance of the `pfcExport.PrinterInstructions` object. The object contains the following instruction attributes:

- *PrinterOption*—Specifies the printer settings for printing a file in terms of the `pfcExport.PrintPrinterOption` object. Set this attribute using the method **`pfcExport.PrinterInstructions.SetPrinterOption`**.
- *PlacementOption*—Specifies the placement options for printing purpose in terms of the `pfcExport.PrintMdlOption` object. Set this attribute using the method **`pfcExport.PrinterInstructions.SetPlacementOption`**.
- *ModelOption*—Specifies the model options for printing purpose in terms of the `pfcExport.PrintPlacementOption` object. Set this attribute using the method **`pfcExport.PrinterInstructions.SetModelOption`**.

- *WindowId*—Specifies the current window identifier. Set this attribute using the method **pfcExport.PrinterInstructions.SetWindowId**.

Printer Options

The printer settings for printing a file are defined in the `pfcExport.PrintPrinterOption` object.

Methods Introduced:

- **pfcExport.pfcExport.PrintPrinterOption_Create**
- **pfcSession.BaseSession.GetPrintPrinterOptions**
- **pfcExport.PrintPrinterOption.SetDeleteAfter**
- **pfcExport.PrintPrinterOption.SetFileName**
- **pfcExport.PrintPrinterOption.SetPaperSize**
- **pfcExport.Export.PrintSize_Create**
- **pfcExport.PrintSize.SetHeight**
- **pfcExport.PrintSize.SetWidth**
- **pfcExport.PrintSize.SetPaperSize**
- **pfcExport.PrintPrinterOption.SetPenTable**
- **pfcExport.PrintPrinterOption.SetPrintCommand**
- **pfcExport.PrintPrinterOption.SetPrinterType**
- **pfcExport.PrintPrinterOption.SetQuantity**
- **pfcExport.PrintPrinterOption.SetRollMedia**
- **pfcExport.PrintPrinterOption.SetRotatePlot**
- **pfcExport.PrintPrinterOption.SetSaveMethod**
- **pfcExport.PrintPrinterOption.SetSaveToFile**
- **pfcExport.PrintPrinterOption.SetSendToPrinter**
- **pfcExport.PrintPrinterOption.SetSlew**
- **pfcExport.PrintPrinterOption.SetSwHandshake**
- **pfcExport.PrintPrinterOption.SetUseTtf**

The method **pfcExport.pfcExport.PrintPrinterOption_Create** creates a new instance of the `pfcExport.PrintPrinterOption` object.

The method **pfcSession.BaseSession.GetPrintPrinterOptions** retrieves the printer settings.

The `pfcExport.PrintPrinterOption` object contains the following options:

- *DeleteAfter*—Determines if the file is deleted after printing. Set it to true to delete the file after printing. Use the method **pfcExport.PrintPrinterOption.SetDeleteAfter** to assign this option.
- *FileName*—Specifies the name of the file to be printed. Use the method **pfcExport.PrintPrinterOption.SetFileName** to set the name.
- *PaperSize*—Specifies the parameters of the paper to be printed in terms of the `pfcExport.PrintSize` object. The method **pfcExport.PrintPrinterOption.SetPaperSize** assigns the *PaperSize* option. Use the method **pfcExport.Export.PrintSize_Create** to create a new instance of the `pfcExport.PrintSize` object. This object contains the following options:
 - *Height*—Specifies the height of paper. Use the method **pfcExport.PrintSize.SetHeight** to set the paper height.
 - *Width*—Specifies the width of paper. Use the method **pfcExport.PrintSize.SetWidth** to set the paper width.
 - *PaperSize*—Specifies the size of the paper used for the plot in terms of the `pfcModel.PlotPaperSize` object. Use the method **pfcExport.PrintSize.SetPaperSize** to set the paper size.
- *PenTable*—Specifies the file containing the pen table. Use the method **pfcExport.PrintPrinterOption.SetPenTable** to set this option.
- *PrintCommand*—Specifies the command to be used for printing. Use the method **pfcExport.PrintPrinterOption.SetPrintCommand** to set the command.
- *PrinterType*—Specifies the printer type. Use the method **pfcExport.PrintPrinterOption.SetPrinterType** to assign the type.
- *Quantity*—Specifies the number of copies to be printed. Use the method **pfcExport.PrintPrinterOption.SetQuantity** to assign the quantity.

- *RollMedia*—Determines if roll media is to be used for printing. Set it to true to use roll media. Use the method **pfcExport.PrintPrinterOption.SetRollMedia** to assign this option.
- *RotatePlot*—Determines if the plot is rotated by 90 degrees. Set it to true to rotate the plot. Use the method **pfcExport.PrintPrinterOption.SetRotatePlot** to set this option.
- *SaveMethod*—Specifies the save method in terms of the `pfcExport.PrintSaveMethod` class. Use the method **pfcExport.PrintPrinterOption.SetSaveMethod** to specify the save method. The available methods are as follows:
 - `PRINT_SAVE_SINGLE_FILE`—Plot is saved to a single file.
 - `PRINT_SAVE_MULTIPLE_FILE`—Plot is saved to multiple files.
 - `PRINT_SAVE_APPEND_TO_FILE`—Plot is appended to a file.
- *SaveToFile*—Determines if the file is saved after printing. Set it to true to save the file after printing. Use the method **pfcExport.PrintPrinterOption.SetSaveToFile** to assign this option.
- *SendToPrinter*—Determines if the plot is directly sent to the printer. Set it to true to send the plot to the printer. Use the method **pfcExport.PrintPrinterOption.SetSendToPrinter** to set this option.
- *Slew*—Specifies the speed of the pen in centimeters per second in X and Y direction. Use the method **pfcExport.PrintPrinterOption.SetSlew** to set this option.
- *SwHandshake*—Determines if the software handshake method is to be used for printing. Set it to true to use the software handshake method. Use the method **pfcExport.PrintPrinterOption.SetSwHandshake** to set this option.
- *UseTtf*—Specifies whether TrueType fonts or stroked text is used for printing. Set this option to true to use TrueType fonts and to false to stroke all text. Use the method **pfcExport.PrintPrinterOption.SetUseTtf** to set this option.

Placement Options

The placement options for printing purpose are defined in the `pfcExport.PrintPlacementOption` object.

Methods Introduced:

- `pfcExport.pfcExport.PrintPlacementOption_Create`
- `pfcSession.BaseSession.GetPrintPlacementOptions`
- `pfcExport.PrintPlacementOption.SetBottomOffset`
- `pfcExport.PrintPlacementOption.SetClipPlot`
- `pfcExport.PrintPlacementOption.SetKeepPanzoom`
- `pfcExport.PrintPlacementOption.SetLabelHeight`
- `pfcExport.PrintPlacementOption.SetPlaceLabel`
- `pfcExport.PrintPlacementOption.SetScale`
- `pfcExport.PrintPlacementOption.SetShiftAllCorner`
- `pfcExport.PrintPlacementOption.SetSideOffset`
- `pfcExport.PrintPlacementOption.SetX1ClipPosition`
- `pfcExport.PrintPlacementOption.SetX2ClipPosition`
- `pfcExport.PrintPlacementOption.SetY1ClipPosition`
- `pfcExport.PrintPlacementOption.SetY2ClipPosition`

The method `pfcExport.pfcExport.PrintPlacementOption_Create` creates a new instance of the `pfcExport.PrintPlacementOption` object.

The method `pfcSession.BaseSession.GetPrintPlacementOptions` retrieves the placement options.

The `pfcExport.PrintPlacementOption` object contains the following options:

- *BottomOffset*—Specifies the offset from the lower-left corner of the plot. Use the method `pfcExport.PrintPlacementOption.SetBottomOffset` to set this option.
- *ClipPlot*—Specifies whether the plot is clipped. Set this option to true to clip the plot or to false to avoid clipping of plot. Use the method `pfcExport.PrintPlacementOption.SetClipPlot` to set this option.

- *KeepPanzoom*—Determines whether pan and zoom values of the window are used. Set this option to true use pan and zoom and false to skip them. Use the method **pfcExport.PrintPlacementOption.SetKeepPanzoom** to set this option.
- *LabelHeight*—Specifies the height of the label in inches. Use the method **pfcExport.PrintPlacementOption.SetLabelHeight** to set this option.
- *PlaceLabel*—Specifies whether you want to place the label on the plot. Use the method **pfcExport.PrintPlacementOption.SetPlaceLabel** to set this option.
- *Scale*—Specifies the scale used for the plot. Use the method **pfcExport.PrintPlacementOption.SetScale** to set this option.
- *ShiftAllCorner*—Determines whether all corners are shifted. Set this option to true to shift all corners or to false to skip shifting of corners. Use the method **pfcExport.PrintPlacementOption.SetShiftAllCorner** to set this option.
- *SideOffset*—Specifies the offset from the sides. Use the method **pfcExport.PrintPlacementOption.SetSideOffset** to set this option.
- *X1ClipPosition*—Specifies the first X parameter for defining the clip position. Use the method **pfcExport.PrintPlacementOption.SetX1ClipPosition** to set this option.
- *X2ClipPosition*—Specifies the second X parameter for defining the clip position. Use the method **pfcExport.PrintPlacementOption.SetX2ClipPosition** to set this option.
- *Y1ClipPosition*—Specifies the first Y parameter for defining the clip position. Use the method **pfcExport.PrintPlacementOption.SetY1ClipPosition** to set this option.
- *Y2ClipPosition*—Specifies the second Y parameter for defining the clip position. Use the method **pfcExport.PrintPlacementOption.SetY2ClipPosition** to set this option.

Model Options

The model options for printing purpose are defined in the `pfcExport.PrintMdlOption` object.

Methods Introduced:

- `pfcExport.pfcExport.PrintMdlOption_Create`
- `pfcSession.BaseSession.GetPrintMdlOptions`
- `pfcExport.PrintMdlOption.SetDrawFormat`
- `pfcExport.PrintMdlOption.SetFirstPage`
- `pfcExport.PrintMdlOption.SetLastPage`
- `pfcExport.PrintMdlOption.SetLayerName`
- `pfcExport.PrintMdlOption.SetLayerOnly`
- `pfcExport.PrintMdlOption.SetMdl`
- `pfcExport.PrintMdlOption.SetQuality`
- `pfcExport.PrintMdlOption.SetSegmented`
- `pfcExport.PrintMdlOption.SetSheets`
- `pfcExport.PrintMdlOption.SetUseDrawingSize`
- `pfcExport.PrintMdlOption.SetUseSolidScale`

The method `pfcExport.pfcExport.PrintMdlOption_Create` creates a new instance of the `pfcExport.PrintMdlOption` object.

The method `pfcSession.BaseSession.GetPrintMdlOptions` retrieves the model options.

The `pfcExport.PrintMdlOption` object contains the following options:

- *DrawFormat*—Displays the drawing format used for printing. Use the method `pfcExport.PrintMdlOption.SetDrawFormat` to set this option.
- *FirstPage*—Specifies the first page number. Use the method `pfcExport.PrintMdlOption.SetFirstPage` to set this option.
- *LastPage*—Specifies the last page number. Use the method `pfcExport.PrintMdlOption.SetLastPage` to set this option.
- *LayerName*—Specifies the name of the layer. Use the method `pfcExport.PrintMdlOption.SetLayerName` to set the name.

- *LayerOnly*—Prints the specified layer only. Set this option to `true` to print the specified layer. Use the method **`pfcExport.PrintMdlOption.SetLayerOnly`** to set this option.
- *Mdl*—Specifies the model to be printed. Use the method **`pfcExport.PrintMdlOption.SetMdl`** to set this option.
- *Quality*—Determines the quality of the model to be printed. It checks for no line, no overlap, simple overlap, and complex overlap. Use the method **`pfcExport.PrintMdlOption.SetQuality`** to set this option.
- *Segmented*—If set to `true`, the printer prints the drawing in full size, but in segments that are compatible with the selected paper size. This option is available only if you are plotting a single page. Use the method **`pfcExport.PrintMdlOption.SetSegmented`** to set this option.
- *Sheets*—Specifies the sheets that need to be printed in terms of the `pfcExport.PrintSheets` class. Use the method **`pfcExport.PrintMdlOption.SetSheets`** to specify the sheets. The sheets can be of the following types:
 - `PRINT_CURRENT_SHEET`—Only the current sheet is printed.
 - `PRINT_ALL_SHEETS`—All the sheets are printed.
 - `PRINT_SELECTED_SHEETS`—Sheets of a specified range are printed.
- *UseDrawingSize*—Overrides the paper size specified in the printer options with the drawing size. Set this option to `true` to use the drawing size. Use the method **`pfcExport.PrintMdlOption.SetUseDrawingSize`** to set this option.
- *UseSolidScale*—Prints with the scale used in the solid model. Set this option to `true` to use solid scale. Use the method **`pfcExport.PrintMdlOption.SetUseSolidScale`** to set this option.

Plotter Configuration File (PCF) Options

The printing options for PCF file are defined in the `pfcExport.PrinterPCFOptions` object.

Methods Introduced:

- **pfcExport.pfcExport.PrinterPCFOptions_Create**
- **pfcExport.PrinterPCFOptions.SetPrinterOption**
- **pfcExport.PrinterPCFOptions.SetPlacementOption**
- **pfcExport.PrinterPCFOptions.SetModelOption**

The method **pfcExport.pfcExport.PrinterPCFOptions_Create** creates a new instance of the `pfcExport.PrinterPCFOptions` object.

The `pfcExport.PrinterPCFOptions` object contains the following options:

- *PrinterOption*—Specifies the printer settings for printing a file in terms of the `pfcExport.PrintPrinterOption` object. Set this attribute using the method **pfcExport.PrinterPCFOptions.SetPrinterOption**.
- *PlacementOption*—Specifies the placement options for printing purpose in terms of the `pfcExport.PrintMdlOption` object. Set this attribute using the method **pfcExport.PrinterPCFOptions.SetPlacementOption**.
- *ModelOption*—Specifies the model options for printing purpose in terms of the `pfcExport.PrintPlacementOption` object. Set this attribute using the method **pfcExport.PrinterPCFOptions.SetModelOption**.

Interface

Solid Operations

Method Introduced:

- **pfcSolid.Solid.CreateImportFeat**

The method **pfcSolid.Solid.CreateImportFeat** creates a new import feature in the solid and takes the following input arguments:

- *IntfData*—The source of data from which to create the import feature. It is given by the `pfcModel.IntfDataSource` object. The type of source data that can be imported is given by the `pfcModel.IntfType` class and can be of the following types:
 - INTF_NEUTRAL
 - INTF_NEUTRAL_FILE
 - INTF_IGES

- INTF_STEP
 - INTF_VDA
 - INTF_SET
 - INTF_PDGS
 - INTF_ICEM
 - INTF_ACIS
 - INTF_DXF
 - INTF_CDRS
 - INTF_STL
 - INTF_VRML
 - INTF_PARASOLID
 - INTF_AI
 - INTF_CATIA_PART
 - INTF_UG
 - INTF_PRODUCTVIEW
 - INTF_CATIA_CGR
 - INTF_JT
- *CoordSys*—The pointer to a reference coordinate system. If this is NULL, the function uses the default coordinate system.
 - *FeatAttr*—The attributes for creation of the new import feature given by the `pfcModel.ImportFeatAttr` object. If this pointer is NULL, the function uses the default attributes.

Example Code: Returning a Feature Object

This method will return a feature object when provided with a solid coordinate system name and an import feature's file name. The method will find the coordinate system in the model, set the Import Feature Attributes, and create an import feature. Then the feature is returned.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcGeometry.*;
public class pfcImportFeatureExample {
```

```

public Feature createImportFeatureFromDataFile (Solid solid,
                                               String csys,
                                               String filename)
{
    IntfNeutralFile data_source;
    ModelItems c_systems;
    CoordSystem c_system = null;
    Feature import_feature = null;
    ImportFeatAttr feat_attr;
    try {
        data_source = pfcModel.IntfNeutralFile_Create(filename);
        c_systems = solid.ListItems(ModelItemType.ITEM_COORD_SYS);
        for (int i = 0; i < c_systems.getarraysize(); i++)
        {
            if (c_systems.get(i).GetName().equals(csys))
            {
                c_system = (CoordSystem)c_systems.get(i);
                break;
            }
        }
        /*
        * Create the import ImportFeatAttr structure
        * Join surfaces, make solids from every closed quilt
        * using the add operation
        */
        feat_attr = pfcModel.ImportFeatAttr_Create();
        feat_attr.SetJoinSurfs(true);
        feat_attr.SetMakeSolid(true);
        feat_attr.SetOperation(OperationType.ADD_OPERATION);
        import_feature = solid.CreateImportFeat(data_source,
                                               c_system,
                                               feat_attr);
    }
    catch (jxthrowable x)
    {
        System.out.println("Exception Occured:" + x);
    }
    return import_feature;
}
}

```

Window Operations

Method Introduced:

- **pfcWindow.Window.ExportRasterImage**

The method **pfcWindow.Window.ExportRasterImage** outputs a standard Pro/ENGINEER raster output file.

Example Code: Generating Raster Files

The following code is used to generate raster image files using a specified window and file type.

```
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcWindow.*;
import com.ptc.cipjava.jxthrowable;
public class pfcWindowExamples {
/**
 *  outputImage takes a Window and outputs a raster image file
 *  depicting the window.  This method takes as an argument the type of
 *  the raster file, but the size and image quality of the raster file are
 *  hardcoded.*/
public static void outputImage (Window window, RasterType type)
{

try {
RasterImageExportInstructions instructions =
                                getRasterInstructions (type);
String ext = getExt (type);
window.ExportRasterImage ("pfcoutput"+ext, instructions);
}
catch (UnsupportedRasterTypeException u)
{
System.out.println ("Unsupported raster file type.  No output file
                    produced.");
return;
}
catch (jxthrowable x)
{
System.out.println ("Exception caught: "+x);
x.printStackTrace();
return;
}
return;
}
/**
 *  outputScreen takes a BaseSession and outputs a raster image file
 *  depicting the current window.  This method takes as an argument the
 *  type of the raster file, but the size and image quality of the raster
 *  file are hardcoded.

public static void outputScreen (Session session, RasterType type)
{

try {
RasterImageExportInstructions instructions =
                                getRasterInstructions (type);
String ext = getExt (type);
session.ExportCurrentRasterImage ("pfcoutput"+ext, instructions);
```

```

}
catch (UnsupportedRasterTypeException u)
{
System.out.println ("Unsupported raster file type. No output file
produced.");
return;
}
catch (jxthrowable x)
{
System.out.println ("Exception caught: "+x);
x.printStackTrace();
return;
}
return;
}
/**
 * A helper method which creates a RasterImageExportInstructions object
 *based on the type.*/
private static RasterImageExportInstructions getRasterInstructions
(RasterType type) throws jxthrowable, UnsupportedRasterTypeException
{
double rasterHeight = 7.5;
double rasterWidth = 10.0;
DotsPerInch dpi = DotsPerInch.RASTERDPI_100;
RasterDepth depth = RasterDepth.RASTERDEPTH_24;
RasterImageExportInstructions instructions;

switch (type.getValue())
{
case RasterType._RASTER_BMP:
BitmapImageExportInstructions bmp_instrs =
pfcWindow.BitmapImageExportInstructions_Create (rasterHeight,
rasterWidth);

instructions = bmp_instrs;
break;
case RasterType._RASTER_TIFF:
TIFFImageExportInstructions tiff_instrs =
pfcWindow.TIFFImageExportInstructions_Create (rasterHeight, rasterWidth);
instructions = tiff_instrs;
break;
case RasterType._RASTER_JPEG:
JPEGImageExportInstructions jpeg_instrs =
pfcWindow.JPEGImageExportInstructions_Create (rasterHeight, rasterWidth);
instructions = jpeg_instrs;
break;
case RasterType._RASTER_EPS:
EPSImageExportInstructions eps_instrs =
pfcWindow.EPSImageExportInstructions_Create (rasterHeight, rasterWidth);
instructions = eps_instrs;
break;
default:

```

```

throw new UnsupportedOperationException(type);
// This is not required, but it maintains the code even if new Raster
types are added in a future release. The method will throw and catch the
exception until the code can be updated with new types.
}
instructions.SetImageDepth (depth);
instructions.SetDotsPerInch (dpi);
return instructions;
}
/**
 * Helper method to get the file extension corresponding to a RasterType.
 */
private static String getExt (RasterType type)
{
switch (type.getValue())
{
case RasterType._RASTER_BMP:
return ".bmp";
case RasterType._RASTER_TIFF:
return ".tiff";
case RasterType._RASTER_JPEG:
return ".jpg";
case RasterType._RASTER_EPS:
return ".eps";
default:
return "Invalid";
}
}
}
}

```


Simplified Representations

J-Link gives programmatic access to all the simplified representation functionality of Pro/ENGINEER. Create simplified representations either permanently or on the fly and save, retrieve, or modify them by adding or deleting items.

Topic	Page
Overview	23 - 2
Retrieving Simplified Representations	23 - 3
Creating and Deleting Simplified Representations	23 - 4
Extracting Information About Simplified Representations	23 - 5
Modifying Simplified Representations	23 - 8
Simplified Representation Utilities	23 - 9

Overview

Using J-Link, you can create and manipulate assembly simplified representations just as you can using Pro/ENGINEER interactively.

Note: J-Link supports simplified representation of assemblies only, not parts.

Simplified representations are identified by the `pfcSimpRep.SimpRep` class. This class is a child of `pfcModelItem.ModelItem`, so you can use the methods dealing with `ModelItems` to collect, inspect, and modify simplified representations.

The information required to create and modify a simplified representation is stored in a class called `pfcSimpRep.SimpRepInstructions` which contains several data objects and fields, including:

- `String`—The name of the simplified representation
- `pfcSimpRep.SimpRepAction`—The rule that controls the default treatment of items in the simplified representation.
- `pfcSimpRep.SimpRepItem`—An array of assembly components and the actions applied to them in the simplified representation.

A `pfcSimpRep.SimpRepItem` is identified by the assembly component path to that item. Each `pfcSimpRep.SimpRepItem` has its own `pfcSimpRep.SimpRepAction` assigned to it. `pfcSimpRep.SimpRepAction` is a visible data object that includes a field of type `pfcSimpRep.SimpRepActionType`.

`pfcSimpRep.SimpActionType` is an enumerated type that specifies the possible treatment of items in a simplified representation. The possible values are as follows

Values	Action
SIMPREP_NONE	No action is specified.
SIMPREP_REVERSE	Reverse the default rule for this component (for example, include it if the default rule is exclude).
SIMPREP_INCLUDE	Include this component in the simplified representation.

Values	Action
SIMPREP_EXCLUDE	Exclude this component from the simplified representation.
SIMPREP_SUBSTITUTE	Substitute the component in the simplified representation.
SIMPREP_GEOM	Use only the geometrical representation of the component.
SIMPREP_GRAPHICS	Use only the graphics representation of the component.

Retrieving Simplified Representations

Methods Introduced:

- **pfcSession.BaseSession.RetrieveAssemSimpRep**
- **pfcSession.BaseSession.RetrieveGeomSimpRep**
- **pfcSession.BaseSession.RetrieveGraphicsSimpRep**
- **pfcSession.BaseSession.RetrieveSymbolicSimpRep**
- **pfcSimpRep.pfcSimpRep.RetrieveExistingSimpRepInstructions_Create**

You can retrieve a named simplified representation from a model using the method **pfcSession.BaseSession.RetrieveAssemSimpRep**, which is analogous to the Assembly mode option **Retrieve Rep** in the **SIMPLFD REP** menu. This method retrieves the object of an existing simplified representation from an assembly without fetching the generic representation into memory. The method takes two arguments, the name of the assembly and the simplified representation data.

To retrieve an existing simplified representation, pass an instance of **pfcSimpRep.pfcSimpRep.RetrieveExistingSimpRepInstructions_Create** and specify its name as the second argument to this method. Pro/ENGINEER retrieves that representation and any active submodels and returns the object to the simplified representation as a `pfcAssembly.Assembly` object.

You can retrieve geometry, graphics, and symbolic simplified representations into session using the methods **pfcSession.BaseSession.RetrieveGeomSimpRep**, **pfcSession.BaseSession.RetrieveGraphicsSimpRep**, and **pfcSession.BaseSession.RetrieveSymbolicSimpRep** respectively. Like **pfcSession.BaseSession.RetrieveAssemSimpRep**, these methods retrieve the simplified representation without bringing the master representation into memory. Supply the name of the assembly whose simplified representation is to be retrieved as the input parameter for these methods. The methods output the assembly. They do not display the simplified representation.

Creating and Deleting Simplified Representations

Methods Introduced:

- **pfcSimpRep.pfcSimpRep.CreateNewSimpRepInstructions_Create**
- **pfcSolid.Solid.CreateSimpRep**
- **pfcSolid.Solid.DeleteSimpRep**

To create a simplified representation, you must allocate and fill a `pfcSimpRep.SimpRepInstructions` object by calling the method **pfcSimpRep.pfcSimpRep.CreateNewSimpRepInstructions_Create**. Specify the name of the new simplified representation as an input to this method. You should also set the default action type and add `SimpRepItems` to the object.

To generate the new simplified representation, call **pfcSolid.Solid.CreateSimpRep**. This method returns the `pfcSimpRep.SimpRep` object for the new representation.

The method **pfcSolid.Solid.DeleteSimpRep** deletes a simplified representation from its model owner. The method requires only the `pfcSimpRep.SimpRep` object as input.

Extracting Information About Simplified Representations

Methods Introduced:

- **pfcSimpRep.SimpRep.GetInstructions**
- **pfcSimpRep.SimpRepInstructions.GetDefaultAction**
- **pfcSimpRep.CreateNewSimpRepInstructions.GetNewSimpName**
- **pfcSimpRep.SimpRepInstructions.GetIsTemporary**
- **pfcSimpRep.SimpRepInstructions.GetItems**

Given the object to a simplified representation, **pfcSimpRep.SimpRep.GetInstructions** fills out the `pfcSimpRep.SimpRepInstructions` object.

The **pfcSimpRep.SimpRepInstructions.GetDefaultAction**, **pfcSimpRep.CreateNewSimpRepInstructions.GetNewSimpName**, and **pfcSimpRep.SimpRepInstructions.GetIsTemporary** methods return the associated values contained in the `pfcSimpRep.SimpRepInstructions` object.

The method **pfcSimpRep.SimpRepInstructions.GetItems** returns all the items that make up the simplified representation.

Example 1: Working with Simplified Representation

This code demonstrates the functionality used when working with existing simplified representations in Pro/ENGINEER. This function `matchSimpRepItem` returns an array of simplified representation matching a `ComponentPath` for a certain feature as well as the `SimpRepActionType` for that item's action in the representation. If none are found the method prints the <NOT FOUND> message and returns null.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcAssembly.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcSimpRep.*;
import java.util.*;
public class pfcSimpRepExamples
{
    public static SimpRep [] matchSimpRepItem
        (com.ptc.pfc.pfcAssembly.ComponentPath path,
```

```

        com.ptc.pfc.pfcSimpRep.SimpRepActionType type)
{
    try{
        Assembly root_assembly;//The parent assembly
        ModelItems mitems;//All modelitems of type ITEM_SIMPREP from the
            assembly
        ModelItem mitem;//A modelitem of type ITEM_SIMPREP
        int num_simpregs;//The total number of simp. reps. in the assembly.
        CreateNewSimpRepInstructions instrs;//The instruction object
            //for the simplified
                representation.
        SimpRepItems simprepitems;//the components of the simplified rep.
        int num_inst;//the number of components in a simp rep.
        SimpRepItem simitem;//a single component in a simp rep.
        SimpRepActionType action;//the action of a certain SimpRepItem
        boolean found = false;//a check for the match in the outer loop
        boolean equal_intseq = false;//a check if the two sequences are equal
        intseq item_path;//A int sequence path to a given comp of a SimpRep
        SimpRep[] simpreps;//an array of found simpreps to be passed back to
            user
        Vector simpr = new Vector();//a vector for storing the found reps
        root_assembly = path.GetRoot();
        mitems = root_assembly.ListItems(ModelItemType.ITEM_SIMPREP);
        num_simpregs = mitems.getarraysize();
        if (mitems == null)
        {
            System.out.println("No Simplified Representations exist");
            return null;
        }
        for (int i = 0; i < num_simpregs; i++)
        {
            SimpRep rep = (SimpRep)mitems.get(i);
            System.out.println("Found Simplified representation: " + Sname);
            instrs = (CreateNewSimpRepInstructions)rep.GetInstructions();
            simprepitems = instrs.GetItems();
            num_inst = simprepitems.getarraysize();
            for (int j = 0; j < num_inst; j++)
            {
                simitem = simprepitems.get(i);
                if (simitem.GetItemPath() instanceof SimpRepCompItemPath)
                {
                    item_path =
                        ((SimpRepCompItemPath)simitem.GetItemPath()).GetItemPath();
                    equal_intseq = CompareSeq(item_path, path.GetComponentIds());
                    if (equal_intseq)
                    {
                        action = simitem.GetAction().GetType();
                        if (action .equals(type))
                        {
                            System.out.println("Found a match: SimpRep: " + srep.GetName());
                            simpr.addElement(srep);
                        }
                    }
                }
            }
        }
    }
}

```

```

        break;
    }
}
    }
    if (simpr.size() == 0)
    {
System.out.println("No Simplified Representations match the
                    description");
return null;
    }
    else
    {
simplereps = new SimpRep [simpr.size()];
simpr.copyInto(simplereps);
return simplereps;
    }
}
    catch (jxthrowable x)
    {
System.out.println("Exception Caught " + x);
x.printStackTrace();
    }
    return null;
}
/**
 * This method compares to intseq object for equivalence
 **/
public static boolean CompareSeq(intseq seq1, intseq seq2) throws
                                jxthrowable
{
    int len1 = seq1.getarraysize();
    int len2 = seq2.getarraysize();
    if (len1 != len2)
return false;
    for (int i = 0; i < len1; i++)
if (seq1.get(i) != seq2.get(i))
    return false;
    return true;
}
}

```

Modifying Simplified Representations

Methods Introduced:

- **pfcSimpRep.SimpRep.GetInstructions**
- **pfcSimpRep.SimpRep.SetInstructions**
- **pfcSimpRep.SimpRepInstructions.SetDefaultAction**
- **pfcSimpRep.CreateNewSimpRepInstructions.SetNewSimpName**
- **pfcSimpRep.SimpRepInstructions.SetIsTemporary**

Using J-Link, you can modify the attributes of existing simplified representations. After you create or retrieve a simplified representation, you can make calls to the `set` methods listed in this section to designate new values for the fields in the `pfcSimpRep.SimpRepInstructions` object.

To modify an existing simplified representation retrieve it and then get the `pfcSimpRep.SimpRepInstructions` object by calling **pfcSimpRep.SimpRep.GetInstructions**. If you created the representation programmatically within the same application, the `pfcSimpRep.SimpRepInstructions` object is already available. Once you have modified the data object, reassign it to the corresponding simplified representation by calling the method **pfcSimpRep.SimpRep.SetInstructions**.

Adding Items to and Deleting Items from a Simplified Representation

Methods Introduced:

- **pfcSimpRep.SimpRepInstructions.SetItems**
- **pfcSimpRep.pfcSimpRep.SimpRepItem_Create**
- **pfcSimpRep.SimpRep.SetInstructions**
- **pfcSimpRep.pfcSimpRep.SimpRepReverse_Create**
- **pfcSimpRep.pfcSimpRep.SimpRepInclude_Create**
- **pfcSimpRep.pfcSimpRep.SimpRepExclude_Create**
- **pfcSimpRep.pfcSimpRep.SimpRepSubstitute_Create**
- **pfcSimpRep.pfcSimpRep.SimpRepGeom_Create**
- **pfcSimpRep.pfcSimpRep.SimpRepGraphics_Create**

You can add and delete items from the list of components in a simplified representation using J-Link. If you created a simplified representation using the option **Exclude** as the default rule, you would generate a list containing the items you want to include. Similarly, if the default rule for a simplified representation is **Include**, you can add the items that you want to be excluded from the simplified representation to the list, setting the value of the `pfcSimpRep.SimpRepActionType` to `SIMPREP_EXCLUDE`.

How to Add Items

1. Get the `pfcSimpRep.SimpRepInstructions` object, as described in the previous section.
2. Specify the action to be applied to the item with a call to one of following methods.
3. Initialize a `pfcSimpRep.SimpRepItem` object for the item by calling the method **`pfcSimpRep.pfcSimpRep.SimpRepItem_Create`** .
4. Add the item to the `pfcSimpRep.SimpRepItem` sequence. Put the new `pfcSimpRep.SimpRepInstructions` using **`pfcSimpRep.SimpRepInstructions.SetItems`** .
5. Reassign the `pfcSimpRep.SimpRepInstructions` object to the corresponding `pfcSimpRep.SimpRep` object by calling **`pfcSimpRep.SimpRep.SetInstructions`** .

How to Remove Items

Follow the procedure above, except remove the unwanted `pfcSimpRep.SimpRepItem` from the sequence.

Simplified Representation Utilities

Methods Introduced:

- **`pfcModellItem.ModellItemOwner.ListItems`**
- **`pfcModellItem.ModellItemOwner.GetItemByld`**
- **`pfcSolid.Solid.GetSimpRep`**
- **`pfcSolid.Solid.SelectSimpRep`**
- **`pfcSolid.Solid.ActivateSimpRep`**
- **`pfcSolid.Solid.GetActiveSimpRep`**

This section describes the utility methods that relate to simplified representations.

The method **pfcModelItem.ModelItemOwner.ListItems** can list all of the simplified representations in a Solid.

The method **pfcModelItem.ModelItemOwner.GetItemById** initializes a `pfcSimpRep.SimpRep` object. It takes an integer `id`.

Note: J-Link supports simplified representation of Assemblies only, not Parts.

The method **pfcSolid.Solid.GetSimpRep** initializes a `pfcSimpRep.SimpRep` object. The method takes the following arguments:

- *SimpRepname*— The name of the simplified representation in the solid. If you specify this argument, the method ignores the *rep_id*.

The method **pfcSolid.Solid.SelectSimpRep** creates a Pro/ENGINEER menu to enable interactive selection. The method takes the owning solid as input, and outputs the object to the selected simplified representation. If you choose the **Quit** menu button, the method throws an exception `XToolkitUserAbort`.

The methods **pfcSolid.Solid.GetActiveSimpRep** and **pfcSolid.Solid.ActivateSimpRep** enable you to find and get the currently active simplified representation, respectively. Given an assembly object, **pfcSolid.Solid.GetActiveSimpRep()** returns the object to the currently active simplified representation. If the current representation is the master representation, the return is **null**.

The method **pfcSolid.Solid.ActivateSimpRep** activates the requested simplified representation.

To set a simplified representation to be the currently displayed model, you must also call **pfcModel.ModelDisplay()**.

24

Asynchronous Mode

This chapter explains how to use J-Link in Asynchronous Mode.

Topic	Page
Overview	24 - 2
Starting and Stopping Pro/ENGINEER	24 - 4
Connecting to a Pro/ENGINEER Process	24 - 7
Full Asynchronous Mode	24 - 9
Troubleshooting Asynchronous J-Link	24 - 14

Overview

Asynchronous mode is a multiprocess mode in which the J-Link application and Pro/ENGINEER can perform concurrent operations. Unlike the synchronous modes, asynchronous mode uses JNI (Java Native Interface) and RPC (remote procedure calls) as the means of communication between the application and Pro/ENGINEER.

Another important difference between synchronous and asynchronous modes is in the startup of the J-Link application. In synchronous mode, the application is started by Pro/ENGINEER, based on information contained in the registry file. In asynchronous mode, the application (containing its own main() method) is started independently of Pro/ENGINEER and subsequently either starts or connects to a Pro/ENGINEER process.

Note: An asynchronous application that starts Pro/ENGINEER will not appear in the Auxiliary Applications dialog box.

The use of RPC causes asynchronous mode to perform more slowly than synchronous mode. For this reason, apply asynchronous mode only when it is needed.

An asynchronous mode is not the only mode in which your application has explicit control over Pro/ENGINEER. Because Pro/ENGINEER calls a Java start method when an application starts, your synchronous application can take control by initiating all operations in Java start method (thus interrupting any user interaction). This technique is important when you want to run Pro/ENGINEER in batch mode.

Depending on how your asynchronous application handles messages from Pro/ENGINEER, your application can be classified as either **simple** or **full**. The following sections describe simple and full asynchronous mode.

Setting up an Asynchronous J-Link Application

For your asynchronous application to communicate with Pro/ENGINEER, you must set the environment variable `PRO_COMM_MSG_EXE` to the full path of the executable `pro_comm_msg`.

On UNIX systems, set `PRO_COMM_MSG_EXE` using the following command:

```
% setenv PRO_COMM_MSG_EXE
<Pro/ENGINEER>/<MACHINE>/obj/pro_comm_msg
```

In this command, % signifies the shell prompt while <Pro/ENGINEER> and <MACHINE> refer to your Pro/ENGINEER installation directory.

On Windows NT systems, set PRO_COMM_MSG_EXE in the **Environment** section of the **System** window that you access from the **Control Panel**.

To support the asynchronous mode, use the jar file pfcasync.jar in your CLASSPATH. This file is available at <Pro/E loadpoint>/text/java. This file contains all required classes for running with asynchronous J-Link.

Note: Asynchronous applications are incompatible with the classes in the synchronous .jar files. You must build and run your application classes specifically to run in asynchronous mode.

You must add the asynchronous library, pfcasyncmt, to your environment that launches the J-Link application. This library is stored in <Pro/E loadpoint><Machine>/<lib>.

Note: The library has prefix and extension specifiers for a dynamically loaded library for the platform being used.

Asynchronous Mode

System	Library	Path
sun4_solaris_64	libpfcasyncmt.so	setenv LD_LIBRARY_PATH "<Pro/E loadpoint>/sun4_solaris_64/lib:\$LD_LIBRARY_PATH"
hpux_pa64	libpfcasyncmt.sl	setenv SHLIB_PATH "<Pro/E loadpoint>/jlink/hpux_pa64/lib:\$SHLIB_PATH"
i486_nt, x86_win64	pfcasyncmt.dll	set PATH=<Pro/E loadpoint>/i486_nt<Machine Type>/lib;%PATH%
i486_linux	libpfcasyncmt.so	setenv LD_LIBRARY_PATH "<Pro/E loadpoint>/i486_linux/lib:\$LD_LIBRARY_PATH"

Asynchronous J-Link applications must load the `pfcasyncmt` library prior to calls made to the asynchronous methods. This can be accomplished by adding the following line to your application.

```
System.loadLibrary("pfcasyncmt")
```

Simple Asynchronous Mode

A simple asynchronous application does not implement a way to handle requests from Pro/ENGINEER. Therefore, J-Link cannot plant listeners to be notified when events happen in Pro/ENGINEER. Consequently, Pro/ENGINEER cannot invoke the methods that must be supplied when you add, for example, menu buttons to Pro/ENGINEER.

Despite this limitation, a simple asynchronous mode application can be used to automate processes in Pro/ENGINEER. The application may either start or connect to an existing Pro/ENGINEER session, and may access Pro/ENGINEER in interactive or in a non graphical, non interactive mode. When Pro/ENGINEER is running with graphics, it is an interactive process available to the user.

When you design a J-Link application to run in simple asynchronous mode, keep the following points in mind:

- The Pro/ENGINEER process and the application perform operations concurrently.
- None of the application's listener methods can be invoked by Pro/ENGINEER.

Simple asynchronous mode supports normal J-Link methods but does not support ActionListeners. These considerations imply that the J-Link application does not know the state (the current mode, for example) of the Pro/ENGINEER process at any moment.

Starting and Stopping Pro/ENGINEER

The following methods are used to start and stop Pro/ENGINEER when using J-Link applications.

Methods Introduced:

- **`pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Start`**
- **`pfcAsyncConnection.AsyncConnection.End`**

A simple asynchronous application can spawn and connect to a Pro/ENGINEER process with the method **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Start**. The Pro/ENGINEER process listens for requests from the application and acts on the requests at suitable breakpoints, usually between commands.

Unlike applications running in synchronous mode, asynchronous applications are not terminated when Pro/ENGINEER terminates. This is useful when the application needs to perform Pro/ENGINEER operations intermittently, and therefore, must start and stop Pro/ENGINEER more than once during a session.

The application can connect to or start only one Pro/ENGINEER session at any time. If the J-Link application spawns a second session, connection to the first session is lost.

To end any Pro/ENGINEER process that the application is connected to, call the method **pfcAsyncConnection.AsyncConnection.End**.

Setting Up a Noninteractive Session

You can spawn a Pro/ENGINEER session that is both noninteractive and nongraphical. In asynchronous mode, include the following strings in the Pro/ENGINEER start or connect call to **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Start**:

- `-g:no_graphics`—Turn off the graphics display.
- `-i:rpc_input`—Causes Pro/ENGINEER to expect input from your asynchronous application only.

Note: Both of these arguments are required, but the order is not important.

The syntax of the call for a noninteractive, nongraphical session is as follows:

```
pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Start
("pro -g:no_graphics -i:rpc_input",<text_dir>);
```

where `pro` is the command to start Pro/ENGINEER.

Example Code

This example demonstrates how to use J-Link in asynchronous mode. The method starts Pro/ENGINEER asynchronously, retrieves a Session, and opens a model in Pro/ENGINEER.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcAsyncConnection.*;

/**
 * This asynchronous class is a simple asynchronous application. It makes
 * Pro/ENGINEER run in batch mode, without user input. The application
 * starts Pro/ENGINEER, performs the designated operations, and shuts down
 * Pro/ENGINEER.
 */
public class pfcAsyncStartExample {

    public static void main (String [] args)
    {
        System.loadLibrary("pfcasyncmt");
        runProE();
    }

    public static void runProE()
    {
        try
        {
            // Second Argument: String path to menu and msg files.
            // null assumes no msg and menu files used in this batch
            application.
            // -i and -g flags make Pro/ENGINEER run in non-graphic,
            non-interactive mode.

            AsyncConnection connection =
                pfcAsyncConnection.AsyncConnection_Start
                ("pro -g:no_graphics -i:rpc_input", null);

            Session session = connection.GetSession();

            /* J-Link processing calls here */

            //null third argument designates model is not an instance.
            ModelDescriptor desc = pfcModel.ModelDescriptor_Create
                (ModelType.MDL_PART, "modelname", null);

            Model model = session.RetrieveModel(desc);

            // end the Pro/ENGINEER process when done
        }
    }
}
```



```

        connection.End();
    }

    catch (jxthrowable x)
    {
        System.out.println("Exception: " + x);
    }
}

```

Connecting to a Pro/ENGINEER Process

Methods Introduced:

- **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Connect**
- **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_ConnectWS**
- **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_GetActiveConnection**
- **pfcAsyncConnection.AsyncConnection.Disconnect**

A simple asynchronous application can also connect to a Pro/ENGINEER process that is already running on a local computer. The method

pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Connect performs this connection. This method fails to connect if multiple Pro/ENGINEER sessions are running. If several versions of Pro/ENGINEER are running on the same computer, try to connect by specifying user and display parameters. However, if several versions of Pro/ENGINEER are running in the same user and display parameters, the connection may not be possible.

pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_ConnectWS connects to both Pro/ENGINEER and Pro/INTRALINK 3.x workspaces simultaneously.

pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_GetActiveConnection returns the current connection to a Pro/ENGINEER session.

To disconnect from a Pro/ENGINEER process, call the method **pfcAsyncConnection.AsyncConnection.Disconnect**. This method can be called only if you used the method **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Connect** to get the connection.

The connection to a Pro/ENGINEER process uses information provided by the name service daemon. The name service daemon accepts and supplies information about the processes running on the specified hosts. The application manager, for example, uses the name service when it starts up Pro/ENGINEER and other processes. The name service daemon is set up as part of the Pro/ENGINEER installation.

Connecting Via Connection ID

Methods Introduced:

- **pfcAsyncConnection.AsyncConnection.GetConnectionId**
- **pfcAsyncConnection.ConnectionId.GetExternalRep**
- **pfcSession.BaseSession.GetConnectionId**
- **pfcAsyncConnection.pfcAsyncConnection.ConnectionId_Create**
- **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_ConnectById**

Each Pro/ENGINEER process maintains a unique identity for communications purposes. Use this ID to reconnect to a Pro/ENGINEER process.

The method

pfcAsyncConnection.AsyncConnection.GetConnectionId returns a data structure containing the connection ID.

If the connection id must be passed to some other application the method **pfcAsyncConnection.ConnectionId.GetExternalRep** provides the string external representation for the connection ID.

The method **pfcSession.BaseSession.GetConnectionId** provides access to the asynchronous connection ID for the current Pro/ENGINEER session. This ID can be passed to any asynchronous mode application that needs to connect to the current session of Pro/ENGINEER.

The method

pfcAsyncConnection.pfcAsyncConnection.ConnectionId_Create takes a string representation and creates a **ConnectionId** data object. The method **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_ConnectById** connects to Pro/ENGINEER at the specified connection ID.

Note: Connection IDs are unique for each Pro/ENGINEER process and are not maintained after you quit Pro/ENGINEER.

Status of a Pro/ENGINEER Process

Method Introduced:

- **pfcAsyncConnection.AsyncConnection.IsRunning**

To find out whether a Pro/ENGINEER process is running, use the method **pfcAsyncConnection.AsyncConnection.IsRunning**.

Getting the Session Object

Method Introduced:

- **pfcAsyncConnection.AsyncConnection.GetSession**

The method **pfcAsyncConnection.AsyncConnection.GetSession** returns the session object representing the Pro/ENGINEER session. Use this object to access the contents of the Pro/ENGINEER session. See the Session Objects chapter for additional information.

Full Asynchronous Mode

Full asynchronous mode is identical to the simple asynchronous mode except in the way the J-Link application handles requests from Pro/ENGINEER. In simple asynchronous mode, it is not possible to process these requests. In full asynchronous mode, the application implements a control loop that “listens” for messages from Pro/ENGINEER. As a result, Pro/ENGINEER can call functions in the application, including callback functions for menu buttons and notifications.

Note: Using full asynchronous mode requires starting or connecting to Pro/ENGINEER using the methods described in the previous sections. The difference is that the application must provide an event loop to process calls from menu buttons and listeners.

Methods Introduced:

- **pfcAsyncConnection.AsyncConnection.EventProcess**
- **pfcAsyncConnection.AsyncConnection.WaitForEvents**
- **pfcAsyncConnection.AsyncConnection.InterruptEventProcessing**
- **pfcAsyncConnection.AsyncActionListener.OnTerminate**

The control loop of an application running in full asynchronous mode must contain a call to the method **pfcAsyncConnection.AsyncConnection.EventProcess**, which takes no arguments. This method allows the application to respond to messages sent from Pro/ENGINEER. For example, if the user selects a menu button that is added by your application, **pfcAsyncConnection.AsyncConnection.EventProcess** processes the call to your listener and returns when the call completes. For more information on listeners and adding menu buttons, see the Session Objects chapter.

The method **pfcAsyncConnection.AsyncConnection.WaitForEvents** provides an alternative to the development of an event processing loop in a full asynchronous mode application. Call this function to have the application wait in a loop for events to be passed from Pro/ENGINEER. No other processing takes place while the application is waiting. The loop continues until **pfcAsyncConnection.AsyncConnection.InterruptEventProcessing** is called from a J-Linkcallback action, or until the application detects the termination of Pro/ENGINEER.

It is often necessary for your full asynchronous application to be notified of the termination of the Pro/ENGINEER process. In particular, your control loop need not continue to listen for Pro/ENGINEER messages if Pro/ENGINEER is no longer running.

An `AsyncConnection` object can be assigned an Action Listener to bind a termination action that is executed upon the termination of Pro/ENGINEER. The method **pfcAsyncConnection.AsyncActionListener.OnTerminate** handles the termination that you must override. It sends a member of the class `pfcAsyncConnection.TerminationStatus`, which is one of the following:

- `TERM_EXIT`—Normal exit (the user clicks **Exit** on the menu).
- `TERM_ABNORMAL`—Quit with error status.
- `TERM_SIGNAL`—Fatal signal raised.

Your application can interpret the termination type and take appropriate action. For more information on Action Listeners, see the Action Listeners chapter.

Example Code

The following asynchronous class is a fully asynchronous application. It follows the procedure for a full asynchronous application:

1. The application establishes listeners for Pro/ENGINEER events, in this case, the menu button and the termination listener.
2. The application goes into a control loop calling **EventProcess** which allows the application to respond to the Pro/ENGINEER events.

```
import com.ptc.cipjava.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcCommand.*;
import com.ptc.pfc.pfcAsyncConnection.*;
import com.ptc.pfc.pfcExceptions.*;

public class pfcAsyncFullExample extends AsyncActionListener_u
{
    private AsyncConnection connection;
    private boolean exit_flag = false;
    public static void main (String [] args) throws
com.ptc.cipjava.jxthrowable
    {
        if (args.length != 2)
        {
            printMsg ("Incorrect argument list.");
            printMsg ("Arguments: java
com.ptc.jlinkasynceexamples.pfcAsyncFullExample <pro/E command> <text
path>");
            return;
        }
        try
        {
            System.loadLibrary ("pfcasyncmt");
        }
        catch (UnsatisfiedLinkError error)
        {
            printMsg ("Could not load J-Link library pfcasyncmt.");
            return;
        }
        new pfcAsyncFullExample (args);
    }
    // Constructor
    private pfcAsyncFullExample (String args[]) throws
com.ptc.cipjava.jxthrowable
    {
        startProE (args);
    }
}
```

```

addTerminationListener ();
addMenuButton();
while (!exit_flag)
{
    // Could do other regular processing here, but the
    // EventProcess() calls should happen regularly, so that
    // Pro/ENGINEER does not appear slow in responding to menu
    // button picks //

    try
    {
        connection.EventProcess ();
        Thread.sleep (100);
    }
    catch (java.lang.InterruptedException ex)
    {
    }
}
// Wait here a bit so Pro/ENGINEER can finish shutting down.

try
{
    Thread.sleep (2000);
    connection.EventProcess ();
}
catch (java.lang.InterruptedException ex)
{
}
}
/**
 * Starts Pro/ENGINEER.
 */
void startProE (String[] args) throws com.ptc.cipjava.jxthrowable
{
    try
    {
        // args[0] = Pro/ENGINEER command
        // args[1] = text path for menu/message files
        connection = pfcAsyncConnection.AsyncConnection_Start (args [0],
args[1]);
    }
    catch (XToolkitGeneralError error)
    {
        printMsg ("Could not start Pro/ENGINEER.");
        System.exit (0);
    }
    return;
}
/**Adds a menu and a menu button to the Pro/E menubar.*/
void addMenuButton () throws com.ptc.cipjava.jxthrowable
{

```

```

    Session s = connection.GetSession ();
    UICommand cmd = s.UICreateCommand ( "AsyncCommand",
        (UICommandActionListener) new ButtonListener());
    s.UIAddMenu ("J-Link", "Applications", "menu_text.txt", null);
    s.UIAddButton (cmd, "J-Link", null, "AsyncApp", "AsyncAppHelp",
        "menu_text.txt");
}
/**Adds a handler for Pro/ENGINEER's exit.*/
void addTerminationListener () throws com.ptc.cipjava.jxthrowable
{
    connection.AddActionListener ((AsyncActionListener)this);
    printMsg ("Termination listener added.");
}

/**Termination handler - from the AsyncActionListener interface.*/
public void OnTerminate (TerminationStatus status)
{
    printMsg ("Pro/ENGINEER shutting down.");
    exit_flag = true;
}
public static void printMsg (String msg)
{
    System.out.println (msg);
}
}
class ButtonListener extends DefaultUICommandActionListener
{
    /**
     * Menu button action - from interface UICommandActionListener
     */
    public void OnCommand ()
    {
        pfcAsyncFullExample.printMsg ("User menu button pushed.");
    }
}
}

```

Message and Menu File

```

J-Link
J-Link
#
#
AsyncApp
Hit me!
#
#
AsyncAppHelp
Launch async application callback
#
#

```

Troubleshooting Asynchronous J-Link

General Problems

UnsatisfiedLinkError in System.loadLibrary ("pfcasyncmt")

Add `$PRO_DIRECTORY/$PRO_MACHINE_TYPE/lib` to your library path:

- Windows and Windows XP 64bit: `$PATH` (separated with semicolon)
- UNIX (separated with colon):
 - sun4_solaris_64, i486_linux: `$LD_LIBRARY_PATH`
 - hpux_pa64: `$SHLIB_PATH`

Java gives this exception when it has any trouble loading the library, not just when the library is not in the library path. If you are working in a non-standard configuration make sure that all of these libraries are in your library path (subject to your OS naming, for example `cipstdmtz` is `libcipstdmtz.so` on Solaris and `cipstdmtz.dll` on Windows):

- `pfcasyncmt`
- `jnicipjavamtz`
- `jniadaptsmtz`
- `cipstdmtz`
- `ctoolsmtz`
- `baselibmtz`
- `il8nmtz`

Look at what is printed on `stdout/stderr`. There can be unresolved symbols. NT usually reports unresolved symbols in a pop-up dialog so you will see it immediately. UNIX systems will print the error to `stderr`. If that does not help, then enable the debug output from the operating system's dynamic loader, start with reading the main page.

UnsatisfiedLinkError on first call to a JLink method

Ensure that you executed the `System.loadLibrary ("pfcasyncmt")`. Put a debug printout right after it to ensure it gets loaded.

In most cases the J-Link jar files (`pfcasync.jar`) are loaded using a non-system class loader. Java lets you load native libraries from classes loaded with either the system class loader (`pfcasync.jar` must be in the default CLASSPATH), or a signed class loader. Java will not throw an exception on `System.loadLibrary`. For this reason everything will appear to be fine until the first call to a native method. At this point you will get an `UnsatisfiedLinkError`. Add J-Link jar files to the default CLASSPATH, usually to the CLASSPATH environment or an appropriate place in your servlet engine's configuration.

NullPointerException from a JLink method early in program execution.

Make sure that you have jar files from only one version of J-Link in your CLASSPATH. If you have both async and sync jar files, the VM will pick up incorrect classes.

- Sync J-Link jars: `pfc.jar`
- Async J-Link jars: `pfcasync.jar`

pfcExceptions.XToolkitNotFound exception on the first call to pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Start on Windows.

Make sure your Pro/ENGINEER command is correct. If it's not a full path to a script/executable, make sure `$PATH` is set correctly. Try full path in the command: if it works, then your `$PATH` is incorrect.

pfcExceptions.XToolkitGeneralError or pfcExceptions.CommError on the first call to pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Start or pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Connect.

- Make sure the environment variable `PRO_COMM_MSG_EXE` is set to full path to `pro_comm_msg`, including file name, including `.exe` on Windows.
- Make sure the environment variable `PRO_DIRECTORY` is set to Pro/ENGINEER installation directory.
- Make sure name service (`nmsd`) is running.

**pfcAsyncConnection.pfcAsyncConnection.AsyncConnection
_Start hangs, even though Pro/ENGINEER already started.**

Make sure name service (nmsd) is also started with Pro/ENGINEER. Open Task Manager and look for nmsd.exe in the process listing.

Problems Specific to Servlets and JSP

pfcExceptions.XToolkitGeneralError or
pfcExceptions.CommError on the first call to
**pfcAsyncConnection.pfcAsyncConnection.AsyncConnection
_Start** or
**pfcAsyncConnection.pfcAsyncConnection.AsyncConnection
_Connect**

- Make sure you have PRO_COMM_MSG_EXE and PRO_DIRECTORY set correctly.
- On Windows, servlet engine deployments typically belong to the SYSTEM account and not a local user account. So, you must set PRO_COMM_MSG_EXE and PRO_DIRECTORY in your system environment and restart Windows to cause this change to take effect.

25

Task Based Application Libraries

Applications created using different Pro/ENGINEER API products are interoperable. These products use Pro/ENGINEER as the medium of interaction, eliminating the task of writing native-platform specific interactions between different programming languages.

Application interoperability allows J-Link applications to call into Pro/TOOLKIT from areas not covered in the native interface. It allows you to put a Java front end on legacy Pro/TOOLKIT applications, and also allows you to use J-Link applications and listeners in conjunction with a Pro/Web.Link or asynchronous J-Link application.

J-Link can call Pro/ENGINEER web pages belonging to Pro/Web.Link, and functions in Pro/TOOLKIT DLLs. J-Link synchronous applications can also register tasks for use by other applications.

Topic	Page
Managing Application Arguments	25 - 2
Launching a Pro/Toolkit DLL	25 - 4
Creating J-Link Task Libraries	25 - 6
Launching Tasks from J-Link Task Libraries	25 - 7

Managing Application Arguments

J-Link passes application data to and from tasks in other applications as members of a sequence of `pfcArgument.Argument` objects. Application arguments consist of a label and a value. The value may be of any one of the following types:

- Integer
- Double
- Boolean
- ASCII string (a non-encoded string, provided for compatibility with arguments provided from C applications)
- String (a fully encoded string)
- `pfcSelect.Selection` (a selection of an item in a Pro/ENGINEER session)
- `pfcBase.Transform3D` (a coordinate system transformation matrix)

Methods Introduced:

- `pfcArgument.pfcArgument.CreateIntArgValue`
- `pfcArgument.pfcArgument.CreateDoubleArgValue`
- `pfcArgument.pfcArgument.CreateBoolArgValue`
- `pfcArgument.pfcArgument.CreateASCIIStringArgValue`
- `pfcArgument.pfcArgument.CreateStringArgValue`
- `pfcArgument.pfcArgument.CreateSelectionArgValue`
- `pfcArgument.pfcArgument.CreateTransformArgValue`
- `pfcArgument.ArgValue.Getdiscr`
- `pfcArgument.ArgValue.GetIntValue`
- `pfcArgument.ArgValue.SetIntValue`
- `pfcArgument.ArgValue.GetDoubleValue`
- `pfcArgument.ArgValue.SetDoubleValue`
- `pfcArgument.ArgValue.GetBoolValue`
- `pfcArgument.ArgValue.SetBoolValue`
- `pfcArgument.ArgValue.GetASCIIStringValue`
- `pfcArgument.ArgValue.SetASCIIStringValue`

- **pfcArgument.ArgValue.GetStringValue**
- **pfcArgument.ArgValue.SetStringValue**
- **pfcArgument.ArgValue.GetSelectionValue**
- **pfcArgument.ArgValue.SetSelectionValue**
- **pfcArgument.ArgValue.GetTransformValue**
- **pfcArgument.ArgValue.SetTransformValue**

The class `pfcArgument.ArgValue` contains one of the seven types of values. J-Link provides different methods to create each of the seven types of argument values.

The method **pfcArgument.ArgValue.Getdiscr** returns the type of value contained in the argument value object.

Use the methods listed above to access and modify the argument values.

Modifying Arguments

Methods Introduced:

- **pfcArgument.pfcArgument.Argument_Create**
- **pfcArgument.Arguments.create**
- **pfcArgument.Argument.GetLabel**
- **pfcArgument.Argument.SetLabel**
- **pfcArgument.Argument.GetValue**
- **pfcArgument.Argument.SetValue**

The method **pfcArgument.pfcArgument.Argument_Create** creates a new argument. Provide a name and value as the input arguments of this method.

The method **pfcArgument.Arguments.create** creates a new empty sequence of task arguments.

The method **pfcArgument.Argument.GetLabel** returns the label of the argument. The method **pfcArgument.Argument.SetLabel** sets the label of the argument.

The method **pfcArgument.Argument.GetValue** returns the value of the argument. The method **pfcArgument.Argument.SetValue** sets the value of the argument.

Launching a Pro/Toolkit DLL

The methods described in this section enable a J-Link user to register and launch a Pro/TOOLKIT DLL from a J-Link application. The ability to launch and control a Pro/TOOLKIT application enables the following:

- Reuse of existing Pro/TOOLKIT code with J-Link applications.
- ATB operations.

Methods Introduced:

- **pfcSession.BaseSession.LoadProToolkitDll**
- **pfcSession.BaseSession.LoadProToolkitLegacyDll**
- **pfcSession.BaseSession.GetProToolkitDll**
- **pfcProToolkit.Dll.ExecuteFunction**
- **pfcProToolkit.Dll.GetId**
- **pfcProToolkit.Dll.IsActive**
- **pfcProToolkit.Dll.Unload**

Use the method **pfcSession.BaseSession.LoadProToolkitDll** to register and start a Pro/TOOLKIT DLL. The input parameters of this method are similar to the fields of a registry file and are as follows:

- *ApplicationName*—The name of the application to initialize.
- *DllPath*—The full path to the DLL binary file.
- *TextPath*—The path to the application's message and user interface text files.
- *UserDisplay*—Set this parameter to `true` to register the application in the Pro/ENGINEER user interface and to see error messages if the application fails. If this parameter is `false`, the application will be invisible to the user.

The application's **user_initialize()** function is called when the application is started. The method returns a handle to the loaded Pro/TOOLKIT DLL.

In order to register and start a legacy Pro/TOOLKIT DLL that is not Unicode-compliant, use the method **pfcSession.BaseSession.LoadProToolkitLegacyDll**. This method conveys to Pro/ENGINEER that the loaded DLL application is not Unicode-compliant and built in the pre-Wildfire 4.0 environment. It takes the same input parameters as the earlier method **pfcSession.BaseSession.LoadProToolkitDll**.

Note: The method **pfcSession.BaseSession.LoadProToolkitLegacyDll** must be used only by a pre-Wildfire 4.0 J-Link application to load a pre-Wildfire 4.0 Pro/TOOLKIT DLL.

Use the method **pfcSession.BaseSession.GetProToolkitDll** to obtain a Pro/TOOLKIT DLL handle. Specify the *Application_Id*, that is, the DLL's identifier string as the input parameter of this method. The method returns the DLL object or null if the DLL was not in session. The *Application_Id* can be determined as follows:

- Use the function **ProToolkitDllIdGet()** within the DLL application to get a string representation of the DLL application. Pass NULL to the first argument of **ProToolkitDllIdGet()** to get the string identifier for the calling application.
- Use the **Get** method for the `Id` attribute in the DLL interface. The method **pfcProToolkit.Dll.GetId()** returns the DLL identifier string.

Use the method **pfcProToolkit.Dll.ExecuteFunction** to call a properly designated function in the Pro/TOOLKIT DLL library. The input parameters of this method are:

- *FunctionName*—Name of the function in the Pro/TOOLKIT DLL application.
- *InputArguments*—Input arguments to be passed to the library function.

The method returns an object of interface **com.ptc.pfc.pfcProToolkit.FunctionReturn**. This interface contains data returned by a Pro/TOOLKIT function call. The object contains the return value, as integer, of the executed function and the output arguments passed back from the function call.

The method **pfcProToolkit.Dll.IsActive** determines whether a Pro/TOOLKIT DLL previously loaded by the method **pfcSession.BaseSession.LoadProToolkitDll** is still active.

The method **pfcProToolkit.Dll.Unload** is used to shutdown a Pro/TOOLKIT DLL previously loaded by the method **pfcSession.BaseSession.LoadProToolkitDll** and the application's **user_terminate()** function is called.

Creating J-Link Task Libraries

The methods described in this section allow you to setup J-Link libraries to be used and called from other custom Pro/ENGINEER applications in Pro/TOOLKIT or J-Link.

J-Link task libraries must be compiled using the synchronous J-Link library called pfc.jar. Each task must be registered within the application for it to be called from external applications. Provide the following information to the application to use your J-Link application as a task library:

1. The required CLASSPATH settings.
2. The name of the invocation class containing the static start and stop methods.
3. The name of static **Start()** and **Stop()** methods
4. The path to the text files, if the application deals with messages or menus.
5. The registration name of the task.
6. The input argument names and types.
7. The output argument names and types.

Methods Introduced:

- **pfcSession.BaseSession.RegisterTask**
- **pfcJLink.JLinkTaskListener.OnExecute**
- **pfcSession.BaseSession.UnregisterTask**

Use the method **pfcSession.BaseSession.RegisterTask** to register the task or tasks to be executed. This method has two input parameters:

- The name of the task. This name must be provided by calling applications.
- Object implementing the interface **JLinkTaskListener** that has the **pfcJLinkTaskListener.OnExecute** callback method overridden. The class **pfcLink.DefaultJLinkTaskListener** makes extending the interface easier.

The method **pfcJLinkTaskListener.OnExecute** is called when the calling application tries to invoke a registered task. This method must contain the body of the J-Link task. The method signature includes a sequence of input arguments and allows you to return a sequence of output arguments to the caller.

Use the method **pfcSession.BaseSession.UnregisterTask** to delete a task that is no longer needed. This method must be called when you exit the application using the application's stop method.

Launching Tasks from J-Link Task Libraries

The methods described in this section allow you to launch tasks from a predefined J-Link task library.

Methods Introduced:

- **pfcSession.BaseSession.StartJLinkApplication**
- **pfcJLink.JLinkApplication.ExecuteTask**
- **pfcJLink.JLinkApplication.IsActive**
- **pfcJLink.JLinkApplication.Stop**

Use the method **pfcSession.BaseSession.StartJLinkApplication** to start a J-Link application. The input parameters of this method are similar to the fields of a registry file and are as follows:

- *ApplicationName*—Assigns a unique name to this J-Link application.
- *ClassName*—Specifies the name of the Java class that contains the J-Link application's start and stop method. This should be a fully qualified Java package and class name.
- *StartMethod*—Specifies the start method of the J-Link application.
- *StopMethod*—Specifies the stop method of the J-Link application.
- *AdditionalClassPath*—Specifies the locations of packages and classes that must be loaded when starting this J-Link application. If this parameter is specified as null, the default classpath locations are used.
- *TextPath*—Specifies the application text path for menus and messages. If this parameter is specified as null, the default text locations are used.

- *UserDisplay*—Specifies whether to display the application in the **Auxiliary Applications** dialog box in Pro/ENGINEER.

Upon starting the application, the static **start()** method is invoked. The method returns a `pfcJLink.JLinkApplication` referring to the J-Link application.

The method **pfcJLink.JLinkApplication.ExecuteTask** calls a registered task method in a J-Link application. The input parameters of this method are:

- Name of the task to be executed.
- A sequence of name value pair arguments contained by the interface **pfcArguments.Arguments**.

The method outputs an array of output arguments. These arguments are returned by the task's implementation of the **pfcJLinkTaskListener.OnExecute** call back method.

The method **pfcJLink.JLinkApplication.IsActive** returns a *True* value if the application specified by the `pfcJLink.JLinkApplication` object is active.

The method **pfcJLink.JLinkApplication.Stop** stops the application specified by the `pfcJLink.JLinkApplication` object. This method activates the application's static **Stop()** method.

26

Graphics

This chapter covers J-Link Graphics including displaying lists, displaying text and using the mouse.

Topic	Page
Overview	26 - 2
Getting Mouse Input	26 - 2
Displaying Graphics	26 - 3
Display Lists and Graphics	26 - 8

Overview

The methods described in this section allow you to draw temporary graphics in a display window. Methods that are identified as 2D are used to draw entities (arcs, polygons, and text) in screen coordinates. Other entities may be drawn using the current model's coordinate system or the screen coordinate system's lines, circles, and polylines. Methods are also included for manipulating text properties and accessing mouse inputs.

Getting Mouse Input

The following methods are used to read the mouse position in screen coordinates with the mouse button depressed. Each method outputs the position and an enumerated type description of which mouse button was pressed when the mouse was at that position. These values are contained in the class `pfcSession.MouseStatus`.

The enumerated values are defined in **`pfcSession.MouseButton`** and are as follows:

- `MOUSE_BTN_LEFT`
- `MOUSE_BTN_RIGHT`
- `MOUSE_BTN_MIDDLE`
- `MOUSE_BTN_LEFT_DOUBLECLICK`

Methods Introduced:

- **`pfcSession.Session.UIGetNextMousePick`**
- **`pfcSession.Session.UIGetCurrentMouseStatus`**

The method **`pfcSession.Session.UIGetNextMousePick`** returns the mouse position when you press a mouse button. The input argument is the mouse button that you expect the user to select.

The method **`pfcSession.Session.UIGetCurrentMouseStatus`** returns a value whenever the mouse is moved or a button is pressed. With this method a button does not have to be pressed for a value to be returned. You can use an input argument to flag whether or not the returned positions are snapped to the window grid.

Drawing a Mouse Box

This method allows you to draw a mouse box.

Method Introduced:

- **pfcSession.Session.UIPickMouseBox**

The method **pfcSession.Session.UIPickMouseBox** draws a dynamic rectangle from a specified point in screen coordinates to the current mouse position until the user presses the left mouse button. The return value for this method is of the type `pfcBase.Outline3D`.

You can supply the first corner location programmatically or you can allow the user to select both corners of the box.

Displaying Graphics

All the methods in this section draw graphics in the Pro/ENGINEER current window and use the color and linestyle set by calls to **pfcSession.BaseSession.SetStdColorFromRGB** and **pfcSession.BaseSession.SetLineStyle**. The methods draw the graphics in the Pro/ENGINEER graphics color. The default graphics color is white.

The methods in this section are called using the interface `pfcDisplay.Display`. The `Display` interface is extended by the `pfcSession.BaseSession` interface. This architecture allows you to call all these methods on any `Session` object.

By default graphic elements are not stored in the Pro/ENGINEER display list. Thus, they do not get redrawn by Pro/ENGINEER when the user selects **View**, **Repaint** or **View, Orientation**. However, if you store graphic elements in either 2-D or 3-D display lists, Pro/ENGINEER will redraw them when appropriate. See the section on “Display Lists and Graphics” for more information.

Methods Introduced:

- **pfcDisplay.Display.SetPenPosition**
- **pfcDisplay.Display.DrawLine**
- **pfcDisplay.Display.DrawPolyline**
- **pfcDisplay.Display.DrawCircle**
- **pfcDisplay.Display.DrawArc2D**
- **pfcDisplay.Display.DrawPolygon2D**

The method **pfcDisplay.Display.SetPenPosition** sets the point at which you want to start drawing a line. The method **pfcDisplay.Display.DrawLine** draws a line to the given point from the position given in the last call to either of the two methods. Call **pfcDisplay.Display.SetPenPosition()** for the start of the polyline, and **pfcDisplay.Display.DrawLine** for each vertex. If you use these methods in two-dimensional modes, use screen coordinates instead of solid coordinates.

The method **pfcDisplay.Display.DrawCircle** uses solid coordinates for the center of the circle and the radius value. The circle will be placed to the XY plane of the model.

The method **pfcDisplay.Display.DrawPolyline** also draws polylines, using an array to define the polyline.

In two-dimensional models the Display Graphics methods draw graphics at the specified screen coordinates.

The method **pfcDisplay.Display.DrawPolygon2D** draws a polygon in screen coordinates. The method **pfcDisplay.Display.DrawArc2D** draws an arc in screen coordinates.

Controlling Graphics Display

Methods Introduced:

- **pfcDisplay.Display.GetCurrentGraphicsColor**
- **pfcDisplay.Display.SetCurrentGraphicsColor**
- **pfcDisplay.Display.GetCurrentGraphicsMode**
- **pfcDisplay.Display.SetCurrentGraphicsMode**

The method **pfcDisplay.Display.GetCurrentGraphicsColor** returns the Pro/ENGINEER standard color used to display graphics. The Pro/ENGINEER default is COLOR_DRAWING (white). The method

pfcDisplay.Display.SetCurrentGraphicsColor allows you to change the color used to draw subsequent graphics.

The method **pfcDisplay.Display.GetCurrentGraphicsMode** returns the mode used to draw graphics:

- **DRAW_GRAPHICS_NORMAL**—Pro/ENGINEER draws graphics in the required color in each invocation.

- **DRAW_GRAPHICS_COMPLEMENT**—Pro/ENGINEER draws graphics normally, but will erase graphics drawn a second time in the same location. This allows you to create rubber band lines.

The method **pfcDisplay.Display.GetCurrentGraphicsMode** allows you to set the current graphics mode.

Example Code: Creating Graphics On Screen

This example demonstrates the use of mouse-tracking methods to draw graphics on the screen. The static method **DrawRubberbandLine** prompts the user to pick a screen point. The example uses the ‘complement mode’ to cause the line to display and erase as the user moves the mouse around the window.

Note: This example uses the method **transformPosition** to convert the coordinates into the 3D coordinate system of a solid model, if one is displayed.

```
package com.ptc.jlinkexamples;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.pfc.pfcDisplay.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcView.*;
import com.ptc.cipjava.*;

public class pfcDisplayExamples
{
    /* For prompt message */
    public static final String MSGFILE = "display_ex.txt";

    /* Static method to draw a rubberband line based on user mouse picks */
    public static void DrawRubberbandLine (Session session) throws jxthrowable
    {
        MouseStatus mouse = null;

        session.UIDisplayMessage (MSGFILE,
            "USER Pick first location for rubberband line",
            null);
        /* Expect the user to pick with left button */
        mouse = session.UIGetNextMousePick (MouseButton.MOUSE_BTN_LEFT);

        /* Transform screen point -> model location, if necessary */
        Point3D first_pos = transformPosition (session,mouse.GetPosition());

        /*Set graphics mode to complement, so that graphics erase after use */
        GraphicsMode current_mode = session.GetCurrentGraphicsMode();
        session.SetCurrentGraphicsMode (GraphicsMode.DRAW_GRAPHICS_COMPLEMENT);
    }
}
```

```

/*Get mouse position */
mouse = session.UIGetCurrentMouseStatus (false);
while (mouse.GetSelectedButton () == null)
{
    session.SetPenPosition (first_pos);
    Point3D second_pos = transformPosition (session,mouse.GetPosition());

    /* Draw rubberband line */
    session.DrawLine (second_pos);

    mouse = session.UIGetCurrentMouseStatus (false);

    /* Erase previously drawn line */
    session.SetPenPosition (first_pos);
    session.DrawLine (second_pos);
}

session.SetCurrentGraphicsMode (current_mode);
return;
}

/* This method transforms the 2D screen coordinates into
3D model coordinates - if necessary. */
private static Point3D transformPosition (Session s, Point3D in) throws
jxthrowable
{
    Model mdl = s.GetCurrentModel ();

    /* Skip transform if not in 3D model */
    if (mdl == null)
        return in;
    ModelType type = mdl.GetType();
    boolean isSolid = type.equals (ModelType.MDL_PART) ||
        type.equals (ModelType.MDL_ASSEMBLY) ||
        type.equals (ModelType.MDL_MFG);
    if (!isSolid)
        return in;

    /* Get current view's orientation and invert it */
    View curr_view = mdl.GetCurrentView();
    Transform3D inv_orient = curr_view.GetTransform();
    inv_orient.Invert();

    /* Get the model point */
    Point3D out = inv_orient.TransformPoint (in);

    return out;
}
}

```


Display example text

```
%C PUSER Pick first location for rubberband line  
Pick first location for rubberband line  
#  
#
```

Displaying Text in the Graphics Window

Method Introduced:

- **pfcDisplay.Display.DrawText2D**

The method **pfcDisplay.Display.DrawText2D** places text at a position specified in screen coordinates. If you want to add text to a particular position on the solid, you must transform the solid coordinates into screen coordinates by using the view matrix.

Text items drawn are not known to Pro/ENGINEER and therefore are not redrawn when you select View, Repaint. To notify the Pro/ENGINEER of these objects, create them inside the **OnDisplay()** method of the Display Listener.

Controlling Text Attributes

Methods Introduced:

- **pfcDisplay.Display.GetTextHeight**
- **pfcDisplay.Display.SetTextHeight**
- **pfcDisplay.Display.GetWidthFactor**
- **pfcDisplay.Display.SetWidthFactor**
- **pfcDisplay.Display.GetRotationAngle**
- **pfcDisplay.Display.SetRotationAngle**
- **pfcDisplay.Display.GetSlantAngle**
- **pfcDisplay.Display.SetSlantAngle**

These methods control the attributes of text added by calls to **pfcDisplay.Display.DrawText2D**.

You can get and set the following information:

- Text height (in screen coordinates)
- Width ratio of each character, including the gap, as a proportion of the height
- Rotation angle of the whole text, in counterclockwise degrees

- Slant angle of the text, in clockwise degrees

Controlling Text Fonts

Methods Introduced:

- **pfcDisplay.Display.GetDefaultFont**
- **pfcDisplay.Display.GetCurrentFont**
- **pfcDisplay.Display.SetCurrentFont**
- **pfcDisplay.Display.GetFontById**
- **pfcDisplay.Display.GetFontByName**

The method **pfcDisplay.Display.GetDefaultFont** returns the default Pro/ENGINEER text font. The text fonts are identified in Pro/ENGINEER by names and by integer identifiers. To find a specific font, use the methods **pfcDisplay.Display.GetFontById** or **pfcDisplay.Display.GetFontByName**.

Display Lists and Graphics

When generating a display of a solid in a window, Pro/ENGINEER maintains two display lists. A display list contains a set of vectors that are used to represent the shape of the solid in the view. A 3D display list contains a set of three-dimensional vectors that represent an approximation to the geometry of the edges of the solid. This list gets rebuilt every time the solid is regenerated.

A 2D display list contains the two-dimensional projections of the edges of the solid 3D display list onto the current window. It is rebuilt from the 3D display list when the orientation of the solid changes. The methods in this section enable you to add your own vectors to the display lists, so that the graphics will be redisplayed automatically by Pro/ENGINEER until the display lists are rebuilt.

When you add graphics items to the 2D display list, they will be regenerated after each repaint (when zooming and panning) and will be included in plots created by Pro/ENGINEER. When you add graphics to the 3D display list, you get the further benefit that the graphics survive a change to the orientation of the solid and are displayed even when you spin the solid dynamically.

Methods Introduced:

- **pfcDisplay.DisplayListener.OnDisplay**
- **pfcDisplay.Display.CreateDisplayList2D**
- **pfcDisplay.Display.CreateDisplayList3D**
- **pfcDisplay.DisplayList2D.Display**
- **pfcDisplay.DisplayList3D.Display**
- **pfcDisplay.DisplayList2D.Delete**
- **pfcDisplay.DisplayList3D.Delete**

A display listener is a class that acts similarly to an action listener. You must implement the method inherited from the `pfcDisplay.DisplayListener` interface. The implementation should provide calls to methods on the provided `pfcDisplay.Display` object to produce 2D or 3D graphics.

In order to create a display list in Pro/ENGINEER, you call **pfcDisplay.Display.CreateDisplayList2D** or **pfcDisplay.Display.CreateDisplayList3D** to tell Pro/ENGINEER to use your listener to create the display list vectors.

pfcDisplay.DisplayList2D.Display or **pfcDisplay.DisplayList3D.Display** will display or redisplay the elements in your display list. The application should delete the display list data when it is no longer needed.

The methods **pfcDisplay.DisplayList2D.Delete** and the method **pfcDisplay.DisplayList3D.Delete** will remove both the specified display list from a session.

Note: The method **pfcWindow.Window.Refresh** does not cause either of the display lists to be regenerated, but simply repaints the window using the 2-D display list.

Exceptions

Possible exceptions that might be thrown by displaying graphics methods are shown in the following table:

Exception	Reason
XToolkitNotExist	The display list is empty.
XToolkitNotFound	The method could not find the display list or the font specified in a previous call to pfcDisplay.Display.SetCurrentFont was not found.
XToolkitCantOpen	The use of display lists is disabled.
XToolkitAbort	The display was aborted.
XToolkitNotValid	The specified display list is invalid.
XToolkitInvalidItem	There is an invalid item in the display list.
XToolkitGeneralError	The specified display list is already in the process of being displayed.

Example Code

This example demonstrates the use of **pfcDisplay** methods with 3D display lists. The static method **AddCircleDisplay()** creates a new 3D display list whose graphics are generated by the code in the **OnDisplay()** method of the Display Circles class. This display list places circles at all of the vertices of a part model on the screen.

```
package com.ptc.jlinkexamples;

import com.ptc.pfc.pfcDisplay.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcModelItem.*;
import com.ptc.pfc.pfcGeometry.*;
import com.ptc.pfc.pfcBase.*;
import com.ptc.cipjava.*;

public class pfcDisplayListExamples
{
    static DisplayList3D list3D;

    /* Static method to create the display list */
    public static void AddCircleDisplay (Session session) throws jxthrowable
    {
        list3D = session.CreateDisplayList3D (1, new DisplayCircles ());
        // Id is an arbitrary number but should be unique to the application

        /* Show the changes */
    }
}
```

```

        session.GetCurrentWindow().Repaint();
    }

    /* Static method to delete the display list */
    public static void DeleteDisplay (Session session) throws jxthrowable
    {
        list3D.Delete();

        /* Show the changes */
        session.GetCurrentWindow().Repaint();
    }
}

/*=====
\
    CLASS:   DisplayCircles
    PURPOSE: Display list listener class - determines how the display
list          shows the graphics.
\=====
\
class DisplayCircles extends DefaultDisplayListener
{
    private static final double RADIUS = 0.5; // Constant for circle size

    /* This methods' signature inherited from DisplayListener */
    public void OnDisplay (Display display) throws jxthrowable
    {

        StdColor curr_color = display.GetCurrentGraphicsColor ();

        display.SetCurrentGraphicsColor (StdColor.COLOR_ERROR);
            // Use error color: magenta

        /* Downcast Display to Session object */
        Session s = (Session)display;
        Model model = s.GetCurrentModel();

        /* Error checking - make sure we have a part */
        if (model == null) return;
        ModelType type = model.GetType();
        if (!type.equals(ModelType.MDL_PART))
            return;

        /* Circle all vertices */
        ModelItems edges = model.ListItems (ModelItemType.ITEM_EDGE);

        for (int i = 0; i < edges.getarraysize(); i++)
        {
            Edge edge = (Edge)edges.get(i);

```

```
        Point3D vertex_1 = edge.Eval3DData(0.0).GetPoint();
        Point3D vertex_2 = edge.Eval3DData(1.0).GetPoint();

        display.DrawCircle (vertex_1, RADIUS);
        display.DrawCircle (vertex_2, RADIUS);
    }

    /* Restore graphics color to original */
    display.SetCurrentGraphicsColor (curr_color);
}
}
```

27

External Data

This chapter explains using External Data in J-Link.

Topic	Page
External Data	27 - 2
Exceptions	27 - 9

External Data

This chapter describes how to store and retrieve external data. External data enables a J-Link application to store its own data in a Pro/ENGINEER database in such a way that it is invisible to the Pro/ENGINEER user. This method is different from other means of storage accessible through the Pro/ENGINEER user interface.

Introduction to External Data

External data provides a way for the Pro/ENGINEER application to store its own private information about a Pro/ENGINEER model within the model file. The data is built and interrogated by the application as a workspace data structure. It is saved to the model file when the model is saved, and retrieved when the model is retrieved. The external data is otherwise ignored by Pro/ENGINEER; the application has complete control over form and content.

The external data for a specific Pro/ENGINEER model is broken down into classes and slots. A class is a named “bin” for your data, and identifies it as yours so no other Pro/ENGINEER API application (or other classes in your own application) will use it by mistake. An application usually needs only one class. The class name should be unique for each application and describe the role of the data in your application.

Each class contains a set of data slots. Each slot is identified by an identifier and optionally, a name. A slot contains a single data item of one of the following types:

J-Link Type	Data
com.ptc.pfc.pfcExternal.ExternalDataType.EXTDATA_INTEGER	integer
com.ptc.pfc.pfcExternal.ExternalDataType.EXTDATA_DOUBLE	double
com.ptc.pfc.pfcExternal.ExternalDataType.EXTDATA_STRING	string

The J-Link interfaces used to access external data in Pro/ENGINEER are:

J-Link Type	Data Type
pfcExternal.ExternalDataAccess	This is the top level object and is created when attempting to access external data.
pfcExternal.ExternalDataClass	This is a class of external data and is identified by a unique name.

J-Link Type	Data Type
<code>pfcExternal.ExternalDataSlot</code>	This is a container for one item of data. Each slot is stored in a class.
<code>pfcExternal.ExternalData</code>	This is a compact data structure that contains either an integer, double or string value.

Compatibility with Pro/TOOLKIT

J-Link and Pro/TOOLKIT share external data in the same manner. J-Link external data is accessible by Pro/TOOLKIT and the reverse is also true. However, an error will result if J-Link attempts to access external data previously stored by Pro/TOOLKIT as a stream.

Accessing External Data

Methods Introduced:

- `pfcModel.Model.AccessExternalData`
- `pfcModel.Model.TerminateExternalData`
- `pfcExternal.ExternalDataAccess.IsValid`

The method `pfcModel.Model.AccessExternalData` prepares Pro/ENGINEER to read external data from the model file. It returns the `pfcExternal.ExternalDataAccess` object that is used to read and write data. This method should be called only once for any given model in session.

The method `pfcModel.Model.TerminateExternalData` stops Pro/ENGINEER from accessing external data in a model. When you use this method all external data in the model will be removed. Permanent removal will occur when the model is saved.

Note: If you need to preserve the external data created in session, you must save the model before calling this function. Otherwise, your data will be lost.

The method `pfcExternal.ExternalDataAccess.IsValid` determines if the `ExternalDataAccess` object can be used to read and write data.

Storing External Data

Methods Introduced:

- **pfExternal.ExternalDataAccess.CreateClass**
- **pfExternal.ExternalDataClass.CreateSlot**
- **pfExternal.ExternalDataSlot.SetValue**

The first step in storing external data in a new class and slot is to set up a class using the method **pfExternal.ExternalDataAccess.CreateClass**, which provides the class name. The method outputs `pfExternal.ExternalDataClass`, used by the application to reference the class.

The next step is to use **pfExternal.ExternalDataClass.CreateSlot** to create an empty data slot and input a slot name. The method outputs a `pfExternal.ExternalDataSlot` object to identify the new slot.

Note: Slot names cannot begin with a number.

The method **pfExternal.ExternalDataSlot.SetValue** specifies the data type of a slot and writes an item of that type to the slot. The input is a `pfExternal.ExternalData` object that you can create by calling any one of the methods in the next section.

Initializing Data Objects

Methods Introduced:

- **pfExternal.pfExternal.CreateIntExternalData**
- **pfExternal.pfExternal.CreateDoubleExternalData**
- **pfExternal.pfExternal.CreateStringExternalData**

These methods initialize a `pfExternal.ExternalData` object with the appropriate data inputs.

Retrieving External Data

Methods Introduced:

- **pfcExternal.ExternalDataAccess.LoadAll**
- **pfcExternal.ExternalDataAccess.ListClasses**
- **pfcExternal.ExternalDataClass.ListSlots**
- **pfcExternal.ExternalDataSlot.GetValue**
- **pfcExternal.ExternalData.Getdiscr**
- **pfcExternal.ExternalData.GetIntegerValue**
- **pfcExternal.ExternalData.GetDoubleValue**
- **pfcExternal.ExternalData.GetStringValue**

For improved performance, external data is not loaded automatically into memory with the model. When the model is in session, call the method **pfcExternal.ExternalDataAccess.LoadAll** to retrieve all the external data for the specified model from the Pro/ENGINEER model file and put it in the workspace. The method needs to be called only once to retrieve all the data.

The method **pfcExternal.ExternalDataAccess.ListClasses** returns a sequence of **ExternalDataClasses** registered in the model. The method **pfcExternal.ExternalDataClass.ListSlots** provide a sequence of **ExternalDataSlots** existing for each class.

The method **pfcExternal.ExternalDataSlot.GetValue** reads the **pfcExternal.ExternalData** from a specified slot.

To find out a data type of a `pfcExternal.ExternalData`, call **pfcExternal.ExternalData.Getdiscr** and then call one of these methods to get the data, depending on the data type:

- **pfcExternal.ExternalData.GetIntegerValue**
- **pfcExternal.ExternalData.GetDoubleValue**
- **pfcExternal.ExternalData.GetStringValue**

Example Code

This example demonstrates the usage of external data in J-Link. It provides utility methods to convert a Java hashtable (java.util.Hashtable) to a model's external data, and to convert external data to a hashtable.

The conversion process makes some assumptions about the type of data to store in each data slot:

- + Short, Byte, Integer = integer external data
- + Float, Double = double external data
- + Any other Java object = String external data using the object's **toString()** method.

```
package com.ptc.jlinkexamples;
import com.ptc.pfc.pfcExternal.*;
import com.ptc.pfc.pfcModel.*;

public class pfcExternalDataExamples
{
    /* This method stores the contents of the Java hashtable
       in the model's external data */
    public static void StoreExternalDataHashtable(java.util.Hashtable table,
        Model the_model,
                                           String classname)
        throws com.ptc.cipjava.jxthrowable
    {
        /* Get or create the external data class */
        ExternalDataAccess access = the_model.AccessExternalData();
        ExternalDataClass the_class = GetClassByName (access,  classname);
        if (the_class == null)
        {
            the_class = access.CreateClass (classname);
        }

        /* Loop on all keys in the hashtable */
        java.util.Enumeration keys = table.keys();
        while (keys.hasMoreElements())
        {
            Object key = keys.nextElement();
            Object value;
            ExternalData data; /* The external data (int, double, string).
*/

            /* Class names must be Strings */
            if (!(key instanceof String))
                continue;

            value = table.get (key);
```

```

        if (value instanceof Short || value instanceof Byte ||
            value instanceof Integer)
        {
            int int_value = ((Number)value).intValue();
            data = pfcExternal.CreateIntExternalData (int_value);
        }
        else if (value instanceof Float || value instanceof Double)
        {
            double dbl_value = ((Number)value).doubleValue();
            data = pfcExternal.CreateDoubleExternalData (dbl_value);
        }
        else
        {
            /* If value is a String, toString() returns its value.
               Else, value becomes the String representation of the
Object.*/
            String str_value = value.toString();
            data = pfcExternal.CreateStringExternalData (str_value);
        }

        /* Get or create the slot and assign the value */
        ExternalDataSlot the_slot = GetSlotByName (the_class,
(String)key);
        if (the_slot == null)
            the_slot = the_class.CreateSlot ((String)key);
        the_slot.SetValue (data);
    }

    /* Store the external data changes */
    the_model.Save();

    return;
}

/* This method stores the contents of the hashtable in the
   model's external data */
public static java.util.Hashtable
RetrieveExternalDataHashtable (Model the_model, String classname)
throws com.ptc.cipjava.jxthrowable
{
    /* Find the external data class */
    java.util.Hashtable ret = new java.util.Hashtable();
    ExternalDataAccess access = the_model.AccessExternalData();
    ExternalDataClass the_class = GetClassByName (access, classname);

    if (the_class != null)
    {
        ExternalDataSlots slots = the_class.ListSlots();

        for (int i = 0; i < slots.getarraysize(); i++)
        {

```

```

Object value = null; /* Holder for slot value */
ExternalDataSlot the_slot = slots.get(i);

/* Assign the value to a Java object */
ExternalData data = the_slot.GetValue();
switch (data.Getdiscr().getValue())
{
    case ExternalDataType._EXTDATA_STRING:
    {
        value = (Object)data.GetStringValue();
        break;
    }
    case ExternalDataType._EXTDATA_INTEGER:
    {
        value = (Object) new Integer (data.GetIntegerValue());
        break;
    }
    case ExternalDataType._EXTDATA_DOUBLE:
    {
        value = (Object) new Double (data.GetDoubleValue());
        break;
    }
}
ret.put (the_slot.GetName(), value);
}
}
/* Returns the filled hashtable, or an empty one if class doesn't
exist*/
return ret;
}

/* This utility method returns a class, given its name,
or null if not found */
public static ExternalDataClass GetClassByName(ExternalDataAccess
the_access,
                                                String name)
throws com.ptc.cipjava.jxthrowable
{
    ExternalDataClasses classes = the_access.ListClasses();

    for (int i = 0; i < classes.getarraysize(); i++)
    {
        ExternalDataClass the_class = classes.get(i);
        if (the_class.GetName().equals (name))
            return the_class;
    }
    /* Class not found */
    return null;
}

```

```

/* This utility method returns a slot, given its name,
   or null if not found */
public static ExternalDataSlot GetSlotByName (ExternalDataClass
the_class,
                                             String name)
throws com.ptc.cipjava.jxthrowable
{
    ExternalDataSlots slots = the_class.ListSlots();

    for (int i = 0; i < slots.getarraysize(); i++)
    {
        ExternalDataSlot the_slot = slots.get(i);
        if (the_slot.GetName().equals (name))
            return the_slot;
    }
    /* Slot not found */
    return null;
}
}

```

Exceptions

Most exceptions thrown by external data methods in J-Link extend `pfExceptions.XExternalDataError`, which is a subclass of `pfExceptions.XToolkitError`.

An additional exception thrown by external data methods is `pfExceptions.XBadExternalData`. This exception signals an error accessing data. For example, external data access might have been terminated or the model might contain stream data from Pro/TOOLKIT.

The following table lists these exceptions.

Exception	Cause
pfCXExternalDataInvalidObject	Generated when a model or class is invalid.
pfCXExternalDataClassOrSlotExists	Generated when creating a class or slot and the proposed class or slot already exists.
pfCXExternalDataNamesTooLong	Generated when a class or slot name is too long.
pfCXExternalDataSlotNotFound	Generated when a specified class or slot does not exist.

Exception	Cause
pfcXExternalDataEmptySlot	Generated when the slot you are attempting to read is empty.
pfcXExternalDataInvalidSlotName	Generated when a specified slot name is invalid.
pfcXBadGetExternalData	Generated when you try to access an incorrect data type in a <code>pfcExternal.ExternalData</code> object.

Windchill Connectivity APIs

Pro/ENGINEER has the capability to be directly connected to Windchill solutions, including Windchill Foundation, ProjectLink, PDMLink, and Windchill ProductPoint servers. This access allows users to manage and control the product data seamlessly from within Pro/ENGINEER.

This chapter lists J-Link APIs that support Windchill servers and server operations in a connected Pro/ENGINEER session.

Topic	Page
Introduction	28 - 2
Accessing a Windchill Server from a Pro/ENGINEER Session	28 - 2
Accessing Workspaces	28 - 6
Workflow to Register a Server	28 - 8
Aliased URL	28 - 9
Server Operations	28 - 10
Utility APIs	28 - 37
Sample Batch Workflow	28 - 38

Introduction

The methods introduced in this chapter provide support for the basic Windchill server operations from within Pro/ENGINEER. With these methods, operations such as registering a Windchill server, managing workspaces, and check in or check out of objects will be possible via J-Link. The capabilities of these APIs are similar to the operations available from within the Pro/ENGINEER Wildfire client, with some restrictions.

Windchill ProductPoint does not have the concept of a workspace. New objects are directly stored to a user-specified folder in the Windchill ProductPoint server. New iteration of the objects are stored in the same folder as the previous iteration. Hence some of the APIs related to Workspace operations may not be supported for customizations using Windchill ProductPoint.

Non-Interactive Mode Operations

Some of the APIs specified in this section operate only in batch mode and cannot be used in the normal Pro/ENGINEER interactive mode. This restriction is mainly centered around the J-Link registered servers, that is, servers registered by J-Link are not available in the Pro/ENGINEER Server Registry or in other locations in the Pro/ENGINEER user interface such as the Folder Navigator and embedded browser. If a J-Link customization requires the user to have interactive access to the server, the server must be registered via the normal Pro/ENGINEER techniques, that is, either by entry in the Server Registry or by automatic registration of a previously registered server.

All of these APIs are supported from a non-interactive, that is, batch mode application or asynchronous application. For more information about batch mode and asynchronous mode, refer to the chapter "Asynchronous Mode".

Accessing a Windchill Server from a Pro/ENGINEER Session

Pro/ENGINEER allows you to register Windchill servers as a connection between the Windchill database and Pro/ENGINEER. Although the represented Windchill database can be from Windchill Foundation, Windchill ProjectLink, Windchill PDMLink, or Windchill ProductPoint, all types of databases are represented in the same way.

You can use the following identifiers when referring to Windchill servers in J-Link:

- **Codebase URL**—This is the root portion of the URL that is used to connect to a Windchill server. For example `http://wcserver.company.com/Windchill`.
- **Server Alias**—A server alias is used to refer to the server after it has been registered. The alias is also used to construct paths to files in the server workspaces and commonspaces. The server alias is chosen by the user or application and it need not have any direct relationship to the codebase URL. An alias can be any normal name, such as `my_alias`.

Accessing Information Before Registering a Server

To start working with a Windchill server, you must establish a connection by registering the server in Pro/ENGINEER. The methods described in this section allow you to connect to a Windchill server and access information related to the server.

Methods Introduced:

- **`pfcSession.BaseSession.AuthenticateBrowser`**
- **`pfcSession.BaseSession.GetServerLocation`**
- **`pfcServer.ServerLocation.GetClass`**
- **`pfcServer.ServerLocation.GetLocation`**
- **`pfcServer.ServerLocation.GetVersion`**
- **`pfcServer.ServerLocation.ListContexts`**
- **`pfcServer.ServerLocation.CollectWorkspaces`**

Use the method **`pfcSession.BaseSession.AuthenticateBrowser`** to set the authentication context using a valid username and password. A successful call to this method allows the Pro/ENGINEER session to register with any server that accepts the username and password combination. A successful call to this method also ensures that an authentication dialog box does not appear during the registration process. You can call this method any number of times to set the authentication context for any number of Windchill servers, provided that you register the appropriate servers or servers immediately after setting the context.

The method **pfcServer.ServerLocation.GetLocation** returns a `pfcServer.ServerLocation` object representing the codebase URL for a possible server. The server may not have been registered yet, but you can use this object and the methods it contains to gather information about the server prior to registration.

The method **pfcServer.ServerLocation.GetClass** returns the class of the server or server location. The values are:

- **Windchill**—Denotes either a Windchill Classic PDM server or a Windchill PDMLink server.
- **ProjectLink**—Denotes Windchill ProjectLink type of servers.
- **productpoint**—Denotes a Windchill ProductPoint server.

The method **pfcServer.ServerLocation.GetVersion** returns the version of Windchill that is configured on the server or server location, for example, "7.0" or "8.0." This method accepts the server codebase URL as the input.

Note: **pfcServer.ServerLocation.GetVersion** works only for Windchill servers and throws the **pfcExceptions.XToolkitUnsupported** exception, if the server is not a Windchill server.

The method **pfcServer.ServerLocation.ListContexts** gives a list of all the available contexts for a specified server. A context is used to associate a workspace with a product, project, or library.

The method **pfcServer.ServerLocation.CollectWorkspaces** returns the list of available workspaces for the specified server. The workspace objects returned contain the name of each workspace and its context.

Note: This method is not supported for Windchill ProductPoint.

Registering and Activating a Server

The methods described in this section are restricted to the non-interactive mode only. Refer to the section, Non-Interactive Mode Operations, for more information.

Methods Introduced:

- **pfcSession.BaseSession.RegisterServer**
- **pfcServer.Server.Activate**
- **pfcServer.Server.Unregister**

The method **pfcSession.BaseSession.RegisterServer** registers the specified server with the codebase URL. A successful call to **pfcSession.BaseSession.AuthenticateBrowser** with a valid username and password is essential for **pfcSession.BaseSession.RegisterServer** to register the server without launching the authentication dialog box. Registration of the server establishes the server alias. You must designate an existing workspace to use when registering the server. After the server has been registered, you may create a new workspace.

Note: While working with the Windchill ProductPoint server, specify the value of the input argument `WorkspaceName` as `NULL` for this method.

The method **pfcServer.Server.Activate** sets the specified server as the active server in the Pro/ENGINEER session.

The method **pfcServer.Server.Unregister** unregisters the specified server. This is similar to **Server Registry>Delete** through the user interface.

Accessing Information From a Registered Server

Methods Introduced:

- **pfcServer.Server.GetIsActive**
- **pfcServer.Server.GetAlias**
- **pfcServer.Server.GetContext**
- **pfcWPP.WPPServer.GetServerTargetfolder**
- **pfcWPP.WPPServer.SetServerTargetfolder**

The method **pfcServer.Server.GetIsActive** specifies if the server is active.

The method **pfcServer.Server.GetAlias** returns the alias of a server if you specify the codebase URL.

The method **pfcServer.Server.GetContext** returns the active context of the active server.

Note: This function is not supported while working with a Windchill ProductPoint server.

The method **pfcWPP.WPPServer.GetServerTargetfolder** returns a location on the Windchill ProductPoint server where you can save new product items. Specify the location of the target folder on the Windchill ProductPoint server using the method **pfcWPP.WPPServer.SetServerTargetfolder**. These methods are applicable only when working with a Windchill ProductPoint server.

Information on Servers in Session

Methods Introduced:

- **pfcSession.BaseSession.GetActiveServer**
- **pfcSession.BaseSession.GetServerByAlias**
- **pfcSession.BaseSession.GetServerByUrl**
- **pfcSession.BaseSession.ListServers**

The method **pfcSession.BaseSession.GetActiveServer** returns the active server handle.

The method **pfcSession.BaseSession.GetServerByAlias** returns the handle to the server matching the given server alias, if it exists in session.

The method **pfcSession.BaseSession.GetServerByUrl** returns the handle to the server matching the given server URL and workspace name, if it exists in session.

The method **pfcSession.BaseSession.ListServers** returns a list of servers registered in this session.

Accessing Workspaces

For every workspace, a new distinct storage location is maintained in the user's personal folder on the server (server-side workspace) and on the client (client-side workspace cache). Together, the server-side workspace and the client-side workspace cache make up the workspace.

Note: Windchill ProductPoint does not have the concept of a workspace or active workspace. Therefore, many methods in this section are not applicable for this product.

Methods Introduced:

- **pfcServer.pfcServer.WorkspaceDefinition_Create**
- **pfcServer.WorkspaceDefinition.GetWorkspaceName**
- **pfcServer.WorkspaceDefinition.GetWorkspaceContext**
- **pfcServer.WorkspaceDefinition.SetWorkspaceName**
- **pfcServer.WorkspaceDefinition.SetWorkspaceContext**

The interface **pfcServer.WorkspaceDefinition** contains the name and context of the workspace. The method **pfcServer.ServerLocation.CollectWorkspaces** returns an array of workspace data. Workspace data is also required for the method **pfcServer.Server.CreateWorkspace** to create a workspace with a given name and a specific context.

The method **pfcServer.pfcServer.WorkspaceDefinition_Create** creates a new workspace definition object suitable for use when creating a new workspace on the server.

The method **pfcServer.WorkspaceDefinition.GetWorkspaceName** retrieves the name of the workspace.

The method **pfcServer.WorkspaceDefinition.GetWorkspaceContext** retrieves the context of the workspace.

The method **pfcServer.WorkspaceDefinition.SetWorkspaceName** sets the name of the workspace.

The method **pfcServer.WorkspaceDefinition.SetWorkspaceContext** sets the context of the workspace.

Creating and Modifying the Workspace

Methods Introduced:

- **pfcServer.Server.CreateWorkspace**
- **pfcServer.Server.GetActiveWorkspace**
- **pfcServer.Server.SetActiveWorkspace**
- **pfcServer.ServerLocation.DeleteWorkspace**

All methods described in this section, except **pfcServer.Server.GetActiveWorkspace**, are permitted only in the non-interactive mode. Refer to the section, Non-Interactive Mode Operations, for more information.

The method **pfcServer.Server.CreateWorkspace** creates and activates a new workspace.

The method **pfcServer.Server.GetActiveWorkspace** retrieves the name of the active workspace.

The method **pfcServer.Server.SetActiveWorkspace** sets a specified workspace as an active workspace.

The method **pfcServer.ServerLocation.DeleteWorkspace** deletes the specified workspace. The method deletes the workspace only if the following conditions are met:

- The workspace is not the active workspace.
- The workspace does not contain any checked out objects.

Use one of the following techniques to delete an active workspace:

- Make the required workspace inactive using **pfcServer.Server.SetActiveWorkspace** with the name of some other workspace and then call **pfcServer.ServerLocation.DeleteWorkspace**.
- Unregister the server using **pfcServer.Server.Unregister** and delete the workspace.

Workflow to Register a Server

To Register a Server with an Existing Workspace

Perform the following steps to register a Windchill server with an existing workspace:

1. Set the appropriate authentication context using the method **pfcSession.BaseSession.AuthenticateBrowser** with a valid username and password.
2. Look up the list of workspaces using the method **pfcServer.ServerLocation.CollectWorkspaces**. If you already know the name of the workspace on the server, then ignore this step.

3. Register the workspace using the method **pfcSession.BaseSession.RegisterServer** with an existing workspace name on the server.
4. Activate the server using the method **pfcServer.Server.Activate**.

To Register a Server with a New Workspace

Perform the following steps to register a Windchill server with a new workspace:

1. Perform steps 1 to 4 in the preceding section to register the Windchill server with an existing workspace.
2. Use the method **pfcServer.ServerLocation.ListContexts** to choose the required context for the server.
3. Create a new workspace with the required context using the method **pfcServer.Server.CreateWorkspace**. This method automatically makes the created workspace active.

Note: You can create a workspace only after the server is registered.

Aliased URL

An aliased URL serves as a handle to the server objects. You can access the server objects in the commonspace (shared folders) and the workspace using an aliased URL. An aliased URL is a unique identifier for the server object and its format is as follows:

- Object in workspace has a prefix `wtps`

```
wtps://<server_alias>/<workspace_name>/<object_server_name>
```

```
where <object_server_name> includes  
<object_name>.<object_extension>
```

For example,

```
wtps://my_server/my_workspace/abcd.prt,  
wtps://my_server/my_workspace/intf_file.igs
```

where

```
<server_alias> is my_server
```

```
<workspace_name> is my_workspace
```

- Object in commonspace has a prefix `wtpub`

```
wtpub://<server_alias>/<folder_location>/<object_
server_name>
```

For example,

```
wtpub://my_server/path/to/cs_folder/abcd.prt
```

where

<server_alias> is my_server

<folder_location> is path/to/cs_folder

Note:

- object_server_name must be in lowercase.
- The APIs are case-sensitive to the aliased URL.
- <object_extension> should not contain Pro/ENGINEER versions, for example, .1 or .2, and so on.
- For Windchill ProductPoint servers, you can specify a large number of URL variations as long as the base server URL is included. For example,
 - wpp://<Server_Alias>/ProdA/ProENGINEER/Document/jan.prt
 - <Server_Alias>/ProdA/ProENGINEER/Documents/jan.prt


You can also specify only the part name and the object will be accessed from the server, if the server is the default location being explored.

Server Operations

After registering the Windchill server with Pro/ENGINEER, you can start accessing the data on the Windchill servers. The Pro/ENGINEER interaction with Windchill servers leverages the following locations:

- Commonsplace (Shared folders)
- Workspace (Server-side workspace)
- Workspace local cache (Client-side workspace)
- Pro/ENGINEER session
- Local disk

The methods described in this section enable you to perform the basic server operations. The following illustration shows how data is transferred among these locations.



Windchill
Connectivity APIs

Save

Methods Introduced:

- `pfcModel.Model.Save`
- `pfcWPP.pfcWPP.ServerSynchronizeConflict_Create`
- `pfcWPP.WPPServer.SynchronizeServer`
- `pfcWPP.ServerSynchronizeConflict.GetDescription`
- `pfcWPP.WPPServer.GetServerSynchronizationState`

The method **pfcModel.Model.Save** stores the object from the session in the local workspace cache, when a server is active. For Windchill ProductPoint servers, this method saves an existing model to the location from where it was retrieved. To save a new object to a specified location on the ProductPoint server, first use the method **pfcWPP.WPPServer.SetServerTargetfolder** to set the target folder location on the server and then call the method **pfcModel.Model.Save**. If you do not set the target folder location, the method **pfcModel.Model.Save** saves the new objects to the top-level folder of the active product or context.

The method **pfcWPP.pfcWPP.ServerSynchronizeConflict_Create** creates the **ServerSynchronizeConflicts** object containing the description of the conflicts encountered during server synchronization.

The method **pfcWPP.WPPServer.SynchronizeServer** synchronizes the objects in the local cache with the contents in the Windchill ProductPoint server. Specify `NULL` as the value of the input synchronization options. The method returns the synchronization conflict object created by the method **pfcWPP.pfcWPP.ServerSynchronizeConflict_Create**. Use the method **pfcWPP.ServerSynchronizeConflict.GetDescription** to access the description of the synchronization conflict.

The method **pfcWPP.WPPServer.GetServerSynchronizationState** specifies if the contents of the Windchill ProductPoint server are synchronized with the local cache. This method returns true if the server is synchronized, and false, if otherwise.

Upload

An upload transfers Pro/ENGINEER files and any other dependencies from the local workspace cache to the server-side workspace.

Methods Introduced:

- **pfcServer.Server.UploadObjects**
- **pfcServer.Server.UploadObjectsWithOptions**
- **pfcServer.pfcServer.UploadOptions_Create**

The method **pfcServer.Server.UploadObjects** uploads the object to the workspace. The object to be uploaded must be present in the current Pro/ENGINEER session. You must save the object to the workspace using **pfcModel.Model.Save**, or import it into the workspace using **pfcSession.BaseSession.ImportToCurrentWS** before attempting to upload it.

The method **pfcServer.Server.UploadObjectsWithOptions** uploads objects to the workspace using the options specified in the `pfcServer.UploadOptions` interface. These options allow you to upload the entire workspace, auto-resolve missing references, and indicate the target folder location for the new content during the upload. You must save the object to the workspace using **pfcModel.Model.Save**, or import it to the workspace using **pfcSession.BaseSession.ImportToCurrentWS** before attempting to upload it.

Create the `pfcServer.UploadOptions` object using the method **pfcServer.pfcServer.UploadOptions_Create**.

The methods available for setting the upload options are described in the following section.

CheckIn

After you have finished working on objects in your workspace, you can share the design changes with other users. The checkin operation copies the information and files associated with all changed objects from the workspace to the Windchill database.

Note: The methods described in this section are not applicable to Windchill ProductPoint server operations.

Methods Introduced:

- **pfcServer.Server.CheckinObjects**
- **pfcServer.pfcServer.CheckinOptions_Create**
- **pfcServer.UploadBaseOptions.SetDefaultFolder**
- **pfcServer.UploadBaseOptions.SetNonDefaultFolderAssignments**
- **pfcServer.UploadBaseOptions.SetAutoresolveOption**
- **pfcServer.CheckinOptions.SetBaselineName**
- **pfcServer.CheckinOptions.SetBaselineNumber**
- **pfcServer.CheckinOptions.SetBaselineLocation**

- **pfcServer.CheckinOptions.GetBaselineLifecycle**
- **pfcServer.CheckinOptions.SetKeepCheckedout**

The method **pfcServer.Server.CheckinObjects** checks in an object into the database. The object to be checked in must be present in the current Pro/ENGINEER session. Changes made to the object are not included unless you save the object to the workspace using the method **pfcModel.Model.Save** before you check it in.

If you pass `NULL` as the value of the *options* parameter, the checkin operation is similar to the **Auto Check-In** option in Pro/ENGINEER. For more details on **Auto Check-In**, refer to the online help for Pro/ENGINEER.

Use the method **pfcServer.pfcServer.CheckinOptions_Create** to create a new `CheckinOptions` object.

By using an appropriately constructed *options* argument, you can control the checkin operation. Use the APIs listed above to access and modify the checkin options. The checkin options are as follows:

- *DefaultFolder*—Specifies the default folder location on the server for the automatic checkin operation.
- *NonDefaultFolderAssignment*—Specifies the folder location on the server to which the objects will be checked in.
- *AutoresolveOption*—Specifies the option used for auto-resolving missing references. These options are defined in the `ServerAutoresolveOption` class, and are as follows:
 - `SERVER_DONT_AUTORESOLVE`—Model references missing from the workspace are not automatically resolved. This may result in a conflict upon checkin. This option is used by default.
 - `SERVER_AUTORESOLVE_IGNORE`—Missing references are automatically resolved by ignoring them.
 - `SERVER_AUTORESOLVE_UPDATE_IGNORE`—Missing references are automatically resolved by updating them in the database and ignoring them if not found.
- *Baseline*—Specifies the baseline information for the objects upon checkin. The baseline information for a checkin operation is as follows:
 - *BaselineName*—Specifies the name of the baseline.
 - *BaselineNumber*—Specifies the number of the baseline.

The default format for the baseline name and baseline number is “Username + time (GMT) in milliseconds”

- *BaselineLocation*—Specifies the location of the baseline.
- *BaselineLifecycle*—Specifies the name of the lifecycle.
- *KeepCheckedout*—If the value specified is `true`, then the contents of the selected object are checked into the Windchill server and automatically checked out again for further modification.

Retrieval

Standard J-Link provides several methods that are capable of retrieving models. When using these methods with Windchill servers, remember that these methods do not check out the object to allow modifications.

Methods Introduced:

- **`pfcSession.BaseSession.RetrieveModel`**
- **`pfcSession.BaseSession.RetrieveModelWithOpts`**
- **`pfcSession.BaseSession.OpenFile`**

The methods **`pfcSession.BaseSession.RetrieveModel`**, **`pfcSession.BaseSession.RetrieveModelWithOpts`**, and **`pfcSession.BaseSession.OpenFile`** load an object into a session given its name and type. The methods search for the object in the active workspace, the local directory, and any other paths specified by the `search_path` configuration option. For Windchill ProductPoint servers, the method **`pfcSession.BaseSession.RetrieveModelWithOpts`** supports the `instance<generic>` notation for the name of the object.

Checkout and Download

To modify an object from the commonspace, you must check out the object. The process of checking out communicates your intention to modify a design to the Windchill server. The object in the database is locked, so that other users can obtain read-only copies of the object, and are prevented from modifying the object while you have checked it out.

Checkout is often accompanied by a download action, where the objects are brought from the server-side workspace to the local workspace cache. In J-Link, both operations are covered by the same set of methods.

Note: The methods described in this section are not applicable to Windchill ProductPoint server operations.

Methods Introduced:

- **pfcServer.Server.CheckoutObjects**
- **pfcServer.Server.CheckoutMultipleObjects**
- **pfcServer.pfcServer.CheckoutOptions_Create**
- **pfcServer.CheckoutOptions.SetDependency**
- **pfcServer.CheckoutOptions.SetSelectedIncludes**
- **pfcServer.CheckoutOptions.SetIncludeInstances**
- **pfcServer.CheckoutOptions.SetVersion**
- **pfcServer.CheckoutOptions.SetDownload**
- **pfcServer.CheckoutOptions.SetReadOnly**

The method **pfcServer.Server.CheckoutObjects** checks out and optionally downloads the object to the workspace based on the configuration specifications of the workspace. The input arguments of this method are as follows:

- *Mdl*—Specifies the object to be checked out. This is applicable if the model has already been retrieved without checking it out.
- *File*—Specifies the top-level object to be checked out.
- *Checkout*—The checkout flag. If you specify the value of this argument as `true`, the selected object is checked out. Otherwise, the object is downloaded without being checked out. The download action enables you to bring read-only copies of objects into your workspace. This allows you to examine the object without locking it.
- *Options*—Specifies the checkout options object. If you pass `NULL` as the value of this argument, then the default Pro/ENGINEER checkout rules apply. Use the method **pfcServer.pfcServer.CheckoutOptions_Create** to create a new `CheckoutOptions` object.

Use the method **pfcServer.Server.CheckoutMultipleObjects** to check out and download multiple objects to the workspace based on the configuration specifications of the workspace. This method takes the same input arguments as listed above, except for *Mdl* and *File*. Instead it takes the argument *Files* that specifies the sequence of the objects to check out or download.

By using an appropriately constructed *options* argument in the above functions, you can control the checkout operation. Use the APIs listed above to modify the checkout options. The checkout options are as follows:

- *Dependency*—Specifies the dependency rule used while checking out dependents of the object selected for checkout. The types of dependencies given by the `ServerDependency` class are as follows:
 - `SERVER_DEPENDENCY_ALL`—All objects that are dependent on the selected object are checked out.
 - `SERVER_DEPENDENCY_REQUIRED`—All models required to successfully retrieve the originally selected model from the CAD application are selected for checkout.
 - `SERVER_DEPENDENCY_NONE`—None of the dependent objects are checked out.
- *IncludeInstances*—Specifies the rule for including instances from the family table during checkout. The type of instances given by the `ServerIncludeInstances` class are as follows:
 - `SERVER_INCLUDE_ALL`—All the instances of the selected object are checked out.
 - `SERVER_INCLUDE_SELECTED`—The application can select the family table instance members to be included during checkout.
 - `SERVER_INCLUDE_NONE`—No additional instances from the family table are added to the object list.
- *SelectedIncludes*—Specifies the sequence of URLs to the selected instances, if *IncludeInstances* is of type `SERVER_INCLUDE_SELECTED`.
- *Version*—Specifies the version of the checked out object. If this value is set to `NULL`, the object is checked out according to the current workspace configuration.
- *Download*—Specifies the checkout type as `download` or `link`. The value `download` specifies that the object content is downloaded and checked out, while `link` specifies that only the metadata is downloaded and checked out.
- *Readonly*—Specifies the checkout type as a read-only checkout. This option is applicable only if the checkout type is `link`.

The following truth table explains the dependencies of the different control factors in the method **pfcServer.Server.CheckoutObjects** and the effect of different combinations on the end result.

Argument <i>checkout</i> in pfcServer.Server. CheckoutObjects	pfcServer. CheckoutOptio ns.SetDownload	pfcServer. CheckoutOptio ns.SetReadOnly	Result
true	true	NA	Object is checked out and its content is downloaded.
true	true	NA	Object is checked out but content is not downloaded.
false	NA	true	Object is downloaded without checkout.
false	NA	false	Not supported

Undo Checkout

Method Introduced:

- **pfcServer.Server.UndoCheckout**

Use the method **pfcServer.Server.UndoCheckout** to undo a checkout of the specified object. When you undo a checkout, the changes that you have made to the content and metadata of the object are discarded and the content, as stored in the server, is downloaded to the workspace. This method is applicable only for the model in the active Pro/ENGINEER session.

Import and Export

J-Link provides you with the capability of transferring specified objects to and from a workspace. Import and export operations must take place in a session with no models. An import operation transfers a file from the local disk to the workspace.

Methods Introduced:

- **pfcWPP.WPPServer.SetWsimpexFolderoption**
- **pfcSession.BaseSession.ExportFromCurrentWS**

- **pfcSession.BaseSession.ImportToCurrentWS**
- **pfcSession.WSImportExportMessage.GetDescription**
- **pfcSession.WSImportExportMessage.GetFileName**
- **pfcSession.WSImportExportMessage.GetMessageType**
- **pfcSession.WSImportExportMessage.GetResolution**
- **pfcSession.WSImportExportMessage.GetSucceeded**
- **pfcSession.BaseSession.SetWSExportOptions**
- **pfcSession.pfcSession.WSExportOptions_Create**
- **pfcSession.WSExportOptions.SetIncludeSecondaryContent**

The method **pfcWPP.WPPServer.SetWsimpexFolderoption** sets the target folder to import data or the source folder to the Windchill ProductPoint servers or to export data from these servers. Set the target folder location using this method before calls to **pfcSession.BaseSession.ExportFromCurrentWS** and **pfcSession.BaseSession.ImportToCurrentWS**. This function is used for Windchill ProductPoint servers only.

The method **pfcSession.BaseSession.ExportFromCurrentWS** exports the specified objects from the current workspace to a disk in a linked session of Pro/ENGINEER. For Windchill ProductPoint servers this function exports files from the specified source folder location on the server to a disk.

The method **pfcSession.BaseSession.ImportToCurrentWS** imports the specified objects from a disk to the current workspace in a linked session of Pro/ENGINEER. For Windchill ProductPoint servers this method copies files from the local disk to the specified target folder location on the server.

Both **pfcSession.BaseSession.ExportFromCurrentWS** and **pfcSession.BaseSession.ImportToCurrentWS** allow you to specify a dependency criterion to process the following items:

- All external dependencies
- Only required dependencies
- No external dependencies

Both **pfcSession.BaseSession.ExportFromCurrentWS** and **pfcSession.BaseSession.ImportToCurrentWS** return the messages generated during the export or import operation in the form of the `pfcSession.WSImportExportMessages` object. Use the APIs listed above to access the contents of a message. The message specified by the `pfcSession.WSImportExportMessage` object contains the following items:

- **Description**—Specifies the description of the problem or the message information.
- **FileName**—Specifies the object name or the name of the object path.
- **MessageType**—Specifies the severity of the message in the form of the `WSImportExportMessageType` class. The severity is one of the following types:
 - **WSIMPEX_MSG_INFO**—Specifies an informational type of message.
 - **WSIMPEX_MSG_WARNING**—Specifies a low severity problem that can be resolved according to the configured rules.
 - **WSIMPEX_MSG_CONFLICT**—Specifies a conflict that can be overridden.
 - **WSIMPEX_MSG_ERROR**—Specifies a conflict that cannot be overridden or a serious problem that prevents processing of an object.
- **Resolution**—Specifies the resolution applied to resolve a conflict that can be overridden. This is applicable when the message is of the type `WSIMPEX_MSG_CONFLICT`.
- **Succeeded**—Determines whether the resolution succeeded or not. This is applicable when the message is of the type `WSIMPEX_MSG_CONFLICT`.

The method **pfcSession.BaseSession.SetWSExportOptions** sets the export options used while exporting the objects from a workspace in the form of the `pfcSession.WSExportOptions` object. Create this object using the method **pfcSession.pfcSession.WSExportOptions.Create**. The export options are as follows:

- **Include Secondary Content**—Indicates whether or not to include secondary content while exporting the primary Pro/ENGINEER model files. Use the method **pfcSession.WSExportOptions.SetIncludeSecondaryContent** to set this option.

File Copy

J-Link provides you with the capability of copying a file from the workspace or target folder to a location on the disk and vice-versa.

Methods Introduced:

- **pfcSession.BaseSession.CopyFileToWS**
- **pfcSession.BaseSession.CopyFileFromWS**

Use the method **pfcSession.BaseSession.CopyFileToWS** to copy a file from the disk to the workspace. The file can optionally be added as secondary content to a given workspace file. For Windchill ProductPoint servers, use this method to copy a viewable file from disk as a new item in the target folder specified by the method **pfcWPP.WPPServer.SetServerTargetfolder**. If the viewable file is added as secondary content, a dependency is created between the Pro/ENGINEER model and the viewable file.

Use the method **pfcSession.BaseSession.CopyFileFromWS** to copy a file from the workspace to a location on disk. For Windchill ProductPoint servers, use this method to copy a single file from the current target folder specified by the method **pfcWPP.WPPServer.SetServerTargetfolder** to the local disk.

When importing or exporting Pro/ENGINEER models, PTC recommends that you use methods **pfcSession.BaseSession.ImportToCurrentWS** and **pfcSession.BaseSession.ExportFromCurrentWS**, respectively, to perform the import or export operation. Methods that copy individual files do not traverse Pro/ENGINEER model dependencies, and therefore do not copy a fully retrievable set of models at the same time.

Additionally, only the methods **pfcSession.BaseSession.ImportToCurrentWS** and **pfcSession.BaseSession.ExportFromCurrentWS** provide full metadata exchange and support. That means **pfcSession.BaseSession.ImportToCurrentWS** can communicate all the Pro/ENGINEER designated parameters, dependencies, and family table information to a PDM system while **pfcSession.BaseSession.ExportFromCurrentWS** can update exported Pro/ENGINEER data with PDM system changes to designated and system parameters, dependencies, and family table information. Hence PTC recommends the use of **pfcSession.BaseSession.CopyFileToWS** and **pfcSession.BaseSession.CopyFileFromWS** to process only non-Pro/ENGINEER files.

Server Object Status

Methods Introduced:

- **pfcServer.Server.IsObjectCheckedOut**
- **pfcServer.Server.IsObjectModified**

The methods described in this section verify the current status of the object in the workspace. The method **pfcServer.Server.IsObjectCheckedOut** specifies whether the object is checked out for modification.

The method **pfcServer.Server.IsObjectModified** specifies whether the object has been modified since checkout. This method returns the value `false` if newly created objects have not been uploaded.

Note: These methods are not applicable for Windchill ProductPoint server operations.

Object Lock Status

In comparison with other Windchill servers, Windchill ProductPoint does not have the concept of a workspace. This means that as soon as changes are saved to the server, they are visible to all users with access to work-in-progress versions. The functions described in this section enable you to establish an exclusive lock when modifying a server-managed part in Pro/ENGINEER. The functions described in this section are applicable only for Windchill ProductPoint server operations.

Methods Introduced:

- **pfcWPP.WPPServer.LockServerObjects**
- **pfcWPP.pfcWPP.ServerLockConflict_Create**
- **pfcWPP.ServerLockConflict.GetObjectName**
- **pfcWPP.ServerLockConflict.GetConflictMessage**
- **pfcWPP.WPPServer.GetServerObjectLockStatus**
- **pfcWPP.WPPServer.GetServerObjectsLockStatus**
- **pfcWPP.pfcWPP.ServerLockStat_Create**
- **pfcWPP.ServerLockStat.GetObjectName**
- **pfcWPP.ServerLockStat.GetStatus**

- **pfcWPP.ServerLockStat.GetStatusMessage**
- **pfcWPP.WPPServer.UnlockServerObjects**

The method **pfcWPP.WPPServer.LockServerObjects** establishes an explicit lock on the specified objects on the server. Specify the full path, name, and extension for the input objects. This method returns the `pfcServerLockConflict` object that contains the details of conflicts, if any, that occurred during the lock operation. Use the method **pfcWPP.ServerLockConflict.GetObjectName** to access the name of the object for which the lock conflict occurred. Use the method **pfcWPP.ServerLockConflict.GetConflictMessage** to get details of the lock conflict.

The method **pfcWPP.WPPServer.GetServerObjectLockStatus** checks the lock status of the specified object on the Windchill ProductPoint server. Specify the full path, name, and extension for the input object. The method returns the `pfcServerLockStat` object that contains information regarding the lock status.

The method **pfcWPP.WPPServer.GetServerObjectsLockStatus** checks the lock status of a set of objects on the Windchill ProductPoint server. Specify the full path, name, and extension for the input objects. The method returns an array of `pfcServerLockStat` objects that contain information regarding the lock status of the input objects.

Use the method **pfcWPP.ServerLockStat.GetObjectName** to access the name of the object, including the extension, for which the lock status is described.

Use the method **pfcWPP.ServerLockStat.GetStatus** to access the status of the lock on the object on the server.

- **PRO_OBJ_LOCK_STAT_UNSET**—Specifies that no lock has been applied on the object.
- **PRO_OBJ_LOCK_STAT_HARDLOCK**—Specifies that objects are locked and that the current user is not the owner of the locks. Therefore, this user cannot modify or release the lock.
- **PRO_OBJ_LOCK_STAT_SOFTLOCK**—Specifies that the objects are locked and the current user is the owner of the locks. Therefore, this user can release the lock.
- **PRO_OBJ_LOCK_STAT_UNLOCKED**—Specifies that the explicit or implicit lock has been removed from the object and it is available for editing.

Use the method **pfcWPP.ServerLockStat.GetStatusMessage** to access the status of the object on the server. It provides the name of the user who locked the object and the time of locking.

The method **pfcWPP.WPPServer.UnlockServerObjects** unlocks a set of objects that have been explicitly locked on the product server. This method returns the `pfcServerLockConflict` object that contains the details of conflicts, if any, that occurred during the unlock operation.

Delete Objects

Method Introduced:

- **pfcServer.Server.RemoveObjects**

The method **pfcServer.Server.RemoveObjects** deletes the array of objects from the workspace. When passed with the *ModelNames* array as `NULL`, this method removes all the objects in the active workspace.

Conflicts During Server Operations

Method Introduced:

- **pfcExceptions.XToolkitCheckoutConflict.GetConflictDescription**

An exception is provided to capture the error condition while performing the following server operations using the specified APIs:

Operation	API
Checkin an object or workspace	<code>pfcServer.Server.CheckinObjects</code>
Checkout an object	<code>pfcServer.Server.CheckoutObjects</code>
Undo checkout of an object	<code>pfcServer.Server.UndoCheckout</code>
Upload object	<code>pfcServer.Server.UploadObjects</code>
Download object	<code>pfcServer.Server.CheckoutObjects</code> (with <code>download as true</code>)
Delete workspace	<code>pfcServer.ServerLocation.DeleteWorkspace</code>
Remove object	<code>pfcServer.Server.RemoveObjects</code>

These APIs throw a common exception **XToolkitCheckoutConflict** if an error is encountered during server operations. Use the method **pfcExceptions.XToolkitCheckoutConflict.GetConflictDescription** to extract details of the error condition. This description is similar to the description displayed by the Pro/ENGINEER HTML user interface in the conflict report.

Example Code: Server APIs

The following code demonstrates the implementation of the Windchill server APIs described in the previous sections.

```
package com.ptc.jlinkexamples;

import com.ptc.cipjava.*;
import com.ptc.pfc.pfcServer.*;
import com.ptc.pfc.pfcModel.*;
import com.ptc.pfc.pfcSession.*;
import com.ptc.pfc.pfcSolid.*;
import com.ptc.pfc.pfcModel2D.*;
import com.ptc.pfc.pfcModelItem.ParamValue;
import com.ptc.pfc.pfcModelItem.Parameter;
import com.ptc.pfc.pfcModelItem.pfcModelItem;
import com.ptc.pfc.pfcExport.*;
import com.ptc.pfc.pfcFamily.FamColParam;
import com.ptc.pfc.pfcFamily.FamilyMember;
import com.ptc.pfc.pfcFamily.FamilyTableRow;
import com.ptc.pfc.pfcFeature.*;
import com.ptc.pfc.pfcComponentFeat.*;
import com.ptc.pfc.pfcExceptions.*;

import java.util.logging.*;
import java.io.IOException;

import java.util.*;

public class pfcServerExamples
{
    protected Logger logger;
    private FileHandler handler;

    /**
     * The Pro/ENGINEER session.
     */
    protected Session session;

    /**
     * The active server for the session.
     */
}
```

```

private Server activeServer = null;

/**
 * The workspace path for the server (needed to copy content to this
 location).
 */
private String workspacePath = null;

/**
 * Indicator for whether the session is interactive or not.
 */
private boolean interactiveSession = true;

/**
 * Message file name for information to be shown to the user.
 */
private static final String messageFile = "jlexamples.txt";

private static final String locationParamName = "PTC_WM_LOCATION";

private static final String instanceParamName = "PROTK_INSTANCE_PARAM";

private static final String versionParamName = "PTC_WM_VERSION";

/**
 * Builds a workspace path String from the given server and workspace
 */
protected static String makeWSPath (Server server, String workspaceName)
throws JxThrowable
{
return ("wtws://" + server.GetAlias() + "/" + workspaceName);
}

/**
 * Builds a ProjectLink path String from the given server/context
 */
protected String makeProjectLinkFolder (Server server, String path)
throws JxThrowable
{
String serverClass = server.GetClass();

if (serverClass.equals ("ProjectLink"))
{
return ("wtpub://" + server.GetAlias() + "/" + path);
}
else
{
return
("wtpub://" + server.GetAlias() + "/Projects/" + server.GetContext () + "/" + path);
}
}
}

```

```
/**
 * Builds a server path String from the given server and folderpath
 */
protected String makeServerFolder (Server server, String path)
throws jxthrowable
{
return ("wtpub://" + server.GetAlias() + "/" + path);
}

/**
 * Outputs details on a checkout or other server error.
 */
protected void handleConflict (XToolkitCheckoutConflict xtcc)
{
try
{
String conflictDescription = xtcc.GetConflictDescription();

logger.log(Level.WARNING, "Conflict occurred: ", xtcc);
logger.log(Level.WARNING, "Conflict details: " + conflictDescription);

if (interactiveSession)
{
stringseq messageArguments = stringseq.create();
messageArguments.set(0, conflictDescription);
session.UIDisplayLocalizedMessage(messageFile, "JLServerEX Conflict",
messageArguments);
}
else
{
System.out.println ("Conflict occurred: " + xtcc);
}
}
catch (jxthrowable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
}

public void addInstance ()
{
try
{
String targetFolder = null;

/*-----*\
Check if the current object is modifiable.
\*-----*/
```

```

Server activeServer = session.GetActiveServer();

Model model = session.GetCurrentModel();

Parameter locationParam = model.GetParam(locationParamName);

if (locationParam != null)
{
String locationParamValue = locationParam.GetValue().GetStringValue();

if (locationParamValue.length() > 0)
{
targetFolder = makeServerFolder (activeServer, locationParamValue);
}
}

boolean modifiable =
activeServer.IsObjectCheckedOut(activeServer.GetActiveWorkspace(),
model.GetFileName());

if (!modifiable)
{
activeServer.CheckoutObjects(null, model.GetFileName(), true, null);
}

/*-----*\
Look for a parameter used by this example.  If its not in the
model, create it.
\*-----*/
Parameter instanceParam = model.GetParam(instanceParamName);

if (instanceParam == null)
{
ParamValue instanceParamValue =
pfcModelItem.CreateStringParamValue("Generic");
instanceParam = model.CreateParam(instanceParamName, instanceParamValue);
}

/*-----*\
Add the parameter to the family table, if not already present.
\*-----*/

FamilyMember genericModel = (FamilyMember)model;

FamColParam column = genericModel.CreateParamColumn(instanceParam);
if (genericModel.GetColumn(column.GetSymbol()) == null)
genericModel.AddColumn(column, null);

/*-----*\
Use the version of the model to construct a unique new instance
name for this example.
\*-----*/

```

```

\*-----*/
Parameter versionParam = model.GetParam(versionParamName);

String version = versionParam.GetValue().GetStringValue();

String instanceName = model.GetInstanceName().toLowerCase() + "_" +
version.replace('.', '_');

/*-----*\
Add the new instance and set the value of the example parameter
for this instance.
\*-----*/

FamilyTableRow newInstance = genericModel.AddRow(instanceName, null);

ParamValue instanceValue = pfcModelItem.CreateStringParamValue("Instance
"+ version);
genericModel.SetCell(column, newInstance, instanceValue);

/*-----*\
Instantiate the instance. This also serves to verify the
instance, allowing it to be checked in.
\*-----*/

Model instance = newInstance.CreateInstance();


instance.Erase();

/*-----*\
Save and checkin the changed model.
\*-----*/
model.Save();

activeServer.CheckinObjects(model, null);
}
catch (XToolkitCheckoutConflict xtcc)
{
handleConflict (xtcc);
}
catch (jxthrowable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
catch (Throwable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
}

/**
 * Action for each part in the assembly. Checkout the part,

```



```

* export it to IGES, and copy the result as secondary content to
* the part in the workspace.
*/
private boolean convertModelToIGES (Model model) throws jxthrowable
{
activeServer.CheckoutObjects(model, null, true, null);

ExportInstructions instrs;
GeometryFlags flags = pfcExport.GeometryFlags_Create();
flags.SetAsSolids(true);
IGES3DNewExportInstructions igesInstrs =

pfcExport.IGES3DNewExportInstructions_Create(AssemblyConfiguration.EXPORT
_ASM_SINGLE_FILE,
flags);
instrs = igesInstrs;
String outputPath = model.GetInstanceName().toLowerCase() + ".igs";

model.Export(outputPath, instrs);

session.CopyFileToWS(outputPath, workspacePath, model.GetFileName());

return true;
}

/**
* Recursive method to collect a list of distinct component parts in the
assembly
*/
private HashMap buildAssemblyPartMap (Solid solid, HashMap map) throws
jxthrowable
{
/*-----*\
If the part is not already in the map, add it, unless its an instance.
If its an instance, add the generic instead.
\*-----*/
if (solid.GetType() == ModelType.MDL_PART)
{
String genericName = solid.GetGenericName();

while (genericName != null)
{
solid = (Solid)solid.GetParent();
genericName = solid.GetGenericName();
}
String modelName = solid.GetFileName();
if (!map.containsKey(modelName))
{
map.put(modelName, solid);
}
}
}

```

```

else
{
/*-----*\
Process all subcomponents in the assembly
\*-----*/
Features components = solid.ListFeaturesByType(Boolean.TRUE,
FeatureType.FEATTYPE_COMPONENT);
if (components != null)
{
for (int i = 0; i < components.getarraysize(); i++)
{
ComponentFeat component = (ComponentFeat)components.get(i);
ModelDescriptor descr = component.GetModelDescr();
Solid componentModel = (Solid)session.GetModelFromDescr(descr);

buildAssemblyPartMap (componentModel, map);
}
}
return map;
}

/**
 * Add an IGES file as secondary content for each part in the assembly.
 */
public void addIGESToAllParts ()
{
/*-----*\
Get the target models to be processed: the active part or assembly,
or the current solid in the active drawing
\*-----*/
try
{
Model m = session.GetCurrentModel();

if (m.GetType() == ModelType.MDL_DRAWING)
{
Model2D m2d = (Model2D) m;

m = m2d.ListModels().get(0);
}

/*-----*\
Save some details about the active server to use for each visited
model.
\*-----*/
activeServer = session.GetActiveServer();
String workspaceName = activeServer.GetActiveWorkspace();
workspacePath = makeWSPath (activeServer, workspaceName);

/*-----*\

```

```

Process the single part, or all displayed parts in the assembly
/*-----*/
if (m.GetType() == ModelType.MDL_PART)
{
convertModelToIGES (m);
}
else
{
HashMap allModels = new HashMap ();
allModels = buildAssemblyPartMap ((Solid)m, allModels);

Iterator models = allModels.values().iterator();
while (models.hasNext())
{
Model partModel = (Model)models.next();
convertModelToIGES (partModel);
}
}

/*-----*\
Check in all changes
/*-----*/
activeServer.CheckinObjects(null, null);

session.UIDisplayMessage(messageFile, "JLServerEX parts succeeded",
null);
}
catch (XToolkitCheckoutConflict xtcc)
{
handleConflict (xtcc);
}
catch (jxthrowable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
catch (Throwable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
}

/**
 * Add a primary content DXF file to the server (generated from the active
drawing).
 */
public void createOrUpdateDXF ()
{
/*-----*\
Obtain current drawing handle and export to DXF
/*-----*/
try

```



```
{
activeServer = session.GetActiveServer();
String workspaceName = activeServer.GetActiveWorkspace();
workspacePath = makeWSPath (activeServer, workspaceName);

Model m = session.GetCurrentModel();

String dxfName = m.GetFullName().toLowerCase()+"_drw.dxf";

DXFExportInstructions exportInstructions =
pfcModel.DXFExportInstructions_Create();

m.Export(dxfName, exportInstructions);

/*-----*\
If the DXF file already exists in the project, check it out by its
object name.
\*-----*/

try
{
String dxfPath = activeServer.GetAliasedUrl(dxfName);
if (dxfPath != null)
{
activeServer.CheckoutObjects(null, dxfName, true, null);
}
}
catch (XToolkitNotFound xtnf)
{
/*-----*\
Ignore XToolkitNotFound as this signals that the file is not already
on the server.
\*-----*/
}

/*-----*\
Get the full disk path to the output DXF file as the source of the
File Copy operation.
\*-----*/
String currentDirectory = session.GetCurrentDirectory();

String diskDXFPath = currentDirectory + dxfName;

/*-----*\
Copy the file to the workspace as a top-level object.
\*-----*/
session.CopyFileToWS(diskDXFPath, workspacePath, null);

/*-----*\
Checkin the workspace. If the object is new, it will go to
the Plans folder.
```

```

\*-----*/
String plansFolder = makeProjectLinkFolder (activeServer, "Plans");

CheckinOptions options = pfcServer.CheckinOptions_Create();
options.SetDefaultFolder(plansFolder);

activeServer.CheckinObjects(null, options);

session.UIDisplayMessage(messageFile, "JLServerEX DXF succeeded", null);
}
catch (XToolkitCheckoutConflict xtcc)
{
handleConflict (xtcc);
}
catch (jxthrowable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
}

public void importAndCheckinModelsInteractive ()
{
try
{
/*-----*\
Prompt user to select folder containing models to import
\*-----*/
session.UIDisplayLocalizedMessage(messageFile, "JLServerEX Enter the
directory", null);

String modelsPath = session.UIReadStringMessage(Boolean.FALSE);

stringseq designModels = session.ListFiles("*.prt,*.asm",
FileListOpt.FILE_LIST_LATEST, modelsPath);

stringseq planModels = session.ListFiles("*.drw",
FileListOpt.FILE_LIST_LATEST, modelsPath);

if (designModels.getarraysize() == 0 && planModels.getarraysize() == 0)
{
stringseq texts = stringseq.create();
texts.append(modelsPath);
session.UIDisplayLocalizedMessage(messageFile, "JLServerEX No models
found", texts);
}
else
{
importAndCheckinModels (designModels, planModels);
session.UIDisplayLocalizedMessage(messageFile, "JLServerEX Import and
checkin completed", null);
}
}
}

```

```
}
catch (XToolkitCheckoutConflict xtcc)
{
handleConflict (xtcc);
}
catch (jxthrowable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
catch (Exception x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}
}

public void importAndCheckinModels (stringseq designModels, stringseq
planModels)
{
try
{
/*-----*\
Import part and assembly models.
\*-----*/

activeServer = session.GetActiveServer();

if (designModels != null)
{
session.ImportToCurrentWS (designModels, RelCriterion.FILE_INCLUDE_ALL);
}

String designFolder = makeProjectLinkFolder (activeServer, "Designs");

/*-----*\
Prepare the checkin options; by default the imported parts
and assemblies go in the "Designs" folder.
\*-----*/
CheckinOptions options = pfcServer.CheckinOptions_Create();
options.SetDefaultFolder(designFolder);

/*-----*\
Import drawing models.
\*-----*/
if (planModels != null)
{
session.ImportToCurrentWS (planModels, RelCriterion.FILE_INCLUDE_NONE);

/*-----*\
The imported drawings go in the "Plans" folder.
\*-----*/
String plansFolder = makeProjectLinkFolder (activeServer, "Plans");
```

```

FolderAssignments assignments = FolderAssignments.create();
for (int i = 0; i < planModels.getarraysize(); i++)
{
/*-----*\
Each item is assigned to the checkin options using its
model name.
\*-----*/
String drawingPath = planModels.get(i);
String drawingName =
drawingPath.substring(drawingPath.lastIndexOf("\\")+1);

FolderAssignment assignment =
pfcServer.FolderAssignment_Create(plansFolder, drawingName);
assignments.append(assignment);
}
options.SetNonDefaultFolderAssignments(assignments);
}

/*-----*\
Check in the entire workspace using the options.
\*-----*/
activeServer.CheckinObjects(null, options);

/*-----*\
Clean the workspace, and free allocated memory
\*-----*/
activeServer.RemoveObjects(null);
}
catch (XToolkitCheckoutConflict xtcc)
{
handleConflict (xtcc);
}
catch (jxthrowable x)
{
logger.log(Level.SEVERE, "Caught exception: ", x);
}

}

public pfcServerExamples (Session s)
{
session = s;
try
{
handler = new FileHandler ("pfcServerExamples.log");
logger = Logger.global;
logger.addHandler(handler);
}
catch (IOException e)

```

```

{
System.out.println ("Caught exception initializing log file: " + e);
}
}
}

```

Utility APIs

The methods specified in this section enable you to obtain the handle to the server objects to access them. The handle may be the aliased URL or the model name of the http URL. These utilities enable the conversion of one type of handle to another.

Methods Introduced:

- **pfcServer.Server.GetAliasedUrl**
- **pfcSession.BaseSession.GetModelNameFromAliasedUrl**
- **pfcSession.BaseSession.GetAliasFromAliasedUrl**
- **pfcSession.BaseSession.GetUrlFromAliasedUrl**

The method **pfcServer.Server.GetAliasedUrl** enables you to search for a server object by its name. Specify the complete filename of the object as the input, for example, `test_part.prt`. The method returns the aliased URL for a model on the server. For more information regarding the aliased URL, refer to the section Aliased URL. During the search operation, the workspace takes precedence over the shared space.

You can also use this method to search for files that are not in the Pro/ENGINEER format. For example, `my_text.txt`, `prodev.dat`, `intf_file.stp`, and so on.

The method **pfcSession.BaseSession.GetModelNameFromAliasedUrl** returns the name of the object from the given aliased URL on the server.

The method **pfcSession.BaseSession.GetUrlFromAliasedUrl** converts an aliased URL to a standard URL for the objects on the server.

For example, `wtws://my_alias/Wildfire/abcd.prt` is converted to an appropriate URL on the server as `http://server.mycompany.com/Windchill`.

For Windchill ProductPoint, the aliased URL
wpp://<Server_Alias>/ProdA/ProENGINEER/Document/jan.
prt is converted to an appropriate URL on server, for example,
http://server.mycompany.com/.

The method **pfcSession.BaseSession.GetAliasFromAliasedUrl**
returns the server alias from aliased URL.

Sample Batch Workflow

A typical workflow using the Windchill APIs for an asynchronous non-graphical application is as follows:

1. Start a Pro/ENGINEER session using the method **pfcAsyncConnection.pfcAsyncConnection.AsyncConnection_Connect**.
2. Authenticate the browser using the method **pfcSession.BaseSession.AuthenticateBrowser**.
3. Register the server with the new workspace using the method **pfcSession.BaseSession.RegisterServer**.
4. Activate the server using the method **pfcServer.Server.Activate**.
5. Check out and retrieve the model from the vault URL using the method **pfcServer.Server.CheckoutObjects** followed by **pfcSession.BaseSession.RetrieveModel**.
6. Modify the model according to the application logic.
7. Save the model to the workspace using the method **pfcModel.Model.Save**.
8. Check in the modified model back to the server using the method **pfcServer.Server.CheckinObjects**.
9. After processing all models, unregister from the server using the method **pfcServer.Server.Unregister**.
10. Delete the workspace using **pfcServer.ServerLocation.DeleteWorkspace**.
11. Stop Pro/ENGINEER using the method **pfcAsyncConnection.AsyncConnection.End**.

A

Summary of Technical Changes

This appendix contains a list of new and enhanced capabilities for J-Link under Pro/ENGINEER Wildfire 5.0. See the APIWizard online browser for complete descriptions of the functions.

Each release of J-Link includes a README file in the loadpoint directory. Check the README file for the most current information.

Topic	Page
Critical Technical Changes	A - 2
New Methods	A - 3
Superseded Methods	A - 13
Miscellaneous Technical Changes	A - 13

Note: Reference information on all capabilities is available in the J-Link APIWizard online browser. Use the APIWizard **Search** function to find information on a function. See section “Online Documentation—J-Link API Wizard” for information on the APIWizard.

Critical Technical Changes

This section describes the changes in Pro/ENGINEER Wildfire 5.0 and J-Link that might require alteration of existing J-Link applications.

pfcdetail.DetailSymbolInstItem.GetInstructions

The method **pfcdetail.DetailSymbolInstItem.GetInstructions** now takes a new *Boolean* argument `GiveParametersAsNames`. Set this argument to `true` to display symbolic representations of parameters and drawing properties in the symbol instance. Set it to `false` to display the actual text seen by the user. To ensure that the compilation succeeds, rebuild your existing J-Link applications calling the method **pfcdetail.DetailSymbolInstItem.GetInstructions**.

Printing Instructions

The interface `pfcdetail.PlotInstructions` containing the instructions for plotting files has been deprecated. Existing J-Link methods for creating and accessing the instruction attributes have also been deprecated. Use the new interface type `pfcdetail.PrinterInstructions` and its methods instead. Refer to the Superseded Methods section for the complete list of methods that have been deprecated.

The following new interface types have also been added:

- `pfcdetail.PrintPrinterOption` for printer settings
- `pfcdetail.PrintMdlOption` for the definition of the model for printing
- `pfcdetail.PrintPlacementOption` for the placement options for use while printing
- `pfcdetail.PrinterPCFOptions` for the definition of the printing options for a Plotter Configuration File (PCF)

No-Resolve Mode

Pro/ENGINEER Wildfire 5.0 introduces No-Resolve mode, wherein if a model and feature regeneration fails, failed features and children of failed features are created and the regeneration of other features continues. By default, Pro/ENGINEER Wildfire 5.0 operates in No-Resolve mode. However, J-Link does not support regeneration in this mode. If Pro/ENGINEER is running in No-Resolve mode, the methods **pfcSolid.Solid.Regenerate** and **pfcSolid.Solid.ExecuteFeatureOps** throw an exception `pfcExceptions.XToolkitBadContext`.

To continue with the behavior of Pro/ENGINEER Wildfire 4.0 in Resolve mode, set the configuration option `regen_failure_handling` to `resolve_mode` in the Pro/ENGINEER session. Setting the configuration option to switch to Resolve mode ensures the old behavior as long as you do not retrieve the models saved under No-Resolve mode. To consistently preserve the old behavior, use Resolve mode from the beginning and throughout your Pro/ENGINEER session.

New Methods

The following section describes the new J-Link methods.

2D Export

New Method	Description
<p><code>pfcModel.pfcModel.MedusaExportInstructions_Create</code></p>	<p>Creates a new instructions object for export of a drawing in EXPORT_MEDUSA format (using <code>pfcModel.Model.Export</code>).</p>
<p><code>pfcModel.pfcModel.Export2DOption_Create</code> <code>pfcModel.Export2DOption.SetExportSheetOption</code> <code>pfcModel.Export2DOption.SetModelSpaceSheet</code> <code>pfcModel.Export2DOption.SetSheets</code></p>	<p>Accesses the options to export multiple sheets of a drawing to 2D formats.</p>

3D Export

New Method	Description
<p>pfcExport.pfcExport.CatiaPart3DExportInstructions_Create</p> <p>pfcExport.pfcExport.CatiaProduct3DExportInstructions_Create</p> <p>pfcExport.pfcExport.CatiaCGR3DExportInstructions_Create</p> <p>pfcExport.pfcExport.JT3DExportInstructions_Create</p> <p>pfcExport.pfcExport.ParaSolid3DExportInstructions_Create</p> <p>pfcExport.Export.UG3DExportInstructions_Create</p>	<p>Creates a new instructions object for import of the following 3D import formats:</p> <ul style="list-style-type: none"> • EXPORT_CATIA_PART • EXPORT_CATIA_PRODUCT • EXPORT_CATIA_CGR • EXPORT_JT • EXPORT_PARASOLID • EXPORT_UG

Datum Features

New Method	Description
Datum Plane Feature	
<p>pfcDatumPlaneFeat.DatumPlaneFeat.GetFlip</p> <p>pfcDatumPlaneFeat.DatumPlaneFeat.GetConstraints</p> <p>pfcDatumPlaneFeat.DatumPlaneConstraint.GetConstraintType</p> <p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneThroughConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneThroughConstraint.GetThroughRef</p> <p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneNormalConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneNormalConstraint.GetNormalRef</p> <p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneParallelConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneParallelConstraint.GetParallelRef</p>	<p>Provides read access to the properties of the Datum Plane feature.</p>

New Method	Description
<p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneTangentConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneTangentConstraint.GetTangentRef</p> <p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneOffsetConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneOffsetConstraint.GetOffsetRef</p> <p>pfcDatumPlaneFeat.DatumPlaneOffsetConstraint.GetOffsetValue</p> <p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneOffsetCoordSysConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneOffsetCoordSysConstraint.GetCsysAxis</p> <p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneAngleConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneAngleConstraint.GetAngleRef</p> <p>pfcDatumPlaneFeat.DatumPlaneAngleConstraint.GetAngleValue</p> <p>pfcDatumPlaneFeat.pfcDatumPlaneFeat.DatumPlaneSectionConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneSectionConstraint.GetSectionRef</p> <p>pfcDatumPlaneFeat.DatumPlaneSectionConstraint.GetSectionIndex</p> <p>pfcDatumPlaneFeat.DatumPlaneDefaultXConstraint.DatumPlaneDefaultXConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneDefaultYConstraint.DatumPlaneDefaultYConstraint_Create</p> <p>pfcDatumPlaneFeat.DatumPlaneDefaultZConstraint.DatumPlaneDefaultZConstraint_Create</p>	<p>Provides read access to the properties of the Datum Plane feature.</p>
Datum Axis Feature	
<p>pfcDatumAxisFeat.DatumAxisFeat.GetConstraints</p> <p>pfcDatumAxisFeat.pfcDatumAxisFeat.DatumAxisConstraint_Create</p> <p>pfcDatumAxisFeat.DatumAxisConstraint.GetConstraintType</p>	<p>Provides read access to the properties of the Datum Axis feature.</p>

New Method	Description
<p>pfcDatumAxisFeat.DatumAxisConstraint.GetConstraintRef</p> <p>pfcDatumAxisFeat.DatumAxisFeat.GetDimConstraints</p> <p>pfcDatumAxisFeat.pfcDatumAxisFeat.DatumAxisDimensionConstraint_Create</p> <p>pfcDatumAxisFeat.DatumAxisDimensionConstraint.GetDimOffset</p> <p>pfcDatumAxisFeat.DatumAxisDimensionConstraint.GetDimRef</p>	<p>Provides read access to the properties of the Datum Axis feature.</p>
General Datum Point Feature	
<p>pfcDatumPointFeat.DatumPointFeat.GetFeatName</p> <p>pfcDatumPointFeat.DatumPointFeat.GetPoints</p> <p>pfcDatumPointFeat.GeneralDatumPoint.GetName</p> <p>pfcDatumPointFeat.pfcDatumPointFeat.DatumPointPlacementConstraint_Create</p> <p>pfcDatumPointFeat.GeneralDatumPoint.GetPlaceConstraints</p> <p>pfcDatumPointFeat.pfcDatumPointFeat.DatumPointDimensionConstraint_Create</p> <p>pfcDatumPointFeat.GeneralDatumPoint.GetDimConstraints</p> <p>pfcDatumPointFeat.DatumPointConstraint.GetConstraintRef</p> <p>pfcDatumPointFeat.DatumPointConstraint.GetConstraintType</p> <p>pfcDatumPointFeat.DatumPointConstraint.GetValue</p>	<p>Provides read access to the properties of the General Datum Point feature.</p>
Datum Coordinate System Feature	
<p>pfcCoordSysFeat.CoordSysFeat.GetOriginConstraints</p> <p>pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysOriginConstraint_Create</p> <p>pfcCoordSysFeat.DatumCsysOriginConstraint.GetOriginRef</p> <p>pfcCoordSysFeat.CoordSysFeat.GetDimensionConstraints</p>	<p>Provides read access to the properties of the Datum Coordinate System feature.</p>

New Method	Description
<p>pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysDimensionConstraint_Create</p> <p>pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimRef</p> <p>pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimValue</p> <p>pfcCoordSysFeat.DatumCsysDimensionConstraint.GetDimConstraintType</p> <p>pfcCoordSysFeat.CoordSysFeat.GetOrientationConstraints</p> <p>pfcCoordSysFeat.pfcCoordSysFeat.DatumCsysOrientMoveConstraint_Create</p> <p>pfcCoordSysFeat.DatumCsysOrientMoveConstraint.GetOrientMoveConstraintType</p> <p>pfcCoordSysFeat.DatumCsysOrientMoveConstraint.GetOrientMoveValue</p> <p>pfcCoordSysFeat.CoordSysFeat.GetIsNormalToScreen</p> <p>pfcCoordSysFeat.CoordSysFeat.GetOffsetType</p> <p>pfcCoordSysFeat.CoordSysFeat.GetOnSurfaceType</p> <p>pfcCoordSysFeat.CoordSysFeat.GetOrientByMethod</p>	<p>Provides read access to the properties of the Datum Coordinate System feature.</p>

Drawing Sheets

New Method	Description
<p>pfcSheet.SheetOwner.GetSheetFormatDescr</p>	<p>Returns the model descriptor of the drawing format used for the specified drawing sheet.</p>

Export to PDF

New Method	Description
pfcExport.pfcExport.PDFExportInstructions_Create	Creates a new instructions object for export to PDF format (using pfcModel.Model.Export).
pfcExport.PDFExportInstructions.SetFilePath pfcExport.PDFExportInstructions.SetOptions	Accesses the instructions for export to PDF.
pfcExport.pfcExport.PDFOption_Create pfcExport.PDFOption.SetOptionType pfcExport.PDFOption.SetOptionValue	Accesses the options required for export to PDF.

Family Tables

New Method	Description
pfcFamily.FamilyMember.GetImmediateGenericInfo	Returns the model descriptor of the immediate generic model.
pfcFamily.FamilyMember.GetTopGenericInfo	Returns the model descriptor of the top generic model.
pfcFamily.FamilyMember.GetCellIsDefault	Determines if the item in the specified cell has the default value. The default value is the value of the specified item in the generic model.

Models

New Method	Description
pfcSession.BaseSession.GetActiveModel	Returns the active Pro/ENGINEER model.

Printing Files

New Method	Description
Printing Instructions	
pfcExport.pfcExport.PrinterInstructions_Create	Creates the pfcExport.PrinterInstructions object.
pfcExport.PrinterInstructions.SetPrinterOption pfcExport.PrinterInstructions.SetPlacementOption pfcExport.PrinterInstructions.SetModelOption pfcExport.PrinterInstructions.SetWindowId	Accesses and modifies the plotting instructions.
Printer Options	
pfcExport.pfcExport.PrintPrinterOption_Create	Creates the pfcExport.PrintPrinterOption object.
pfcSession.BaseSession.GetPrintPrinterOptions	Returns the pfcExport.PrintPrinterOption object containing the printer options.
pfcExport.PrintPrinterOption.SetDeleteAfter pfcExport.PrintPrinterOption.SetFileName pfcExport.PrintPrinterOption.SetPaperSize pfcExport.Export.PrintSize_Create pfcExport.PrintSize.SetHeight pfcExport.PrintSize.SetWidth pfcExport.PrintSize.SetPaperSize pfcExport.PrintPrinterOption.SetPenTable pfcExport.PrintPrinterOption.SetPrintCommand pfcExport.PrintPrinterOption.SetPrinterType pfcExport.PrintPrinterOption.SetQuantity pfcExport.PrintPrinterOption.SetRollMedia pfcExport.PrintPrinterOption.SetRotatePlot pfcExport.PrintPrinterOption.SetSaveMethod pfcExport.PrintPrinterOption.SetSaveToFile pfcExport.PrintPrinterOption.SetSendToPrinter pfcExport.PrintPrinterOption.SetSlew	Accesses and modifies the options for a specified printer.

New Method	Description
pfcExport.PrintPrinterOption.SetSwHandshake pfcExport.PrintPrinterOption.SetUseTtf	Accesses and modifies the options for a specified printer.
Placement Options	
pfcExport.pfcExport.PrintPlacementOption_Create	Creates the pfcExport.PrintPlacementOption object.
pfcSession.BaseSession.GetPrintPlacementOptions	Returns the pfcExport.PrintPlacementOption object containing the placement options.
pfcExport.PrintPlacementOption.SetBottomOffset pfcExport.PrintPlacementOption.SetClipPlot pfcExport.PrintPlacementOption.SetKeepPanzoom pfcExport.PrintPlacementOption.SetLabelHeight pfcExport.PrintPlacementOption.SetPlaceLabel pfcExport.PrintPlacementOption.SetScale pfcExport.PrintPlacementOption.SetShiftAllCorner pfcExport.PrintPlacementOption.SetSideOffset pfcExport.PrintPlacementOption.SetX1ClipPosition pfcExport.PrintPlacementOption.SetX2ClipPosition pfcExport.PrintPlacementOption.SetY1ClipPosition pfcExport.PrintPlacementOption.SetY2ClipPosition	Accesses and modifies the placement options.
Model Options	
pfcExport.pfcExport.PrintMdlOption_Create	Creates the pfcExport.PrintMdlOption object.
pfcSession.BaseSession.GetPrintMdlOptions	Returns the pfcExport.PrintMdlOption object containing the model options for printing purpose.

New Method	Description
<p> <code>pfcExport.PrintMdlOption.SetDrawFormat</code> <code>pfcExport.PrintMdlOption.SetFirstPage</code> <code>pfcExport.PrintMdlOption.SetLastPage</code> <code>pfcExport.PrintMdlOption.SetLayerName</code> <code>pfcExport.PrintMdlOption.SetLayerOnly</code> <code>pfcExport.PrintMdlOption.SetMdl</code> <code>pfcExport.PrintMdlOption.SetQuality</code> <code>pfcExport.PrintMdlOption.SetSegmented</code> <code>pfcExport.PrintMdlOption.SetSheets</code> <code>pfcExport.PrintMdlOption.SetUseDrawingSize</code> <code>pfcExport.PrintMdlOption.SetUseSolidScale</code> </p>	<p>Accesses and modifies the model options.</p>
<p>Plotter Configuration File (PCF) Option</p>	
<p><code>pfcExport.pfcExport.PrinterPCFOptions_Create</code></p>	<p>Creates the <code>pfcExport.PrinterPCFOptions</code> object.</p>
<p><code>pfcSession.BaseSession.GetPrintPCFOptions</code></p>	<p>Returns the <code>pfcExport.PrinterPCFOptions</code> object containing the printing options for a Plotter Configuration File (PCF).</p>
<p> <code>pfcExport.PrinterPCFOptions.SetPrinterOption</code> <code>pfcExport.PrinterPCFOptions.SetPlacementOption</code> <code>pfcExport.PrinterPCFOptions.SetModelOption</code> </p>	<p>Accesses and modifies the printing options for a Plotter Configuration File (PCF).</p>

User Interface

New Method	Description
<p>File > Open</p>	
<p> <code>pfcSession.BaseSession.UIRegisterFileOpen</code> <code>pfcUI.pfcUI.FileOpenRegisterOptions_Create</code> <code>pfcUI.FileOpenRegisterOptions.SetFileDescription</code> <code>pfcUI.FileOpenRegisterOptions.SetFileType</code> <code>pfcUI.FileOpenRegisterListener.FileOpenAccess</code> <code>pfcUI.FileOpenRegisterListener.OnFileOpenRegister</code> </p>	<p>Adds a new file type in the Open dialog box.</p>

New Method	Description
File > Save	
pfcSession.BaseSession.UIRegisterFileSave pfcUI.pfcUI.FileSaveRegisterOptions_Create pfcUI.FileSaveRegisterOptions.SetFile Description pfcUI.FileSaveRegisterOptions.SetFileType pfcUI.FileSaveRegisterListener.FileSaveAccess pfcUI.FileSaveRegisterListener.OnFileSave Register	Adds a new file type in the Save a Copy dialog box.
Navigation Area	
pfcSession.Session.NavigatorPaneBrowserAdd pfcSession.Session.NavigatorPaneBrowserIconSet pfcSession.Session.NavigatorPaneBrowserURL Set	Adds custom panes containing custom Web pages to the Navigation area.

Utility

New Method	Description
Pro/TOOLKIT DLL	
pfcSession.BaseSession.LoadProToolkitLegacyDll	Registers and starts a legacy Pro/TOOLKIT DLL that is not Unicode-compliant and built in the pre-Wildfire 4.0 environment.

Pro/ENGINEER Window

New Method	Description
Window ID	
pfcWindow.Window.GetId	Retrieves the ID of the Pro/ENGINEER window.

Superseded Methods

The following table lists the superseded methods in this release.

New Method	Description
pfcModel.pfcModel.PlotInstructions.Create	pfcExport.pfcExport.PrinterInstructions.Create
pfcModel.PlotInstructions.SetPlotterName	pfcExport.PrinterInstructions.SetPrinterOption
pfcModel.PlotInstructions.SetOutputQuality	pfcExport.PrinterInstructions.SetPlacementOption
pfcModel.PlotInstructions.SetUserScale	pfcExport.PrinterInstructions.SetModelOption
pfcModel.PlotInstructions.SetPenSlew	pfcExport.PrinterInstructions.SetWindowId
pfcModel.PlotInstructions.SetPenVelocityX	
pfcModel.PlotInstructions.SetPenVelocityY	
pfcModel.PlotInstructions.SetSegmentedOutput	
pfcModel.PlotInstructions.SetLabelPlot	
pfcModel.PlotInstructions.SetSeparatePlotFiles	
pfcModel.PlotInstructions.SetPaperSize	
pfcModel.PlotInstructions.SetPageRangeChoice	
pfcModel.PlotInstructions.SetPaperSizeY	
pfcModel.PlotInstructions.SetFirstPage	
pfcModel.PlotInstructions.SetLastPage	

Summary of Technical Changes

Miscellaneous Technical Changes

The following changes in Pro/ENGINEER Wildfire 5.0 can affect functional behavior in J-Link. PTC does not anticipate that these changes cause critical issues with existing J-Link applications.

3D Import Formats

The class `pfcImport.NewModelImportType` now contains new 3D import formats. The J-Link method **`pfcSession.BaseSession.ImportNewModel`** supports the following new import formats:

- `IMPORT_NEW_CATIA_PART`
- `IMPORT_NEW_UG`
- `IMPORT_NEW_PRODUCTVIEW`

- IMPORT_NEW_CATIA_CGR
- IMPORT_NEW_JT

The class `pfcModel.IntfType` also contains new 3D feature import formats. The J-Link method **pfcSolid.Solid.CreateImportFeat** supports the following new import formats:

- INTF_ICEM
- INTF_ACIS
- INTF_DXF
- INTF_CDRS
- INTF_STL
- INTF_VRML
- INTF_PARASOLID
- INTF_AI
- INTF_CATIA_PART
- INTF_UG
- INTF_PRODUCTVIEW
- INTF_CATIA_CGR
- INTF_JT

Datum Features Properties

J-Link now provides read access to the properties of Datum features. The table below lists the Datum features supported and the new packages in which their properties and the corresponding read methods have been defined:

Datum Feature	J-Link Package
Datum Plane feature	<code>com.ptc.pfc.pfcDatumPlaneFeat</code>
Datum Axis feature	<code>com.ptc.pfc.pfcDatumAxisFeat</code>
Datum Point feature	<code>com.ptc.pfc.pfcDatumPointFeat</code>
Coordinate System feature	<code>com.ptc.pfc.pfcCoordSysFeat</code>

Export Formats

New export formats have been added to the class `pfcModel.ExportType`. The following table lists the new export formats and the new instructions object added for each format:

Export Format	Interface
EXPORT_MEDUSA	<code>pfcExport.MedusaExportInstructions</code>
EXPORT_CATIA_PART	<code>pfcExport.CatiaPart3DExportInstructions</code>
EXPORT_CATIA_PRODUCT	<code>pfcExport.CatiaProduct3DExportInstructions</code>
EXPORT_CATIA_CGR	<code>pfcExport.CatiaCGR3DExportInstructions</code>
EXPORT_JT	<code>pfcExport.JT3DExportInstructions</code>
EXPORT_PARASOLID	<code>pfcExport.ParaSolid3DExportInstructions</code>
EXPORT_UG	<code>pfcExport.UG3DExportInstructions</code>
EXPORT_PDF	<code>pfcExport.PDFExportInstructions</code>

Export to PDF and U3D

J-Link now supports the export of Pro/ENGINEER drawings and solid models to PDF and U3D formats. A drawing can be exported as a 2D raster image embedded in a PDF file. The 3D models can be exported in the following ways:

- As a U3D model embedded in a one-page PDF file
- As 2D raster images representing saved views embedded in pages of a PDF file
- As a standalone U3D file

A new interface `pfcExport.PDFExportInstructions` containing all the instructions for export to PDF has been added. New PDF option types have also been defined in the class `pfcExport.PDFOptionType`.

ProductView Export Formats

The J-Link method **pfcModel.Model.Export** now supports export to any one of the ProductView formats listed in the next table. These formats have been defined in a new class `pfcExport.ProductViewFormat`.

ProductView Format	Type Constant
PVS	PV_FORMAT_PVS
ED	PV_FORMAT_ED
EDZ	PV_FORMAT_EDZ
PVZ	PV_FORMAT_PVZ

The attribute *PVExportOptions* has been added to the existing interface `pfcExport.ProductViewExportInstructions`. The values taken by this attribute are given by the new interface `pfcExport.ProductViewExportOptions`. This interface contains the attribute *PVFormat*, which can be set to any one of the ProductView formats listed above.

New Types for pfcSession.BaseSession.ListFiles

Starting with Pro/ENGINEER Wildfire 5.0 M040, the method **pfcSession.BaseSession.ListFiles** has been enhanced to return instance objects when accessing Windchill workspaces or folders. A PDM location (for workspace or commonspace) must be passed as the directory path. The following new types have been added under the enumerated type `FileListOpt`:

- **FILE_LIST_ALL_INST**—Same as the **FILE_LIST_ALL** option. It returns instances only for PDM locations.
- **FILE_LIST_LATEST_INST**—Same as the **FILE_LIST_LATEST** option. It returns instances only for PDM locations.

Obsolete Data Exchange Formats

The following data exchange formats and the corresponding type constants are no longer supported:

Data Exchange Format	Type Constant
CADAM	CADAM_CPTR_FILE CADAM_DIRECT_FILE CADAM_FILE IMPORT_2D_CADAM
PDGS	EXPORT_PDGS
CATIA	EXPORT_CATIA INTF_CATIA IMPORT_NEW_CATIA



B

Sample Applications

This appendix lists the sample applications provided with J-Link.

Topic	Page
Installing J-Link	B - 2
Sample Applications	B - 2

Installing J-Link

J-Link is available on the same CD as Pro/ENGINEER. When Pro/ENGINEER is installed using PTC.SetUp, one of the optional components is “API Toolkits”. This includes Pro/TOOLKIT, Pro/Web.Link, and J-Link.

If you select J-Link, a directory called `jlink` is created under the Pro/ENGINEER loadpoint and J-Link is automatically installed in this directory. This directory contains all the libraries, example applications, and documentation specific to J-Link.

Sample Applications

The J-Link sample applications are available in the location `jlink/jlink_appls`.

InstallTest

Location	Main Class
<code>jlink/jlink_appls/install_test</code>	<i>StartInstallTest</i>

The application `StartInstallTest` is used to check the J-Link synchronous installation. It verifies the following:

- Application start and stop functions.
- Menubar functions.
- Custom UI functions.
- Sequences, arrays, exceptions, and action listener functions.

Testing the J-Link Synchronous Installation

After the system administrator has installed J-Link, compile, link, and run a simple J-Link application on the machine you intend to use for development. Test the following items:

- The installation of J-Link is present, complete, and visible from your machine.
- The version of Pro/ENGINEER you plan to use during development has the J-Link license option added to it.

To test the synchronous J-Link installation:

1. Set the path and CLASSPATH variables to include the Java Development Kit as described in Java Options and Debugging.
2. Set the CLASSPATH to include the J-Link synchronous archive and the current directory.

For example, on UNIX set the CLASSPATH as:

```
setenv CLASSPATH " .:<Pro/ENGINEER  
loadpoint>/text/java/pfc.jar:$CLASSPATH"
```

On NT set the CLASSPATH as:

```
set CLASSPATH= .;<Pro/ENGINEER  
loadpoint>\text\java\pfc.jar;%CLASSPATH%
```

3. Compile the java files in the directory using the command
javac *.java.

Note: The java file AsyncInstallTest.java is not compiled because it is used in the asynchronous mode only. Before compiling, rename this file to a non-Java file, that is, AsyncInstallTest.bak.


4. Create a config.pro file if you are using Java 1.1. Add the following line to this file:

```
jlink_java2    off
```

Note: For more information on the supported JDK versions for synchronous J-Link refer to <http://www.ptc.com/partners/hardware/current/jlink.htm>.

5. Run Pro/ENGINEER.

The Pro/ENGINEER FILE menu has a new button, added by the J-Link application, called “**J-Link Install Test**”. When you choose this button, the J-Link application displays a custom dialog indicating whether the installation test has succeeded:



Note: On Windows the results dialog may appear behind the Pro/ENGINEER window. Use **Atl-Tab** to switch to the Java dialog.

InstallTest

Location	Main Class
jlink/jlink_appls/install_test	<i>AsyncInstallTest</i>

The application `AsyncInstallTest` is used to check the J-Link asynchronous installation. It verifies the following:

- Asynchronous J-Link setup
- Pro/ENGINEER start and stop methods
- Menubar functions
- Custom UI functions
- Sequences, arrays, exceptions, and action listener functions

Testing the J-Link Asynchronous Installation

To test the asynchronous J-Link application:

1. Set the path and CLASSPATH variables to include the Java Development Kit as described in Java Options and Debugging.
2. Set the CLASSPATH to include the J-Link asynchronous archive and the current directory.

For example, on UNIX set the CLASSPATH as:

```
setenv CLASSPATH " .:<Pro/E
loadpoint>/text/java/pfcasync.jar:$CLASSPATH"
```

On NT set the CLASSPATH as:

```
set CLASSPATH=.;<Pro/E
loadpoint>\text\java\pfcasync.jar;%CLASSPATH%
```

3. Set the library path to include the asynchronous library and make sure that PRO_COMM_MSG_EXE is set.

For example, on UNIX set the library path as:

```
setenv LD_LIBRARY_PATH "<Pro/E
loadpoint>/sun4_solaris/lib:$LD_LIBRARY_PATH"

setenv PRO_COMM_MSG_EXE "<Pro/E
loadpoint>/sun4_solaris/obj/pro_comm_msg"
```

On NT set the library path as:

```
set path=<Pro/E loadpoint>\i486_nt\lib;%PATH%

set PRO_COMM_MSG_EXE=<Pro/E
loadpoint>\i486_nt\obj\pro_comm_msg.exe
```

4. Compile the java files in the directory using the command `javac *.java`.

Note:

- The java file "StartInstallTest.java" does not get compiled as it is used in the synchronous mode only. Before compiling, rename this file to a non java file, that is, StartInstallTest.bak.
 - Remove any .class files compiled previously using synchronous J-Link.
 - Rename or remove the registry file (protk.dat or prodev.dat) from the location from where you are running the Jlink asynchronous test.
5. Run the application `java [asynchronous flags] AsyncInstallTest <command to run Pro/ENGINEER>`.

Note: For more information on the supported JDK versions for asynchronous J-Link and the value of the asynchronous flags refer to <http://www.ptc.com/partners/hardware/current/jlink.htm>

jlinkexamples

Location	Main Class
jlink/jlink_appls/jlinkexamples	pfcExamplesMenu.java, however note that not all examples may be tied to this class.

The application `jlinkexamples` is a collection of the J-Link User's Guide example source files . It covers most of the areas of J-Link.

jlinkasyncexamples

Location	Main Class
jlink/jlink_appls/jlinkasyncexamples	Many independent examples

The application `jlinkasyncexamples` is a collection of the asynchronous J-Link User's Guide example source files.

Parameter Editor

Location	Main Class
jlink/jlink_appls/jlink_param	com.ptc.jlinkdemo.parameditor.ParamEditor

The parameter editor example demonstrates a synchronous J-Link user interface that governs parameters and parameter values in the model. Setup and run the J-Link Parameter Editor example using the following:


1. Set the path and CLASSPATH variables to include the Java Development Kit as described in (link) as described in Java Options and Debugging.
2. Set the CLASSPATH to include the `jlink_param` directory and the J-Link synchronous Jar file (`pfc.jar`). Refer to the section Testing the J-Link Synchronous Installation for more information on setting the CLASSPATH.
3. Compile the code as follows:

- On UNIX, enter following to compile the code:

```
javac source/**/*.java -d.
```

After the first compilation some packages that depend on other packages may give errors. However, the parent packages will be compiled correctly. Continue compiling by reentering the command line string

```
javac source/**/*.java -d .
```
 - On Windows, execute the batch file *compile.bat*.
4. Start Pro/ENGINEER from a directory containing the *protk.dat* file. Create or retrieve any model that contains parameters.
 5. Select **J-Link Parameter Editor** from the Applications Menu. The system will display a graphical interface that contains a list of parameters for the selected model as shown in the following figure.



The parameter editor also supports the following customized types of parameters:

- Using the editor to create parameters with descriptive names (user interface names) of up to 80 character. The value of the assigned user interface name will be displayed as the parameter name in the J-Link user interface.
- Creating parameters that obey specific rules:
 - Enumerated lists
 - Specified ranges
 - Specified ranges, with values limited to a certain increments (for example, any multiple of 5 between 0 and 100).

When you open the J-Link user interface, the parameter value is governed by the rules assigned to it. If the parameter value is changed to fall outside the permitted values it will be highlighted in red.

Round Checker Utility

Location	Main Class
jlink/jlink_appls/jlink_elev	com.ptc.jlinkdemo.round.RoundChecker

The round checker example demonstrates a synchronous J-Link utility that monitors the values assigned to round dimensions. If the value of any modified or newly created round is reduced below a programmed limit, a J-Link user interface will appear with information about the violation.

Use the following steps to setup and run the example:


1. Set the path and CLASSPATH variables to include the Java Development Kit as described in (link).
2. Set the CLASSPATH to include the jlink_elev directory and the J-Link synchronous Jar file (pfc.jar).
3. Compile the code as follows:
 - On UNIX, enter following line to compile the code:
`javac source/**/*.java -d .`
 After the first compilation some packages that depend on other packages may give errors. However, the parent packages will be compiled correctly. Continue compiling by reentering the command line string
`javac source/**/*.java -d .`
 - On Windows, execute the batch file *compile.bat*.
4. Load any Pro/ENGINEER model with rounds. Modify the round to less than 0.5. A J-Link dialog that identifies the problem will be displayed. The same dialog will appear if a new round that does not adhere to the specified dimensions is created.

Save Check Utility

Location	Main Class
jlink/jlink_appls/jlink_elev	com.ptc.jlinkdemo.savecheck.SaveChecker

The save check example demonstrates a synchronous J-Link utility that presents a user interface that identifies if any problems exist in the model you are about to save. If any problems exist in the assigned parameter values or if a material has not been assigned to a part, the user interface will appear with information about the problems.

The instructions to setup and run the save check example are similar to the instructions for the round checker utility. To access the interface, choose **Tools, Perform Release Checks**.



Java Options and Debugging

This appendix describes how to control the procedure used by Pro/ENGINEER to invoke synchronous J-Link applications to enable you to use a non-default JVM or to debug your applications.

Topic	Page
Supported Java Virtual Machine Versions	C - 2
Overriding the Java command used by Synchronous J-Link	C - 3
Debugging a Synchronous Mode Application	C - 3
CLASSPATH Variables	C - 3

Supported Java Virtual Machine Versions

The machine information for the JVM versions supported by J-Link is available at

<http://www.ptc.com/partners/hardware/current/jlink.htm>

The Pro/ENGINEER installation includes a default JVM shipped as a part of its CD image. For synchronous J-Link applications, Pro/ENGINEER uses the Pro/ENGINEER-supplied JVM by default.

Pro/ENGINEER includes the ability to override the default JVM command used to invoke J-Link applications. This allows you to:

- Use a non-standard JVM in your deployment, if that JVM has a feature or a fix that is necessary for your application to work correctly.
- Apply command line flags to the Java invocation, thus allowing it to be used for debugging or other customized purposes.

Overriding the Java command used by Synchronous J-Link

The JVM that is used can be overridden using one of the following mechanisms:

- The configuration option `jlink_java_command`, if set to the path to the java executable, will determine the JVM be used to start synchronous J-Link applications.
- The environment variable `PRO_JAVA_COMMAND` serves the same purpose as the configuration option. The environment variable takes precedence over the configuration option.

Note: The appropriate flags for synchronous J-Link as well as the flags for the user-supplied JRE must be used. The synchronous J-Link flags are listed on the J-Link platform page. It is recommended that you update the version of the JVM on your machine to the minimum supported version for the platform.

Debugging a Synchronous Mode Application

As Pro/ENGINEER has control over the start and stop of Java processes used by J-Link, you must use special controls to be able to debug an application. The most typical deployment should do the following:

1. Use the appropriate javac compiler flags to build the application debuggable.
2. Use the technique described in the section *Overriding the Java command* used by Synchronous J-Link to set the Java command to the appropriate debug command line, for example, `[JDK_HOME]/bin/java.exe -Xdebug`
3. Start Pro/ENGINEER and let it invoke the Java application.
4. Attach your Java debugger to the process that was started by Pro/ENGINEER.

If you need to debug within the application start method, you can make the first invocation within that method a UI popup dialog box (`javax.swing.JOptionPane`) which will allow time to attach the debugger to the process.

CLASSPATH Variables

Synchronous Mode

If you are using the default JVM and are running J-Link applications on your machine, you need to add only your application classes to the classpath. The mechanisms to accomplish this are:

- Setting the environment variable `CLASSPATH`.
- Using the `java_app_classpath` field in the registry file. This field has a character limit of 2047 wide characters (`wchar_t`).
- Loading a user-specified Jar file through the user interface (only available for a model program).

Pro/ENGINEER will automatically add the J-Link archive `pfc.jar` to the `CLASSPATH`.

To compile J-Link applications the environment variable `CLASSPATH` must include the path to the locations of classes and archives that you intend to use. Also, you must add J-Link archive `pfc.jar` to the `CLASSPATH`. This archive is located at `<ProE Loadpoint>/text/java/pfc.jar`.

JAVA Options for Asynchronous Mode


Asynchronous mode applications are started by an external Java process. Thus Pro/ENGINEER does not have any control over them, and you may use any JVM and command line to invoke them.

Note: Regardless of how the Java process is invoked, it must use the Java command line flags specified for asynchronous mode under

<http://www.ptc.com/partners/hardware/current/jlink.htm>

For both running and compiling, the environment variable CLASSPATH must point to the locations of the application classes and archives.

The CLASSPATH should also include the path to the J-Link asynchronous mode archive file pfcasync.jar. This archive is located at <ProE Loadpoint>/text/java/pfcasync.jar.



Digital Rights Management

This appendix describes the implications of DRM on J-Link applications.

Topic	Page
Introduction	D - 2
Implications of DRM on J-Link	D - 2
Additional DRM Implications	D - 6

Introduction

Digital Rights Management (DRM) helps to control access to your intellectual property. Intellectual property could be sensitive design and engineering information that you have stored within Pro/ENGINEER parts, assemblies, or drawings. You can control access by applying policies to these Pro/ENGINEER objects. Such objects remain protected by the policies even after they are distributed or downloaded. Pro/ENGINEER objects for which you have applied policies are called DRM-protected objects. For more information on the use of DRM in Pro/ENGINEER Wildfire 4.0, refer to the DRM online help.

The following sections describe how J-Link applications deal with DRM-protected objects.

Implications of DRM on J-Link

Any J-Link application accessing DRM-protected objects can run only in interactive Pro/ENGINEER sessions having COPY permissions. As J-Link applications can extract content from models into an unprotected format, J-Link applications will not run in a Pro/ENGINEER session lacking COPY permission.

If the user tries to open a model lacking the COPY permission into a session with a J-Link application running, Pro/ENGINEER prompts the user to spawn a new session. Also, new J-Link applications will not be permitted to start when the Pro/ENGINEER session lacks COPY permission.

If a J-Link application tries to open a model lacking COPY permission from an interactive Pro/ENGINEER session, the application throws the **pfcExceptions.XToolkitNoPermission** exception.

When a J-Link application tries to open a protected model from a non-interactive or batch mode application, the session cannot prompt for DRM authentication, instead the application throws the **pfcExceptions.XToolkitAuthenticationFailure** exception.

Exception Types

Some J-Link methods require specific permissions in order to operate on a DRM-protected object. If these methods cannot proceed due to DRM restrictions, the following exceptions are thrown:

- **pfcExceptions.XToolkitNoPermission**—Thrown if the method cannot proceed due to lack of needed permissions.
- **pfcExceptions.XToolkitAuthenticationFailure**—Thrown if the object cannot be opened because the policy server could not be contacted or if the user was unable to interactively login to the server.
- **pfcExceptions.XToolkitUserAbort**—Thrown if the object cannot be operated upon because the user cancelled the action at some point.

The following table lists the methods along with the permission required and implications of operating on DRM-protected objects.


Methods	Permission Required	Implications
<p>pfcSession.BaseSession.RetrieveAss emSimpRep</p> <p>pfcSession.BaseSession.CreateDraw ingFromTemplate</p> <p>pfcSession.BaseSession.RetrieveGra phicsSimpRep</p> <p>pfcSession.BaseSession.RetrieveGeo mSimpRep</p> <p>pfcSession.BaseSession.RetrieveMo del</p> <p>pfcSession.BaseSession.RetrieveMo delWithOpts</p> <p>pfcSession.BaseSession.RetrievePar tSimpRep</p> <p>pfcSession.BaseSession.RetrieveSy mbolicSimpRep</p>	OPEN	<ul style="list-style-type: none"> • If file has OPEN and COPY permissions, model opens after authentication. • Throws the pfcExceptions.XToolkitNoPermission exception otherwise.
pfcModel.Model.Rename	OPEN	<ul style="list-style-type: none"> • File is saved with the current policy to disk if it has COPY permission.

Methods	Permission Required	Implications
<p>pfcModel.Model.Backup pfcModel.Model.Copy</p>	<p>SAVE</p>	<ul style="list-style-type: none"> • File is saved with the current policy to disk if it has SAVE and COPY permissions. • Throws the pfcExceptions.XToolkit NoPermission exception if model has COPY permission, but lacks SAVE permission.
<p>pfcModel.Model.Save</p>	<p>SAVE</p>	<ul style="list-style-type: none"> • File is saved with the current policy to disk if it has SAVE and COPY permissions. • Throws the pfcExceptions.XToolkit NoPermission exception if model has COPY permission, but lacks SAVE permission. • Throws the pfcExceptions.XToolkit NoPermission exception if the assembly file has models with COPY permission, but lacking SAVE permission.
<p>pfcModel.Model.Export for PlotInstructions pfcModel.Model.Export for ProductViewExportInstructions (only if the input model is a drawing) pfcSession.BaseSession.ExportCurrentRasterImage</p>	<p>PRINT</p>	<ul style="list-style-type: none"> • Drawing file is printed if it has PRINT permission. • Throws the pfcExceptions.XToolkit NoPermission exception if drawing file lacks PRINT permission.

Copy Permission to Interactively Open Models

When the user tries to open protected content lacking COPY permission through the Pro/ENGINEER user interface with a J-Link application running in the same session:

1. Pro/ENGINEER checks for the authentication credentials through the user interface, if they are not already established.
2. If the user has permission to open the file, Pro/ENGINEER checks if the permission level includes COPY. If the level includes COPY, Pro/ENGINEER opens the file.
3. If COPY permission is not included, the following message is displayed:



4. If the user clicks **Cancel**, the file is not opened in the current Pro/ENGINEER session and no new session is spawned.
5. If the user clicks **OK**, an additional session of Pro/ENGINEER is spawned which does not permit any J-Link application. J-Link applications set to automatically start by Pro/ENGINEER will not be started. Asynchronous applications will be unable to connect to this session.
6. The new session of Pro/ENGINEER is automatically authenticated with the same session credentials as were used in the previous session.
7. The model that Pro/ENGINEER was trying to load in the previous session is loaded in this session.
8. Other models already open in the previous session will not be loaded in the new session.
9. Session settings from the previous session will not be carried into the new session.

10. The new session will be granted the licenses currently used by the previous session. This means that the next time the user tries to do something in the previous session, Pro/ENGINEER must obtain a new license from the license server. If the license is not available, the action will be blocked with an appropriate message.

Additional DRM Implications

- The method **pfcModel.Model.CheckIsSaveAllowed** returns `false` if prevented from save by DRM restrictions.
- The method **pfcSession.BaseSession.CopyFileToWS** is designed to fail and throw the **pfcExceptions.XToolkitNoPermission** exception if passed a DRM-protected Pro/ENGINEER model file.
- The method **pfcSession.BaseSession.ImportToCurrentWS** reports a conflict in its output text file and does not copy a DRM-protected Pro/ENGINEER model file to the Workspace.
- While erasing an active Pro/ENGINEER model with DRM restrictions, the methods **pfcModel.Model.Erase** and **pfcModel.Model.EraseWithDependencies** do not clear the data in the memory until the control returns to Pro/ENGINEER from the Pro/TOOLKIT application. Thus, the Pro/ENGINEER session permissions may also not be cleared immediately after these methods return.




Geometry Traversal

This appendix illustrates the relationships between faces, contours, and edges. Examples E-1 through E-5 show some sample parts and list the information about their surfaces, faces, contours, and edges.

Topic	Page
Example 1	E - 2
Example 2	E - 2
Example 3	E - 3
Example 4	E - 4
Example 5	E - 5


Example 1



This part has 6 faces.


- Face A has 1 contour and 4 edges.
- Edge E2 is the intersection of faces A and B.
- Edge E2 is a component of contours C1 and C2.

Example 2



Face A has 2 contours and 6 edges.


Example 3



This part was extruded from a rectangular cross section. The feature on the top was added later as an extruded protrusion in the shape of a semicircle.

- Face A has 1 contour and 6 edges.
- Face B has 2 contours and 8 edges.
- Face C has 1 contour and 4 edges.


Example 4



This part was extruded from a cross section identical to Face A. In the Sketcher, the top boundary was sketched with two lines and an arc. The sketch was then extruded to form the base part, as shown.

- Face A has 1 contour and 6 edges.
- Face B has 1 contour and 4 edges.
- Face C has 1 contour and 4 edges.
- Face D has 1 contour and 4 edges.

Example 5



This part was extruded from a rectangular cross section. The slot and hole features were added later.

- Face A has 1 contour and 8 edges.
- Face B has 3 contours and 10 edges.



Geometry Representations

This appendix describes the geometry representations of the data used by J-Link.

Topic	Page
Surface Parameterization	F - 2
Edge and Curve Parameterization	F - 13


Surface Parameterization

A surface in Pro/ENGINEER contains data that describes the boundary of the surface, and a pointer to the primitive surface on which it lies. The primitive surface is a three-dimensional geometric surface parameterized by two variables (u and v). The surface boundary consists of closed loops (contours) of edges. Each edge is attached to two surfaces, and each edge contains the u and v values of the portion of the boundary that it forms for both surfaces. Surface boundaries are traversed clockwise around the outside of a surface, so an edge has a direction in each surface with respect to the direction of traversal.

This section describes the surface parameterization. The surfaces are listed in order of complexity. For ease of use, the alphabetical listing of the data structures is as follows:

- Cone
- Coons Patch
- Cylinder
- Cylindrical Spline Surface
- Fillet Surface
- General Surface of Revolution
- NURBS Surface
- Plane
- Ruled Surface
- Spline Surface
- Tabulated Cylinder
- Torus

Plane



The plane entity consists of two perpendicular unit vectors ($e1$ and $e2$), the normal to the plane ($e3$), and the origin of the plane.


Data Format:

```
e1[3]      Unit vector, in the  $u$  direction  
e2[3]      Unit vector, in the  $v$  direction  
e3[3]      Normal to the plane  
origin[3]  Origin of the plane
```

Parameterization:

$$(x, y, z) = u * e1 + v * e2 + \text{origin}$$

Cylinder



The generating curve of a cylinder is a line, parallel to the axis, at a distance R from the axis. The radial distance of a point is constant, and the height of the point is v .

Data Format:

e1[3] Unit vector, in the u direction
e2[3] Unit vector, in the v direction
e3[3] Normal to the plane
origin[3] Origin of the cylinder
radius Radius of the cylinder


Parameterization:

$$(x, y, z) = \text{radius} * [\cos(u) * e1 + \sin(u) * e2] + v * e3 + \text{origin}$$

Engineering Notes:

For the cylinder, cone, torus, and general surface of revolution, a local coordinate system is used that consists of three orthogonal unit vectors ($e1$, $e2$, and $e3$) and an origin. The curve lies in the plane of $e1$ and $e3$, and is rotated in the direction from $e1$ to $e2$. The u surface parameter determines the angle of rotation, and the v parameter determines the position of the point on the generating curve.

Cone



The generating curve of a cone is a line at an angle α to the axis of revolution that intersects the axis at the origin. The v parameter is the height of the point along the axis, and the radial distance of the point is $v * \tan(\alpha)$.


Data Format:

e1[3] Unit vector, in the u direction
e2[3] Unit vector, in the v direction
e3[3] Normal to the plane
origin[3] Origin of the cone
alpha Angle between the axis of the cone
 and the generating line

Parameterization:

$$(x, y, z) = v * \tan(\alpha) * [\cos(u) * e1 + \sin(u) * e2] + v * e3 + \text{origin}$$

Torus



The generating curve of a torus is an arc of radius $R2$ with its center at a distance $R1$ from the origin. The starting point of the generating arc is located at a distance $R1 + R2$ from the origin, in the direction of the first vector of the local coordinate system. The radial distance of a point on the torus is $R1 + R2 * \cos(v)$, and the height of the point along the axis of revolution is $R2 * \sin(v)$.


Data Format:

```
e1[3]      Unit vector, in the u direction
e2[3]      Unit vector, in the v direction
e3[3]      Normal to the plane
origin[3]  Origin of the torus
radius1    Distance from the center of the
           generating arc to the axis of
           revolution
radius2    Radius of the generating arc
```

Parameterization:

$$(x, y, z) = (R1 + R2 * \cos(v)) * [\cos(u) * e1 + \sin(u) * e2] + R2 * \sin(v) * e3 + \text{origin}$$

General Surface of Revolution



A general surface of revolution is created by rotating a curve entity, usually a spline, around an axis. The curve is evaluated at the normalized parameter v , and the resulting point is rotated around the axis through an angle u . The surface of revolution data structure consists of a local coordinate system and a curve structure.

Data Format:


```
e1[3]      Unit vector, in the u direction
e2[3]      Unit vector, in the v direction
e3[3]      Normal to the plane
origin[3]  Origin of the surface of revolution
curve      Generating curve
```

Parameterization:

$\text{curve}(v) = (c1, c2, c3)$ is a point on the curve.

$$(x, y, z) = [c1 * \cos(u) - c2 * \sin(u)] * e1 + [c1 * \sin(u) + c2 * \cos(u)] * e2 + c3 * e3 + \text{origin}$$

Ruled Surface



A ruled surface is the surface generated by interpolating linearly between corresponding points of two curve entities. The u coordinate is the normalized parameter at which both curves are evaluated, and the v coordinate is the linear parameter between the two points. The curves are not defined in the local coordinate system of the part, so the resulting point must be transformed by the local coordinate system of the surface.


Data Format:

```
e1[3]      Unit vector, in the u direction
e2[3]      Unit vector, in the v direction
e3[3]      Normal to the plane
origin[3]  Origin of the ruled surface
curve_1    First generating curve
curve_2    Second generating curve
```

Parameterization:

(x', y', z') is the point in local coordinates.
 $(x', y', z') = (1 - v) * C1(u) + v * C2(u)$
 $(x, y, z) = x' * e1 + y' * e2 + z' * e3 + origin$

Tabulated Cylinder



A tabulated cylinder is calculated by projecting a curve linearly through space. The curve is evaluated at the u parameter, and the z coordinate is offset by the v parameter. The resulting point is expressed in local coordinates and must be transformed by the local coordinate system to be expressed in part coordinates.


Data Format:

```
e1[3]      Unit vector, in the u direction
e2[3]      Unit vector, in the v direction
e3[3]      Normal to the plane
origin[3]  Origin of the tabulated cylinder
curve      Generating curve
```

Parameterization:

(x', y', z') is the point in local coordinates.
 $(x', y', z') = C(u) + (0, 0, v)$
 $(x, y, z) = x' * e_1 + y' * e_2 + z' * e_3 + \text{origin}$

Coons Patch




A Coons patch is used to blend surfaces together. For example, you would use a Coons patch at a corner where three fillets (each of a different radius) meet.

Data Format:

le_curve	$u = 0$ boundary
ri_curve	$u = 1$ boundary
dn_curve	$v = 0$ boundary
up_curve	$v = 1$ boundary
point_matrix[2][2]	Corner points
uvder_matrix[2][2]	Corner mixed derivatives

Fillet Surface



A fillet surface is found where a round or a fillet is placed on a curved edge, or on an edge with non-constant arc radii. On a straight edge, a cylinder would be used to represent the fillet.

Data Format:

```


pnt_spline  P(v) spline running along the u = 0 boundary
ctr_spline  C(v) spline along the centers of the
            fillet arcs
tan_spline  T(v) spline of unit tangents to the
            axis of the fillet arcs
    
```

Parameterization:

$$R(v) = P(v) - C(v)$$

$$(x, y, z) = C(v) + R(v) * \cos(u) + T(v) \times R(v) * \sin(u)$$

Spline Surface



The parametric spline surface is a nonuniform bicubic spline surface that passes through a grid with tangent vectors given at each point. The grid is curvilinear in *uv* space. Use this for bicubic blending between corner points.

Data Format:

```

u_par_arr[]  Point parameters, in the u
            direction, of size Nu
v_par_arr[]  Point parameters, in the v
            direction, of size Nv
point_arr[][3]  Array of interpolant points, of
            size Nu x Nv
u_tan_arr[][3]  Array of u tangent vectors
            at interpolant points, of size
            Nu x Nv
    
```

v_tan_arr[][3] Array of v tangent vectors at interpolant points, of size $N_u \times N_v$


uvder_arr[][3] Array of mixed derivatives at interpolant points, of size $N_u \times N_v$

Engineering Notes:

- Allows for a unique 3×3 polynomial around every patch.
- There is second order continuity across patch boundaries.
- The point and tangent vectors represent the ordering of an array of $[i][j]$, where u varies with i , and v varies with j . In walking through the *point_arr*[[3]], you will find that the innermost variable representing $v(j)$ varies first.

NURBS Surface

The NURBS surface is defined by basis functions (in u and v), expandable arrays of knots, weights, and control points.



Cubic NURBS Surface

Data Format:

deg[2] Degree of the basis functions (in u and v)

u_par_arr[] Array of knots on the parameter line u

v_par_arr[] Array of knots on the parameter line v

wghts[] Array of weights for
 rational NURBS, otherwise
 NULL
 c_point_arr[][3] Array of control points

Definition:

$$R(u, v) = \frac{\sum_{i=0}^{N1} \sum_{j=0}^{N2} C_{i,j} \times B_{i,k}(u) \times B_{j,l}(v)}{\sum_{i=0}^{N1} \sum_{j=0}^{N2} w_{i,j} \times B_{i,k}(u) \times B_{j,l}(v)}$$


k = degree in u
 l = degree in v
 $N1$ = (number of knots in u) - (degree in u) - 2
 $N2$ = (number of knots in v) - (degree in v) - 2
 $B_{i,k}$ = basis function in u
 $B_{j,l}$ = basis function in v
 $w_{i,j}$ = weights
 $C_{i,j}$ = control points $(x, y, z) * w_{i,j}$

Engineering Notes:

The *weights* and *c_points_arr* arrays represent matrices of size *wghts*[$N1+1$][$N2+1$] and *c_points_arr* [$N1+1$][$N2+1$]. Elements of the matrices are packed into arrays in row-major order.

Cylindrical Spline Surface

The cylindrical spline surface is a nonuniform bicubic spline surface that passes through a grid with tangent vectors given at each point. The grid is curvilinear in modeling space.



Data Format:

```
e1[3]      x' vector of the local coordinate
           system
e2[3]      y' vector of the local coordinate
           system
e3[3]      z' vector of the local coordinate
           system, which corresponds to the
           axis of revolution of the surface
origin[3]  Origin of the local coordinate
           system
splsrfspl  Spline surface data structure
```

The spline surface data structure contains the following fields:

```
u_par_arr[]  Point parameters, in the
             u direction, of size Nu
v_par_arr[]  Point parameters, in the
             v direction, of size Nv
point_arr[][3]  Array of points, in
               cylindrical coordinates,
               of size Nu x Nv. The array
               components are as follows:
                 point_arr[i][0] - Radius
                 point_arr[i][1] - Theta
                 point_arr[i][2] - Z
u_tan_arr[][3]  Array of u tangent vectors.
               in cylindrical coordinates,
               of size Nu x Nv
v_tan_arr[][3]  Array of v tangent vectors,
               in cylindrical coordinates,
               of size Nu x Nv
uvsr_arr[][3]  Array of mixed derivatives,
               in cylindrical coordinates,
               of size Nu x Nv
```

Engineering Notes:

If the surface is represented in cylindrical coordinates (r, θ, z) , the local coordinate system values (x', y', z') are interpreted as follows:

$$\begin{aligned}x' &= r \cos(\theta) \\y' &= r \sin(\theta) \\z' &= z\end{aligned}$$

A cylindrical spline surface can be obtained, for example, by creating a smooth rotational blend (shown in the figure on the previous page).

In some cases, you can replace a cylindrical spline surface with a surface such as a plane, cylinder, or cone. For example, in the figure, the cylindrical spline surface S_1 was replaced with a cone ($r_1 = r_2$, $r_3 = r_4$, and $r_1 \neq r_3$).

If a replacement cannot be done (such as for the surface S_0 in the figure ($r_a \neq r_b$ or $r_c \neq r_d$)), leave it as a cylindrical spline surface representation.

Edge and Curve Parameterization

This parameterization represents edges (line, arc, and spline) as well as the curves (line, arc, spline, and NURBS) within the surfaces.

This section describes edges and curves, arranged in order of complexity. For ease of use, the alphabetical listing is as follows:

- Arc
- Line
- NURBS
- Spline

Line

Data Format:

```
end1[3]   Starting point of the line
end2[3]   Ending point of the line
```

Parameterization:

$$(x, y, z) = (1 - t) * \text{end1} + t * \text{end2}$$

Arc

The arc entity is defined by a plane in which the arc lies. The arc is centered at the origin, and is parameterized by the angle of rotation from the first plane unit vector in the direction of the second plane vector. The start and end angle parameters of the arc and the radius are also given. The direction of the arc is counterclockwise if the start angle is less than the end angle, otherwise it is clockwise.

Data Format:

vector1[3]	First vector that defines the plane of the arc
vector2[3]	Second vector that defines the plane of the arc
origin[3]	Origin that defines the plane of the arc
start_angle	Angular parameter of the starting point
end_angle	Angular parameter of the ending point
radius	Radius of the arc.

Parameterization:

t' (the unnormalized parameter) is
 $(1 - t) * \text{start_angle} + t * \text{end_angle}$
 $(x, y, z) = \text{radius} * [\cos(t') * \text{vector1} + \sin(t') * \text{vector2}] + \text{origin}$

Spline

The spline curve entity is a nonuniform cubic spline, defined by a series of three-dimensional points, tangent vectors at each point, and an array of unnormalized spline parameters at each point.

Data Format:

par_arr[]	Array of spline parameters (t) at each point.
pnt_arr[][3]	Array of spline interpolant points
tan_arr[][3]	Array of tangent vectors at each point

Parameterization:

x , y , and z are a series of unique cubic functions, one per segment, fully determined by the starting and ending points, and tangents of each segment.

Let p_{max} be the parameter of the last spline point. Then, t' , the unnormalized parameter, is $t * p_{max}$.


Locate the i th spline segment such that:

$par_arr[i] < t' < par_arr[i+1]$
 (If $t < 0$ or $t > +1$, use the first or last segment.)

$t_0 = (t' - par_arr[i]) / (par_arr[i+1] - par_arr[i])$
 $t_1 = (par_arr[i+1] - t') / (par_arr[i+1] - par_arr[i])$

NURBS

The NURBS (nonuniform rational B-spline) curve is defined by expandable arrays of knots, weights, and control points.



Cubic NURBS Curve

Data Format:

degree Degree of the basis function
 params[] Array of knots
 weights[] Array of weights for rational
 NURBS, otherwise NULL.
 c_pnts[][3] Array of control points

Definition:

$$R(t) = \frac{\sum_{i=0}^N C_i \times B_{i,k}(t)}{\sum_{i=0}^N w_i \times B_{i,k}(t)}$$

k = degree of basis function

N = (number of knots) - (degree) - 2

w_j = weights

C_j = control points (x, y, z) * w_j

$B_{i,k}$ = basis functions

By this equation, the number of control points equals $N+1$.

References:

Faux, I.D., M.J. Pratt. *Computational Geometry for Design and Manufacture*. Ellis Harwood Publishers, 1983.

Mortenson, M.E. *Geometric Modeling*. John Wiley & Sons, 1985.



J-Link Classes

This appendix lists and briefly describes the classes that make up the J-Link interface.

Topic	Page
List of J-Link Classes	G - 2

List of J-Link Classes

The following table briefly describes the classes in the J-Link interface.

Class	Package	Returned by
ActionListener	pfcBase	Base class; not returned.
This class defines an action listener.		
ActionListeners	pfcBase	ActionListeners.create()
This data type is used to specify a list of action listeners.		
ActionSource	pfcBase	Base class; not returned.
This class specifies an action source.		
ActionSources	pfcBase	ActionSources.create()
This type describes an array of action sources.		
AnalysisFeat	pfcAnalysisFeat	Downcast of pfcFeature.Feature.
This feature type specifies an analysis feature.		
Arc	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines an arc.		
AreaNibbleFeat	pfcAreaNibbleFeat	Downcast of pfcFeature.Feature.
This feature type specifies a nibble area. This feature type is used in sheetmetal applications.		
Arrow	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines an arrow.		
Assembly	pfcAssembly	Session.CreateAssembly(), ComponentPath.GetRoot()
This class describes an assembly.		
AssemblyCutCopyFeat	pfcAssemblyCutCopyFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cut and copied feature, which is used in the Pro/ASSEMBLY module.		
AssemblyCutFeat	pfcAssemblyCutFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cutout feature, which is used in the Pro/ASSEMBLY module.		
AttachFeat	pfcAttachFeat	Downcast of pfcFeature.Feature.
This feature type specifies an attached feature.		
AttachVolumeFeat	pfcAttachVolumeFeat	Downcast of pfcFeature.Feature.
This feature type specifies an attached volume.		
AuxiliaryFeat	pfcAuxiliaryFeat	Downcast of pfcFeature.Feature.
This feature type specifies an auxiliary feature.		

Class	Package	Returned by
Axis	pfcGeometry	Downcast of pfcModelItem.ModelItem.
This class defines an axis.		
BaseDimension	pfcDimension	Base class; not returned.
This class defines the base dimension.		
BaseParameter	pfcModelItem	Base class; not returned.
Describes the base parameter.		
BeamSectionFeat	pfcBeamSectionFeat	Downcast of pfcFeature.Feature.
This feature type specifies a beam section.		
BendBackFeat	pfcBendBackFeat	Downcast of pfcFeature.Feature.
This feature type specifies a bend back feature, which is used in the Pro/NC-SHEETMETAL module.		
BendFeat	pfcBendFeat	Downcast of pfcFeature.Feature.
This feature type specifies a bend feature.		
BldOperationFeat	pfcBldOperationFeat	Downcast of pfcFeature.Feature.
This feature type specifies a build operation.		
BOMExportInstructions	pfcModel	pfc-Model.BOMExportInstructions_Create()
Used to export a BOM for an assembly.		
BSpline	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines a B-spline curve.		
BSplinePoint	pfcGeometry	BSplinePoints.get()
This class defines a B-spline point.		
BSplinePoints	pfcGeometry	BSplinePoints.create(), BSpline.GetPoints()
This data type is used to specify an array of B-spline points.		
BulkObjectFeat	pfcBulkObjectFeat	Downcast of pfcFeature.Feature.
This feature type specifies a bulk object.		
CableCosmeticFeat	pfcCableCosmeticFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cosmetic feature used with the Pro/CABLING module.		
CableFeat	pfcCableFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cabling feature.		
CableLocationFeat	pfcCableLocationFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cable location.		

Class	Package	Returned by
CableParamsFileInstructions	pfcModel	pfc-Model.CableParamsFileInstructions_Create()
Used to export cable parameters from an assembly.		
CableSegmentFeat	pfcCableSegmentFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cable segment.		
CATIAExportInstructions	pfcModel	pfc-Model.CATIAExportInstructions_Create()
Used to export a part or assembly in CATIA format (as precise geometry)		
CATIAFacetsExportInstructions	pfcModel	pfc-Model.CATIAFacetsExportInstructions_Create()
Used to export a part or assembly in CATIA format (as a faceted model).		
CavDeviationFeat	pfcCavDeviationFeat	Downcast of pfcFeature.Feature.
This feature type specifies a deviation feature, which is used in the Pro/VERIFY module.		
CavFitFeat	pfcCavFitFeat	Downcast of pfcFeature.Feature.
This feature type specifies a fit feature, which is used in the Pro/VERIFY module.		
CavScanSetFeat	pfcCavScanSetFeat	Downcast of pfcFeature.Feature.
This feature type specifies a scanset feature, which is used in the Pro/VERIFY module.		
CGMExportType	pfcModel	CGMExportType.FromInt() or by using one of the static instances (e.g., EXPORT_CGM_CLEAR_TEXT)
Indicates whether a CGM export file should be ASCII (clear text) or binary (mil spec)		
CGMFILEExportInstructions	pfcModel	pfc-Model.CGMFILEExportInstructions_Create()
Used to export a drawing in CGM format.		
CGMScaleType	pfcModel	CGMScaleType.FromInt() or by using any of the static instances (e.g., EXPORT_CGM_ABSTRACT)
Indicates whether a CGM export file should include abstract or metric units		
ChamferFeat	pfcChamferFeat	Downcast of pfcFeature.Feature.
This feature type specifies a chamfer.		
ChannelFeat	pfcChannelFeat	Downcast of pfcFeature.Feature.
This feature type specifies a channel.		
Child	pfcObject	Parent.GetChild(),

Class	Package	Returned by
Describes a child feature.		
Circle	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines a circle.		
CMMConstrFeat	pfcCMMConstrFeat	Downcast of pfcFeature.Feature.
This feature type specifies a construction feature used in the Pro/CMM module.		
CMMMeasureStepFeat	pfcCMMMeasureStepFeat	Downcast of pfcFeature.Feature.
This feature type specifies a measured step feature, which is used in the Pro/CMM module.		
CMMVerifyFeat	pfcCMMVerifyFeat	Downcast of pfcFeature.Feature.
This feature type specifies a verify feature, which is used in the Pro/CMM module.		
ColorRGB	pfcBase	pfcBase.ColorRGB_Create(), Session.GetRGBFromStdColor()
Specifies the red, green, and blue (RGB) values of a color.		
CompModelReplace	pfcComponentFeat	ComponentFeat.CreateReplaceOp()
Used to replace one model in a component with another.		
ComponentFeat	pfcComponentFeat	Downcast of pfcFeature.Feature.
Specifies a component feature.		
ComponentPath	pfcAssembly	Selection.GetPath()
This class describes a component path.		
ComponentType	pfcComponentFeat	ComponentType.FromInt() or by using any of the static instances (e.g., COMP_WORKPIECE)
This enumerated type lists the possible component types.		
CompositeCurve	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines a composite curve.		
Cone	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a cone.		
ConnectorParamExportInstructions	pfcModel	pfc-Model.ConnectorParamExportInstructions_Create()
Used to write the parameters of a connector to a file.		
ContMapFeat	pfcContMapFeat	Downcast of pfcFeature.Feature.
This feature type specifies a contour map, which is used in the Pro/DIEFACE module.		
Contour	pfcGeometry	Contours.get(), Contour.FindContainingContour()
This class describes a contour.		

Class	Package	Returned by
Contours	pfcGeometry	Contours.create(), Surface.ListContours()
This data type is used to describe an array of contours.		
ContourTraversal	pfcGeometry	ContourTraversal.FromInt() or by using any of the static instances (e.g., CONTOUR_TRAV_INTERNAL)
This enumerated type lists the possible values for traversing the contour.		
CoordAxis	pfcBase	CoordAxis.FromInt() or by using any of the static instances (e.g., COORD_AXIS_X)
This enumerated type specifies the axes of a coordinate system.		
CoordSysExportInstructions	pfcModel	Base class; not returned.
Base class of classes that export files with information that describes faceted, solid models		
CoordSysFeat	pfcCoordSysFeat	Downcast of pfcFeature.Feature.
Describes a coordinate system feature, including constraint and translation information.		
CoordSystem	pfcGeometry	Downcast of pfcModelItem.ModelItem.
This class describes a coordinate system.		
CoreFeat	pfcCoreFeat	Downcast of pfcFeature.Feature.
This feature type specifies a core feature, which is used in the Pro/COMPOSITE module.		
CornerChamferFeat	pfcCornerChamferFeat	Downcast of pfcFeature.Feature.
This feature type specifies a corner chamfer.		
CosmeticFeat	pfcCosmeticFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cosmetic feature.		
CrossSectionFeat	pfcCrossSectionFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cross section.		
CurvatureData	pfcGeometry	Surface.EvalPrincipalCurv()
This class specifies the curvature data.		
Curve	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines a curve.		
CurveFeat	pfcCurveFeat	Downcast of pfcFeature.Feature.
Specifies a curve feature.		
Curves	pfcGeometry	Curves.create(), CompositeCurve.ListElements()
This data type is used to specify an array of curves.		

Class	Package	Returned by
CurveStartPoint	pfcCurveFeat	CurveStartPoint.FromInt() or by using any of the static instances (e.g., CURVE_START)
This enumerated type lists the possible starting points of the datum curve offset.		
CurveXYZData	pfcGeometry	GeomCurve.Eval3DData(), GeomCurve.EvalFromLength()
Stores the results of an edge evaluation.		
CustomizeFeat	pfcCustomizeFeat	Downcast of pfcFeature.Feature.
This feature type specifies a customized feature.		
CutFeat	pfcCutFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cut feature.		
CutMotionFeat	pfcCutMotionFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cut motion feature, which is used in the Pro/NC module.		
Cylinder	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a cylinder.		
DatumAxisFeat	pfcDatumAxisFeat	Downcast of pfcFeature.Feature.
This feature type specifies a datum axis feature.		
DatumPlaneFeat	pfcDatumPlaneFeat	Downcast of pfcFeature.Feature.
This feature type specifies a datum plane.		
DatumPointFeat	pfcDatumPointFeat	Downcast of pfcFeature.Feature.
This feature type specifies a datum point.		
DatumQuiltFeat	pfcDatumQuiltFeat	Downcast of pfcFeature.Feature.
This feature type specifies a datum quilt.		
DatumSurfaceFeat	pfcDatumSurfaceFeat	Downcast of pfcFeature.Feature.
This feature type specifies a datum surface.		
DeclareFeat	pfcDeclareFeat	Downcast of pfcFeature.Feature.
This feature type specifies a declared feature.		
DeformAreaFeat	pfcDeformAreaFeat	Downcast of pfcFeature.Feature.
This feature type specifies a deformed area.		
DeleteOperation	pfcFeature	Feature.CreateDeleteOp()
This class defines a delete operation.		
Dependencies	pfcModel	Dependencies.create(), Model.ListDependencies()
This data type is used to specify the first-level dependencies for an object.		
Dependency	pfcModel	Dependencies.get()

Class	Package	Returned by
Describes the first-level dependency for an object.		
Dimension	pfcDimension	Downcast of pfcModelItem.ModelItem.
This class describes a dimension.		
DimensionType	pfcDimension	DimensionType.FromInt() or by using any of the static instances (e.g., DIM_LINEAR)
This enumerated type lists the possible dimension types.		
DimTolerance	pfcDimension	Dimension.GetTolerance().
This class defines the dimension tolerance.		
DimTolLimits	pfcDimension	DimTolLimits.Create()
This class displays the limits for the dimension tolerance.		
DimTolPlusMinus	pfcDimension	DimTolPlusMinus.Create
This class displays the dimension tolerance in the form +/-x, where x is the plus tolerance. The value of the minus tolerance is unused.		
DimTolSymmetric	pfcDimension	DimTolSymmetric.Create()
This class displays the dimension tolerance in symmetrical form.		
DisplayStatus	pfcLayer	DisplayStatus.FromInt() or by using any of the static instances (e.g., LAYER_NORMAL).
This enumerated type lists the possible values for the display status of a layer.		
Dome2Feat	pfcDome2Feat	Downcast of pfcFeature.Feature.
This feature type specifies a section dome.		
DomeFeat	pfcDomeFeat	Downcast of pfcFeature.Feature.
This feature type specifies a radius dome.		
DraftFeat	pfcDraftFeat	Downcast of pfcFeature.Feature.
This feature type specifies a draft.		
DraftLineFeat	pfcDraftLineFeat	Downcast of pfcFeature.Feature.
This feature type specifies a line draft, which is used with the Pro/LEGACY module.		
Drawing	pfcDrawing	Session.CreateDrawing
This class describes a drawing.		
DrillFeat	pfcDrillFeat	Downcast of pfcFeature.Feature.
This feature type specifies a drill, which is used with the Pro/NC module.		
DrillGroupFeat	pfcDrillGroupFeat	Downcast of pfcFeature.Feature.
This feature type specifies a drill group, which is used in the Pro/NC module.		

Class	Package	Returned by
DrvToolCurveFeat	pfcDrvToolCurveFeat	Downcast of pfcFeature.Feature.
This feature type specifies a driven-tool curve, which is used in the Pro/NC module.		
DrvToolEdgeFeat	pfcDrvToolEdgeFeat	Downcast of pfcFeature.Feature.
This feature type specifies a driven-tool edge, which is used in the Pro/NC module.		
DrvToolProfileFeat	pfcDrvToolProfileFeat	Downcast of pfcFeature.Feature.
This feature type specifies a driven-tool profile.		
DrvToolSketchFeat	pfcDrvToolSketchFeat	Downcast of pfcFeature.Feature.
This feature type specifies a driven-tool sketch.		
DrvToolSurfFeat	pfcDrvToolSurfFeat	Downcast of pfcFeature.Feature.
This feature type specifies a driven-tool surface.		
DrvToolTwoCntrFeat	pfcDrvToolTwoCntrFeat	Downcast of pfcFeature.Feature.
This feature type specifies a tool with two centers.		
DWGSetupExportInstructions	pfcModel	pfc-Model.DWGSetupExportInstructions_Create()
Used to export a drawing setup file.		
DXFExportInstructions	pfcModel	pfc-Model.DXFExportInstructions_Create()
Used to export a drawing in DXF format.		
EarFeat	pfcEarFeat	Downcast of pfcFeature.Feature.
This feature type specifies an ear feature.		
Edge	pfcGeometry	Edges.get(), Edge.GetEdge1(), Edge.GetEdge2()
Describes the edge, including the next and previous edge, and the two surfaces.		
EdgeBendFeat	pfcEdgeBendFeat	Downcast of pfcFeature.Feature.
This feature type specifies an edge bend.		
EdgeEvalData	pfcGeometry	Edge.EvalUV()
This class provides edge evaluation data.		
Edges	pfcGeometry	Edges.create(), Contour.ListElements(),
This data type is used to specify an array of edges.		
Ellipse	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines an ellipse.		
EtchFeat	pfcEtchFeat	Downcast of pfcFeature.Feature.

Class	Package	Returned by
This feature type specifies an etched feature.		
ExplodeLineFeat	pfcExplodeLineFeat	Downcast of pfcFeature.Feature.
This feature type specifies an explode line.		
ExportInstructions	pfcModel	Base class; not returned.
Base class to all the export-instructions classes.		
ExportType	pfcModel	ExportType.FromInt() or by using any of the static instances (e.g., EXPORT_IGES_SECTION)
Enumeration of the available export options.		
ExpRatioFeat	pfcExpRatioFeat	Downcast of pfcFeature.Feature.
This feature type specifies an exponential-ratio feature.		
ExtendFeat	pfcExtendFeat	Downcast of pfcFeature.Feature.
This feature type specifies an extend feature.		
ExtractFeat	pfcExtractFeat	Downcast of pfcFeature.Feature.
This feature type specifies an extraction.		
FamColComp	pfcFamily	FamilyMember.CreateComponentColumn()
This class describes a component column in a family table.		
FamColCompModel	pfcFamily	FamilyMember.CreateCompModelColumn()
This class describes a component model column in a family table.		
FamColDimension	pfcFamily	FamilyMember.CreateDimensionColumn()
This class specifies a dimension column in a family table.		
FamColExternalRef	pfcFamily	Not returned.
This class describes an external reference column in a family table.		
FamColFeature	pfcFamily	FamilyMember.CreateFeatureColumn()
This class specifies a family column feature.		
FamColGroup	pfcFamily	FamilyMember.CreateGroupColumn()
This class describes a group column in a family table.		
FamColGTol	pfcFamily	Not returned.
This class describes a geometric tolerance (gtol) column in a family table.		
FamColMergePart	pfcFamily	FamilyMember.CreateMergePartColumn()
This class describes a merged part column in a family table.		

Class	Package	Returned by
FamColModelItem	pfcFamily	Base class; not returned.
This class specifies a column in the family table.		
FamColParam	pfcFamily	FamilyMember.CreateParamColumn()
This class specifies a parameter column in a family table.		
FamColSystemParam	pfcFamily	Not returned.
This class describes a system parameter column in a family table.		
FamColUDF	pfcFamily	Not returned.
This class describes a UDF column in a family table.		
FamilyMember	pfcFamily	FamilyMember.GetParent()
This class describes a member in a family table.		
FamilyTableColumn	pfcFamily	FamilyMember.AddColumn(), FamilyTableColumns.get(),
This class specifies a column in a family table.		
FamilyTableColumns	pfcFamily	FamilyTableColumns.create(), FamilyMember.ListColumns()
This data type is used to specify a list of columns in a family table.		
FamilyTableRow	pfcFamily	FamilyMember.AddRow(), FamilyMember.GetRow(), FamilyTableRows.get()
This class specifies a row in a family table.		
FamilyTableRows	pfcFamily	FamilyTableRows.create(), FamilyMember.ListRows()
This data type is used to specify a list of rows in a family table.		
FamIParNote	pfcFamily	Not returned.
This class specifies an integer parameter note.		
FeatIdExportInstructions	pfcModel	Base class; not returned.
Base class of instructions classes that export data for a single feature.		
FeatInfoExportInstructions	pfcModel	pfc-Model.FeatInfoExportInstructions_Create()
Used to export information about one feature in a part or assembly.		
Feature	pfcFeature	Solid.GetFeatureByName(), FeatureOperation.GetOpFeature(). Also, by downcasting pfcModelItem.ModelItem.
This class defines the feature information.		
FeatureActionListener_u	pfcFeature	Base class; not returned.

Class	Package	Returned by
Abstract base class that all user-defined FeatureActionListener classes must extend.		
FeatureActionListener	pfFeature	Base class; not returned.
Interface that must be implemented by user-defined classes that respond to Feature events.		
FeatureGroup	pfFeature	Feature.GetGroup()
This class describes a feature group.		
FeatureOperation	pfFeature	FeatureOperations.get()
This class defines a feature operation.		
FeatureOperations	pfFeature	FeatureOperations.create()
This class specifies a list of feature operations.		
FeaturePattern	pfFeature	Feature.GetPattern(), Feature-Group.GetPattern()
This class specifies a feature pattern.		
FeaturePlacement	pfFeature	Feature.GetPlacement()
Specifies the placement of a feature.		
Features	pfFeature	Features.create(), Feature.ListChildren(), Feature.ListParents(), Feature-Pattern.ListMembers()
This data type specifies an array of features.		
FeatureStatus	pfFeature	FeatureStatus.FromInt() or by using any of the static instances (e.g., FEAT_ACTIVE)
This enumerated type specifies the feature status.		
FeatureType	pfFeature	FeatureType.FromInt() or by using any of the static instances (e.g., FEATTYPE_PROTRUSION)
This enumerated type lists the possible feature types.		
FIATExportInstructions	pfModel	pf-Model.FIATExportInstructions_Create()
Used to export a part or assembly in FIAT format.		
FirstFeat	pfFirstFeat	Downcast of pfFeature.Feature.
This feature type specifies the first feature in a model.		
FixtureSetupFeat	pfFixtureSetupFeat	Downcast of pfFeature.Feature.
This feature type specifies a fixture setup.		
FlangeFeat	pfFlangeFeat	Downcast of pfFeature.Feature.
This feature type specifies a flange.		

Class	Package	Returned by
FlatPatFeat	pfcFlatPatFeat	Downcast of pfcFeature.Feature.
This feature type specifies a flat pattern.		
FlatRibbonSegmentFeat	pfcFlatRibbonSegmentFeat	Downcast of pfcFeature.Feature.
This feature type is for flat ribbon segments.		
FlattenFeat	pfcFlattenFeat	Downcast of pfcFeature.Feature.
This feature type specifies a flattened-harness feature.		
FormFeat	pfcFormFeat	Downcast of pfcFeature.Feature.
This feature type specifies a form feature.		
FreeFormFeat	pfcFreeFormFeat	Downcast of pfcFeature.Feature.
This feature type specifies a free-form feature.		
FreeNotePlacement	pfcNote	pfcNote.FreeNotePlacement_Create()
Specifies the location of the attachment point "free" -- at a parametric point with respect to the model outline. For example, (0.5, 0.5, 0.5) would be the center, whereas (0.0, 0.0, 1.1) would be just outside one of the corners.		
GeomCopyFeat	pfcGeomCopyFeat	Downcast of pfcFeature.Feature.
This feature type specifies a geometric copy feature.		
GeomCurve	pfcGeometry	RevolvedSurface.GetProfile(), RuledSurface.GetProfile1(), RuledSurface.GetProfile2(), TabulatedCylinder.GetProfile()
This class provides information for a geometry curve.		
GeomExportFlags	pfcModel	pfcModel.GeoExportFlags_Create()
Stores extend-surface and Bezier options for use when exporting geometric information from a model.		
GeomExportInstructions	pfcModel	Base class; not returned.
Base class to classes used to export precise geometric information from a model.		
GraphFeat	pfcGraphFeat	Downcast of pfcFeature.Feature.
This feature type specifies a graph.		
GrooveFeat	pfcGrooveFeat	Downcast of pfcFeature.Feature.
This feature type specifies a groove.		
HoleFeat	pfcHoleFeat	Downcast of pfcFeature.Feature.
This feature type specifies a hole feature.		
IGES3DExportInstructions	pfcModel	pfc-Model.IGES3DExportInstructions_Create()
Used to export a part or assembly in IGES format.		

Class	Package	Returned by
IGESFileExportInstructions	pfcModel	pfc-Model.IGESFileExportInstructions_Create()
Used to export a drawing in IGES format		
ImportFeat	pfcImportFeat	Downcast of pfcFeature.Feature.
This feature type specifies an import feature.		
IntegerOld	pfcObject	Base class; not returned.
This class specifies an integer identifier. <i>For internal use only.</i>		
InternalUDFFeat	pfcInternalUDFFeat	Downcast of pfcFeature.Feature.
This feature type is for internal use only.		
IntersectFeat	pfcIntersectFeat	Downcast of pfcFeature.Feature.
This feature type specifies an intersection.		
InventorExportInstructions	pfcModel	pfc-Model.InventorExportInstructions_Create()
Used to export a part or assembly in Inventor format.		
IPMQuiltFeat	pfcIPMQuiltFeat	Downcast of pfcFeature.Feature.
Specifies an IPM Quilt feature.		
ISegmentFeat	pfcISegmentFeat	Downcast of pfcFeature.Feature.
This feature type specifies an ideal segment.		
Layer	pfcLayer	Model.CreateLayer(). Also, by down-casting pfcModelItem.ModelItem.
This class describes a layer.		
Line	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines a line.		
LineStockFeat	pfcLineStockFeat	Downcast of pfcFeature.Feature.
This feature type specifies a line stock, which is used in the Pro/PIPING module.		
LipFeat	pfcLipFeat	Downcast of pfcFeature.Feature.
This feature type specifies a lip feature.		
LocPushFeat	pfcLocPushFeat	Downcast of pfcFeature.Feature.
This feature type specifies a local push feature.		
ManualMillFeat	pfcManualMillFeat	Downcast of pfcFeature.Feature.
This feature type specifies a manual-mill feature.		
Material	pfcPart	Materials.get(), Part.GetCurrentMaterial(), Part.CreateMaterial(), Part.RetrieveMaterial()

Class	Package	Returned by
This class provides information about a material.		
MaterialExportInstructions	pfModel	pfModel.MaterialExportInstructions_Create()
Used to export a material from a part.		
MaterialOID	pfPart	
This class specifies the identifier of a Material. <i>For internal use only.</i>		
MaterialRemovalFeat	pfMaterialRemovalFeat	Downcast of pfFeature.Feature.
This feature type specifies a material removal feature.		
Materials	pfPart	Materials.create(), PartListMaterials()
This data type is used to specify a list of materials.		
Matrix3D	pfBase	Matrix3D.create(), Transform3D.GetMatrix()
This data type is used to describe a three-dimensional matrix.		
MeasureFeat	pfMeasureFeat	Downcast of pfFeature.Feature.
This feature type specifies a measure feature.		
MergeFeat	pfMergeFeat	Downcast of pfFeature.Feature.
This feature type specifies a merge feature.		
MFG	pfMFG	Session.CreateMFG(). Also, by down-casting pfModel.Model.
This class describes a manufacturing object.		
MFGCLExportInstructions	pfModel	Base class; not returned.
Base class to classes that export cutter-location files.		
MFGFeatCLExportInstructions	pfModel	pfModel.MFGFeatCLExportInstructions_Create()
Used to export a cutter location (CL) file for one NC sequence in a manufacturing assembly.		
MFGGatherFeat	pfMFGGatherFeat	Downcast of pfFeature.Feature.
This feature type specifies a gather feature.		
MFGMergeFeat	pfMFGMergeFeat	Downcast of pfFeature.Feature.
This feature type specifies a manufacturing merge feature.		
MFGOperCLExportInstructions	pfModel	pfModel.MFGOperCLExportInstructions_Create()
Used to export a cutter location (CL) file for all the NC sequences in an operation.		
MFGRefineFeat	pfMFGRefineFeat	Downcast of pfFeature.Feature.

Class	Package	Returned by
This feature type specifies a manufacturing refine feature.		
MFGTrimFeat	pfcMFGTrimFeat	Downcast of pfcFeature.Feature.
This feature type specifies a manufacturing trim feature.		
MFGUseVolumeFeat	pfcMFGUseVolumeFeat	Downcast of pfcFeature.Feature.
This feature type specifies a manufacturing use volumes feature.		
MillFeat	pfcMillFeat	Downcast of pfcFeature.Feature.
This feature type specifies a milling feature.		
Model	pfcModel	Selection.GetSelModel(), Window.GetModel(), CompModelReplace.GetNewModel(), CableParamsFileInstructions.GetMdl()
This class specifies the information about a model.		
ModelDescriptor	pfcModel	pfcModelDescriptor.ModelDescriptor_Create(), Model.GetDescr()
This class describes the descriptor for a model.		
ModelDescriptors	pfcModel	ModelDescriptors.create(), Model.ListDeclaredModels()
This data type is used to specify an array of model descriptors.		
ModelInfoExportInstructions	pfcModel	pfc-Model.ModelInfoExportInstructions_Create()
Used to export information about a model, including units information, features, and children.		
ModelItem	pfcModelItem	ModelItemOwner.GetItemById(), ModelItemOwner.GetItemByName(), Selection.GetSelItem(), FamColModelItem.GetRefItem()
This class defines a model item.		
ModelItemOID	pfcModelItem	pfcModel.ModelItemOID_Create()
This class specifies the owner of a model item. <i>For internal use only.</i>		
ModelItemOwner	pfcModelItem	Base class; not returned.
This class specifies the owner of a model item.		
ModelItems	pfcModelItem	ModelItems.create(), Feature.ListSubItems(), ModelItemOwner.ListItems(), Layer.ListItems()
Specifies a list of model items.		

Class	Package	Returned by
ModelItemType	pfcModelItem	ModelItemType.FromInt() or by using any of the static instances (e.g., ITEM_SURFACE)
This enumerated type lists the different kinds of model item.		
ModelItemTypes	pfcModelItem	ModelItemTypes.create(), Solid.ExcludeTypes()
Specifies a list of model item types.		
ModelOID	pfcModel	pfcModelOID.ModelOID_Create(), Model.GetOID()
This class describes a model owner. <i>For internal use only.</i>		
Models	pfcModel	Models.create(), Session.ListModels()
This data type is used to specify a list of models.		
ModelType	pfcModel	ModelType.FromInt() or by using any of the static instances (e.g., MDL_ASSEMBLY)
This enumerated type lists the supported model types.		
MoldFeat	pfcMoldFeat	Downcast of pfcFeature.Feature.
This feature type specifies a mold feature.		
NamedModelItem	pfcModelItem	Base class; not returned.
This class specifies the name of a model item.		
NeckFeat	pfcNeckFeat	Downcast of pfcFeature.Feature.
This feature type specifies a neck feature.		
Note	pfcNote	pfcSolid.CreateNote()
Specifies the information for a note.		
NoteLeader	pfcNote	pfcNote.NoteLeader_Create()
Specifies the note leader information.		
NoteLeaders	pfcNote	NoteLeaders.create(), Parametric-NotePlacement.GetLeaders()
Specifies an array of note leaders.		
NoteLeaderType	pfcNote	NoteLeaderType.FromInt() or by using any of the static instances (e.g., NOTE_LEADER_NONE)
This enumerated type lists the possible kids of note leader.		
NotePlacement	pfcNote	Note.GetPlacement()
Specifies the placement of the note.		
Object	pfcObject	Base class; not returned.

Class	Package	Returned by
Base classes to classes that represent Pro/ENGINEER objects.		
OffsetCurveDirection	pfcCurveFeat	OffsetCurveDirection.FromInt() or by using any of the static instances (e.g., OFFSET_SIDE_ONE)
This enumerated type specifies the direction of an offset.		
OffsetFeat	pfcOffsetFeat	Downcast of pfcFeature.Feature.
This feature type specifies an offset feature.		
OID	pfcObject	Child.GetOID()
This class defines the owner identifier object. <i>For internal use only.</i>		
OperationComponentFeat	pfcOperationComponentFeat	Downcast of pfcFeature.Feature.
This feature type specifies an operation component feature.		
OperationFeat	pfcOperationFeat	Downcast of pfcFeature.Feature.
This feature type specifies an operation feature.		
OptegraVisExportInstructions	pfcModel	pfc-Model.OptegraVisExportInstructions_Create()
Used to export a part or assembly in Optegra Vis format.		
Outline2D	pfcBase	Outline2D.create(), Contour.EvalOutline()
This data type is used to specify a two-dimensional outline.		
Outline3D	pfcBase	Outline3D.create(), Solid.GetGeomOutline(), Solid.EvalOutline()
This data type is used to specify a three-dimensional outline.		
Parameter	pfcModelItem	ParameterOwner.CreateParam(), ParameterOwner.GetParam(), ParameterOwner.SelectParam(), FamColParam.GetRefParam(), Parameters.get(), pfcModelItem.Create*ParamValue()
This class defines a parameter object.		
ParameterOwner	pfcModelItem	Base class; not returned.
This class defines a parameter owner object.		
Parameters	pfcModelItem	Parameters.create()
Specifies a list of parameters.		
ParametricNotePlacement	pfcNote	pfc-Note.ParametricNotePlacement_Create()

Class	Package	Returned by
Defines the parametric placement of a note.		
ParamOld	pfcModelItem	pfcModel.ParamOld_Create(), ParameterOwner.ListParams()
This class specifies the owner of a parameter. <i>For internal use only.</i>		
ParamType	pfcSession	ParamType.FromInt() or by using any of the static instances (e.g., DIMTOL_PARAM)
Enumeration of parameters types that is used to specify which parameters to display.		
ParamValue	pfcModelItem	BaseParameter.GetValue(), Family-Member.GetCell(), ParamValues.get(),
This class describes the value of the parameter.		
ParamValues	pfcModelItem	ParamValues.create()
This data type is used to specify an array of parameters.		
ParamValueType	pfcModelItem	ParamValueType.FromInt() or by using any of the static instances (e.g., PARAM_STRING)
This enumerated type lists the possible kinds of parameter value.		
Parent	pfcObject	Child.GetDBParent()
This class specifies a parent object.		
Part	pfcPart	Session.CreatePart()
This class defines the material data for a part.		
PatchFeat	pfcPatchFeat	Downcast of pfcFeature.Feature.
This feature type specifies a patch.		
PipeBranchFeat	pfcPipeBranchFeat	Downcast of pfcFeature.Feature.
This feature type specifies a pipe branch.		
PipeExtendFeat	pfcPipeExtendFeat	Downcast of pfcFeature.Feature.
This feature type specifies a pipe extension.		
PipeFeat	pfcPipeFeat	Downcast of pfcFeature.Feature.
This feature type specifies a pipe feature.		
PipeFollowFeat	pfcPipeFollowFeat	Downcast of pfcFeature.Feature.
This feature type specifies a follow feature, which is used in pipe routing.		
PipeJoinFeat	pfcPipeJoinFeat	Downcast of pfcFeature.Feature.
This feature type specifies a pipe join feature.		
PipeJointFeat	pfcPipeJointFeat	Downcast of pfcFeature.Feature.
This feature type specifies a pipe joint.		

Class	Package	Returned by
PipeLineFeat	pfcPipeLineFeat	Downcast of pfcFeature.Feature.
This feature type specifies a pipeline feature.		
PipePointToPointFeat	pfcPipePointToPointFeat	Downcast of pfcFeature.Feature.
This feature type specifies a point-to-point pipe feature.		
PipeSetStartFeat	pfcPipeSetStartFeat	Downcast of pfcFeature.Feature.
This feature type specifies a start feature, which is used in the Pro/PIPING module.		
PipeTrimFeat	pfcPipeTrimFeat	Downcast of pfcFeature.Feature.
This feature type specifies a trim feature, which is used in the Pro/PIPING module.		
Placement	pfcBase	Placement.FromInt() or by using any of the static instances (e.g., PLACE_INSIDE)
This enumerated type lists the possible placement types for points on contours.		
Plane	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a plane.		
PlotInstructions	pfcModel	pfcModel.PlotInstructions_Create()
Used with Model.Export() to plot a part, drawing, or assembly.		
PlotPageRange	pfcModel	PlotPageRange.FromInt() or by using any of the static instances (e.g., PLOT_RANGE_CURRENT)
This enumerated type specifies which pages to plot.		
PlotPaperSize	pfcModel	PlotPaperSize.FromInt() or by using any of the static instances (e.g., BSIZEPLOT)
This enumerated type specifies the size of the paper used for the plot.		
PlyFeat	pfcPlyFeat	Downcast of pfcFeature.Feature.
This feature type specifies a ply feature.		
Point	pfcGeometry	Downcast of pfcModelItem.ModelItem.
This class defines a point.		
Point2D	pfcBase	Point2D.create(), Outline2D.get()
This data type is used to specify a two-dimensional point.		
Point3D	pfcBase	Point3D.create(), Outline3D.get(), and additional methods that return multiple points
This data type is used to specify a three-dimensional point.		
Point3Ds	pfcBase	Point3Ds.create(), Polygon.GetVertices()

Class	Package	Returned by
Defines a list of three-dimensional points.		
Polygon	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines a polygon.		
PositionFoldFeat	pfcPositionFoldFeat	Downcast of pfcFeature.Feature.
This feature type specifies a position fold feature.		
ProcessStepFeat	pfcProcessStepFeat	Downcast of pfcFeature.Feature.
This feature type specifies a process step feature, which is used in the Pro/PROCESS for ASSEMBLIES module.		
ProgramExportInstructions	pfcModel	pfc-Model.ProgramExportInstructions_Create()
Used to export a program file for a part or assembly, which can be edited to change the model.		
ProtrusionFeat	pfcProtrusionFeat	Downcast of pfcFeature.Feature.
This feature type specifies a protrusion.		
Quilt	pfcGeometry	Surface.GetOwnerQuilt(). Also, by downcasting pfcModelItem.ModelItem.
This class defines a quilt.		
RefDimension	pfcDimension	Downcast of pfcModelItem.ModelItem.
This class describes a reference dimension.		
RegenInstructions	pfcSolid	pfcSolid.RegenInstructions_Create()
This class describes the regeneration instructions of a feature.		
RelationExportInstructions	pfcModel	pfc-Model.RelationExportInstructions_Create()
Used to export a list of the relations and parameters in a part or assembly.		
RemoveSurfacesFeat	pfcRemoveSurfacesFeat	Downcast of pfcFeature.Feature.
This feature type specifies a removed-surface feature.		
RenderExportInstructions	pfcModel	pfc-Model.RenderExportInstructions_Create()
Used to export a part or assembly in RENDER format.		
ReorderAfterOperation	pfcFeature	Feature.CreateReorderAfterOp()
This class defines how to reorder the features in the regeneration order list.		
ReorderBeforeOperation	pfcFeature	Feature.CreateReorderBeforeOp()
This class determines how to move the features backward in the regeneration order list.		

Class	Package	Returned by
ReplaceSurfaceFeat	pfcReplaceSurfaceFeat	Downcast of pfcFeature.Feature.
This feature type specifies a replaced surface feature.		
ResumeOperation	pfcFeature	Feature.CreateResumeOp()
Specifies a resume operation for a feature.		
RetrieveModelOptions	pfcSession	pfcSession.RetrieveModelOptions_Create()
This class determines what information about the simplified representations in a model to retrieve.		
RevolvedSurface	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a revolved surface.		
RibbonCableFeat	pfcRibbonCableFeat	Downcast of pfcFeature.Feature.
This feature type specifies a ribbon cable.		
RibbonExtendFeat	pfcRibbonExtendFeat	Downcast of pfcFeature.Feature.
This feature type specifies a ribbon extension.		
RibbonPathFeat	pfcRibbonPathFeat	Downcast of pfcFeature.Feature.
This feature type specifies a ribbon path feature.		
RibbonSolidFeat	pfcRibbonSolidFeat	Downcast of pfcFeature.Feature.
This feature type specifies a solid ribbon.		
RibFeat	pfcRibFeat	Downcast of pfcFeature.Feature.
This feature type specifies a rib feature.		
RipFeat	pfcRipFeat	Downcast of pfcFeature.Feature.
This feature type specifies a rip feature, which is used in the Pro/NC-SHEETMETAL module.		
RoundFeat	pfcRoundFeat	Downcast of pfcFeature.Feature.
This feature type specifies a round feature.		
RuledSurface	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a ruled surface.		
SawFeat	pfcSawFeat	Downcast of pfcFeature.Feature.
This feature type specifies a saw feature.		
Selection	pfcSelect	Selections.get(), NoteLeader.GetSel()
This class contains the selection information.		
SelectionOptions	pfcSelect	pfcSelect.SelectionOptions_Create()
This class describes the selection options.		
Selections	pfcSelect	Selections.create(), Session.Select()
This data type is used to specify an array of selections.		
Session	pfcSession	pfcGlobo.GetProESession()

Class	Package	Returned by
This class defines the information about a session object.		
SessionActionListener_u	pfcSession	Base class; not returned.
Abstract base class that all user-defined SessionActionListener classes must extend.		
SessionActionListener	pfcSession	Base class; not returned.
Interface to be implemented by user-defined classes that respond to session events.		
SETExportInstructions	pfcModel	pfc-Model.SETExportInstructions_Create()
This class defines a ruled surface.		
SETFeat	pfcSETFeat	Downcast of pfcFeature.Feature.
This feature type specifies a SET file.		
ShaftFeat	pfcShaftFeat	Downcast of pfcFeature.Feature.
This feature type specifies a shaft.		
SheetmetalClampFeat	pfcSheetmetalClampFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal clamp.		
SheetmetalConversionFeat	pfcSheetmetalConversion-Feat	Downcast of pfcFeature.Feature.
This feature type specifies a conversion feature, which is used in the Pro/NC-SHEETMETAL module.		
SheetmetalCutFeat	pfcSheetmetalCutFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal cut feature.		
SheetmetalOptimizeFeat	pfcSheetmetalOptimizeFeat	Downcast of pfcFeature.Feature.
This feature type specifies an optimize feature, used in the Pro/NC-SHEETMETAL module.		
SheetmetalPopulateFeat	pfcSheetmetalPopulateFeat	Downcast of pfcFeature.Feature.
This feature type specifies a populate feature, which is used in the Pro/NC-SHEETMETAL module.		
SheetmetalPunchPointFeat	pfcSheetmetalPunchPoint-Feat	Downcast of pfcFeature.Feature.
This feature type specifies a punch point, which is used in the Pro/NC-SHEETMETAL module.		
SheetmetalShearFeat	pfcSheetmetalShearFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal shear feature.		
SheetmetalZoneFeat	pfcSheetmetalZoneFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal zone.		
ShellFeat	pfcShellFeat	Downcast of pfcFeature.Feature.
This feature type specifies a shell.		
ShrinkageFeat	pfcShrinkageFeat	Downcast of pfcFeature.Feature.

Class	Package	Returned by
This feature type specifies a shrinkage feature, which is used in the Pro/MOLD and Pro/CAST modules.		
ShrinkDimFeat	pfcShrinkDimFeat	Downcast of pfcFeature.Feature.
This feature type specifies a shrink dimension feature, which is used in the Pro/MOLD and Pro/CAST modules.		
SilhouetteTrimFeat	pfcSilhouetteTrimFeat	Downcast of pfcFeature.Feature.
This feature type specifies a silhouette trim feature.		
STLASCIIExportInstructions	pfcModel	pfc-Model.SLAASCIIExportInstructions_Create()
Used to export a part or assembly to an ASCII STL file.		
STLBinaryExportInstructions	pfcModel	pfc-Model.SLABinaryExportInstructions_Create()
Used to export a part or assembly in a binary STL file.		
SlotFeat	pfcSlotFeat	Downcast of pfcFeature.Feature.
This feature type specifies a slot.		
SMMFGApproachFeat	pfcSMMFGApproachFeat	Downcast of pfcFeature.Feature.
This feature type specifies an approach feature, which is used in sheetmetal manufacturing.		
SMMFGCosmeticFeat	pfcSMMFGCosmeticFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cosmetic feature used in sheetmetal manufacturing.		
SMMFGCutFeat	pfcSMMFGCutFeat	Downcast of pfcFeature.Feature.
This feature type specifies a cut feature for sheetmetal manufacturing.		
SMMFGFormFeat	pfcSMMFGFormFeat	Downcast of pfcFeature.Feature.
This feature type specifies a form feature used in sheetmetal manufacturing.		
SMMFGMaterialRemoveFeat	pfcSMMFGMaterialRemoveFeat	Downcast of pfcFeature.Feature.
This feature type specifies a material removal feature, which is used in sheetmetal manufacturing.		
SMMFGOffsetFeat	pfcSMMFGOffsetFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal offset feature.		
SMMFGPunchFeat	pfcSMMFGPunchFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal punch feature.		
SMMFGShapeFeat	pfcSMMFGShapeFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal shape feature.		
SMMFGSlotFeat	pfcSMMFGSlotFeat	Downcast of pfcFeature.Feature.
This feature type specifies a sheetmetal slot.		

Class	Package	Returned by
Solid	pfcSolid	ComponentPath.GetLeaf()
This class defines a solid.		
SolidActionListener _u	pfcSolid	Base class; not returned.
Abstract base class that all user-defined SolidActionListener classes must extend.		
SolidActionListener	pfcSolid	Base class; not returned.
Interface to be implemented by user-defined classes that respond to solid events.		
SolidifyFeat	pfcSolidifyFeat	Downcast of pfcFeature.Feature.
This feature type specifies a solidify feature, which is used in the Pro/COMPOSITE module.		
SolidPipeFeat	pfcSolidPipeFeat	Downcast of pfcFeature.Feature.
This feature type specifies a solid pipe feature.		
SpinalBendFeat	pfcSpinalBendFeat	Downcast of pfcFeature.Feature.
This feature type specifies a spinal bend.		
Spline	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines a spline.		
SplinePoint	pfcGeometry	SplinePoints.get()
This class defines a spline point.		
SplinePoints	pfcGeometry	SplinePoints.create(), Spline.Get-Points()
This data type is used to specify an array of spline points.		
SplitFeat	pfcSplitFeat	Downcast of pfcFeature.Feature.
This feature type specifies a split feature.		
SplitSurfaceFeat	pfcSplitSurfaceFeat	Downcast of pfcFeature.Feature.
This feature type specifies a split-surface feature.		
SpoolFeat	pfcSpoolFeat	Downcast of pfcFeature.Feature.
This feature type specifies a spool.		
SpringBackFeat	pfcSpringBackFeat	Downcast of pfcFeature.Feature.
This feature type specifies a spring-back feature.		
StdColor	pfcBase	Session.SetTextColor(), GetRGB-FromStdColor(), StdColor.FromInt(), or by using any of the static instances (e.g., COLOR_SHEETMETAL)
This enumerated type lists the supported color types.		
StdLineStyle	pfcBase	Session.SetLineStyle(), StdLineStyle.FromInt(), or by using any of the static instances (e.g., LINE_SOLID)

Class	Package	Returned by
This enumerated type lists the possible line styles.		
STEPExportInstructions	pfcModel	pfc-Model.STEPExportInstructions_Create()
Used to export a part or assembly in STEP format.		
StringOld	pfcObject	Base class; not returned.
This class specifies a string identifier. <i>For internal use only.</i>		
SubHarnessFeat	pfcSubHarnessFeat	Downcast of pfcFeature.Feature.
This feature type specifies a subharness.		
SuppressOperation	pfcFeature	Feature.CreateSuppressOp()
This class defines a suppress operation.		
Surface	pfcGeometry	Surfaces.get(), Edge.GetSurface1(), GetSurface2(). Also, by downcasting pfcModelItem.ModelItem.
This class defines a surface.		
SurfaceModelFeat	pfcSurfaceModelFeat	Downcast of pfcFeature.Feature.
This feature type specifies a surface model.		
Surfaces	pfcGeometry	Surfaces.create(), Quilt.ListElements(), Surface.ListSameSurfaces().
This data type is used to describe an array of surfaces.		
SurfXYZData	pfcGeometry	Surface.Eval3DData()
Stores the results of a surface evaluation.		
TabulatedCylinder	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a tabulated cylinder.		
Text	pfcGeometry	Downcast of pfcGeometry.Curve.
This class defines the text information.		
TextStyle	pfcBase	pfcBase.TextStyle_Create(), Text.GetStyle(). Note.GetStyle(),
This class specifies the text attributes.		
ThickenFeat	pfcThickenFeat	Downcast of pfcFeature.Feature.
This feature type specifies a thicken feature, which is used in the Pro/NC-SHEETMETAL module.		
ThreadFeat	pfcThreadFeat	Downcast of pfcFeature.Feature.
This feature type specifies a thread.		
Torus	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a torus.		

Class	Package	Returned by
TorusFeat	pfcTorusFeat	Downcast of pfcFeature.Feature.
This feature type is used for a torus.		
Transform3D	pfcBase	pfcBase.Transform3D_Create(), ComponentPath.GetTransform(), CoordSystem.GetCoordSys(), TransformedSurface.GetCoordSys() View.GetTransform(), Window.GetTransform()
This class provides information about the transformation.		
TransformedSurface	pfcGeometry	Downcast of pfcGeometry.Surface.
This class defines a transformed surface.		
TurnFeat	pfcTurnFeat	Downcast of pfcFeature.Feature.
This feature type specifies a turn feature, which is used in the manufacturing module.		
TwistFeat	pfcTwistFeat	Downcast of pfcFeature.Feature.
This feature type specifies a twist feature.		
UDFClampFeat	pfcUDFClampFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF clamp.		
UDFFeat	pfcUDFFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF feature.		
UDFNotchFeat	pfcUDFNotchFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF notch feature.		
UDFPunchFeat	pfcUDFPunchFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF punch feature.		
UDFRmdtFeat	pfcUDFRmdtFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF for rapid mold design.		
UDFThreadFeat	pfcUDFThreadFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF thread feature.		
UDFWorkRegionFeat	pfcUDFWorkRegionFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF work region feature.		
UDFZoneFeat	pfcUDFZoneFeat	Downcast of pfcFeature.Feature.
This feature type specifies a UDF zone feature.		
UICommand	pfcCommand	Session.UICreateCommand()
An action-listener object for menu commands.		
UICommandActionListener_u	pfcCommand	Base class; not returned.
Abstract base class that all user-defined UICommandActionListener classes must extend.		

Class	Package	Returned by
UICommandActionListener	pfcCommand	Base class; not returned.
Interface to be implemented by user-defined classes that respond to UI command events.		
UnbendFeat	pfcUnbendFeat	Downcast of pfcFeature.Feature.
This feature type specifies an unbend feature, which is used in the Pro/NC-SHEETMETAL module.		
UserFeat	pfcUserFeat	Downcast of pfcFeature.Feature.
This feature type specifies a user feature.		
UVParams	pfcBase	UVParams.create(), EdgeEvalData.GetPoint*(), Selection.GetParams(), SurfXYZData.GetParams()
This data type is used to specify UV parameters.		
UVVector	pfcBase	UVVector.create(), EdgeEvalData.GetDerivative*()
This data type is used to specify a UV-vector.		
VDAExportInstructions	pfcModel	pfc-Model.CATIAExportInstructions_Create().VDAExportInstructions_Create()
Used to export a part or assembly in VDA format.		
VDAFeat	pfcVDAFeat	Downcast of pfcFeature.Feature.
This feature type specifies a VDA file.		
Vector2D	pfcBase	Vector2D.create()
This data type is used to specify a two-dimensional vector.		
Vector3D	pfcBase	Vector3D.create(), Vectors3D.get(), and additional methods that return information about geometric curves.
This data type is used to specify a three-dimensional vector.		
Vector3Ds	pfcBase	Vector3Ds.create()
This data type is used to specify a list of three-dimensional vectors.		
View	pfcView	ViewOwner.GetView(), ViewOwner.SaveView(), ViewOwner.RetrieveView(), Views.get()
This class specifies information about a view.		
ViewOId	pfcView	pfcView.ViewOId_Create()
This class specifies the owner of a view. <i>For internal use only.</i>		
ViewOwner	pfcView	Base class; not returned.
This class describes the owner of the view.		

Class	Package	Returned by
Views	pfcView	Views.create(), ViewOwner.ListViews()
This data type is used to specify an array of views.		
VolSplitFeat	pfcVolSplitFeat	Downcast of pfcFeature.Feature.
This feature type specifies a split-volume feature.		
WallFeat	pfcWallFeat	Downcast of pfcFeature.Feature.
This feature type specifies a wall, which is used in the Pro/NC-SHEETMETAL module.		
WaterLineFeat	pfcWaterLineFeat	Downcast of pfcFeature.Feature.
This feature type specifies a waterline feature.		
WeldEdgePrepFeat	pfcWeldEdgePrepFeat	Downcast of pfcFeature.Feature.
This feature type specifies a preparation edge, which is used in the Pro/WELDING module.		
WeldFilletFeat	pfcWeldFilletFeat	Downcast of pfcFeature.Feature.
This feature type specifies a welding fillet.		
WeldGrooveFeat	pfcWeldGrooveFeat	Downcast of pfcFeature.Feature.
This feature type specifies a weld groove.		
WeldingRodFeat	pfcWeldingRodFeat	Downcast of pfcFeature.Feature.
This feature type specifies a welding rod.		
WeldPlugSlotFeat	pfcWeldPlugSlotFeat	Downcast of pfcFeature.Feature.
This feature type specifies a plug-slot feature, which is used in the Pro/WELDING module.		
WeldSpotFeat	pfcWeldSpotFeat	Downcast of pfcFeature.Feature.
This feature type specifies a welding spot.		
Window	pfcWindow	Session.GetCurrentWindow(), Session.CreateModelWindow(), Session.OpenFile(), Session.GetWindow(), Windows.get()
This class describes the attributes of a window.		
WindowOId	pfcWindow	pfcWindow.WindowOId_Create()
This class specifies a window identifier. <i>For internal use only.</i>		
Windows	pfcWindow	Session.ListWindows(), Windows.create()
This data type is used to specify an array of windows.		
WorkcellFeat	pfcWorkcellFeat	Downcast of pfcFeature.Feature.
This feature type specifies a workcell.		
XBadArgument	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when you specify an invalid argument.		

Class	Package	Returned by
XBadGetParamValue	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when you specify an invalid parameter type.		
XBadOutlineExcludeType	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when you specify an invalid outline exclusion type.		
XInAMethod	pfcExceptions	Base class of most J-Link exceptions.
This exception is thrown when you specify an invalid method name.		
XInvalidEnumValue	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when you specified an invalid enumerated value.		
XPFC	pfcExceptions	Base class of most J-Link exceptions.
This exception is thrown when a general usage error occurs.		
XSequenceTooLong	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when the sequence length exceeds the maximum allowable size.		
XStringTooLong	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when the specified string exceeds the maximum allowable length.		
XToolkitError	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when there is a toolkit error.		
XUnimplemented	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when there is a call to a function that is unimplemented.		
XUnknownModelExtension	pfcExceptions	Created, thrown in J-Link code.
This exception is thrown when you specify an invalid model extension.		
ZoneFeat	pfcZoneFeature	Downcast of pfcFeature.Feature
This feature type specifies a zone feature.		

Index

A

- abstract keyword 2-6
- Accuracy
 - getting and setting 11-2
- ActionListener
 - creating 21-2
 - definition 2-6
 - description of the class 3-10
 - events 21-2
 - feature-level 21-10
 - session-level 21-4
 - solid-level 21-8
 - types 21-2
 - UI command 21-5
- ActionSource interface 21-3
 - definition 3-11
- Activate
 - window 12-4
- Adapters 2-6
- Add
 - items to a layer 13-4
- Allocate
 - simplified representations 23-4
- allow_stop field 1-3
- APIWizard
 - browsing
 - objects 5-9
 - user's guide 5-11
 - defined 5-2
 - display frame 5-7
 - find (search mechanism) 5-13
 - interface defined 5-6
 - Internet Explorer
 - Java2 plug in 5-3
 - Java2 plugin 5-6
 - requirements 5-3
 - navigating the tree 5-9
- Netscape Navigator
 - Java2 plugin not recommended 5-6
 - requirements 5-3
- searching for a string 5-13
- supported web browsers 5-3
- Swing
 - class path-NT 5-4
 - class path-UNIX 5-4
 - download JFC archive 5-3
 - Java Foundation Class 5-3
 - topic/object selection frame 5-6
 - tree updating
 - defined 5-6
 - Java2 plugin requirements 5-6
- Applications
 - creating 3-14
 - hierarchy 3-14
 - registering 1-4
 - running 1-5
 - setting up 1-2
 - standalone 1-2
- Arcs
 - description 16-4
 - representation F-14
- Area
 - surface 16-11
- Arguments, optional 4-2
- Arrays 3-7
 - sample class 3-8
- Arrows 16-5
- Assemblies
 - coordinate systems 12-8
 - creating 11-2
 - hierarchy 19-3

- structure of 19-2
- Axes 16-12
 - evaluating 16-12

B

- Bounding box 11-5
- Browsing
 - objects with APIWizard 5-9
 - Pro/TOOLKIT user's guide with APIWizard 5-11
- B-splines
 - description 16-4
- Button
 - placing 8-14
- Buttons
 - creating 8-2
- Bytecodes 2-4

C

- catch block
 - using multiple 3-22
- catch keyword 2-7
- Cells
 - accessing 20-4
- Child.GetDBParent description
 - method 10-21
- Children 14-2
- cipjava 3-14
- Circles 16-5
- Classes
 - list of G-2
 - types 3-2
- Clear
 - window 12-3
- Close
 - window 12-4
- Collect
 - garbage 2-4
- Colors 6-8
- Commands
 - designating 8-12
- Comments 2-7
- Composite curves
 - description 16-4
- Cones
 - class representation 16-9
 - geometry representation F-4
- Configuration file
 - PROTKDAT option 1-4
 - toolkit_registry_file option 1-4
- Configuration options 6-6
- Constants 2-4
- Contours
 - evaluating 16-7
 - traversing 16-2

- Contours, locating in a model 16-7
- Coons patches
 - geometry representation F-8
- Coordinate systems 12-6, 16-12
 - assemblies 12-8
 - datum 12-8
 - drawing 12-7
 - Drawing View 12-7
 - evaluating 16-12
 - screen 12-7
 - section 12-8
 - solid 12-6
 - window 12-7
- Coordinate transformations 12-6
- Copy
 - models 9-9
- Create
 - action listeners 21-2
 - applications 3-14
 - assembly 11-2
 - buttons 8-2
 - family table columns 20-5
 - family table instance 20-3
 - layer 13-4
 - local group 14-7
 - material 11-15
 - menus 8-2
 - parameters 17-4
 - part 11-2
 - simplified representations 23-4
 - UDFs 14-9
 - window 12-2
- Create Interactively Defined UDFs 14-11
- Creating UDFs 14-10
- Curves 16-3
 - data structures F-13
 - determining the type 16-4
 - principal 16-11
 - t parameter 16-3
 - types 16-4
 - reserved 16-5
- Cylinders 16-9
 - geometry representation F-3
 - spline surfaces F-11
 - tabulated 16-9
 - geometry representation F-7

D

- Data types 2-6
 - enums 3-9
- delay_start field 1-3
- Delete
 - feature pattern 14-6
 - models 9-9
 - row from a family table 20-3

- simplified representations 23-4
- Dependencies
 - creating 1-7
- Depth
 - selection 7-4
- Descriptors
 - model 9-3
- Designating
 - command 8-13
 - commands 8-12
 - icon 8-12
- Designating commands 8-12
- Detail.DetailEntityInstructions interface
 - description 10-52
- Detail.DetailEntityItem interface
 - description 10-52
- Diameter
 - surface 16-11
- Dictionaries 3-9
- Dimension2D.Dimension2D interface
 - description 10-26
- Dimensions 17-13
 - information 17-13
 - tolerances 17-14
- Display
 - model in window 12-2
 - models 9-9
 - selection 7-5
- Display status
 - of layers 13-4
- Documentation
 - see APIWizard 5-2
- Drawing
 - models
 - code example 10-17
 - sheets
 - example 10-12
 - transformations 12-11
 - views
 - code example 10-17

E

- Edges 16-3
 - determining the type 16-4
 - evaluating 16-5
 - t parameter 16-3
 - traversing 16-2
 - types 16-4
 - reserved 16-5
- Ellipses 16-5
- end field 1-4
- Enumerated types 3-9
 - sample class 3-10
- Erase
 - models 9-9

- Evaluation
 - axes 16-12
 - contour 16-7
 - coordinate system 16-12
 - edge 16-5
 - point 16-12
 - surface 16-10
- Event handling
 - try blocks 2-7
 - try-catch-finally blocks 3-15
- Examples
 - creating drawing views 10-17
 - listing views 10-23
 - normalizing a coordinate transformation matrix
 - 12-11
 - of ActionListeners 3-12
 - of arrays 3-8
 - of dictionaries 3-10
 - of sequences 3-7
 - of utilities 3-13
 - retrieving a model 9-5
 - setting angular tolerances 17-15
 - using drawing sheets 10-12
 - visiting the items in a simplified representation
 - 23-5
- Exceptions
 - ActionListener 3-11
 - array 3-8
 - enumerated type 3-10
 - handling in code 3-15
 - Pro/ENGINEER-related object 3-4 to 3-5
 - sequence 3-7
 - utility 3-13
- Export
 - files 22-2

F

- Faces
 - traversing 16-2
- Family tables 20-2
 - cells 20-4
 - columns
 - accessing 20-3
 - instances
 - accessing 20-2
 - symbols 20-3
- Features
 - accessing 14-2
 - creating 14-4
 - failed 14-2
 - groups 14-2, 14-7
 - identifiers 14-2
 - information 14-3
 - operations 14-4
 - parents 14-2

- patterns 14-6
- read-only 14-3
- resuming 14-4
- suppressing 14-4
- user-defined 14-9
- Fields
 - of ActionListeners 3-11
 - of arrays 3-8
 - of enumerated types 3-9
 - of Pro/ENGINEER-related objects 3-4
 - of sequences 3-6
 - of utilities 3-13
- Files
 - exporting 22-2
 - JAR 1-7
 - message 6-8
 - contents 6-9
 - naming restrictions 6-9
 - plotting 22-32
- Fillet surfaces
 - geometry representation F-8
- final keyword 2-5
- finally keyword 2-7
- Find
 - APIWizard search mechanism 5-13
- FocusListener 2-7
- Frames
 - display frame in APIWizard 5-7
 - topic/object selection 5-6

G

- Garbage collection 2-4
- General surface of revolution F-6
- Generic model
 - getting 20-3
- Geometry
 - solid edge 16-6
 - terms 16-2
 - traversal 16-2
- Groups 14-6, 14-9

H

- Hierarchy
 - application 3-14
- Highlight
 - selections 7-5

I

- Implementation
 - and inheritance 2-3
- Import
 - packages 3-14
- Information
 - Drawing 10-6

- Inheritance
 - of ActionListeners 3-11
 - of arrays 3-8
 - of enumerated types 3-10
 - of Pro/ENGINEER-related objects 3-3, 3-5
 - of sequences 3-6
 - of utilities 3-13
 - overview 2-3
- Initialize
 - ActionListeners 3-11
 - arrays 3-8
 - dictionaries 3-9
 - Pro/ENGINEER-related objects 3-2, 3-4
 - sequences 3-6
 - utilities 3-12
- Install
 - See J-Link Installing B-2
- Installation
 - See J-Link Installing B-2
- instanceof operator 2-5
- Interactive selection 7-2
- Interactively Defined UDFs
 - create 14-11
- Internet Explorer
 - Java2 plug in 5-3
 - requirements 5-3
- ItemListener 2-7

J

- JAR files 1-7
- Java
 - bytecodes 2-4
 - comments 2-7
 - data types 2-6
 - enumerated types 3-9
 - equivalents to constants 2-4
 - event handling 2-6
 - implementation 2-3
 - inheritance 2-3
 - jar command 1-7
 - javadoc 2-8
 - JDBC 2-2
 - JDK
 - functionality 2-2
 - JVM 2-4
 - keywords 2-4
 - overview 2-3
 - platform independence 2-4
 - polymorphism 2-3
- Java Virtual Machine 2-4
- java.applet API 2-2
- java.awt API 2-2
- java.io API 2-2
- java.lang API 2-2
- java_app_class field 1-3

- java_app_classpath field 1-3
- java_app_start field 1-3
- java_app_stop field 1-3
- Java2 plugin
 - not recommended for APIWizard with Netscape Navigator 5-6
 - recommended for APIWizard use with Internet Explorer 5-6
 - required for APIWizard with Internet Explorer 5-3
- javadoc tool 2-8
- J-Link
 - installing
 - test of B-2
- JLinkApplication.IsActive method
 - description 25-8
- jxthrowable exception
 - description 3-15

K

- Keywords
 - abstract 2-6
 - catch 2-7
 - final 2-5
 - finally 2-7
 - instanceof 2-5
 - using 16-4
 - native 2-6
 - new 2-5
 - package 2-5
 - private 2-5
 - protected 2-5
 - public 2-5
 - static 2-5
 - throw 2-7
 - try 2-7

L

- Layers 13-4
 - operations 13-4
- Lines
 - description 16-4
 - representation F-13
 - styles 6-8
- Lists
 - of children 14-2
 - of current windows 12-2
 - of layer items 13-4
 - of materials 11-15
 - of ModelItems 13-2
 - of parents 14-2
 - of pattern members 14-2, 14-7
 - of rows in a family table 20-3
 - of subitems 13-2
 - of views 12-5

- of windows 12-2
- Local groups
 - creating 14-7
- Locks 20-3

M

- Machines
 - setting up 1-2
- Macros 6-7
- Mass properties 11-12
- Materials 11-15
- Matrix
 - code example 12-11
- Matrix3D object 12-12
- Menus
 - creating 8-2
- Message files 6-8
 - contents 6-9
 - restrictions 6-9
- Message window
 - reading from 6-11
 - writing to 6-11
- Methods
 - of ActionListeners 3-11
 - of arrays 3-8
 - of dictionaries 3-9
 - of Pro/ENGINEER-related objects 3-3, 3-5
 - of sequences 3-6
 - of utilities 3-13
 - overloading and overriding 2-4
 - starting and stopping 1-7
- Model programs 1-5
 - definition 1-5
 - running 1-6
- ModelItems
 - evaluating 16-12
 - getting 13-2
 - information 13-3
 - types 13-2
- Models
 - descriptors 9-3
 - Drawing
 - Obtaining 10-6
 - exporting 22-2
 - getting 9-2
 - operations 9-9
 - retrieving 9-4
 - code example 9-5
- Modify
 - simplified representations 23-8

N

- name field 1-3
- native keyword 2-6
- Netscape Navigator

- requirements 5-3
- Swing required 5-3
- new keyword 2-5
- Normalize
 - matrix 12-11
- Notification of events 2-6
- NURBS
 - representation F-15
 - surface F-10

O

- Objects
 - browsing with APIWizard 5-9
- Open
 - file 9-4
- Operations
 - Drawing 10-7
 - feature 14-4
 - layer 13-4
 - model 9-9
 - solid 11-3, 22-41
 - view 12-5
 - window 12-3, 22-43
- Optional arguments 4-2
- Outlines
 - contour 16-7
- Overload
 - methods 2-4
- Override
 - methods 2-4

P

- package keyword 2-5
- Packages
 - importing 3-14
- Parameters 17-4
 - information 17-7
- ParamValue objects 17-2
- Parents 14-2
- Parts 11-15
 - creating 11-2
- Pattern leaders 14-2, 14-7
- Patterns 14-6
- pfcArgument.Argument.GetLabel method
 - description 25-3
- pfcArgument.Argument.GetValue method
 - description 25-3
- pfcArgument.Argument.SetLabel method
 - description 25-3
- pfcArgument.Argument.SetValue method
 - description 25-3
- pfcArgument.Argument.Create method
 - description 25-3
- pfcArgument.Arguments.create method
 - description 25-3

- pfcArgument.ArgValue.Getdiscr method
 - description 25-3
- pfcAssembly.Assembly.AssembleByCopy method
 - description 19-10
- pfcAssembly.Assembly.AssembleComponent
 - method
 - description 19-9
- pfcAssembly.Assembly.AssembleSkeleton method
 - description 19-21
- pfcAssembly.Assembly.AssembleSkeletonByCopy
 - method
 - description 19-21
- pfcAssembly.Assembly.CreateComponentPath
 - method
 - description 19-8
- pfcAssembly.Assembly.DeleteSkeleton method
 - description 19-21
- pfcAssembly.Assembly.GetActiveExplodedState
 - method
 - description 19-20
- pfcAssembly.Assembly.GetDefaultExplodedState
 - method
 - description 19-21
- pfcAssembly.Assembly.GetIsExploded method
 - description 19-20
- pfcAssembly.Assembly.GetSkeleton method
 - description 19-21
- pfcAssembly.Assembly.UnExplod method
 - description 19-20
- pfcAssembly.ComponentFeat.GetIsVisible method
 - description 19-9
- pfcAssembly.ComponentPath.GetComponentIds
 - method
 - description 19-9
- pfcAssembly.ComponentPath.GetLeaf method
 - description 11-2, 19-9
- pfcAssembly.ComponentPath.GetRoot method
 - description 11-2, 19-8
- pfcAssembly.ComponentPath.GetTransform method
 - description 19-9
- pfcAssembly.ComponentPath.SetComponentIds
 - method
 - description 19-9
- pfcAssembly.ComponentPath.SetRoot method
 - description 19-8
- pfcAssembly.ComponentPath.SetTransform method
 - description 19-9
- pfcAssembly.ExplodedState.Activate method
 - description 19-21
- pfcAsyncConnection.AsyncActionListener.OnTerminate
 - method
 - description 24-10
- pfcAsyncConnection.AsyncConnection.Disconnect
 - method
 - description 24-7
- pfcAsyncConnection.AsyncConnection.End method

description 24-5

pfAsyncConnection.AsyncConnection.EventProcesses method
description 24-10

pfAsyncConnection.AsyncConnection.GetConnectionId method
description 24-8

pfAsyncConnection.AsyncConnection.GetSession method
description 24-9

pfAsyncConnection.AsyncConnection.InterruptEventProcessing method
description 24-10

pfAsyncConnection.AsyncConnection.WaitForEvents method
description 24-10

pfAsyncConnection.ConnectionId.GetExternalRep method
description 24-8

pfAsyncConnection.pfAsyncConnection.AsyncConnection_GetActiveConnection method
description 24-7

pfAsyncConnection.pfAsyncConnection.AsyncConnection_Connect method
description 24-7

pfAsyncConnection.pfAsyncConnection.AsyncConnection_ConnectById method
description 24-8

pfAsyncConnection.pfAsyncConnection.AsyncConnection_ConnectWS method
description 24-7

pfAsyncConnection.pfAsyncConnection.AsyncConnection_Start method
description 24-5

pfAsyncConnection.pfAsyncConnection.ConnectionId_Create method
description 24-8

pfAsyncConnection.AsyncConnection.IsRunning method
description 24-9

pfBase.ActionSource.AddActionListener method
description 21-3

pfBase.ActionSource.RemoveActionListener method
description 21-3

pfBase.Transform3D.GetMatrix method
description 12-8

pfBase.Transform3D.GetOrigin method
description 12-8

pfBase.Transform3D.GetXAxis method
description 12-8

pfBase.Transform3D.GetYAxis method
description 12-8

pfBase.Transform3D.GetZAxis method
description 12-8

pfBase.Transform3D.Invert method

description 12-8, 12-10

pfBase.Transform3D.SetMatrix method
description 12-8

pfBase.Transform3D.SetOrigin method
description 12-8

pfBase.Transform3D.TransformPoint method
description 12-8

pfBase.Transform3D.TransformVector method
description 12-8

pfComponentFeat.ComponentFeat.ComponentFeat.ConstraintAttributes_Create method
description 19-11

pfComponentFeat.ComponentFeat.ComponentFeat.MoveThroughUI method
description 19-14

pfComponentFeat.ComponentFeat.ComponentFeat.RedefineThroughUI method
description 19-14

pfComponentFeat.ComponentFeat.ComponentFeat.SetConstraints method
description 19-10

pfComponentFeat.ComponentFeat.CreateReplaceOp method
description 19-6

pfComponentFeat.ComponentFeat.GetCompType method
description 19-4

pfComponentFeat.ComponentFeat.GetConstraints method
description 19-10

pfComponentFeat.ComponentFeat.GetIsBulkitem method
description 19-4

pfComponentFeat.ComponentFeat.GetIsFrozen method
description 19-5

pfComponentFeat.ComponentFeat.GetIsPackaged method
description 19-5

pfComponentFeat.ComponentFeat.GetIsPlaced method
description 19-5

pfComponentFeat.ComponentFeat.GetIsSubstitute method
description 19-4

pfComponentFeat.ComponentFeat.GetIsUnderconstrained method
description 19-5

pfComponentFeat.ComponentFeat.GetIsVisible method
description 19-6

pfComponentFeat.ComponentFeat.GetModelDescr method
description 19-5

pfComponentFeat.ComponentFeat.GetPosition method

description 19-6
 pfcComponentFeat.ComponentFeat.Regenerate method
 description 19-8
 pfcComponentFeat.ComponentFeat.SetCompType method
 description 19-4
 pfcDetail.Attachment.GetType method
 description 10-89
 pfcDetail.Detail.DetailNoteItem interface
 description 10-57
 pfcDetail.Detail.DetailSymbolInstInstructions interface
 description 10-76
 pfcDetail.DetailEntityInstructions.Create method
 description 10-52
 pfcDetail.DetailEntityInstructions.GetColor method
 description 10-53
 pfcDetail.DetailEntityInstructions.GetFontName method
 description 10-53
 pfcDetail.DetailEntityInstructions.GetGeometry method
 description 10-53
 pfcDetail.DetailEntityInstructions.GetIsConstruction method
 description 10-53
 pfcDetail.DetailEntityInstructions.GetView method
 description 10-54
 pfcDetail.DetailEntityInstructions.GetWidth method
 description 10-54
 pfcDetail.DetailEntityInstructions.SetColor method
 description 10-53
 pfcDetail.DetailEntityInstructions.SetFontName method
 description 10-53
 pfcDetail.DetailEntityInstructions.SetGeometry method
 description 10-53
 pfcDetail.DetailEntityInstructions.SetIsConstruction method
 description 10-53
 pfcDetail.DetailEntityInstructions.SetView method
 description 10-54
 pfcDetail.DetailEntityInstructions.SetWidth method
 description 10-54
 pfcDetail.DetailEntityItem.Draw method
 description 10-56
 pfcDetail.DetailEntityItem.Erase method
 description 10-56
 pfcDetail.DetailEntityItem.GetInstructions method
 description 10-56
 pfcDetail.DetailEntityItem.GetSymbolDef method
 description 10-56
 pfcDetail.DetailEntityItem.Modify method
 description 10-56
 pfcDetail.DetailGroupInstructions interface
 description 10-64
 pfcDetail.DetailGroupInstructions.Create method
 description 10-65
 pfcDetail.DetailGroupInstructions.GetElements method
 description 10-65
 pfcDetail.DetailGroupInstructions.GetIsDisplayed method
 description 10-65
 pfcDetail.DetailGroupInstructions.GetName method
 description 10-65
 pfcDetail.DetailGroupInstructions.SetElements method
 description 10-65
 pfcDetail.DetailGroupInstructions.SetIsDisplayed method
 description 10-65
 pfcDetail.DetailGroupInstructions.SetName method
 description 10-65
 pfcDetail.DetailGroupInstructions_Create method
 description 10-51
 pfcDetail.DetailGroupItem.Draw method
 description 10-66
 pfcDetail.DetailGroupItem.Erase method
 description 10-66
 pfcDetail.DetailGroupItem.GetInstructions method
 description 10-65
 pfcDetail.DetailGroupItem.Modify method
 description 10-66
 pfcDetail.DetailItemOwner.CreateDetailItem method
 description 10-51
 pfcDetail.DetailItemOwner.ListDetailItems method
 description 10-51
 pfcDetail.DetailItemOwner.RetrieveSymbolDefinition method
 description 10-71
 pfcDetail.DetailNoteInstructions interface
 description 10-57
 pfcDetail.DetailNoteInstructions.Create method
 description 10-58
 pfcDetail.DetailNoteInstructions.GetColor method
 description 10-59
 pfcDetail.DetailNoteInstructions.GetHorizontal method
 description 10-59
 pfcDetail.DetailNoteInstructions.GetIsDisplayed method
 description 10-59
 pfcDetail.DetailNoteInstructions.GetIsMirrored method
 description 10-59
 pfcDetail.DetailNoteInstructions.GetIsReadOnly method
 description 10-59
 pfcDetail.DetailNoteInstructions.GetLeader method

description 10-59
 pfcDetail.DetailNoteInstructions.GetTextAngle method
 description 10-59
 pfcDetail.DetailNoteInstructions.GetTextLines method
 description 10-59
 pfcDetail.DetailNoteInstructions.GetVertical method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetColor method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetHorizontal method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetIsDisplayed method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetIsMirrored method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetIsReadOnly method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetLeader method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetTextAngle method
 description 10-60
 pfcDetail.DetailNoteInstructions.SetTextLines method
 description 10-59
 pfcDetail.DetailNoteInstructions.SetVertical method
 description 10-59
 pfcDetail.DetailNoteItem.Draw method
 description 10-64
 pfcDetail.DetailNoteItem.Erase method
 description 10-64
 pfcDetail.DetailNoteItem.GetInstructions method
 description 10-63
 pfcDetail.DetailNoteItem.GetLineEnvelope method
 description 10-63
 pfcDetail.DetailNoteItem.GetModelReference method
 description 10-63
 pfcDetail.DetailNoteItem.GetSymbolDef method
 description 10-63
 pfcDetail.DetailNoteItem.Modify method
 description 10-64
 pfcDetail.DetailNoteItem.Remove method
 description 10-64
 pfcDetail.DetailNoteItem.Show method
 description 10-64
 pfcDetail.DetailOLEObject.GetApplicationType method
 description 10-57
 pfcDetail.DetailOLEObject.GetOutline method

description 10-57
 pfcDetail.DetailOLEObject.GetPath method
 description 10-57
 pfcDetail.DetailOLEObject.GetSheet method
 description 10-57
 pfcDetail.DetailSymbolDefInstructions interface
 description 10-68
 pfcDetail.DetailSymbolDefInstructions.Create method
 description 10-68
 pfcDetail.DetailSymbolDefInstructions.GetAttachments method
 description 10-69
 pfcDetail.DetailSymbolDefInstructions.GetFullPath method
 description 10-70
 pfcDetail.DetailSymbolDefInstructions.GetHasElbow method
 description 10-69
 pfcDetail.DetailSymbolDefInstructions.GetIsTextAngleFixed method
 description 10-69
 pfcDetail.DetailSymbolDefInstructions.GetReference method
 description 10-70
 pfcDetail.DetailSymbolDefInstructions.GetSymbolHeight method
 description 10-69
 pfcDetail.DetailSymbolDefInstructions.SetAttachments method
 description 10-69
 pfcDetail.DetailSymbolDefInstructions.SetFullPath method
 description 10-70
 pfcDetail.DetailSymbolDefInstructions.SetHasElbow method
 description 10-69
 pfcDetail.DetailSymbolDefInstructions.SetIsTextAngleFixed method
 description 10-69
 pfcDetail.DetailSymbolDefInstructions.SetReference method
 description 10-70
 pfcDetail.DetailSymbolDefInstructions.SetSymbolHeight method
 description 10-69
 pfcDetail.DetailSymbolDefItem.CreateDetailItem method
 description 10-70
 pfcDetail.DetailSymbolDefItem.GetInstructions method
 description 10-70
 pfcDetail.DetailSymbolDefItem.ListDetailItems method
 description 10-70
 pfcDetail.DetailSymbolDefItem.Modify method

description 10-71
 pfcDetail.DetailSymbolInstInstructions.Create method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.GetAngle method
 description 10-78
 pfcDetail.DetailSymbolInstInstructions.GetAttachOnDefType method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.GetColor method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.GetCurrentTransform method
 description 10-79
 pfcDetail.DetailSymbolInstInstructions.GetDefAttachment method
 description 10-78
 pfcDetail.DetailSymbolInstInstructions.GetInstAttachment method
 description 10-78
 pfcDetail.DetailSymbolInstInstructions.GetIsDisplayed method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.GetSymbolDef method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.GetTextValues method
 description 10-79
 pfcDetail.DetailSymbolInstInstructions.SetAngle method
 description 10-78
 pfcDetail.DetailSymbolInstInstructions.SetAttachOnDefType method
 description 10-78
 pfcDetail.DetailSymbolInstInstructions.SetColor method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.SetDefAttachment method
 description 10-78
 pfcDetail.DetailSymbolInstInstructions.SetInstAttachment method
 description 10-78
 pfcDetail.DetailSymbolInstInstructions.SetIsDisplayed method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.SetSymbolDef method
 description 10-77
 pfcDetail.DetailSymbolInstInstructions.SetTextValues method
 description 10-79
 pfcDetail.DetailSymbolInstItem.Draw method

description 10-80
 pfcDetail.DetailSymbolInstItem.Erase method
 description 10-80
 pfcDetail.DetailSymbolInstItem.GetInstructions method
 description 10-80
 pfcDetail.DetailSymbolInstItem.Modify method
 description 10-80
 pfcDetail.DetailSymbolInstItem.Remove method
 description 10-80
 pfcDetail.DetailSymbolInstItem.Show method
 description 10-80
 pfcDetail.FreeAttachment.GetAttachmentPoint method
 description 10-90
 pfcDetail.FreeAttachment.GetView method
 description 10-90
 pfcDetail.FreeAttachment.SetAttachmentPoint method
 description 10-90
 pfcDetail.FreeAttachment.SetView method
 description 10-90
 pfcDetail.OffsetAttachment.GetAttachedGeometry method
 description 10-91
 pfcDetail.OffsetAttachment.GetAttachmentPoint method
 description 10-91
 pfcDetail.OffsetAttachment.SetAttachedGeometry method
 description 10-91
 pfcDetail.OffsetAttachment.SetAttachmentPoint method
 description 10-92
 pfcDetail.ParametricAttachment.GetAttachedGeometry method
 description 10-91
 pfcDetail.ParametricAttachment.SetAttachedGeometry method
 description 10-91
 pfcDetail.UnsupportedAttachment.GetAttachmentPoint method
 description 10-92
 pfcDetail.UnsupportedAttachment.SetAttachmentPoint method
 description 10-92
 pfcDimension.BaseDimension.GetDimType method
 description 17-14
 pfcDimension.BaseDimension.GetSymbol method
 description 17-14
 pfcDimension.BaseDimension.GetTexts method
 description 17-14
 pfcDimension.BaseDimension.SetTexts method
 description 17-14
 pfcDimension.Dimension.GetTolerance method
 description 17-14

pfcDimension.Dimension.SetTolerance method
 description 17-14
 pfcDimension2D.AngleDimensionSense_Create
 method
 description 10-30
 pfcDimension2D.Dimension2D.ConvertToBaseline
 method
 description 10-33
 pfcDimension2D.Dimension2D.ConvertToLinear
 method
 description 10-33
 pfcDimension2D.Dimension2D.ConvertToOrdinate
 method
 description 10-33
 pfcDimension2D.Dimension2D.GetAttachmentPoint
 s method
 description 10-32
 pfcDimension2D.Dimension2D.GetBaselineDimensi
 on method
 description 10-32
 pfcDimension2D.Dimension2D.GetDimensionSense
 s method
 description 10-32
 pfcDimension2D.Dimension2D.GetIsAssociative
 method
 description 10-31
 pfcDimension2D.Dimension2D.GetIsReference
 method
 description 10-31
 pfcDimension2D.Dimension2D.GetLocation method
 description 10-32
 pfcDimension2D.Dimension2D.GetOrientationHint
 method
 description 10-32
 pfcDimension2D.Dimension2D.GetView method
 description 10-32
 pfcDimension2D.Dimension2D.SetLocation method
 description 10-33
 pfcDimension2D.Dimension2D.SwitchView method
 description 10-33
 pfcDimension2D.DrawingDimCreateInstructions_Cr
 eate method
 description 10-28
 pfcDimension2D.EmptyDimensionSense_Create
 method
 description 10-29
 pfcDimension2D.LinAOCTangentDimensionSense_
 Create method
 description 10-30
 pfcDimension2D.Model2D.SetViewDisplaying
 method
 description 10-34
 pfcDimension2D.PointDimensionSense_Create
 method
 description 10-29
 pfcDimension2D.SplinePointDimensionSense_Creat
 e method
 description 10-29
 pfcDimension2D.TangentIndexDimensionSense_Cre
 ate method
 description 10-29
 pfcExceptions.XCancelProEAction.Throw method
 description 22-30
 pfcExceptions.XToolkitCheckoutConflict.GetConfl
 ictDescription method
 description 28-25
 pfcExceptions.XToolkitDrawingCreateErrors
 description 10-3
 pfcExceptions.XToolkitDrawingCreateErrors.GetErr
 ors method
 description 10-4
 pfcExport.ACIS3DExportInstructions_Create
 method
 description 22-16
 pfcExport.CADDSExportInstructions_Create
 method
 description 22-16
 pfcExport.CATIA3DExportInstructions_Create
 method
 description 22-16
 pfcExport.CATIAModel3DExportInstructions_Creat
 e method
 description 22-16
 pfcExport.CATIASession3DExportInstructions_Crea
 te method
 description 22-16
 pfcExport.Export3DInstructions interface
 description 22-14
 pfcExport.GeometryFlags_Create method
 description 22-15
 pfcExport.IGES3DNEWExportInstructions_Create
 method
 description 22-16
 pfcExport.InclusionFlags_Create method
 description 22-15
 pfcExport.LayerExportOptions_Create method
 description 22-16
 pfcExport.PDGS3DExportInstructions_Create
 method
 description 22-16
 pfcExport.SET3DExportInstructions_Create method
 description 22-16
 pfcExport.STEP2DExportInstructions_Create
 method
 description 22-16
 pfcExport.STEP3DExportInstructions_Create
 method
 description 22-16
 pfcExport.VDA3DExportInstructions_Create
 method
 description 22-16
 pfcFamily 20-4

pfcFamily.FamColModelItem.GetRefItem method
 description 13-3
 pfcFamily.FamColParam.GetRefParam method 17-4
 pfcFamily.FamilyMember.AddRow method
 description 20-5
 pfcFamily.FamilyMember.CreateColumn method
 description 20-6
 pfcFamily.FamilyMember.CreateCompModelColumn
 method
 description 20-5
 pfcFamily.FamilyMember.CreateComponentColumn
 method
 description 20-5
 pfcFamily.FamilyMember.CreateDimensionColumn
 method
 description 20-5
 pfcFamily.FamilyMember.CreateGroupColumn
 method
 description 20-5
 pfcFamily.FamilyMember.CreateMergePartColumn
 method
 description 20-5
 pfcFamily.FamilyMember.CreateParamColumn
 method
 description 20-5
 pfcFamily.FamilyMember.GetCell method
 description 20-4
 pfcFamily.FamilyMember.GetCellIsDefault method
 description 20-4
 pfcFamily.FamilyMember.GetColumn method
 description 20-3
 pfcFamily.FamilyMember.ListColumns method
 description 20-3
 pfcFamily.FamilyMember.ListRows method
 description 20-3
 pfcFamily.FamilyMember.RemoveColumn method
 description 20-3
 pfcFamily.FamilyMember.RemoveRow method
 description 20-3
 pfcFamily.FamilyMember.SetCell method
 description 20-4
 pfcFamily.FamilyTableColumn.GetType method
 description 20-4
 pfcFamily.FamilyTableRow.CreateInstance method
 description 9-2
 pfcFamily.FamTabColumn.GetSymbol method
 description 20-3
 pfcFamily.FamTableRow.GetInstanceName method
 description 20-3
 pfcFamily.FamTableRow.SetIsLocked method
 description 20-3
 pfcFeature.DeleteOperation.SetClip option 14-4
 pfcFeature.Feature.CreateDeleteOp method 14-4
 pfcFeature.Feature.CreateReorderAfterOp method
 14-4
 pfcFeature.Feature.CreateReorderBeforeOp method
 14-4
 pfcFeature.Feature.CreateResumeOp method 14-4
 pfcFeature.Feature.CreateSuppressOp method 14-4
 pfcFeature.Feature.GetFeatSubType method
 description 14-3
 pfcFeature.Feature.GetFeatType method
 description 14-3
 pfcFeature.Feature.GetFeatTypeName method
 description 14-3
 pfcFeature.Feature.GetGroup method
 description 14-7
 pfcFeature.Feature.GetIsVisible method
 description 14-3
 pfcFeature.Feature.GetNumber method
 description 14-3
 pfcFeature.Feature.GetPattern method
 description 14-7
 pfcFeature.Feature.GetStatus method
 description 14-3
 pfcFeature.Feature.ListParents method
 description 14-2
 pfcFeature.Feature.ListSubItems method
 description 13-3
 pfcFeature.FeatureActionListener.OnAfterCopy
 method
 description 21-11
 pfcFeature.FeatureActionListener.OnAfterRegen
 method 21-10
 description 21-10
 pfcFeature.FeatureActionListener.OnAfterSuppress
 method
 description 21-10
 pfcFeature.FeatureActionListener.OnBeforeDelete
 method 21-10
 description 21-10
 pfcFeature.FeatureActionListener.OnBeforeParameterDelete
 method
 description 21-11
 pfcFeature.FeatureActionListener.OnBeforeRedefine
 method 21-10
 description 21-11
 pfcFeature.FeatureActionListener.OnBeforeRegen
 method 21-10
 description 21-10
 pfcFeature.FeatureActionListener.OnBeforeSuppress
 method 21-10
 description 21-10
 pfcFeature.FeatureActionListener.OnRegenFailure
 method 21-10
 description 21-10
 pfcFeature.FeatureGroup.GetPattern method
 description 14-7
 pfcFeature.FeatureGroup.GetUDFName method
 description 14-9
 pfcFeature.FeatureGroup.ListUDFDimensions
 method

description 14-9, 14-14
 pfcFeature.FeatureOperations.create method 14-4
 pfcFeature.FeaturePattern.Delete method
 description 14-7
 pfcFeature.FeaturePattern.ListMembers method
 description 14-2, 14-7
 pfcFeature.ResumeOperation.SetWithParents option
 14-4
 pfcFeature.SuppressOperation.SetClip option 14-4
 pfcGeometry.Axis.GetSurf method
 description 16-12
 pfcGeometry.Contour.EvalArea method
 description 16-7
 pfcGeometry.Contour.EvalOutline method
 description 16-7
 pfcGeometry.Contour.FindContainingContour
 method
 description 16-7
 pfcGeometry.Contour.ListElements method
 using 16-3
 pfcGeometry.CoordSystem.GetCoordSys method
 description 12-11
 pfcGeometry.CoordSystem.GetTransform method
 description 16-12
 pfcGeometry.Edge.EvalUV method
 description 16-6
 pfcGeometry.Edge.GetDirection method
 description 16-6
 pfcGeometry.Edge.GetEdge1 method
 description 16-6
 pfcGeometry.Edge.GetEdge2 method
 description 16-6
 pfcGeometry.Edge.GetSurface1 method
 description 16-6
 pfcGeometry.Edge.GetSurface2 method
 description 16-6
 pfcGeometry.GeomCurve.EvalFromLength method
 description 16-5
 pfcGeometry.GeomCurve.EvalLength method
 description 16-5
 pfcGeometry.GeomCurve.EvalLengthBetween
 method
 description 16-5
 pfcGeometry.GeomCurve.EvalParameter method
 description 16-5
 pfcGeometry.Point.GetPoint method
 description 16-12
 pfcGeometry.Surface.Eval3DData method
 description 16-11
 pfcGeometry.Surface.EvalArea method
 description 16-11
 pfcGeometry.Surface.EvalClosestointOnSurface
 method
 description 16-11
 pfcGeometry.Surface.EvalMaximum method
 description 16-11
 pfcGeometry.Surface.EvalMinimum method
 description 16-11
 pfcGeometry.Surface.EvalParameters method
 description 16-11
 pfcGeometry.Surface.EvalPrincipalCurv method
 description 16-11
 pfcGeometry.Surface.GetOwnerQuilt method
 description 16-10
 pfcGeometry.Surface.ListContours method
 description 16-7
 using 16-3
 pfcGeometry.Surface.ListSameSurfaces method
 description 16-11
 pfcGeometry.Surface.VerifyUV method
 description 16-11
 pfcGlobal.pfcGlobal.GetProEArguments method
 description 6-2
 pfcGlobal.pfcGlobal.GetProEBuildCode method
 description 6-3
 pfcGlobal.pfcGlobal.GetProESession method
 description 6-2
 pfcGlobal.pfcGlobal.GetProEVersion method
 description 6-3
 pfcImport.ImportedLayer.GetCurveCount method
 description 22-31
 pfcImport.ImportedLayer.GetName method
 description 22-31
 pfcImport.ImportedLayer.GetTrimmedSurfaceCount
 method
 description 22-31
 pfcImport.ImportedLayer.SetAction method
 description 22-31
 pfcImport.ImportedLayer.SetNewName method
 description 22-31
 pfcJLink.JLinkApplication.ExecuteTask method
 description 25-8
 pfcJLink.JLinkApplication.Stop method
 description 25-8
 pfcJLinkTaskListener.OnExecute method
 description 25-6
 pfcLayer.Layer.AddItem method
 description 13-4
 pfcLayer.Layer.Delete method
 description 13-4
 pfcLayer.Layer.GetStatus method
 description 13-4
 pfcLayer.Layer.ListItems method
 description 13-4
 pfcLayer.Layer.RemoveItem method
 description 13-4
 pfcLayer.Layer.SetStatus method
 description 13-4
 pfcLayer.Layers
 display status 13-4
 pfcLayerImportFilter.OnLayerImport method
 description 22-30

pfcMFG.MFG.GetSolid method
 description 11-2
 pfcModel.Import2DInstructions interface
 description 22-28
 pfcModel.Model.Backup method
 description 9-10
 pfcModel.Model.CheckIsModifiable method
 description 9-9
 pfcModel.Model.CheckIsSaveAllowed method
 description 9-9
 pfcModel.Model.Copy method
 description 9-9 to 9-10
 pfcModel.Model.CopyAndRetrieve method
 description 9-9 to 9-10
 pfcModel.Model.CreateLayer method
 description 13-4
 pfcModel.Model.Delete method
 description 9-9 to 9-10
 pfcModel.Model.Display method
 description 9-9 to 9-10, 12-2
 pfcModel.Model.Erase method
 description 9-9 to 9-10
 pfcModel.Model.EraseWithDependencies method
 description 9-10
 pfcModel.Model.Export method
 description 22-2, 22-17
 pfcModel.Model.GetBranch method
 description 9-6, 9-8
 pfcModel.Model.GetCommonName method
 description 9-6
 pfcModel.Model.GetDescr method
 description 9-6 to 9-7
 pfcModel.Model.GetFileName method
 description 9-6
 pfcModel.Model.GetFullName method
 description 9-3, 9-7
 pfcModel.Model.GetGenericName method
 description 9-7
 pfcModel.Model.GetInstanceName method
 description 9-7
 pfcModel.Model.GetIsCommonNameModifiable
 method
 description 9-6
 pfcModel.Model.GetIsModified method
 description 9-6, 9-8
 pfcModel.Model.GetOrigin method
 description 9-7
 pfcModel.Model.GetRelationId method
 description 9-7
 pfcModel.Model.GetReleaseLevel method
 description 9-6, 9-8
 pfcModel.Model.GetRevision method
 description 9-6, 9-8
 pfcModel.Model.GetType method
 description 9-8
 pfcModel.Model.GetVersion method
 description 9-6, 9-8
 pfcModel.Model.GetVersionStamp method
 description 9-6, 9-8
 pfcModel.Model.Import method
 description 22-26
 pfcModel.Model.ListDeclaredModels method
 description 9-6, 9-9
 pfcModel.Model.ListDependencies method
 description 9-6, 9-8
 pfcModel.Model.Rename method
 description 9-9 to 9-10
 pfcModel.Model.Save method
 description 9-9 to 9-10, 28-12
 pfcModel.Model.SaveAs method
 description 9-9
 pfcModel.Model.SetCommonName method
 description 9-10
 pfcModel.ModelDescriptor.GetFullName method
 description 9-3
 pfcModel.ModelDescriptor.SetDevice method
 description 9-3
 pfcModel.ModelDescriptor.SetFileVersion method
 description 9-3
 pfcModel.ModelDescriptor.SetGenericName method
 description 9-3
 pfcModel.ModelDescriptor.SetHost method
 description 9-3
 pfcModel.ModelDescriptor.SetInstanceName
 method
 description 9-3
 pfcModel.ModelDescriptor.SetModelType method
 description 9-3
 pfcModel.ModelDescriptor.SetPath method
 description 9-3
 pfcModel.ModelDescriptor_Create method
 description 9-3
 used in a code example 9-5
 pfcModel.Models
 information 9-6
 pfcModel.PlotInstructions_Create method 22-32
 pfcModel2D.Model2D.AddModel method
 description 10-7
 pfcModel2D.Model2D.AddSimplifiedRep method
 description 10-8
 pfcModel2D.Model2D.Create View method
 description 10-8
 pfcModel2D.Model2D.CreateDrawingDimension
 method
 description 10-8
 pfcModel2D.Model2D.CreateView method
 description 10-15
 pfcModel2D.Model2D.DeleteModel method
 description 10-7
 pfcModel2D.Model2D.DeleteSimplifiedRep method
 description 10-8
 pfcModel2D.Model2D.GetTextHeight method

description 10-7

pfModel2D.Model2D.GetViewByName method
description 10-20

pfModel2D.Model2D.GetViewDisplaying method
description 10-21

pfModel2D.Model2D.List2DViews 10-53

pfModel2D.Model2D.List2DViews method
description 10-20

pfModel2D.Model2D.ListModels method
description 10-6

pfModel2D.Model2D.ListSimplifiedReps method
description 10-7

pfModel2D.Model2D.Regenerate method
description 10-8

pfModel2D.Model2D.ReplaceModel method
description 10-7

pfModel2D.Model2D.SetCurrentSolid method
description 10-7

pfModel2D.Model2D.SetTextHeight method
description 10-8

pfModel2D.Model2D.CreateDrawingDimension
method
description 10-28

pfModelCheck.CustomCheckInstructions.SetAction
ButtonLabel method
description 9-14

pfModelCheck.CustomCheckInstructions.SetCheck
Label method
description 9-14

pfModelCheck.CustomCheckInstructions.SetCheck
Name method
description 9-14

pfModelCheck.CustomCheckInstructions.SetListen
er method
description 9-14

pfModelCheck.CustomCheckInstructions.SetUpdat
eButtonLabel method
description 9-14

pfModelCheck.CustomCheckResults.SetResultsCo
unt method
description 9-16

pfModelCheck.CustomCheckResults.SetResultsTab
le method
description 9-16

pfModelCheck.CustomCheckResults.SetResultsUrl
method
description 9-16

pfModelCheck.ModelCheckCustomCheckListener.
OnCustomCheck method
description 9-16

pfModelCheck.ModelCheckCustomCheckListener.
OnCustomCheckAction method
description 9-16

pfModelCheck.ModelCheckCustomCheckListener.
OnCustomCheckUpdate method
description 9-16

pfModelCheck.ModelCheckInstructions.SetConfig
Dir method
description 9-12

pfModelCheck.ModelCheckInstructions.SetMode
method
description 9-12

pfModelCheck.ModelCheckInstructions.SetOutput
Dir method
description 9-12

pfModelCheck.ModelCheckInstructions.SetShowIn
Browser method
description 9-12

pfModelCheck.ModelCheckResults.GetNumberOf
Errors method
description 9-12

pfModelCheck.ModelCheckResults.GetNumberOf
Warning method
description 9-12

pfModelCheck.ModelCheckResults.GetWasModelS
aved method
description 9-12

pfModelCheck.pfModelCheck.CustomCheckInstr
uctions_Create method
description 9-14

pfModelCheck.pfModelCheck.CustomCheckResul
ts_Create method
description 9-16

pfModelCheck.pfModelCheck.ModelCheckInstruc
tions_Create method
description 9-12

pfModelItem.BaseDimension.GetDimValue method
description 17-14

pfModelItem.BaseDimension.SetDimValue method
description 17-14

pfModelItem.BaseParameter.GetIsDesignated
method
description 17-8

pfModelItem.BaseParameter.GetIsModified method
description 17-8

pfModelItem.BaseParameter.GetIsRelationDriven
method
description 17-14

pfModelItem.BaseParameter.GetValue method
description 17-7

pfModelItem.BaseParameter.ResetFromBackup
method
description 17-8

pfModelItem.BaseParameter.SetIsDesignated
method
description 17-8

pfModelItem.BaseParameter.SetValue method
description 17-7

pfModelItem.CreateBoolParamValue method
description 17-2

pfModelItem.CreateDoubleParamValue method
description 17-2

pfcModellItem.CreateIntParamValue method
 description 17-2
 pfcModellItem.CreateStringParamValue method
 description 17-2
 pfcModellItem.ModellItem.GetId method
 description 13-3
 pfcModellItem.ModellItem.GetName method
 description 13-3
 pfcModellItem.ModellItem.GetType method
 description 13-3
 pfcModellItem.ModellItem.SetName method
 description 13-3
 pfcModellItem.ModellItemOwner.GetItemById
 method
 description 10-27, 10-51, 13-3
 pfcModellItem.ModellItemOwner.GetItemByName
 method
 description 13-3
 pfcModellItem.ModellItemOwner.ListItems method
 13-2
 description 10-27, 10-50, 13-3, 16-3
 using 16-3
 pfcModellItem.NamedModellItem.GetName method
 description 17-8
 pfcModellItem.ParameterOwner.CreateParam method
 description 17-4
 pfcModellItem.ParameterOwner.GetParam method
 description 17-4
 pfcModellItem.ParameterOwner.GetRefParam
 method 17-4
 pfcModellItem.ParameterOwner.ListParams method
 description 17-4
 pfcModellItem.ParameterOwner.SelectParam method
 description 17-4
 pfcModellItem.ParamValue.GetBoolValue method
 17-3
 pfcModellItem.ParamValue.Getdiscr method
 description 17-3
 pfcModellItem.ParamValue.GetDoubleValue method
 17-3
 pfcModellItem.ParamValue.GetIntValue method
 17-3
 pfcModellItem.ParamValue.GetStringValue method
 17-3
 pfcModellItem.ParamValue.SetBoolValue method
 17-3
 pfcModellItem.ParamValue.SetDoubleValue method
 17-3
 pfcModellItem.ParamValue.SetIntValue method 17-3
 pfcModellItem.ParamValue.SetStringValue method
 17-3
 pfcModellItem.ParamValues.create method
 description 20-5
 pfcModellItem.pfcModellItem.CreateStringParamVal
 ue method
 description 20-5
 pfcNote.Note.Delete function
 description 11-14
 pfcNote.Note.Display method
 description 11-14
 pfcNote.Note.GetLines method
 description 11-14
 pfcNote.Note.GetOwner method
 description 11-14
 pfcNote.Note.GetURL method
 description 11-14
 pfcNote.Note.SetURL method
 description 11-14
 pfcPart.Material.Delete method
 description 11-16
 pfcPart.Material.GetBendTable method
 description 11-21
 pfcPart.Material.GetCondition method
 description 11-21
 pfcPart.Material.GetCrossHatchFile method
 description 11-21
 pfcPart.Material.GetFailureCriterion method
 description 11-20
 pfcPart.Material.GetFatigueMaterialFinish function
 description 11-20
 pfcPart.Material.GetFatigueMaterialType method
 description 11-20
 pfcPart.Material.GetFatigueType method
 description 11-20
 pfcPart.Material.GetHardness method
 description 11-21
 pfcPart.Material.GetHardnessType method
 description 11-21
 pfcPart.Material.GetMaterialModel method
 description 11-21
 pfcPart.Material.GetModelDefByTests method
 description 11-21
 pfcPart.Material.GetPermittedFatigueMaterialTypes
 method
 description 11-20
 pfcPart.Material.GetPermittedFatigueTypes method
 description 11-20
 pfcPart.Material.GetPropertyValue method
 description 11-19
 pfcPart.Material.GetStructuralMaterialType method
 description 11-17
 pfcPart.Material.GetSubType method
 description 11-18
 pfcPart.Material.GetThermalMaterialType method
 description 11-17
 pfcPart.Material.RemoveProperty method
 description 11-20
 pfcPart.Material.Save method
 description 11-16
 pfcPart.Material.SetBendTable method
 description 11-21
 pfcPart.Material.SetCondition method

description 11-21
 pfcPart.Material.SetCrossHatchFile method
 description 11-21
 pfcPart.Material.SetFailureCriterion method
 description 11-20
 pfcPart.Material.SetFatigueMaterialFinish method
 description 11-20
 pfcPart.Material.SetFatigueMaterialType method
 description 11-20
 pfcPart.Material.SetFatigueType method
 description 11-20
 pfcPart.Material.SetHardness method
 description 11-21
 pfcPart.Material.SetHardnessType method
 description 11-21
 pfcPart.Material.SetModelDefByTests method
 description 11-21
 pfcPart.Material.SetPropertyUnits method
 description 11-20
 pfcPart.Material.SetPropertyValue method
 description 11-20
 pfcPart.Material.SetStructuralMaterialType method
 description 11-17
 pfcPart.Material.SetSubType method
 description 11-18
 pfcPart.Material.SetThermalMaterialType method
 description 11-18
 pfcPart.Part.CreateMaterial method 11-15
 pfcPart.Part.CreateMaterials method
 description 11-16
 pfcPart.Part.GetCurrentMaterial method 11-15
 description 11-16
 pfcPart.Part.ListMaterials method 11-15
 description 11-16
 pfcPart.Part.RetrieveMaterial method 11-15
 description 11-17
 pfcPart.Part.SetCurrentMaterial method 11-15
 description 11-16
 pfcProToolkit.Dll.ExecuteFunction method
 description 25-5
 pfcProToolkit.Dll.GetId() method
 description 25-5
 pfcProToolkit.Dll.IsActive method
 description 25-5
 pfcProToolkit.Dll.Unload method
 description 25-6
 pfcSelect.Selection.Display method
 description 7-5
 pfcSelect.Selection.GetDepth method 7-4
 description 7-4
 pfcSelect.Selection.GetParams method 7-4
 pfcSelect.Selection.GetPath method 7-4
 pfcSelect.Selection.GetPoint method 7-4
 description 7-4
 pfcSelect.Selection.GetSelItem method 7-4
 description 10-27, 10-39, 13-3
 getting a ModelItem 13-2
 pfcSelect.Selection.GetSelModel method 7-4
 pfcSelect.Selection.GetSelTableCell method
 description 7-4, 10-39
 pfcSelect.Selection.GetSelTableSegment method
 description 7-4, 10-39, 10-48
 pfcSelect.Selection.GetSelView2D method
 description 7-4, 10-20
 pfcSelect.Selection.GetTParam method
 description 7-4
 pfcSelect.Selection.Highlight method 7-5
 description 7-5
 pfcSelect.Selection.SetParams method
 Description 7-7
 pfcSelect.Selection.SetPath method
 description 7-7
 pfcSelect.Selection.SetPoint method
 description 7-7
 pfcSelect.Selection.SetSelItem method
 description 7-7
 pfcSelect.Selection.SetSelTableCell method
 description 7-7
 pfcSelect.Selection.SetSelView2D method
 description 7-7
 pfcSelect.Selection.SetTParam method
 description 7-7
 pfcSelect.Selection.UnHighlight method
 description 7-5
 pfcSelect.Selection.Unhighlight method 7-5
 pfcSelect.SelectionBuffer.AddSelection method
 description 7-9
 pfcSelect.SelectionBuffer.Clear method
 description 7-9
 pfcSelect.SelectionBuffer.GetContents method
 description 7-8
 pfcSelect.SelectionBuffer.RemoveSelection method
 description 7-9
 pfcSelect.SelectionOptions argument
 table of strings 7-2
 pfcSelect.SelectionOptions.SetMaxNumSels method
 7-2
 description 7-3
 pfcSelect.SelectionOptions.SetOptionKeywords
 method 7-2
 description 7-2
 pfcSelect.SelectionOptions_Create method 7-2
 description 7-2
 used in a code example 7-6
 pfcServer.CheckinOptions.SetBaselineLocation
 method
 description 28-13
 pfcServer.CheckinOptions.SetBaselineName method
 description 28-13
 pfcServer.CheckinOptions.SetBaselineNumber
 method
 description 28-13

pfcServer.CheckinOptions.SetKeepCheckedout method
 description 28-14
 pfcServer.CheckoutOptions.SetDependency method
 description 28-16
 pfcServer.CheckoutOptions.SetDownload method
 description 28-16
 pfcServer.CheckoutOptions.SetIncludeInstances method
 description 28-16
 pfcServer.CheckoutOptions.SetReadOnly method
 description 28-16
 pfcServer.CheckoutOptions.SetSelectedIncludes method
 description 28-16
 pfcServer.CheckoutOptions.SetVersion method
 description 28-16
 pfcServer.pfcServer.CheckinOptions_Create method
 description 28-14
 pfcServer.pfcServer.CheckoutOptions_Create method
 create 28-16
 pfcServer.pfcServer.WorkspaceDefinition_Create method
 description 28-7
 pfcServer.Server.Activate method
 description 28-5
 pfcServer.Server.CheckinObjects method
 description 28-14
 pfcServer.Server.CheckoutMultipleObjects method
 description 28-16
 pfcServer.Server.CheckoutObjects method
 description 28-16
 pfcServer.Server.CreateWorkspace method
 description 28-7 to 28-8
 pfcServer.Server.GetActiveWorkspace method
 description 28-8
 pfcServer.Server.GetAlias method
 description 28-5
 pfcServer.Server.GetAliasedUrl method
 description 28-37
 pfcServer.Server.GetContext method
 description 28-5
 pfcServer.Server.GetIsActive method
 description 28-5
 pfcServer.Server.IsObjectCheckedOut method
 description 28-22
 pfcServer.Server.RemoveObjects method
 description 28-24
 pfcServer.Server.SetActiveWorkspace method
 description 28-8
 pfcServer.Server.UndoCheckout method
 description 28-18
 pfcServer.Server.Unregister method
 description 28-5
 pfcServer.Server.UploadObjects method
 description 28-13
 pfcServer.Server.UploadObjectsWithOptions method
 description 28-13
 pfcServer.Server.UploadOptions_Create method
 description 28-13
 pfcServer.ServerLocation.CollectWorkspaces function
 description 28-4
 pfcServer.ServerLocation.DeleteWorkspace method
 description 28-8
 pfcServer.ServerLocation.GetClass method
 description 28-4
 pfcServer.ServerLocation.GetLocation method
 description 28-4
 pfcServer.ServerLocation.GetVersion method
 description 28-4
 pfcServer.ServerLocation.ListContexts method
 description 28-4
 pfcServer.UploadBaseOptions.SetAutoreresolveOption method
 description 28-13
 pfcServer.UploadBaseOptions.SetDefaultFolder method
 description 28-13
 pfcServer.UploadBaseOptions.SetNonDefaultFolder Assignments method
 description 28-13
 pfcServer.WorkspaceDefinition.GetWorkspaceName method
 description 28-7
 pfcServer.WorkspaceDefinition.SetWorkspaceName method
 description 28-7
 pfcSession.BaseSession.AuthenticateBrowser method
 description 28-3, 28-5
 pfcSession.BaseSession.ChangeDirectory method
 description 6-5
 pfcSession.BaseSession.CopyFileFromWS method
 description 28-21
 pfcSession.BaseSession.CopyFileToWS method
 description 28-21
 pfcSession.BaseSession.CreateAssembly method
 description 11-2
 pfcSession.BaseSession.CreateDrawingFrom Template method
 description 10-2
 pfcSession.BaseSession.CreateModelWindow method
 description 12-2
 pfcSession.BaseSession.CreatePart method
 description 11-2
 pfcSession.BaseSession.ExecuteModelCheck method
 description 9-11 to 9-12
 pfcSession.BaseSession.ExportfromCurrentWS

method
description 28-19
pfcSession.BaseSession.GetActiveServer method
description 28-6
pfcSession.BaseSession.GetAliasFromAliasedUrl
method
description 28-38
pfcSession.BaseSession.GetByRelationId method
description 9-2
pfcSession.BaseSession.GetConfigOpt method 6-6
pfcSession.BaseSession.GetConfigOptionValues
method
description 6-6
pfcSession.BaseSession.GetCurrentDirectory
method
description 6-5
pfcSession.BaseSession.GetCurrentModel method
description 9-2
pfcSession.BaseSession.GetImportSourceType
method
description 22-29
pfcSession.BaseSession.GetModel method
description 9-2, 10-6
pfcSession.BaseSession.GetModelFromDescr
method
description 10-6
pfcSession.BaseSession.GetModelWindow function
description 12-2
pfcSession.BaseSession.GetProToolkitDll method
description 25-5
pfcSession.BaseSession.GetRGBFromStdColor
method
description 6-8
pfcSession.BaseSession.GetSelModel method
description 9-2
pfcSession.BaseSession.GetStdColorFromRGB
method
description 6-8
pfcSession.BaseSession.GetWindow method
description 12-2
pfcSession.BaseSession.Import2DModel method
description 22-28
pfcSession.BaseSession.ImportfromCurrentWS
method
description 28-19
pfcSession.BaseSession.IsConfigurationSupported
method
description 22-17
pfcSession.BaseSession.IsGeometryRepSupported
method
description 22-17
pfcSession.BaseSession.ListModels method
description 9-2, 10-6
pfcSession.BaseSession.ListServers method
description 28-6
pfcSession.BaseSession.ListWindows method
description 12-2
pfcSession.BaseSession.LoadConfigFile method
description 6-6
pfcSession.BaseSession.LoadProToolkitDll method
description 25-4 to 25-6
pfcSession.BaseSession.OpenFile method
description 9-4, 28-15
used with windows 12-2
pfcSession.BaseSession.RegisterCustomModelChec
k method
description 9-14
pfcSession.BaseSession.RegisterServer method
description 28-5
pfcSession.BaseSession.RegisterTask method
description 25-6
pfcSession.BaseSession.RetrieveAssemSimpRep
method
description 23-3
pfcSession.BaseSession.RetrieveGeomSimpRep
method
description 23-4
pfcSession.BaseSession.RetrieveGraphicsSimpRep
method
description 23-4
pfcSession.BaseSession.RetrieveModel method
description 9-4, 28-15
pfcSession.BaseSession.RetrieveModelWithOpts
method
description 28-15
pfcSession.BaseSession.RetrieveModel method
description 10-6
pfcSession.BaseSession.RunMacro method 6-7
description 6-7
pfcSession.BaseSession.Select method
description 7-2, 10-39
pfcSession.BaseSession.SetConfigOpt method 6-6
pfcSession.BaseSession.SetConfigOption method
description 6-6
pfcSession.BaseSession.SetLineStyle method
description 6-8
pfcSession.BaseSession.SetStdColorFromRGB
method
description 6-8
pfcSession.BaseSession.SetTextColor method
description 6-8
pfcSession.BaseSession.SetWSExportOptions
method
description 28-20
pfcSession.BaseSession.StartJLinkApplication
method
description 25-7
pfcSession.BaseSession.UnregisterTask method
description 25-7
pfcSession.BaseSessionGetServerByAlias method
description 28-6
pfcSession.BaseSessionGetServerByUrl method

description 28-6
pfcSession.pfcSession.WSExportOptions_Create method
description 28-20
pfcSession.Session.GetCurrentSelectionBuffer method
description 7-8
pfcSession.Session.NavigatorPaneBrowserAdd method
description 6-19
pfcSession.Session.NavigatorPaneBrowserIconSet method
description 6-20
pfcSession.Session.NavigatorPaneBrowserURLSet method
description 6-20
pfcSession.Session.UIAddButton method
description 8-2 to 8-3
pfcSession.Session.UIAddMenu method
description 8-2 to 8-3
pfcSession.Session.UIAddSubMenu method
description 8-2
pfcSession.Session.UIClearMessage method 6-11
pfcSession.Session.UICreateCommand method
description 8-2 to 8-3, 21-5
pfcSession.Session.UICreateMaxPriorityCommand method
description 8-3
pfcSession.Session.UIDisplayFeatureParams method
description 6-14
pfcSession.Session.UIDisplayMessage method
description 6-11
pfcSession.Session.UIReadIntMessage method
description 6-14
pfcSession.Session.UIReadRealMessage method
description 6-14
pfcSession.Session.UIReadStringMessage method
description 6-14
pfcSession.Session.UISelectDirectory method
description 6-17
pfcSession.Session.UIShowMessageDialog method
description 6-10
pfcSession.SessionActionListener.OnAfterDirectoryChange method
description 21-4
pfcSession.SessionActionListener.OnAfterModelDisplay method 21-5
pfcSession.SessionActionListener.OnAfterWindowChange method
description 21-4
pfcSession.WSExportOptions.SetIncludeSecondaryContent method
description 28-20
pfcSession.WSImportExportMessage.GetDescription method
description 28-19
pfcSession.WSImportExportMessage.GetFileName method
description 28-19
pfcSession.WSImportExportMessage.GetMessageType method
description 28-19
pfcSession.WSImportExportMessage.GetResolution method
description 28-19
pfcSession.WSImportExportMessage.GetSucceeded method
description 28-19
pfcSheet.SheetOwner.AddSheet method
description 10-11
pfcSheet.SheetOwner.DeleteSheet method
description 10-11
pfcSheet.SheetOwner.GetCurrentSheetNumber method
description 10-11
pfcSheet.SheetOwner.GetNumberOfSheets method
description 10-11
pfcSheet.SheetOwner.GetSheetBackgroundView 10-53
pfcSheet.SheetOwner.GetSheetBackgroundView method
description 10-11, 10-21
pfcSheet.SheetOwner.GetSheetData method
description 10-10
pfcSheet.SheetOwner.GetSheetFormat method
description 10-11
pfcSheet.SheetOwner.GetSheetScale method
description 10-11
pfcSheet.SheetOwner.GetSheetTransform method
description 10-10
pfcSheet.SheetOwner.RegenerateSheet method
description 10-12
pfcSheet.SheetOwner.ReorderSheet method
description 10-12
pfcSheet.SheetOwner.SetCurrentSheetNumber method
description 10-12
pfcSheet.SheetOwner.SetSheetFormat method
description 10-12
pfcSheet.SheetOwner.SetSheetScale method
description 10-12
pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.GetShrinkwrapFacetedFormat method
description 22-22
pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.GetFramesFile method
description 22-22
pfcShrinkwrap.ShrinkwrapFacetedFormatInstructions.SetFramesFile method
description 22-22
pfcShrinkwrap.ShrinkwrapFacetedPartInstructions.GetLightweight method

description 22-23
pfcShrinkwrap.ShrinkwrapFacetedPartInstructions.SetLightweight method
description 22-23
pfcShrinkwrap.ShrinkwrapFacetedPartInstructions.Create method
description 22-23
pfcShrinkwrap.ShrinkwrapMergedSolidInstructions.GetAdditionalComponents method
description 22-24
pfcShrinkwrap.ShrinkwrapMergedSolidInstructions.SetAdditionalComponents method
description 22-24
pfcShrinkwrap.ShrinkwrapMergedSolidInstructions.Create method
description 22-24
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetAssignMassProperties method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetAutoHoleFilling method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetDatumReferences method
description 22-21
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreQuilts method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreskeleton method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetIgnoreSmallSurfaces method
description 22-21
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetQuality method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetShrinkwrapMethod method
description 22-19
pfcShrinkwrap.ShrinkwrapModelExportInstructions.GetSmallSurfPercentage method
description 22-21
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetAssignMassProperties method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetAutoHoleFilling method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetDatumReferences method
description 22-21
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreQuilts method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreskeleton method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetIgnoreSmallSurfaces method
description 22-21
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetQuality method
description 22-20
pfcShrinkwrap.ShrinkwrapModelExportInstructions.SetSmallSurfPercentage method
description 22-21
pfcShrinkwrap.ShrinkwrapSTLInstructions.GetOutputFile method
description 22-24
pfcShrinkwrap.ShrinkwrapSTLInstructions.SetOutputFile method
description 22-24
pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.GetAdditionalSurfaces method
description 22-21
pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.GetOutputModel method
description 22-22
pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.SetAdditionalSurfaces method
descriptions 22-21
pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.SetOutputModel method
description 22-22
pfcShrinkwrap.ShrinkwrapSurfaceSubsetInstructions.Create method
description 22-21
pfcShrinkwrap.ShrinkwrapVRMLInstructions.GetOutputFile method
description 22-23
pfcShrinkwrap.ShrinkwrapVRMLInstructions.SetOutputFile method
description 22-23
pfcShrinkwrap.ShrinkwrapVRMLInstructions.Create method
description 22-24
pfcSimpRep.CreateNewSimpRepInstructions.GetDefaultAction method
description 23-5
pfcSimpRep.CreateNewSimpRepInstructions.GetIsTemporary method
description 23-5
pfcSimpRep.CreateNewSimpRepInstructions.GetItems method
description 23-5
pfcSimpRep.CreateNewSimpRepInstructions.GetNewSimpName method
description 23-5
pfcSimpRep.CreateNewSimpRepInstructions.Create method
description 23-4

pfcSimpRep.RetrieveExistingSimpRepInstructions_ Create method
 description 23-3
 pfcSimpRep.SimpRep.GetInstructions method
 description 23-5
 pfcSolid.Solid.ExecuteFeatureOps method
 description 14-4
 pfcSolid.RegenInstructions.SetAllowFixUI method
 description 11-4
 pfcSolid.RegenInstructions.SetForceRegen method
 description 11-4
 pfcSolid.RegenInstructions.SetFromFeat method
 description 11-4
 pfcSolid.RegenInstructions.SetRefreshModelTree method
 description 11-4
 pfcSolid.RegenInstructions.SetResumeExcludedComponents method
 description 11-4
 pfcSolid.RegenInstructions.SetUpdateAssemblyOnly method
 description 11-4
 pfcSolid.RegenInstructions.SetUpdateInstances method
 description 11-5
 pfcSolid.RegenInstructions_ Create method
 11-3, 22-41
 pfcSolid.Solid.CreateCustomUnit method
 description 11-9
 pfcSolid.Solid.CreateImportFeat method
 description 22-41
 pfcSolid.Solid.CreateSimpRep method
 description 23-4
 pfcSolid.Solid.CreateUDFGroup method
 description 14-9, 14-15
 pfcSolid.Solid.CreateUnitSystem method
 description 11-11
 pfcSolid.Solid.DeleteSimpRep method
 description 23-4
 pfcSolid.Solid.ExportShrinkwrap method
 description 22-18
 pfcSolid.Solid.GetAbsoluteAccuracy method 11-2
 pfcSolid.Solid.GetCrossSection method
 description 11-15
 pfcSolid.Solid.GetFeatureById method
 description 14-2
 pfcSolid.Solid.GetGeomOutline method
 description 11-5
 pfcSolid.Solid.GetHasRetrievalErrors method
 description 9-5
 pfcSolid.Solid.GetIsSkeleton method
 description 19-21
 pfcSolid.Solid.GetMassProperty method
 description 11-12
 pfcSolid.Solid.GetPrincipalUnits method
 description 11-10
 pfcSolid.Solid.GetRelativeAccuracy method 11-2
 pfcSolid.Solid.GetUnit method
 description 11-7
 pfcSolid.Solid.ListCrossSections method
 Description 11-15
 pfcSolid.Solid.ListFailedFeatures method
 description 14-2
 pfcSolid.Solid.ListFeaturesByType method
 description 14-2
 pfcSolid.Solid.ListUnits method
 description 11-7
 pfcSolid.Solid.ListUnitSystems method
 description 11-10
 pfcSolid.Solid.Regenerate method
 description 11-3
 pfcSolid.Solid.SetAbsoluteAccuracy method 11-2
 pfcSolid.Solid.SetPrincipalUnits method
 description 11-11
 pfcSolid.Solid.SetRelativeAccuracy method 11-2
 pfcSolid.SolidActionListener.OnAfterFeatureCreate method
 description 21-9
 pfcSolid.SolidActionListener.OnAfterFeatureDelete method
 description 21-9
 pfcSolid.SolidActionListener.OnAfterRegenerate method
 description 21-8
 pfcSolid.SolidActionListener.OnAfterUnitConvert method
 description 21-9
 pfcSolid.SolidActionListener.OnBeforeFeatureCreate method
 description 21-9
 pfcSolid.SolidActionListener.OnBeforeRegenerate method
 description 21-8
 pfcSolid.SolidActionListener.OnBeforeUnitConvert method
 description 21-9
 pfcTable.Table.CheckIfIsFromFormat method
 description 10-41
 pfcTable.Table.DeleteColumn method
 description 10-43
 pfcTable.Table.DeleteRow method
 description 10-43
 pfcTable.Table.DeleteTable method
 description 10-43
 pfcTable.Table.Display method
 description 10-42
 pfcTable.Table.Erase method
 description 10-42
 pfcTable.Table.GetCellComponentModel method
 description 10-49
 pfcTable.Table.GetCellNote method
 description 10-42

pfcTable.Table.GetCellReferenceModel method
 description 10-49
 pfcTable.Table.GetCellTopModel method
 description 10-49
 pfcTable.Table.GetColumnCount method
 description 10-41
 pfcTable.Table.GetColumnSize method
 description 10-41
 pfcTable.Table.GetInfo method
 description 10-48
 pfcTable.Table.GetRowCount method
 description 10-41
 pfcTable.Table.GetRowSize method
 description 10-41
 pfcTable.Table.GetSegmentCount method
 description 10-48
 pfcTable.Table.GetSegmentSheet method
 description 10-48
 pfcTable.Table.GetText method
 description 10-41
 pfcTable.Table.InsertColumn method
 description 10-42
 pfcTable.Table.InsertRow method
 description 10-42
 pfcTable.Table.IsCommentCell method
 description 10-49
 pfcTable.Table.MergeRegion method
 description 10-43
 pfcTable.Table.MoveSegment method
 description 10-48
 pfcTable.Table.RotateClockwise method
 description 10-42
 pfcTable.Table.SetText method
 description 10-43
 pfcTable.Table.SubdivideRegion method
 description 10-43
 pfcTable.Table.UpdateTables method
 description 10-49
 pfcTable.TableCell_Create method
 description 10-38
 pfcTable.TableCreateInstructions_Create method
 description 10-39
 pfcTable.TableOwner.CreateTable method
 description 10-40
 pfcTable.TableOwner.GetTable method
 description 10-41
 pfcTable.TableOwner.ListTable method
 description 10-41
 pfcTable.TableOwner.RetrieveTable method
 description 10-40
 pfcTable.TableRetrieveInstructions_Create method
 description 10-40
 pfcUDFCreate.pfcUDFCreate.UDFAssemblyIntersection_Create method
 description 14-16
 pfcUDFCreate.UDFAssemblyIntersection.SetInstanceName method
 description 14-16
 pfcUDFCreate.UDFCustomCreateInstructions.GetDependencyType method
 description 14-12
 pfcUDFCreate.UDFCustomCreateInstructions.GetDimDisplayType method
 description 14-13
 pfcUDFCreate.UDFCustomCreateInstructions.GetInstanceName method
 description 14-12
 pfcUDFCreate.UDFCustomCreateInstructions.GetScale method
 description 14-12
 pfcUDFCreate.UDFCustomCreateInstructions.GetScaleType method
 description 14-12
 pfcUDFCreate.UDFCustomCreateInstructions.SetDependencyType method
 description 14-12
 pfcUDFCreate.UDFCustomCreateInstructions.SetDimDisplayType method
 description 14-13
 pfcUDFCreate.UDFCustomCreateInstructions.SetInstanceName method
 description 14-12
 pfcUDFCreate.UDFCustomCreateInstructions.SetIntersections method
 description 14-16
 pfcUDFCreate.UDFCustomCreateInstructions.SetQuadrant method
 description 14-17
 pfcUDFCreate.UDFCustomCreateInstructions.SetReference method
 description 14-16
 pfcUDFCreate.UDFCustomCreateInstructions.SetScaleType method
 description 14-12
 pfcUDFCreate.UDFCustomCreateInstructions.SetVariantValues method
 description 14-13
 pfcUDFCreate.UDFCustomCreateInstructions_Create method
 description 14-11
 pfcUDFCreate.UDFOrientations.create method
 description 14-17
 pfcUDFCreate.UDFOrientations.insert method
 description 14-17
 pfcUDFCreate.UDFReference.SetIsExternal method
 description 14-15
 pfcUDFCreate.UDFReference_Create method
 description 14-15
 pfcUDFCreate.UDFVariantDimension_Create method
 description 14-13
 pfcUDFCreate.UDFVariantPatternParam_Create

method
description 14-13

pfcUDFCreate.UDFVariantValues.create method
description 14-13

pfcUDFCreate.UDFVariantValues.insert method
description 14-13

pfcUDFGroup.UDFDimension.GetUDFDimensionName method
description 14-9, 14-14

pfcUDFGroup.UDFPromptCreateInstructions_Create method
description 14-11

pfcUI.FileOpenOptions.SetFilterString method
description 6-16

pfcUI.FileOpenOptions.SetPreselectedItem method
description 6-16

pfcUI.FileUIOptions.SetDefaultPath method
description 6-16

pfcUI.FileUIOptions.SetDialogLabel method
description 6-16

pfcUI.MessageDialogOptions.SetButtons methods
description 6-10

pfcUI.MessageDialogOptions.SetDefaultButton method
description 6-10

pfcUI.MessageDialogOptions.SetDialogLabel method
description 6-10

pfcUI.MessageDialogOptions.SetMessageDialogType method
description 6-10

pfcUI.pfcUI.MessageDialogOptions_Create() method
description 6-10

pfcUnits.pfcUnits.UnitConversionFactor_Create method
description 11-9

pfcUnits.pfcUnits.UnitConversionOptions_Create method
description 11-11

pfcUnits.Unit.Delete method
description 11-9

pfcUnits.Unit.GetConversionFactor method
description 11-8

pfcUnits.Unit.GetExpression method
description 11-7

pfcUnits.Unit.GetIsStandard method
description 11-8

pfcUnits.Unit.GetName method
description 11-7

pfcUnits.Unit.GetReferenceUnit method
description 11-8

pfcUnits.Unit.GetType method
description 11-7

pfcUnits.Unit.Modify method
description 11-9

pfcUnits.UnitConversionFactor.GetOffset method
description 11-8

pfcUnits.UnitConversionFactor.GetScale method
description 11-8

pfcUnits.UnitConversionOptions.SetDimensionOption method
description 11-12

pfcUnits.UnitConversionOptions.SetIgnoreParameters method
description 11-12

pfcUnits.UnitSystem.Delete method
description 11-11

pfcUnits.UnitSystem.GetIsStandard method
description 11-10

pfcUnits.UnitSystem.GetName method
description 11-10

pfcUnits.UnitSystem.GetType method
description 11-10

pfcUnits.UnitSystem.GetUnit method
description 11-10

pfcView.View.GetName method
description 12-5

pfcView.View.GetTransform method
description 12-10

pfcView.View.Reset method
description 12-5

pfcView.View.Rotate method
description 12-10

pfcView.View.SetTransform method
description 12-10

pfcView.View2D.GetDisplay method
description 10-22

pfcView.View2D.GetIsBackground method
description 10-21

pfcView.View2D.GetIsScaleUserdefined method
description 10-22

pfcView.View2D.GetLayerDisplayStatus method
description 10-22

pfcView.View2D.GetModel method
description 10-21

pfcView.View2D.GetName method
description 10-22

pfcView.View2D.GetOutline method
description 10-22

pfcView.View2D.GetScale method
description 10-21

pfcView.View2D.GetSheetNumber method
description 10-21

pfcView.View2D.GetTransform method
description 10-22

pfcView.ViewOwner.GetView method
description 12-5

pfcView.ViewOwner.ListViews method
description 12-5

pfcView.ViewOwner.RetrieveView method
description 12-5

pfcView.ViewOwner.SaveView method
 description 12-5
 pfcView2D.View2D.Delete method
 description 10-26
 pfcView2D.View2D.Regenerate method
 description 10-26
 pfcView2D.View2D.SetDisplay method
 description 10-26
 pfcView2D.View2D.SetDisplayStatus method
 description 10-26
 pfcView2D.View2D.SetScale method
 description 10-26
 pfcView2D.View2D.Translate method
 description 10-26
 pfcWindow.Window.Activate method
 description 12-4
 pfcWindow.Window.Clear method
 description 12-3
 pfcWindow.Window.Close method
 description 12-4
 pfcWindow.Window.ExportRasterImage method
 description 22-43
 pfcWindow.Window.GetBrowserSize method
 description 12-4
 pfcWindow.Window.GetHeight method 12-3
 pfcWindow.Window.GetId method
 description 12-4
 pfcWindow.Window.GetModel method
 description 9-4
 pfcWindow.Window.GetScreenTransform method
 description 12-11
 pfcWindow.Window.GetURL method
 description 12-4
 pfcWindow.Window.GetWidth method 12-3
 pfcWindow.Window.GetXPos method 12-3
 pfcWindow.Window.GetYPos method
 description 12-3
 pfcWindow.Window.Refresh method
 description 12-3
 pfcWindow.Window.Repaint method
 description 12-3
 pfcWindow.Window.SetBrowserSize method
 description 12-4
 pfcWindow.Window.SetScreenTransform method
 description 12-11
 pfcWindow.Window.SetURL method
 description 12-4
 pfcWPP.pfcWPP.ServerSynchronizeConflict_Create
 method
 description 28-12
 pfcWPP.ServerLockConflict.GetConflictMessage
 method
 description 28-23
 pfcWPP.ServerLockConflict.GetObjectName
 method
 description 28-23
 pfcWPP.ServerLockStat.GetObjectName method
 description 28-23
 pfcWPP.ServerLockStat.GetStatus method
 description 28-23
 pfcWPP.ServerLockStat.GetStatusMessage method
 description 28-24
 pfcWPP.ServerSynchronizeConflict.GetDescription
 method
 description 28-12
 pfcWPP.WPPServer.GetServerObjectLockStatus
 method
 description 28-23
 pfcWPP.WPPServer.GetServerObjectsLockStatus
 method
 description 28-23
 pfcWPP.WPPServer.GetServerSynchronizationState
 method
 description 28-12
 pfcWPP.WPPServer.GetServerTargetfolder method
 description 28-6
 pfcWPP.WPPServer.LockServerObjects method
 description 28-23
 pfcWPP.WPPServer.SetWsimpexFolderoption
 method
 description 28-19
 pfcWPP.WPPServer.SynchronizeServer method
 description 28-12
 pfcWPP.WPPServer.UnlockServerObjects method
 description 28-24
 pfcXSection.XSection.Delete method
 description 11-15
 pfcXSection.XSection.Display method
 description 11-15
 pfcXSection.XSection.GetName method
 description 11-15
 pfcXSection.XSection.GetXSecType method
 description 11-15
 pfcXSection.XSection.Regenerate method
 description 11-15
 pfcXSection.XSection.SetName method
 description 11-15
 Placing
 toolbar 8-14
 toolbar button 8-14
 Placing toolbar button 8-14
 Planes 16-9
 geometry representation F-3
 Plot 22-32
 Pointers 2-4
 Points 16-12
 evaluating 16-12
 PointToAngleDimensionSense_Create method
 description 10-31
 Polygons 16-5
 Polymorphism 2-3
 Popup Menu

- Adding to the Graphics Window 8-15
- Using Trail files to determine names 8-16
- Popup Menus 8-15
 - Accessing 8-16
- Popup menus
 - Adding 8-17
- Preprocessors 2-4
- Principal curve 16-11
- private keyword 2-5
- Pro/ENGINEER
 - accessing 6-8
- Pro/J.Link
 - class types 3-2
 - menu option 1-6
 - programs 1-2
- ProBrowserAuthenticate() function
 - description 28-3
- ProServerConflictsDescriptionGet() function
 - description 28-25
- protected keyword 2-5
- protk.dat file 1-2
- public keyword 2-5

R

- Refresh
 - window 12-3, 22-43
- Regenerate
 - events 21-5
 - solids 11-3, 22-41
- Register
 - applications 1-4
- Registry file 1-2
- Remove
 - items from a layer 13-4
- Rename
 - models 9-9
- Repaint
 - events 21-5
 - window 12-3, 22-43
- Reset
 - view 12-5
- Restrictions
 - on text message files 6-9
 - on threads 4-2
- Retrieve
 - geometry of a simplified representation 23-4
 - graphics of a simplified representation 23-4
 - material 11-15
 - model
 - code example 9-5
 - simplified representations 23-3
 - view 12-5
- Revolved surfaces 16-9
- Rotate
 - view 12-6

- Ruled surfaces 16-9
 - geometry representation F-6
- Run
 - applications 1-5
 - model program 1-6

S

- Save
 - models 9-9
 - view 12-5
- Screen coordinate system 12-7
- Search
 - APIWizard search mechanism 5-13
 - using the APIWizard 5-13
- Selection 7-2
 - accessing data 7-4
 - controlling display 7-5
- Sequences 3-6
 - sample class 3-7
- Session objects
 - getting 6-2
- Session.Select method
 - used in a code example 7-6
- Set up
 - applications 1-2
 - machine 1-2
 - model programs 1-5
- Sheets
 - Drawing 10-10
- Simplified representations
 - adding items 23-8
 - creating 23-4
 - deleting 23-4
 - items 23-8
 - extracting information from 23-5
 - modifying 23-8
 - retrieving
 - geometry 23-4
 - graphics 23-4
 - utilities 23-9
- Solids
 - accuracy 11-2
 - coordinate system 12-6
 - geometry traversal 13-2
 - getting a solid object 11-2
 - information 11-2
 - mass properties 11-12
 - operations 11-3, 22-41
- Splines
 - cylindrical spline surface F-11
 - description 16-4
 - representation F-14
 - surface F-9
- Standalone applications 1-2
- Start method 1-7

- startup field 1-3
- static keyword 2-5
- Status
 - feature 14-3
 - layer 13-4
- Stop method 1-7
- Strings 2-6
- Surfaces 16-8
 - cylindrical spline F-11
 - data structures F-2
 - evaluating 16-10
 - area 16-11
 - evaluating parameters 16-11
 - fillet
 - geometry representation F-8
 - general surface of revolution F-6
 - NURBS
 - geometry representation F-10
 - revolved 16-9
 - ruled 16-9, F-6
 - spline F-9
 - traversing 16-2
 - types 16-9
 - UV parameterization 16-8
- Swing
 - class path
 - NT 5-4
 - UNIX 5-4
 - download Java foundation class archive 5-3
 - in APIWizard 5-3
 - required for APIWizard with Netscape 5-3
 - required Java Foundation Class for APIWizard 5-3

T

- t parameter
 - description 16-3
- Table.Table interface
 - description 10-38
- Tabulated cylinders 16-9
 - geometry representation F-7
- Text 16-5
 - message files 6-8
- text_dir field 1-4
- Threads
 - restrictions 4-2
- throw keyword 2-7
- Tolerance 17-14
- Tolerances
 - setting
 - example 17-15
- Toolbar
 - placing 8-14
- Torii 16-9
- Torus F-5

- Transformations 12-6, 12-8
 - solid to coordinate system datum coordinates 12-11
 - solid to screen coordinates 12-10
 - in a drawing 12-11
- Traversal
 - of a solid block 16-3
 - of geometry 16-2
- try keyword 2-7
- try-catch-finally block
 - description 3-22

U

- UDFs 14-9
 - creating 14-9
- User's Guide
 - browsing with APIWizard 5-11
 - documentation
 - online 5-2
- Utilities 3-12
 - sample class 3-13
 - simplified representations 23-9

V

- Values
 - ParamValue 17-3
- View2D.View2D interface
 - description 10-15
- Views
 - Drawing 10-15
 - getting a view object 12-5
 - list of 12-5
 - listing
 - example 10-23
 - operations 12-5
 - retrieving 12-5
 - saving 12-5
- Visibility 14-3
- Visit
 - simplified representations 23-5

W

- Window coordinate system 12-7
- Windows 12-2
 - activating 12-4
 - clearing 12-3
 - closing 12-4
 - creating 12-2
 - operations 12-3, 22-43
 - repainting 12-3
- Write
 - to the message window 6-11